MEDIATEK

# MT6765_62 ETT test & stress test reference for LP4X V1.6

Agenda

- ETT test step by step
- MTK Eye-Scan Function
- DRAM Stress Test step by step
- Nenamark2 + DVFS for Fast-K
- Suspend/Resume
- Reboot(DDR Reserve mode,Full-K,Fast-k)
-   pass
-
-

Chang list

Vison	changlist	date
1	Original version	2018　4　11
1.1	pass	2018　4　20
1.2	LP4X ETT	2018　7　9
1.3	Fix script device id	2018/09/12
1.4	Page 49　　note　　Log	2018/12/10
1.5	Page42　　note	2018/12/20
1.6	Page7　Page26 change VM(LV) from 1.09 to 1.06	2018/12/25

ETT TEST STEP BY STEP

MT6765_62 DRAM Validation Flow

ETT Test Environment Setup (1/2)

{Test 3 grids
    {HTLV, NTNV, LTHV

ETT Test Environment Setup (2/2)

For LPDDR4X 3200MHz

Condition	Temperature (°C)	Vcore (V)	Vm (V)	Vddq(V)
HTLV	65	0.75625	1.06	0.58
NTNV	25	0.80	1.12	0.6
LTHV	-20	0.84375	1.17	0.65

ETT   (1/12)

- ：   MT6765_62   Flash tool(W1748   ).
- 不   **Format whole flash;**
- ETT BIN   :
  https://online.mediatek.com/qvl/_layouts/15/mol/qvl/ext/QVLHomeExternal.aspx不   memory   ETT bin

- Note1.   VBAT   不
- Note2.   NTC   不 10K   GND ,   NTC!

ETT   (2/12)

- **Step1.** UART Cable   PC   uart0

- **Step2.**

ETT　(3/12)

- **Step3**:　　　　UART0　　　COM port　MT6765_62　　　　ETT log
  uart0　　　　ok

ETT　(4/12)

- **Step4:**　　　**921600** _U　　　→

ETT　　(5/12)

- **Step5:**　　　　ETT raw data　　　➔　不Start➔　不CALL　.

CALL

Note1:

Note2:　　　　　　　　　　　　　　,　　　　　　　　　　　　　　　　停　　,

　　　　　　　　　　停.

　　　　:　　　　　　ETT LOG

ETT （6/12）

- **Step6:** Flash tool download scatter file

- 不 **Format whole flash**

ETT (7/12)

- **Step7:** Ctrl+Alt+A flash tool brom Adapter→ ETT bin→ start address(**0x204000**)→ Jump→ download

ETT (8/12)

- **Step8:** USB ETT bin不 →


```
[MT6765] Welcome to ETT's world ... LPDDR3

PMIC TRAP GET DDR TYPE: 0x3
Vcore = 800000
Vdram = 1220000

G : Start the ETT test.
P : Print voltage settings
V : Voltage adjustment.
Please enter selection:v.
Vdram (HV, NV, LV)=(1.1, 1.1, 1.06)
Vddq  (HV, NV, LV)=(0.65, 0.6, 0.57)
1 : (Vcore HV, Vdram HV, Vddq HV)
2 : (Vcore NV, Vdram NV, Vddq NV)
3 : (Vcore LV, Vdram LV, Vddq LV)
4 : (Vcore HV, Vdram LV, Vddq LV)
5 : (Vcore LV, Vdram HV, Vddq HV)
6 : (Vcore) ++ ...
7 : (Vcore) -- ...
8 : (Vdram) ++ ...
9 : (Vdram) -- ...
10: (Vddq) ++ ...
11: (Vddq) -- ...
12: Max Vdram for heavy load test
```

- Step9.　　　　　(HV, NV, LV)　　　　　　　　　　　**Step11**
  三

```
G : Start the ETT test.
P : Print voltage settings
V : Voltage adjustment.
Please enter selection:v.
Vdram (HV, NV, LV)=(1.17, 1.1, 1.06)
Vddq (HV, NV, LV)=(0.65, 0.6, 0.57)
1 : (Vcore HV, Vdram HV, Vddq HV)
2 : (Vcore NV, Vdram NV, Vddq NV)
3 : (Vcore LV, Vdram LV, Vddq LV)
4 : (Vcore HV, Vdram LV, Vddq LV)
5 : (Vcore LV, Vdram HV, Vddq HV)
6 : (Vcore) ++ ...
7 : (Vcore) -- ...
8 : (Vdram) ++ ...
9 : (Vdram) -- ...
10: (Vddq) ++ ...
11: (Vddq) -- ...
12: Max Vdram for heavy load test
13: Min Vdram for heavy load test
Please enter pattern selection:2No VDDQ for LP3, return
```

ETT (10/12)

- **Step10:** G ETT

```
[PMIC] pmic_voltage_read:
[HQA] Vcore = NV + 0
[HQA] Vdram = NV + 0

G : Start the ETT test.
P : Print voltage settings
V : Voltage adjustment.
Please enter selection gStart the test...
ett_before_k_test();
```

[HQA] Set Vdram = 1220000 + 0

ETT (11/12)

- **Step11:** ETT　　　　　　　　ETT log　　　　　　log
  　　不　　三　　　　　　　　　　Vcore,Vmem, Vddq
  　　20mV

For LPDDR4X 3200MHz

Condition	Temperature （°C）	Vcore (V)	Vm (V)	Vddq(V)
HTLV	65	0.75625	1.09	0.58
NTNV	25	0.80	1.12	0.6
LTHV	-20	0.84375	1.17	0.65

ETT (12/12)

Step12 ETT pass 3200 fail pass ETT

```
[HQA] information for measurement,          Dram Data rate = 3200
[Read Voltage]
[HQALOG] 3200 Vcore_HQA = 756250
[HQALOG] 3200 Vdram_HQA = 1060000
[HQALOG] 3200 Vddq_HQA = 570000


[Cmd Bus Training window]
VrefCA Range : 1
VrefCA
```

```
[HQALOG] 3200 CA_Window Channel0 Rank0 46 (bit 3)
[HQALOG] 3200 CA_Window Channel0 Rank1 47 (bit 2)
[HQALOG] 3200 CA_Window Channel1 Rank0 49 (bit 4)
[HQALOG] 3200 CA_Window Channel1 Rank1 50 (bit 3)
CA Min Window(%)
[HQALOG] 3200 CA_Window(%) Channel0 Rank0 72% (PASS)
[HQALOG] 3200 CA_Window(%) Channel0 Rank1 74% (PASS)
[HQALOG] 3200 CA_Window(%) Channel1 Rank0 77% (PASS)
[HQALOG] 3200 CA_Window(%) Channel1 Rank1 79% (PASS)
```

ETT log ETT pass
停NTNV HTLV LTHV下 ETT log
parsetool ETT out

MTK EYE-SCAN FUNCTION

ETT 务 (1/2)

MT6765_62 ETT LP4X 务

- 务 LPDDR4X memory

  LPDDR3

- 务 Vref

  DQ 住 别pass

  0

  务 不

MTK Eye-Scan for each bit

VREF Setting

PASS timing window

2018-1
CONFIDENTIAL B
21

FAQ

- →
  dram SI　　　　　　　　　不　Eye Scan　　　　(　　5　　)　　　　　　　debug
  Debug　　　　　　　　　　　1.　Eye　　　　　　　　　　　　　2.　后　停
  　　bit/byte　　　　　　　　　　后

- 10.
  →　　　　　　　　　　　Vref　　　　住　Vref
  不　　　　　　DQ　pass window　Vref　JEDEC　　　　　之
  JEDEC Vref Setting table for LP4X

MTK Eye-Scan for each bit

VREF Setting

DRAM STRESS TEST STEP BY STEP

MT6765_62 DRAM Stress Test

- Stress Test   PMIC

-               不   NTNV   HTLV   LTHV   下
  preloader bin   preloader bin

-               preloder   code

-               份   Linux kernel code

- VDD2   VDDQ   preloader   linux kernel

- Vcore   Linux kernel   (Vcore DVFS)

-          1.停Memory

                                                    2.   root
  build   MTK_BUILD_ROOT=yes

Note   **ENG**   **userdebug**   **user**

MT6765_62 DRAM Stress Test SW Configuration Android preloader

- D }] (vendor/mediatek/proprietary/bootable/bootloader/preloader/platform/MT6765/src/drivers/inc/emi.h _

í X   v   DRAM_HQA _   u   Œ }

```
//===============================================
//============pmic related api for ETT HQA
//===============================================
-#if __ETT__
+#if 1
#define DRAM_HQA
#endif
```

2. Select voltage condition

- HVCORE_HVDRAM / NVCORE_NVDRAM / LVCORE_LVDRAM
- The 3 macros are exclusive for each other, please enable just one macro for each voltage condition.

```
465
466 #ifdef DRAM_HQA
467
468 //#define HVCORE_HVDRAM
469 #define NVCORE_NVDRAM
470 //#define LVCORE_LVDRAM
471 //#define HVCORE_LVDRAM
472 //#define LVCORE_HVDRAM
473
474 #if defined(HVCORE_HVDRAM)
```

- DRAM   不   停Stress test.
- MT6765_62   3D TEST   ETT   stress test
Vcore   不   Vcore   住

For LPDDR4X :

LP4X	DRAM Data Rate	HV	NV	LV
Vcore	3200(opp1)	0.84375	0.8	0.75625
	2400(opp3)	0.84375	0.8	0.75625
	2400(opp8)	0.7375	0.7	0.6625
	1534(opp10)	0.7375	0.7	0.6625
	1534(opp15)	0.6875	0.65	0.6125
VDRAM(VDD2)		1.17	1.12	1.06
VDDQ		0.65	0.6	0.58

后 PMIC   run ETT

Stress test   后

Note1: Vcore DVFS   Vcore   script

Note2:   不   Vcore   Vcore

Note3: VDD2   preloader   Vcore 住

Note4:   download   HV / NV / LV   preloader bin

Note5:   份   1ms   Vcore

      Vcore

1.   dvfs   0   1

adb shell cat /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_enable---   dvfs

adb shell "echo 1 > /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_enable"

-------   dvfs

```
C:\Users\mtk07417>adb shell cat /sys/devices/platform/10012000.dvfsrc/helio-dvfs
rc/dvfsrc_enable
0

C:\Users\mtk07417>adb shell "echo 1 > /sys/devices/platform/10012000.dvfsrc/heli
o-dvfsrc/dvfsrc_enable"

C:\Users\mtk07417>adb shell cat /sys/devices/platform/10012000.dvfsrc/helio-dvfs
rc/dvfsrc_enable
1
```

2.   vcore   DVFS OPP table   不   NV   cat   OPP13   OPP14   0.675V   0.65V

   cat   cat

cat /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_opp_table

```
C:\Users\mtk07417>adb shell
1 > /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_enabl
s/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_enable
sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_opp_table
[OPP0 ]: 0        uv 0        khz
[OPP1 ]: 800000   uv 3200000  khz
[OPP2 ]: 800000   uv 3200000  khz
[OPP3 ]: 800000   uv 2400000  khz
[OPP4 ]: 800000   uv 3200000  khz
[OPP5 ]: 800000   uv 2400000  khz
[OPP6 ]: 800000   uv 3200000  khz
[OPP7 ]: 800000   uv 2400000  khz
[OPP8 ]: 700000   uv 2400000  khz
[OPP9 ]: 700000   uv 2400000  khz
[OPP10]: 700000   uv 1534000  khz
[OPP11]: 700000   uv 2400000  khz
[OPP12]: 700000   uv 1534000  khz
[OPP13]: 700000   uv 1534000  khz
[OPP14]: 700000   uv 1534000  khz
[OPP15]: 650000   uv 1534000  khz
```

3.   HV   DVFS_Nenamark_Memtester_Script

          set_opp_table_HV.bat   device id

            LV

set_opp_table_LV.bat   opp table

```
[OPP0 ]: 0        uv 0        khz
[OPP1 ]: 843750   uv 3200000  khz
[OPP2 ]: 843750   uv 3200000  khz
[OPP3 ]: 843750   uv 2400000  khz
[OPP4 ]: 843750   uv 3200000  khz
[OPP5 ]: 843750   uv 2400000  khz
[OPP6 ]: 843750   uv 3200000  khz
[OPP7 ]: 843750   uv 2400000  khz
[OPP8 ]: 737500   uv 2400000  khz
[OPP9 ]: 737500   uv 2400000  khz
[OPP10]: 737500   uv 1534000  khz
[OPP11]: 737500   uv 2400000  khz
[OPP12]: 737500   uv 1534000  khz
[OPP13]: 737500   uv 1534000  khz
[OPP14]: 737500   uv 1534000  khz
[OPP15]: 687500   uv 1534000  khz
```

4.   adb   5 住   住   Vcore   关
    5   5   Opp0   Vcore
                下   3200,2400,1534   下   0.84375   0.7375,0.6875
                1866   0.84375   OPP1   OPP2

echo OPP_ID > /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_force_vcore_dvfs_opp

        不   HV   preload   OPP8   0.7375V   不   三   Vcore
    0.7375V   VDD2   1.12V

```
evb6765_64_emmc:/ # echo 8 > /sys/devices/platform/10012000.dvfsrc/helio-dvfsr>
 /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_opp_table              <
```

5.   住   _cat /sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_dump _

    不   catch

```
sys/devices/platform/10012000.dvfsrc/helio-dvfsrc/dvfsrc_dump
Vcore               : 843750  uv  (PMIC: 0x34)
DDR                 : 1866000  khz
```

Step1： 1 Only need to do this for once on your PC

Download and install JAVA
- http://www.java.com

Install Android SDK to have ADB.
- http://developer.android.com/sdk/index.html
- Remember to add ADB in your PATH.
  - EX: C:\ path = %path%; YOU_ADB_PATH
  - 变ADB   ADB   住   tool   不   monkeyrunner.bat
    PATH   EX   ADB   D:\Program Files   monkeyrunner.bat住
    D:\Program Files\Android\android-sdk\tools   D:\Program Files\Android\android-sdk\tools
    PC   PATH

Install a python environment to be able to run python programs.
- For example, download Python 2.7.3 Windows Installer (Windows binary -- does not include source) from http://www.python.org/getit/

控制版面 → 系统 → 高级
→ 环境变量 → Path
在原有的路径后面添加
monkeyrunner.bat的路径，用

- **Step2.   2**
  - ➢   **Test_Tools.rar**
  - ➢   Test_Tools
  - ➢   adb,   SP_Driver_V2.0

  Note1. MOL不   MTK_MVG_TOOLs.rar,

  Note2. Test_Tools   reboot_script   DVFS_Nenamark_Memtester_Script
  suspend_and_DVFS script   OA
          Stess Test   UART log

- **Step3.** load (HTLV/LTHV/NTNV),不
  不
- → → →30
- →Developer options→stay awake
- **Step4.** MTK mobile log

  : Nenamark , ,
  , MD wifi

▪ **Step5.   device id**

        eo   eo   不

c d gxkeg

        gxkeg k   不   23456789 CDEF   2

```
C:\Users\mtk07417>adb devices
List of devices attached
0123456789ABCDEF          device
```

F UaPgpcoctmaogovg va etkrvaNRFFT6   vctvaF UaP4a goavg v dcv

 gv gxkegk   2   gxkeg k . 不   .

```
1_start_DVFS_N2_Mem_test.bat - 记事本
文件(F)  编辑(E)  格式(O)  查看(V)  帮助(H)

@echo off
setlocal EnableDelayedExpansion
set deviceid=-s 0123456789ABCDEF
set memtester=/data/memtester
set chk_status=/data/memtest_check_status.sh
set test_rank=no
set test_num=6
```

DRAM Stress test (5/8)

- **Step6. Install_Nenamark2.bat**

NenaMark2 , choose what to allow NenaMark2 to access 的 , continue Nenamark2 run **3D**

DRAM Stress test   (7/8)

- Step9.   停HV   set_opp_table_HV.bat   **HV OPP table**
-               停LV   set_opp_table_LV.bat   **LV OPP table**
-               停NV   OPP table

  device id

- **Step10: adb shell**
-               **sh /data/run.sh &**
- **Step11: adb shell**
-               **sh /data/vcorefs_cervino.sh &**
- **Step12:**
DVFS_Nenamark_memtest_script_LPDDR4
               start_DVFS_N2_Mem_test.bat
               n   ,后   3D
               ,   3D   run
        display the x and y point.pdf

   •

DRAM Stress test　　　(8/8)

- Step13.　　　　三　　　　USB　　　8　　Stress test
- Step14.　　　"　　　rc　　　"
- Step15.　　　　　　>3　　　　HTLV\LTHV\NTNV　　　不　Stress test
- 　　　　　　　　　preloader bin,　　　　　　　　preloader bin,
　preloader bin.
- 　　　　　　　　　download.

New
UART
log

USB　三

Nenamark2 + DVFS for Fast-K

DRAM Stress test   DRAM Stress

Test   后   **Step3**   .

Step 3   load (HTLV/LTHV)   关

HTLV fast-k   不   **load**

不   **HT**   不   **Stress Test**

LTHV fast-k   不   **load**

不   **LT**   不   **Stress Test**

New   UART
log

USB 三

SUSPEND/RESUME

Suspend/Resume (1/3)

- **Preloader bin** .
- always on MTK mobile log
- **Step1.** **suspend_loop** **debug**务
- **Step2.** **suspend_loop_push.bat** 份


```
b shell "chmod +rwx /data/suspend_loop.sh"

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ad
b shell "setprop log.tag S"

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ad
b shell "echo 1 > /proc/mtprintk"

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ad
b shell "echo 8 8 8 8 > /proc/sys/kernel/printk"

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ec
ho === 300m DVFS script ===
=== 300m DVFS script ===

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ad
b push dvfs_300m.sh /data/dvfs_300m.sh
30 KB/s (1448 bytes in 0.046s)

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>ad
b shell chmod 777 /data/dvfs_300m.sh

D:\SS8\Task\Sylvia\MUG\upload\Test_Tools\suspend_and_DVFS script\suspend_loop>pa
use
請按任意鍵繼續 . . .
```

Suspend/Resume (2/3)

- **Step3.** **cmd** 不

  adb shell

  sh /data/suspend_loop.sh &

```
D:\adb_1_031>adb shell
k71v1_64_bsp:/ # sh /data/suspend_loop.sh &
sh /data/suspend_loop.sh &
[1] 3309
k71v1_64_bsp:/ # !!![@@@]!!!_wakeup_!!![@@@]!!!
```

- **Step4.** **usb,** **usb,** **usb,** 下

  power monitor **usb adapter**

  12

New UART log

USB

Suspend/Resume (3/3)

- **Step5.** 停 不

  adb shell cat /sys/kernel/debug/cpuidle/spm/spm_sleep_count

  不 0

  ```
  evb6765_64_emmc:/ # cat /sys/kernel/debug/cpuidle/spm/spm_sleep_count
  0
  ```

  USB USB 不 662

  1.USB 2.

  ```
  C:\Users\mtk07417>adb shell cat /sys/kernel/debug/cpuidle/spm/spm_sleep_count
  662
  ```

- **Step6.** " rc 3 5"

- **Step7.** >3 不

New UART log

USB

REBOOT
(DDR RESERVE MODE , FULL-K　FAST K)

DDR reserve mode Reboot　　　(1/2)

- DDR Reserve mode test　　　　　DDR reserve mode 务　　不　　reboot　DDR reserve mode　reboot　DRAM　self refresh,　reboot　DRAM　　　　　,　reboot　　　　debug

- **Step1. Preloader bin**　　　　　.

　　　　　always on　　　　　　　MTK mobile log

- **Step2.　reboot_script** **reboot_ddr_reserve_mode.bat　device id** **id**　　　　　不　　　　**reboot**　　　　　**"reboot with ddr reserve mode"**

  Note:Opp table　16

DDR reserve mode Reboot (2/2)

- **Step4.** **UART log** **UART log** **UART log** ,
  下 **12**

- **Step5.** " rc 3 5"

- **Step6.** CTV n i CTV n i . n i kng Urnkvvgt 不 n i

- **Fail** ↑RGU] WDT DDR reserve mode FAIL! _

- RCUU ^DDR RESERVED ^ 不log pass

  [RGU] WDT DDR reserve mode success! 1387F1
  [DDR Reserve] DCS/DVFSRC success! (dcs_en=0, dvfsrc_en=1)
  [RGU] WDT **DDR reserve mode success!** 1387F1
  [RGU] DDR RESERVE Success 1
  [DDR Reserve] release dram from self-refresh PASS!

- **Step7.** **>3** 不**reboot**

URART LOG

USB 三

Full-K Reboot (1/2)

- Step1. **Preloader** **full k bin.**
- **Full k bin**
- 1 define DRAM_HQA
- 2: dramc_pi_api.h
- define SUPPORT_SAVE_TIME_FOR_CALIBRATION **CFG_DRAM_CALIB_OPTIMIZATION**
- define SUPPORT_SAVE_TIME_FOR_CALIBRATION **0**

Step 2. always on MTK mobile log

- **Step3.** **reboot_full_k.bat** **device id**
- **id**

- Note1: Full k 5
- Note2: device id

```
DDR                    : 3200000  khz
reboot full-k, opp table: 1
2018/09/12 周三 19:05:08.24
Vcore                  : 800000   uv  (PMIC: 0x2d)
DDR                    : 2400000  khz
reboot full-k, opp table: 7
2018/09/12 周三 19:05:08.24
Vcore                  : 700000   uv  (PMIC: 0x1d)
DDR                    : 2400000  khz
reboot full-k, opp table: 8
2018/09/12 周三 19:05:08.24
Vcore                  : 700000   uv  (PMIC: 0x1d)
DDR                    : 1534000  khz
reboot full-k, opp table: 14
2018/09/12 周三 19:05:08.24
Vcore                  : 650000   uv  (PMIC: 0x15)
DDR                    : 1534000  khz
reboot full-k, opp table: 15
2018/09/12 周三 19:05:08.24
reboot full-k, round: 5
Vcore                  : 800000   uv  (PMIC: 0x2d)
DDR                    : 3200000  khz
reboot full-k, opp table: 1
2018/09/12 周三 19:07:41.00
```

- **Step4. opp table** 住

- **12**

- **Step5.** " rc 3 5"

- **Step6.** **>3** 不**reboot**

New   UART
log

USB 三

Fast-k Reboot (1/2)

- 　　　　　　　　**LPDDR4** **LPDDR3** 　　　**停** 　　　　**Preloader bin** 　　**LV bin**
  不

- Fast-k Stress test 　　　不 　　　　　　　　　　　　　　　　　　不

- Step1. 　　reboot_script 　　　　　　reboot_fast_K.bat　device id
  　　　　　　id

- Step2.　　　reboot_fast_K.bat　　　　　　　　　　12

```
C:\Windows\system32\cmd.exe
reboot, round: 1, opp table: 1
2018/09/13 周四 12:15:11.59
reboot, round: 2, opp table: 2
2018/09/13 周四 12:16:28.62
reboot, round: 3, opp table: 3
2018/09/13 周四 12:17:44.05
reboot, round: 4, opp table: 0
2018/09/13 周四 12:18:59.11
reboot, round: 5, opp table: 1
```

- Step3.　　　　　"　　　　pass　　　　"

- Step4.　　　UART log　　UART log　　　　　　　　　n i　　　　　kng
  Urnkvvgt　　不　　　n i

　　　　Fail　　　　　　　↑Save calibration result to emmc _

　　　　PASS　　　　　　　　↑Bypass saving calibration result to emmc ^

- Step5.　　　　　　　　>3　　　NT　　不reboot

PASS

pass (1/3)

1.   N

2.   memtester   memtester   memtester
     不   fail

     memtester   Error detected   不

```
C:\Windows\system32\cmd.exe
"wait for device.."
adbd is already running as root
remount succeeded
adbd is already running as root
"push memtester"
2169 KB/s (319856 bytes in 0.144s)
108 KB/s (555 bytes in 0.005s)
"total " 335544320
"each "67108864
check_sum=6
[DRAM_MEMTEST] Error detected, exit
Press any key to continue . . .
```

       collect_memtest_log.bat   log   memtester fail log
               MTK

pass　　　(2/3)

3. 不　　　　　不　　　　　　　4　　　　KE,HWT　HW_reboot, MEMTEST,
　　　　不　　　　　　份　　　　　　fail,　　　3　　　　　pass
　　(1) /data/aee_exp　(2) /data/vendor/mtklog/aee_exp

3 份　　　　　　　　　**fail,**　　　**log**　　**MTK**

　　1　　　　　　cmd
adb shell
cd data/aee_exp
ls

　　　aee_exp
　　4

pass (3/3)

2   不   /data/vendor/mtklog/aee_exp   KE/HWT/HW_Reboot/
                       DB   db   pull_log.bat pull   MTK

```
C:\Users\mtk10621>adb shell
evb6765_64_emmc:/ # cd /data/vendor/mtklog/aee_exp
evb6765_64_emmc:/data/vendor/mtklog/aee_exp # ls -al
total 16
drwxr-xr-x 3 root root 4096 2010-01-02 20:57 .
drwxr-xr-x 3 root root 4096 2018-04-11 05:36 ..
-rw------- 1 root root    0 2010-01-01 04:04 aee.lck
drwxrwxrwx 2 root root 4096 2010-01-01 04:04 db.00.KernelAPI
-rw-r--r-- 1 root root  103 2010-01-01 04:04 db_history
evb6765_64_emmc:/data/vendor/mtklog/aee_exp #
```

         aee_exp   pull   MTK

1.   D   1   mtklog

2.   pull_log.bat   mtklog   usb   不
   pull_log.bat   log   mtklog   MTK

- ETT BIN　　不
  → 　　　停Format whole flash　　　　　　　　　　　Jump, Address　　　　　　　　　　不Download key.
-
  → 　　UART cable　　　　　1.8V,　　　　　　　　　　　　　log.　　UART cable　　双

-
  → 　　UART　　RX, TX　GND
- ETT
  →
- adb
  → 　ADB　　双　　　　　　　务
- APK
  → 　　　　　　　　　　　　APK
- eMMC R/W
  → 　　　　32bit　　64bit,
- 　　　　　　　　Power KEY
  → 　　　　　　　　　->　　->30

NTNV/LTHV   3D   HTLV   Log

Thermal

停   PA   Thermal ADC

65   不停   PCB   100

Thermal   NTC   停

况

1.   NTC   10K

2.

3.   Thermal Throttling   务   不   1   2

4.   LTE   Thermal Throttling   不   3

Mobile Log   Log

LTE Throttling   LTE throttling   LTE

Throttling   AP   Throttling   (不   3

How To Modify Thermal Policy

- thermal throttling 不

(1)User sw load thermal throttling
- (a) Get root permission
- (b) adb shell "/system/bin/thermal_manager /etc/.tp/.ht120.mtc" (for Android M)
    adb shell "/vendor/bin/thermal_manager /vendor/etc/.tp/.ht120.mtc"(for Android N)
- (c)   cat /data/.tp/.settings
   /etc/.tp/.ht120.mtc   /vendor/etc/.tp/.ht120.mtc代表修改成功

(2)Eng sw load thermal throttling
- (a)   不others-thermal   thermal policy   high temp 120deg c, apply
- (b) adb shell "/system/bin/thermal_manager /etc/.tp/.ht120.mtc" (for Android M)
    adb shell "/vendor/bin/thermal_manager /vendor/etc/.tp/.ht120.mtc"(for Android N)
- (c)   cat /data/.tp/.settings
   /etc/.tp/.ht120.mtc   /vendor/etc/.tp/.ht120.mtc代表修改成功

(3)僅取消LTE throttling,保留其餘的thermal throttling功能
- (a)adb shell "echo 1 120000 0 mtk-cl-shutdown02 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 0 0 no-cooler 1000 > /proc/driver/thermal/tzbtspa ^
- (b)   cat /proc/driver/thermal/tzbtspa, 如果
  cooldev1=mtk-cl-mutt02,cooldev2=mtk-cl-mutt01,cooldev3=mtk-cl-mutt00,   成cooldev1=no-cooler,cooldev2=no-cooler,cooldev3=no-cooler代表修改成功

How to check LTE throttling is triggered?

Thermal   Mobile Log

- How to Check if LTE throttling is triggered from mobilelog

    searching keyword in kernel_log

    ^ š Z Œ u o l } } o Œ m h t k μ c š š m u t t _ s e t _ Œ m u t t _ l i m i t _

    If the following log is found, LTE throttling is triggered.

```
(0)[481:kworker/0:2][Auxadc] [AUXADC] ch=4 raw=1466 data=544
(0)[481:kworker/0:2][Power/PA_Thermal] PA T=111000
(0)[481:kworker/0:2][Power/BTSMDPA Thermal] T_btsmdpa=61000
(0)[481:kworker/0:2]thermal/cooler/mutt[mtk_cl_mutt_set_mutt_limit] ret 0 param 20101 bcnt 11
(0)[481:kworker/0:2][Power/BTS_Thermal] T_AP=56000
(0)[55:cfinteractive][Power/cpufreq] _mt_cpufreq_power_limited_verify(): idx = 10, limited_max_
```

LTE Thermal Throttling   Transceiver   之

                                                          Debug

SOP   Eservice