



AOS-CX 10.18.xxxx Monitoring Guide (4100i, 6000, 6100 Switch Series)

AOS-CX 10.18.xxxx Monitoring Guide (4100i, 6000, 6100 Switch Series)

Published: May 2026

© Copyright 2026 – Hewlett Packard Enterprise Development LP

Notices

The information provided here is subject to change without notice. Hewlett Packard Enterprise's products and services are covered only by the express warranty statements that come with them. This document does not constitute an additional warranty. Hewlett Packard Enterprise is not responsible for any technical or editorial errors or omissions in this document.

Confidential computer software. You must have a valid license from Hewlett Packard Enterprise to possess, use, or copy the software. In accordance with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under the vendor's standard commercial license.

Links to third-party websites will take you outside of the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for the information outside the Hewlett Packard Enterprise website.

Open source code

This product includes code licensed under certain open source licenses which require source compliance. The corresponding source for these components is available upon request. This offer is valid to anyone in receipt of this information and shall expire three years following the date of the final distribution of this product version by Hewlett Packard Enterprise Company. To obtain such source code, please check if the code is available in the HPE Software Center at <https://myenterpriselicense.hpe.com/cwp-ui/software> but, if not, send a written request for specific software version and product for which you want the open source code. Along with the request, please send a check or money order in the amount of US \$10.00 to:

Hewlett Packard Enterprise Company

Attn: General Counsel

WW Corporate Headquarters

1701 E Mossy Oaks Rd, Spring, TX 77389

United States of America.



Legal disclaimer

The resource assets in this document may include abbreviated and/or legacy terminology for products. See [**www.arubanetworks.com**](http://www.arubanetworks.com) for current and complete product lines and names.

Table of contents

About this document.....	7
Applicable products.....	7
Latest version available online.....	7
Command syntax notation conventions.....	7
About the examples.....	9
Identifying switch ports and interfaces.....	9
Monitoring hardware through visual observation.....	10
Confirming normal operation of the switch by reading LEDs.....	10
Detecting if the switch is not ready for a failover event.....	12
Finding faulted components using the switch LEDs.....	13
IP Flow Information Export.....	14
Flow monitors.....	16
Flow Records.....	17
Flow Exporters.....	17
Destinations.....	18
Configuring IP Flow Information Export on 4100i, 6000, and 6100 Switches.....	18
Alarms.....	21
Alarm commands.....	22
alarm	22
alarm input	25
alarm snooze	27
show alarm	28
Boot commands.....	31
Boot commands.....	31
boot set-default	31
boot system	32
show boot-history	34
L1-100Mbps downshift.....	39
Limitations with speed downshift.....	40
L1-100Mbps downshift commands.....	40
downshift enable	40
show interface	41
show interface downshift-enable	53
show running-config interface	55

Mirroring.....	57
Mirror statistics.....	59
Classifier policies and mirroring sessions.....	59
Mirroring commands.....	60
clear mirror	60
comment	61
destination interface	62
destination tunnel	64
diagnostic	66
disable	68
enable	68
mirror endpoint	70
mirror session	72
show mirror	73
show mirror endpoint	76
source interface	78
Monitoring a device using SNMP.....	80
Packet Capture.....	80
Power-over-Ethernet.....	81
PoE commands.....	82
lldp dot3 poe	83
lldp med poe	84
power-over-ethernet	85
power-over-ethernet allocate-by	86
power-over-ethernet always-on	88
power-over-ethernet assigned-class	89
power-over-ethernet pre-std-detect	90
power-over-ethernet priority	91
power-over-ethernet quick-poe	92
power-over-ethernet threshold	94
power-over-ethernet trap	95
show lldp local	96
show lldp neighbor	97
show power-over-ethernet	98
Aruba AirWave.....	101
SNMP support and AirWave.....	101
Supported features with AirWave and the AOS-CX switch.....	102
Configuring the AOS-CX switch to be monitored by AirWave.....	103

AirWave commands.....	104
logging	104
snmp-server community	107
snmp-server host	110
snmp-server vrf	116
snmpv3 context	117
snmpv3 user	118
snmpv3 user view	122
Support and Other Resources.....	123
Accessing HPE Aruba Networking Support.....	124
Accessing Updates.....	125
Warranty Information.....	125
Regulatory Information.....	126
Documentation Feedback.....	126

About this document

This document describes features of the AOS-CX network operating system. It is intended for administrators responsible for installing, configuring, and managing HPE Aruba Networking switches on a network.

Subtopics

Applicable products

Latest version available online

Command syntax notation conventions

About the examples

Identifying switch ports and interfaces

Applicable products

This document applies to the following products:

- HPE Aruba Networking 4100i Switch Series (JL817A, JL818A)
- HPE Aruba Networking 6000 Switch Series (R8N85A, R8N86A, R8N87A, R8N88A, R8N89A, R9Y03A, S4R20A, S4R21A, S4R22A, S4R23A, S4R24A, S4R25A, S4R26A, S4R27A, S4R28, S4R29A)
- HPE Aruba Networking 6100 Switch Series (JL675A, JL676A, JL677A, JL678A, JL679A)

Latest version available online

Updates to this document can occur after initial publication. For the latest versions of product documentation, see the links provided in [Support and Other Resources](#).

Command syntax notation conventions

Convention	Usage
example - text	Identifies commands and their options and operands , code examples, filenames, pathnames, and output displayed in a command window. Items that appear li

Convention	Usage
	ke the example text in the previous column are to be entered exactly as shown and are required unless enclosed in brackets ([]).
example - text	In code and screen examples, indicates text entered by a user.
Any of the following: • <example - text> • <example - text> • example - text • example - text	Identifies a placeholder—such as a parameter or a variable—that you must substitute with an actual value in a command or in code: • For output formats where italic text cannot be displayed, variables are enclosed in angle brackets (< >). Substitute the text—including the enclosing angle brackets—with an actual value. • For output formats where italic text can be displayed, variables might or might not be enclosed in angle brackets. Substitute the text including the enclosing angle brackets, if any, with an actual value.
	Vertical bar. A logical OR that separates multiple items from which you can choose only one. Any spaces that are on either side of the vertical bar are included for readability and are not a required part of the command syntax.
{ }	Braces. Indicates that at least one of the enclosed items is required.
[]	Brackets. Indicates that the enclosed item or items are optional.
... or ...	Ellipsis: • In code and screen examples, a vertical or horizontal ellipsis indicates an omission of information. • In syntax using brackets and braces, an ellipsis indicates items that can be repeated. When an item followed by ellipses is enclosed in brackets, zero or more items can be specified.

About the examples

Examples in this document are representative and might not match your particular switch or environment.

The slot and port numbers in this document are for illustration only and might be unavailable on your switch.

Understanding the CLI prompts

When illustrating the prompts in the command line interface (CLI), this document uses the generic term **switch**, instead of the host name of the switch. For example:

```
switch>
```

The CLI prompt indicates the current command context. For example:

```
switch>
```

Indicates the operator command context.

```
switch#
```

Indicates the manager command context.

```
switch (CONTEXT-NAME) #
```

Indicates the configuration context for a feature. For example:

```
switch (config-if) #
```

Identifies the **interface** context.

Variable information in CLI prompts

In certain configuration contexts, the prompt may include variable information. For example, when in the VLAN configuration context, a VLAN number appears in the prompt:

```
switch (config-vlan-100) #
```

When referring to this context, this document uses the syntax:

```
switch (config-vlan-<VLAN-ID>) #
```

Where <VLAN-ID> is a variable representing the VLAN number.

Identifying switch ports and interfaces

Physical ports on the switch and their corresponding logical software interfaces are identified using the format: **member/slot/port**.

On the HPE Aruba Networking 4100i Switch Series

- member: Always 1. VSF is not supported on this switch.
- slot: Always 1. This is not a modular switch, so there are no slots.
- port: Physical number of a port on the switch.

For example, the logical interface **1/1/4** in software is associated with physical port 4 on the switch.

On the HPE Aruba Networking 6000 and 6100 Switch Series

- member: Always 1. VSF is not supported on this switch.
- slot: Always 1. This is not a modular switch, so there are no slots.
- port: Physical number of a port on the switch.

For example, the logical interface **1/1/4** in software is associated with physical port 4 on the switch.

Monitoring hardware through visual observation

Subtopics

Confirming normal operation of the switch by reading LEDs

Detecting if the switch is not ready for a failover event

Finding faulted components using the switch LEDs

Confirming normal operation of the switch by reading LEDs

This task describes using the switch LEDs to confirm that the switch is operating normally.



NOTE

For complete information on LED behaviors for your AOS-CX switch, refer to the **Installation and Getting Started Guide** for that switch series, available for download from the section of the .

Procedure

1. Quick check: Verify that the chassis has power and there are no fault conditions.
On the front of the switch, verify that the states of the following LEDs are On Green:
2.
 - Power
 - Health

Verify that the Health LEDs of all installed line modules are On Green.

3. Verify that the Health LEDs of all installed management modules are On Green.
4. Verify that the network ports are operating normally.
 - a. On the active management module, check the Status Front section. Verify that each LED that indicates a line module is in one of the following states:
 - On Green (normal operation)
 - Off (no line module installed)
 - b. On each line module, verify that each port LED is in one of the following states:
 - On Green, Half-Bright Green, or Flickering Green (normal operation)
 - Off (no cable connected or port off by default in config)
5. Verify that the power supplies are operating normally.
 - a. On the active management module, check the Status Front section. Verify that each LED that indicates a power supply is in one of the following states:
 - On Green (normal operation)
 - Off (no power supply installed)
 - b. On each power supply, verify that LEDs are in the following states:
 - Power LED: On Green
 - Fault LED: Off
6. Verify that the rear components are operating normally by checking the Status Rear section of the active management module:
 - a. Verify that the LEDs for the fabric modules are in one of the following states:
 - On Green (normal operation)
 - Off (component not installed)
 - b. Verify that the LEDs for the fan trays and fans are On Green.
7. Verify that the standby management module is ready to take over as the active management module. On the standby management module, verify the states of the following LEDs:
 - Health LED is On Green.
 - Management state standby (Stby) LED is On Green.

Detecting if the switch is not ready for a failover event

This task describes using the switch LEDs to detect if the switch is not ready for the loss of a fabric module or for a failover from the active management module to the standby management module.



NOTE

Although you can detect power supply failures by viewing the LEDs, you must use software commands to determine if the power supply redundancy is sufficient to power the chassis if a power supply fails. For complete information on LED behaviors for your AOS-CX switch, refer to the **Installation and Getting Started Guide** for that switch series, available for download from the section of the .

Procedure

1. Detect if the standby management module is shut down.

If the standby management module is shut down, the LED states are as follows:

- The standby management module health LED is Off.
- The standby management state active (Actv) LED is Off.
- The standby management state standby (Stby) LED is Off.
- On the active management module in the Status Front Management Modules section, the LED for the standby management module is Off. For example, if the active management module is Management Module LED 5, Management Modules LED 6 is Off.

2. Detect if the standby management module is in a transient state. If the standby management module is booting, updating, or in another transient state, the LED states are as follows:

- The standby management module health LED is Slow Flash Green when the service operating system is running or during an operating system update.
- The standby management module Booting LED is Slow Flash Green when the AOS-CX operating system is booting.
- The standby management state active (Actv) LED is Off.
- The standby management state standby (Stby) LED is Off.
- On the active management module in the Status Front Management Modules section, the LED for the standby management module is Slow Flash Green.

3. Detect if a fabric module is shut down or not present. If a fabric module is shut down or not present, the LED states are as follows:

- On the active management module, in the Status Rear section, the LED for the fabric module is Off.

- On the rear display module, the LED for the fabric module is Off.
- On the fabric module, the health LED is Off. However, the fabric module is behind fan 1 and is not directly visible.

Finding faulted components using the switch LEDs

This task describes using the switch LEDs to find components that are in a fault condition.



NOTE

All green LEDs—except for chassis power LEDs and the Usr1 LED—are off when the LED mode is set to Light Faults (The Usr1 LED of the LED Mode section of the active management module is On Green and the default behavior for the Usr1 LED is being used.). For complete information on LED behaviors for your AOS-CX switch, refer to the **Installation and Getting Started Guide** for that switch series, available for download from the section of the .

Procedure

1. Find the switch that has the fault condition, which is indicated by a chassis health LED in the state of Slow Flash Orange.
The chassis health LED is located on the front of the switch and on the rear panel of the switch.
2. If you are at the back of the switch, on the rear panel, look for LEDs that are in the Slow Flash Orange state:
The Status Rear area has LEDs for power supplies, fabric modules, fan trays, and fans. The number on the LED represents the unit number of the component.

If the only LED in a state of Slow Flash Orange is the Chassis health LED, go to the front of the switch.
3. At the front of the switch, on the active management module, look for LEDs that are in the Slow Flash Orange state:
 - The Status Front area has LEDs for power supplies, line and fabric modules, and management modules. The number on the LED indicates the slot number of the component.
 - The Status Rear area has LEDs for fabric modules and fan trays, with a single LED for all the fans in the fan tray. The number on the LED represents the slot or bay number of the component.
4. Use the number indicated by the LED that is flashing to locate the slot that contains the faulted component.
The fabric modules are located behind the fan trays, and the fabric module number corresponds to the fan tray number.

5. At the front of the switch, on line modules, look for LEDs that are in the Slow Flash Orange state: Module LEDs and Port LEDs indicate faults if their states are Slow Flash Orange.

IP Flow Information Export

IP Flow Information Export (IPFIX) is an embedded network flow analysis tool that compiles characteristic and measured properties of flows and sends flow reports to internal or external flow collectors. IPFIX is configurable via the command-line or REST interfaces. With IPFIX, customers configure flow records with match (key) fields and collection (non-key) fields. Match fields are the set of fields that define a flow, such as IP address or UDP port. Collection fields are the set of fields that identify information to collect for a flow, such as packet and byte counters.

A flow exporter defines where and how to export flow reports. Flow exporters are created as standalone entities in the **config** context to provide flow monitors the ability to export flow reports.

Compatibility with Traffic Insight

The AOS-CX traffic insight feature allows monitoring of large amount of data that it collects from various flow exporters like IPFIX, and provides the ability to filter, aggregate, and sort the data based on user flow monitor requests. Traffic insight tracks different monitor requests simultaneously and provides monitor reports per request. For more information on configuring the Traffic Insight features, refer to the AOS-CX Security Guide.

Information Elements

The IPFIX Information Elements (IE) are entities that are defined and maintained by the Internet Assigned Numbers Authority (IANA). They are characterized by a unique piece of information they can provided about a flow. Information Elements may be either private or public. Private Information Elements are exported with a Private Enterprise Number (PEN).

AOS-CX can act as an intermediate collecting process for flow reports from hardware to append certain additional IPFIX information elements to the flow reports. When configured, the software will act as an intermediate exporting process to export the augmented flow reports to any configured flow exporters.

AOS-CX supports the standard and private information elements shown in the tables below.



NOTE

Not all switches support all information elements. View a list of information elements supported by your switch using the command **show flow monitor <monitor-name> information-elements**. All Standard Information Element registration information can be found on the IANA website, at <https://www.iana.org/assignments/ipfix/>.

Standard Information Elements

octetDeltaCount

packetDeltaCount

protocolIdentifier

sourceTransportPort

sourceIPv4Address

ingressInterface

destinationTransportPort

destinationIPv4Address

vlanId

ipVersion

flowStartMicroseconds

flowEndMicroseconds

paddingOctets

ingressPhysicalInterface

About individual Information Elements

The following IEs are used for both IPv4 and IPv6 flows:

- cngSourceIP
- cngDestinationIP

They are always 16 bytes wide. The IP version of the flow is indicated in the **ipVersion** IE. For IPv4 addresses, the first 12 octets are zero and the IPv4 address is encoded in the last 4 octets. For IPv6 addresses, the full 16 bytes encode the address.

The following IEs reflect the hardware interface ID used by the associated flow:

- ingressPhysicalInterface

- egressPhysicalInterface

The hardware interface ID does not match the front-panel port number of the interface. The hardware interface ID can be mapped to the front-panel port number by using the REST API to query for **hw_intf_info** for all interfaces and saving the **switch_intf_id** value together with the associated front-panel name to form a mapping table.

Example using curl and jq:

```
bash
$ curl -X GET
    "{SWITCH}/rest/{VERSION}/system/interfaces?
attributes=hw_intf,info,name&depth=2"
-H "x-csrf-token: {CSRFTOKEN}"
-b {AUTH COOKIE FILE}
| jq 'to_entries
    | map({port: .key, switch_intf_id:
(.value.hw_intf_info.switch_intf_id | tonumber)})
    | sort_by(.switch_intf_id)
    | map({(.port): .switch_intf_id})
    | add'
{
  "1/1/6": 1,
  "1/1/2": 2,
  "1/1/1": 3,
  ...
}
```

Subtopics

Flow monitors

Flow Records

Flow Exporters

Destinations

Configuring IP Flow Information Export on 4100i, 6000, and 6100 Switches

Flow monitors

A flow monitor is applied to an interface to perform network traffic monitoring. A flow monitor consists of a flow record, a flow cache, and optional flow exporters. A flow record must be created and assigned to the flow monitor for the monitoring process to function. Flow data is compiled from the network traffic on the interface and stored in the flow cache based on the match (key) and collect (non-key) fields in the flow record. Data from the flow cache is exported by the flow exporters assigned to the flow monitor. 4100i, 6000, and 6100 switch series support a maximum of sixteen flow exporters that can be applied to a single flow monitor.

Flow Records

A flow record defines match (key) fields and collection (non-key) fields. Match fields are the set of fields that define a flow, such as IP address or UDP port. Collection fields are the set of fields that identify information to collect for a flow, such as packet and byte counters. On the 4100i, 6000, and 6100 switch series a maximum of sixteen flow records can be created.

There are six mandatory match fields, of which the IP match fields must be of the same type (IPv4 or IPv6).



NOTE

A flow record is invalid if it does not contain one of the supported sets of match fields.

The supported sets of match fields are:

- IPv4 version
- IPV4 source address
- IPv4 destination address
- IPv4 protocol
- Transport destination port
- Transport source port
- IPv6 version
- IPv6 source address
- IPv6 destination address
- IPv6 protocol
- Transport destination port
- Transport source port

Flow Exporters

A flow exporter defines where and how to export flow reports. Flow exporters are created as standalone entities in the **config** context to provide flow monitors the ability to export flow reports. 4100i, 6000,

and 6100 Switch series support a maximum of sixteen flow exporters that can be applied to a single flow monitor.

Destinations

About this task

The destination specifies where flow reports are sent. There are two possible destination types for a flow exporter, but only one can be used at a time within the 4100i, 6000, and 6100 switch series:

Procedure

Hostname or IP address of a device .

Results

A flow exporter can only send flow reports to one destination. The destination type specifies which destination to use. If no destination type is specified, the default destination type is the hostname or IP address of a device supported on 4100i, 6000, and 6100 Switch series. A destination of each type can be configured, but only the one corresponding to the destination type is used. If there is no destination corresponding to the destination type, then the flow exporter configuration is incomplete. If a new destination of a particular type is configured, it will replace the destination of that type that was previously configured.

- Traffic Insight instance

Configuring IP Flow Information Export on 4100i, 6000, and 6100 Switches

The following list describes the steps required to configure a IP flow information export (IPFIX) solution:

- Step one: Create flow records
- Step two: Configure flow exporter(s)
- Step three: Configure monitor(s)
- Step four: Apply a flow monitors to interface(s)



NOTE

IPv6 related commands are only applicable to switches that support IPv6 protocol.

Step one: Create Flow Records

Flow Records are used to define the data that will be added to the IPFIX template. This example configures one record for IPv4 and one for IPv6.

```
switch(config)# flow record flowRecordv4
switch(config-flow-record)# match ip protocol
switch(config-flow-record)# match ip source address
switch(config-flow-record)# match ip destination address
switch(config-flow-record)# match ip version
switch(config-flow-record)# match transport destination port
switch(config-flow-record)# match transport source port
switch(config-flow-record)# collect counter bytes
switch(config-flow-record)# collect counter packets
switch(config-flow-record)# collect application name
switch(config-flow-record)# collect timestamp absolute first
switch(config-flow-record)# collect timestamp absolute last
switch(config-flow-record)# collect application https url
switch(config)# flow record flowRecordv6
switch(config-flow-record)# match ipv6 protocol
switch(config-flow-record)# match ipv6 source address
switch(config-flow-record)# match ipv6 destination address
switch(config-flow-record)# match ipv6 version
switch(config-flow-record)# match transport destination port
switch(config-flow-record)# match transport source port
switch(config-flow-record)# collect counter bytes
switch(config-flow-record)# collect counter packets
switch(config-flow-record)# collect timestamp absolute first
```

Next, use the **show flow record** command to verify the configuration.

Step two: Configure flow exporter(s)

In this step, you can define an exporter to send to an external destination by hostname or IP address, or to an internal destination such as Traffic Insight. The example below configures IPFIX to export data to an external address/hostname:

```
switch(config)# flow exporter flowExternal
switch(config-flow-exporter)# destination type hostname-or-ip-addr
switch(config-flow-exporter)# destination 11.1.1.1
switch(config-flow-exporter)# show flow exporter

-----
----
Flow exporter 'flowExternal
-----
----
Status                        : Accepted
```

```
Export Protocol      : ipfix
Destination Type     : Hostname or IP address
Destination          : 11.1.1.1
Transport Configuration
Protocol             : udp
Port                 : 4739
```

To configure IPFIX to export to Traffic Insight, first configure Traffic Insight.

```
switch(config)# traffic-insight TI
switch(config-ti-TI)# source ipfix
switch(config-ti-TI)# monitor topN type topN-flows
switch(config-ti-TI)# monitor appFlow type application-flows
switch(config-ti-TI)# enable
```

Next, configure the flow exporter for Traffic Insight

```
switch(config)# flow exporter flowExpTI
switch(config-flow-exporter)# export-protocol ipfix
switch(config-flow-exporter)# destination type traffic-insight
switch(config-flow-exporter)# destination traffic-insight TI
```

You can use the **show flow exporter** command to verify the flow exporter configuration for Traffic Insight

```
switch(config)# show flow exporter flowExpTI
-----
----
Flow exporter 'flowExpTI'
-----
----
Status                : Accepted
Export Protocol        : ipfix
Destination Type       : Traffic Insight
Destination            : TI
Transport Configuration
Protocol               : udp
Port                   : 4739
```

Finally, use the **show run traffic-insight** command to verify the Traffic Insight configuration:

```
switch(config)# show running-config traffic-insight
traffic-insight TI
enable
source ipfix
!
monitor topN type topN-flows entries 5
monitor appFlow type application-flows
```

Step three: Configure the monitor(s)

First, configure an IPv4 flow monitor.

```

switch(config)# flow monitor flowMonv4
switch(config-flow-monitor)# record flowRecordv4
Switch (config-flow-monitor)# exporter flowExternal
switch(config-flow-monitor)# exit

```

Next, configure an IPv6 flow monitor.

```

switch(config)# flow monitor flowMonv6
switch(config-flow-monitor)# record flowRecordv6
switch(config-flow-monitor)# exporter flowExternal
switch(config-flow-monitor)# exit

```

Once both flow monitors are created, use the **show flow monitor** command to verify the flow monitor configurations.

```

switch(config-flow-monitor)# show flow monitor

```

```

-----
----
Flow monitor 'flowMonv4'
-----
----
Status                : Accepted
Flow Record           : flowRecordv4
Flow Exporter(s)      : flowExternal
Cache Configuration
Inactive Timeout      : 120
Active Timeout        : 1800
-----
----
Flow monitor 'flowMonv6'
-----
----
Status                : Accepted
Flow Record           : flowRecordv6
Flow Exporter(s)      : flowExternal
Cache Configuration
Inactive Timeout      : 120
Active Timeout        : 1800

```

Alarms

Alarms allow you to configure physical alarms for alarm input ports and specific systems events.



CAUTION

Alarms are only available on the 4100i switch.

Subtopics

Alarm commands

Alarm commands

Subtopics

alarm

alarm input

alarm snooze

show alarm

alarm

Syntax

```
alarm
  power-supply|temperature
action <LOG-AND-TRAP>|<RELAY>
  input IN1|IN2
action <LOG-AND-TRAP>|<RELAY>
name <STRING>
trigger <CLOSED>| <OPEN>
  no...
  snooze
<time in minutes>
repeat
```

Description

Configures input alarm and actions, or global events to be forwarded to the output alarm port, or temporarily disables (snoozes) active event forwarding to the alarm relay for a specified time interval.

Parameter	Description
temperature	Selects the alarm for ambient temperatures reaching the threshold limit of 70°C.
power-supply	Selects the alarm events from the power supply.
action	Specifies the action to be taken when the monitored event occurs.
<LOG-AND-TRAP>	Generates an event log and SNMP trap.
<RELAY>	Relays an event to alarm output port.
input IN1 IN2	Specifies the input alarm port.
action	Specifies the action to be taken when the monitored event occurs.
<LOG-AND-TRAP>	Generates an event log and SNMP trap.
<RELAY>	Relays an event to alarm output port.
name <STRING>	Specifies the external device connected.
trigger	Triggers an alarm based on a normally open or closed circuit.
<CLOSED>	Generates an alarm event when the circuit is closed.
	Generates an alarm event when the circuit is open.

Parameter	Description
<OPEN>	
no ...	Negates any configured parameter or removes the specified configuration.
snooze	Snooze the relay action for specified time interval.
<time in minutes>	Specifies the snooze time in minutes. The range is 0 - 1440 minutes..
repeat	Repeats the previous snooze time.

Examples

Disabling a temperature event to remove the configuration for all actions associated with the event:

```
switch(config) # no alarm temperature
```

Configuring an alarm for a temperature event for the log-and-trap action:

```
switch(config) # alarm temperature action log-and-trap
```

Removing the configuration for the temperature event for a log-and-trap action:

```
switch(config) # no alarm temperature action log-and-trap
```

Configuring an alarm for a power-supply event for the relay action:

```
switch(config) # alarm power-supply action relay
```

Removing the configuration for the power-supply event for the relay action:

```
switch(config) # no alarm power-supply action relay
```

Configuring an alarm on input port 1 named Door-Sensor:

```
switch(config) # alarm input IN1 name Door-Sensor
```

Removing the configuring for an alarm on input port 1:

```
switch(config) # no alarm input IN1
```

Configuring an alarm on input port 1 with log-and-trap action:

```
switch(config) # alarm input IN1 action log-and-trap
```

Removing the configuration for an alarm on input port 1 with log-and-trap action:


```
switch(config) # no alarm input IN1 action log-and-trap
```

Configuring an alarm on input port 1 to trigger an alarm when the door sensor circuit is closed:

```
switch(config) # alarm input IN1 trigger closed
```

Configuring an alarm relay action for 10 minutes:

```
switch(config) # alarm snooze 10
```

Configuring an alarm relay action to be repeated with previously configured snooze time:

```
switch(config) # alarm snooze repeat
```

Command History

Release	Modification
10.08	Feature introduced.

Command Information

Platforms	Command context	Authority
4100i	config	Administrators or local user group members with execution rights for this command.

alarm input

Syntax

```
alarm input {IN1 | IN2} [name <STRING>] [action <LOG-AND-TRAP> | <RELAY>]  
[trigger <CLOSED | OPEN>]  
no alarm input {IN1 | IN2} [name <STRING>] [action <LOG-AND-TRAP> | <RELAY>]  
[trigger <CLOSED | OPEN>]
```

Description

Configures input alarm and actions. The **no** form of this command removes the specified configuration.

Parameter	Description
{IN1 IN2}	Specifies the input alarm port..
name	Specifies the external device connected.
<STRING>	Descriptive string.
action	Specifies the action to be taken when the monitored event occurs.
<LOG-AND-TRAP>	Generates an event log and SNMP trap.
<RELAY>	Relays an event to alarm output port.
trigger	Triggers an alarm based on a normally open or closed circuit.
<CLOSED>	Generates an alarm event when the circuit is closed.
<OPEN>	Generates an alarm event when the circuit is open.

Examples

Configuring an alarm on input port 1 named Door-Sensor:

```
switch(config)# alarm input IN1 name Door-Sensor
```

Removing the configuring for an alarm on input port 1:

```
switch(config)# no alarm input IN1
```

Configuring an alarm on input port 1 with log-and-trap action:

```
switch(config) # alarm input IN1 action log-and-trap
```

Removing the configuration for an alarm on input port 1 with log-and-trap action:

```
switch(config) # no alarm input IN1 action log-and-trap
```

Configuring an alarm on input port 1 to trigger an alarm when the door sensor circuit is closed:

```
switch(config) # alarm input IN1 trigger closed
```

Command History

Release	Modification
10.08	Feature introduced.

Command Information

Platforms	Command context	Authority
4100i	config	Administrators or local user group members with execution rights for this command.

alarm snooze

Syntax

```
alarm snooze [time in minutes] [repeat]
```

Description

Configures any active event forwarded to alarm relay to be snoozed.

Parameter	Description
time in minutes	Specifies the value for time in minutes. The range is 0 - 1440 minutes..
repeat	Repeats the previous snooze time.

Examples

Configuring an alarm relay action for 10 minutes:

```
switch(config)# alarm snooze 10
```

Configuring an alarm relay action to be repeated with previously configured snooze time:

```
switch(config)# alarm snooze repeat
```

Command History

Release	Modification
10.08	Feature introduced.

Command Information

Platforms	Command context	Authority
4100i	config	Administrators or local user group members with execution rights for this command.

show alarm

Syntax

```
show alarm
  input [IN1 | IN2]
  power supply
  temperature
  timer
```

Description

Shows all of the details of global status monitoring alarm events.

Parameter	Description
{IN1 IN2}	Specifies the input alarm port..
power supply	Selects the alarm events from the power supply.

Parameter	Description
timer	Shows the status of an alarm snooze timer's status and duration .
temperature	Selects the alarm for ambient temperatures reaching threshold limits.

Examples

Showing details for all global alarm events on the switch:

```
switch# show alarm
Alarm Snooze Timer Status: active
Duration remaining: 1 min 32 sec
-----
Global Alarm: Temperature
-----
Alarm Event          Status          log-and-trap      Relay
-----
Temperature          inactive        true              false
-----
Global Alarm: power-supply
-----
Alarm Event          Status          log-and-trap      Relay
-----
power-supply         active          false             true
```

Showing details for the temperature alarm:

```
switch# show alarm temperature
Alarm Snooze Timer Status: Active
Duration remaining: 5 min 36 sec
-----
Global Alarm: Temperature
-----
Alarm Event          Status          log-and-trap      Relay
-----
Temperature          inactive        true              false
```

Showing the status of an alarm snooze timer when it is inactive :

```
switch# show alarm timer
Alarm Snooze Timer Status: inactive
```

Showing the status of an active 3-minute alarm snooze timer:

```
switch# show alarm timer
Alarm Snooze Timer Status: active
Duration remaining: 2 min 55 sec
```

Showing details for all alarm input ports on the switch:

```
switch# show alarm input
Alarm Snooze Timer Status: inactive
-----
Input Alarm IN1, Name: Door-Sensor
-----
Alarm Port      Status      log-and-trap  Relay      Trigger
-----
IN1             inactive   true          false      closed
-----
Input Alarm IN2, Name: N/A
-----
Alarm Port      Status      log-and-trap  Relay      Trigger
-----
IN2             active     false         true       open
```

Showing details for alarm input ports IN1:

```
switch# show alarm input IN1
Alarm Snooze Timer Status: inactive
-----
Input Alarm IN1, Name: Door-Sensor
-----
Alarm Port      Status      log-and-trap  Relay      Trigger
-----
IN1             inactive   true          false      closed
```

Command History

Release	Modification
10.08	Feature introduced.

Command Information

Platforms	Command context	Authority
4100i	Manager (#)	Administrators or local user group members with execution rights for this command.

Boot commands

Subtopics

[Boot commands](#)

Boot commands

Subtopics

[boot set-default](#)

[boot system](#)

[show boot-history](#)

boot set-default

Syntax

```
boot set-default {primary | secondary}
```

Description

Sets the default operating system image to use when the system is booted.

Parameter	Description
primary	Selects the primary network operating system image.
secondary	Selects the secondary network operating system image.

Example

Selecting the primary image as the default boot image:

```
switch# boot set-default primary  
Default boot image set to primary.
```



NOTE

For more information on features that use this command, refer to the Fundamentals Guide or the Monitoring Guide for your switch model.

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

boot system

Syntax

```
boot system [primary | secondary | serviceos]
```

Description

Reboots all modules on the switch. By default, the configured default operating system image is used. Optional parameters enable you to specify which system image to use for the reboot operation and for future reboot operations.

Parameter	Description
primary	Selects the primary operating system image for this reboot and sets the configured default operating system image to primary for future reboots.
secondary	Selects the secondary operating system image for this reboot and sets the configured default operating system image to secondary for future reboots.
serviceos	Selects the service operating system for this reboot. Does not change the configured default operating system image. The service operating system acts as a standalone bootloader and recovers OS for switches running the AOS-CX operating system and is used in rare cases when troubleshooting a switch.

Usage

This command reboots the entire system. If you do not select one of the optional parameters, the system reboots from the configured default boot image.

You can use the **show images** command to show information about the primary and secondary system images.

Choosing one of the optional parameters affects the setting for the default boot image:

- If you select the **primary** or **secondary** optional parameter, that image becomes the configured default boot image for future system reboots. The command fails if the switch is not able to set the operating system image to the image you selected.
You can use the **boot set-default** command to change the configured default operating system image.
- If you select **serviceos** as the optional parameter, the configured default boot image remains the same, and the system reboots all management modules with the service operating system.

If the configuration of the switch has changed since the last reboot, when you execute the **boot system** command you are prompted to save the configuration and you are prompted to confirm the reboot operation.

Saving the configuration is not required. However, if you attempt to save the configuration and there is an error during the save operation, the **boot system** command is aborted.

Examples

Rebooting the system from the configured default operating system image:

```
switch# boot system
Do you want to save the current configuration (y/n)? y
The running configuration was saved to the startup configuration.
This will reboot the entire switch and render it unavailable
until the process is complete.
Continue (y/n)? y
The system is going down for reboot.
The system is going down for reboot.
```

Rebooting the system from the secondary operating system image, setting the secondary operating system image as the configured default boot image:

```
switch# boot system secondary
Default boot image set to secondary.
Do you want to save the current configuration (y/n)? n
This will reboot the entire switch and render it unavailable
until the process is complete.
Continue (y/n)? y
The system is going down for reboot.
```

Canceling a system reboot:

```
switch# boot system
Do you want to save the current configuration (y/n)? n
This will reboot the entire switch and render it unavailable
until the process is complete.
Continue (y/n)? n
Reboot aborted.
switch#
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

show boot-history

Syntax

```
show boot-history [all|{vsf member <1-10>}]
```

Description

Shows boot history information. When no parameters are specified, shows the most recent information about the current boot operation, and the three previous boot operations for the switch. When the **all** parameter is specified, the output of this command shows the boot information for the active management module.



NOTE

To view boot-history on a standby, the command must be sent on the conductor console.

Parameter	Description
all	Optional. Shows boot information for the active management module.
vsf member <1-10>	Optional. Display boot history for the specified VSF member

Usage

This command displays the boot-index, boot-ID, and up time in seconds for the current boot. If there is a previous boot, it displays boot-index, boot-ID, reboot time (based on the time zone configured in the system) and reboot reasons. Previous boot information is displayed in reverse chronological order.

The output of this command includes the following information:

Parameter	Description
Index	The position of the boot in the history file. Range: 0 to 3.
Boot ID	A unique ID for the boot . A system - generated 128 - bit string.
Current Boot, up for <time>	For the current boot, the show boot - history command shows the number of seconds the module has been running on the current software.
<Timestamp>: boot reason	For previous boot operations, the show boot - history command shows the time at which the operation occurred and the reason for the boot. The reason for the boot is one of the following values: • <DAEMON - NAME> crash: The daemon identified by <DAEMON - NAME> caused the module to boot. • Kernel crash: The operating system software associated with the module caused the module to boot. • Uncontrolled reboot: The reason for the reboot is not known. • Reboot requested through database: The reboot occurred because of a request made through the CLI or other API.

Table 1. Description of reboots handled through the database

Boot History String	Description
Reboot requested by user	A user requested a switch reboot through the CLI or web UI.
Reset button pressed	The switch detected a short - press of the reset button
Backplane fault	A backplane fault occurred.
Configuration change	A configuration change resulted in a reboot.
Configuration version migration	A configuration version migration occurred which required a reboot.
Console error	The console failed to start.
Fabric fault	A fabric fault occurred.
All line modules faulted	A zero line card condition occurred.
Redundancy switchover requested	A user requested a redundancy switchover.
Redundant Management communication timeout	The standby management module has taken over from an unresponsive active management module.
Redundant Management election timeout	A failure to elect a standby management module in the allotted time.
Critical service fault (error)	A daemon critical to switch operation has stopped functioning. An extra error string may be present to describe the error in detail.
VSF autojoin renumber	Reset triggered by VSF autojoin.
VSF member renumbered	A user requested a renumber of a VSF member.
VSF switchover requested	A user requested a VSF switchover.
VSX software update	Reset triggered by a VSX software update.
Chassis critical temperature	Chassis operating temperature exceeded.
Chassis low critical temperature	Chassis temperature below the minimum operating threshold.
Chassis insufficient fans	Insufficient fans to cool the chassis.

Boot History String	Description
Chassis unsupported PSUs/fans	Unsupported or misconfigured PSUs or system fans.
Management module critical temperature	Management module operating temperature exceeded.
ISSU SMM update	Standby management module reboot triggered by an In - Service Software Upgrade (ISSU).
ISSU switchover	Redundancy switchover triggered by an In - Service Software Upgrade.
ISSU aborted	Standby management module reset triggered by failure during an In - Service Software Upgrade.
Rollback timer expired	Reset triggered by the ISSU rollback timer expiring.

Examples

Showing the boot history of the active management module:

```
switch# show boot-history
Management module
=====
Index : 2
Boot ID : c34a2c2499004a02bbeeff4992e1fdbd
Current Boot, up for 1 days 13 hrs 13 mins 27 secs
Index : 1
Boot ID : bfba9bc486304e57904ac717a0ccbdcd
02 Sep 23 02:55:33 : CPU request reset with 0x20201, Version:
FL.10.14.0000-1619-ga9ec1805bd442~dirty
02 Sep 23 02:55:33 : Switch boot count is 2
Index : 0
Boot ID : a88a71b7ca9a4574af7e3b811ddfdc7e
02 Sep 23 02:49:26 : Reboot requested by user, Version: FL.10.14.0000-1619-
ga9ec1805bd442~dirty
02 Sep 23 02:50:02 : Switch boot count is 1
Index : 3
Boot ID : f00ba10c8c44457f83fee303d014a89a
25 Aug 23 10:27:42 : Power on reset with 0x1, Version: FL.10.14.0000-1465-
g9df95249d06b0~dirty
25 Aug 23 10:28:18 : Switch boot count is 3
25 Aug 23 10:29:02 : Primary overtemperature fault detected with 0x2 in
PSU 1/1
```

```

switch#
Management module
=====
Index : 3
Boot ID : f1bf071bdd04492bbf8439c6e479d612
Current Boot, up for 22 hrs 12 mins 22 secs
Index : 2
Boot ID : edfa2d6598d24e989668306c4a56a06d
07 Aug 18 16:28:01 : Reboot requested through database
Index : 1
Boot ID : 0bda8d0361df4a7e8e3acdc1dba5caad
07 Aug 18 14:08:46 : Reboot requested through database
Index : 0
Boot ID : 23da2b0e26d048d7b3f4b6721b69c110
07 Aug 18 13:00:46 : Reboot requested through database
Line module 1/1
=====
Index : 3
10 Aug 17 12:45:46 : dune_agent crashed
...
Management module
=====
Index : 3
Boot ID : f1bf071bdd04492bbf8439c6e479d612
Current Boot, up for 22 hrs 12 mins 22 secs
Index : 2
Boot ID : edfa2d6598d24e989668306c4a56a06d
07 Aug 18 16:28:01 : Reboot requested through database
Index : 1
Boot ID : 0bda8d0361df4a7e8e3acdc1dba5caad
07 Aug 18 14:08:46 : Reboot requested through database
Index : 0
Boot ID : 23da2b0e26d048d7b3f4b6721b69c110
07 Aug 18 13:00:46 : Reboot requested through database
Line module 1/1
=====
Index : 3
10 Aug 17 12:45:46 : dune_agent crashed
...
switch# show boot-history
Management module
=====
Index : 2

```

```

Boot ID : a61ad00d10864c748bc7893a5d4af2e4
15 Dec 23 19:02:02 : Power on reset with 0x1, Version: FL.10.13.1000AF
15 Dec 23 19:02:02 : Switch boot count is 0
15 Dec 23 19:02:17 : PSU 1/1: Fault detected
Index : 1
Boot ID : 30d831bbfdfa425baf50a629ee01b185
15 Dec 23 19:01:58 : Power on reset with 0x1, Version: FL.10.13.1000AF
15 Dec 23 19:01:58 : Switch boot count is 0
switch# show boot-history vsf member 2
Member-2
=====
Index : 0
Boot ID : df99026c194a44f1944a3e7685fb4d90
Current Boot, up for 3 hrs 31 mins 39 secs
Index : 3
Boot ID : 7bf4104903fe4ad1ba4bce40e8099c76
10 Aug 17 10:02:24 : Reboot requested through database
10 Aug 17 10:02:13 : Switch boot count is 2

```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

L1-100Mbps downshift

The speed downshift feature allows the user to link-up at sub-optimal speeds when failing to link-up at the highest advertised speed. There are fixed number of link attempts made to establish link at highest advertised speed and when all of them fail and attempt is made to link-up at a lower possible speed.

This feature requires underlying PHY to have support for the same and hence capability is only added to select set of ports. If a link cannot be established at the highest common denominator within a set number of link attempts, the PHY advertises the next highest speed using auto-negotiation.

Subtopics

Limitations with speed downshift

L1-100Mbps downshift commands

Limitations with speed downshift

- Link up may be delayed as certain number of retries are done to establish the link at highest advertise speeds by both link partners before downshifting.
- Link may be established at sub-optimal speed.

L1-100Mbps downshift commands

Subtopics

downshift enable

show interface

show interface downshift-enable

show running-config interface

downshift enable

Syntax

```
downshift-enable  
no downshift-enable
```

Description

Enables/disables automatic speed downshift on an interface that supports downshift, generally 1GBASE-T ports. When enabled, downshift allows an interface to link at a lower advertised speed when unable to establish a stable link at the maximum speed. Downshifting only applies to physical interfaces that are not members of a LAG and is only available when auto-negotiation is enabled. When only one speed is advertised, downshift will not be triggered.

Examples

```
switch(config-if)# interface 1/1/1
switch(config-if)# downshift-enable
Warning: this is a non-standard mode for use only when standards-based
auto-negotiation is not able to establish a stable link. Enabling this
may cause the port to link at a lower than expected speed and should
not be used on ports that are members of a LAG. Support calls may require
this feature to be disabled
Continue (y/n)?
switch(config-if)#
```

When automatic downshift is enabled:

```
switch(config-if)# show running-config interface
interface 1/1/1
    downshift-enable
```

Disabling automatic speed downshift:

```
switch(config-if)# interface 1/1/1
switch(config-if)# no downshift-enable
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

show interface

Syntax

```
show interface [<IFNNAME>|<IFRANGE>] [brief | physical]
show interface [<IFNNAME>|<IFRANGE>] [extended [non-zero] | [human-
readable]]
show interface [<IFNNAME>] monitor [human-readable]
show interface [lag | vlan ] [<ID>] [brief]
show interface lag [<LAG-ID>] [extended [non-zero] | [human-readable]]
show interface lag [<LAG-ID>] monitor [human-readable]
```

Description

Shows active configurations and operational status information for interfaces.

Parameter	Description
<IFNAME>	Specifies a interface name.
<IFRANGE>	Specifies the port identifier range.
brief	Shows brief info in tabular format.
physical	Shows the physical connection info in tabular format.
extended	Shows additional statistics, including the tx filtered and rx filtered counters. - Rx filter packets are protocol packets received when the protocol is disabled on the switch and there is only one port in the VLAN. Protocols include OSPF, PIM, RIP, LACP, and LLDP. - An example of a Tx filtered packet would be a multicast packet being filtered from going out of the ingress port.
human-readable	Shows statistics rounded to the nearest power of 1000, for example, 1K, 345M, 2G. This is available only in the CLI interface output.
non-zero	Shows only non zero statistics.
LAG	Shows LAG interface information.

Parameter	Description
monitor	Continuously monitor interface statistics.
VLAN	Shows VLAN interface information.
<LAG-ID>	Specifies the LAG number. Range: 1 - 256
<VLAN-ID>	Specifies the VLAN ID. Range: 1 - 4094

Examples

```
switch# show interface 1/1/1
Interface 1/1/1 is up
Admin state is up
Link state: up for 2 days (since Sun Jun 21 05:30:22 UTC 2020)
Link transitions: 1
Description: backup data center link
Hardware: Ethernet, MAC Address: 70:72:cf:fd:e7:b4
MTU 1500
Type 1GbT
Full-duplex
qos trust none
Speed 1000 Mb/s
Auto-negotiation is on
Flow-control: off
Error-control: off
                Energy-Efficient Ethernet is enabled
                MDI mode: MDIX
L3 Counters: Rx Enabled, Tx Enabled
Rate collection interval: 300 seconds
Rates                RX                TX                Total (RX+TX)
-----
Mbits / sec          0.00                0.00                0.00
KPkts / sec          0.00                0.00                0.00
Unicast              0.00                0.00                0.00
Multicast            0.00                0.00                0.00
Broadcast            0.00                0.00                0.00
Utilization %        0.00                0.00                0.00
```

Statistics	RX	TX	Total
-----	-----	-----	-----
Packets	0	0	0
Unicast	0	0	0
Multicast	0	0	0
Broadcast	0	0	0
Bytes	0	0	0
Jumbos	0	0	0
Dropped	0	0	0
Filtered	0	0	0
Pause Frames	0	0	0
L3 Packets	0	0	0
L3 Bytes	0	0	0
Errors	0	0	0
CRC/FCS	0	n/a	0
Collision	n/a	0	0
Runts	0	n/a	0
Giants	0	n/a	0
Other	0	0	0

Showing information when interface 1/1/1 is configured:

MDI mode: MDIX

VLAN Mode: native-untagged

Native VLAN: 1

Allowed VLAN List: all

Rate collection interval: 300 seconds

Rates	RX	TX	Total (RX+TX)
-----	-----	-----	-----
Mbits / sec	0.00	0.00	0.00
KPkts / sec	0.00	0.00	0.00
Unicast	0.00	0.00	0.00
Multicast	0.00	0.00	0.00
Broadcast	0.00	0.00	0.00
Utilization %	0.00	0.00	0.00
Statistics	RX	TX	Total
-----	-----	-----	-----
Packets	0	0	0
Unicast	0	0	0
Multicast	0	0	0
Broadcast	0	0	0
Bytes	0	0	0
Jumbos	0	0	0
Dropped	0	0	0
Filtered	0	0	0

Pause Frames	0	0	0
Errors	0	0	0
CRC/FCS	0	n/a	0
Collision	n/a	0	0
Runts	0	n/a	0
Giants	0	n/a	0

Showing information when the interface is currently linked at a downshifted speed:

```
switch(config-if)# show interface 1/1/1
Interface 1/1/1 is up
...
Auto-negotiation is on with downshift active
```

Showing information when the interface is currently linked with energy-efficient-ethernet negotiated:

```
switch(config-if)# show interface 1/1/1
Interface 1/1/1 is up
...
Energy-Efficient Ethernet is enabled and active
switch(config-if)# show interface 1/1/1
Interface 1/1/1 is down
Admin state is up
State information: Disabled by VSX
Link state: down for 3 days (since Tue Mar 16 05:20:47 UTC 2021)
Link transitions: 0
Description:
Hardware: Ethernet, MAC Address: 04:09:73:62:90:e7
MTU 1500
Type SFP+DAC3
Full-duplex
qos trust none
Speed 0 Mb/s
Auto-negotiation is off
Flow-control: off
Error-control: off
VLAN Mode: native-untagged
Native VLAN: 1
Allowed VLAN List: 1502-1505
Rate collection interval: 300 seconds
```

Rate	RX	TX	Total
(RX+TX)			

Mbits / sec	0.00	0.00	
0.00			
KPkts / sec	0.00	0.00	

0.00		
Unicast	0.00	0.00
0.00		
Multicast	0.00	0.00
0.00		
Broadcast	0.00	0.00
0.00		
Utilization	0.00	0.00
0.00		
Statistic	RX	TX
Total		

Packets	0	
0	0	
Unicast	0	
0	0	
Multicast	0	
0	0	
Broadcast	0	
0	0	
Bytes	0	
0	0	
Jumbos	0	
0	0	
Dropped	0	
0	0	
Pause Frames	0	
0	0	
Errors	0	
0	0	
CRC/FCS	0	
n/a	0	
Collision	n/a	
0	0	
Runts	0	
n/a	0	
Giants	0	
n/a	0	

Showing information when the interface is configured with EEE and the EEE has auto-negotiated:

```
switch(config-if) # show interface 1/1/1 physical
```

Control	EEE	Link PoE	Admin Power	Speed	Port	Flow-
Port Config	Type Status	Config	Status (Watts)	Config	Status	Status
Config	Status	Config	State	Information	Description	
1/1/1	1GbT	up	up	1G	auto	off
off	on	on	--	10M/100M/1G	--	

Showing the monitor information:



NOTE

In monitor mode, the CLI refreshes data automatically until it is exited by entering **q**. Pressing **?** opens the help menu to display which options are available in this context.

Interface 1/1/1 is up

Rate	RX	TX	Total
(RX+TX)			
-----	-----	-----	-----

MBits / sec	30196.43	30196.43	
60392.85			
MPkts / sec	58977.39	58977.40	
117954.79			
Unicast	0.00	0.00	
0.00			
Multicast	58977.39	58977.40	
117954.79			
Broadcast	0.00	0.00	
0.00			
Utilization %	75.49	75.49	
150.98			
Statistic	RX	TX	Total
(RX+TX)			
-----	-----	-----	-----

Packets	4756527649	4756527865	
9513055514			
Unicast	0		
0	0		
Multicast	4756527649	4756527865	
9513055514			
Broadcast	2		

```

0                               2
Bytes                          304417778668          304417795428
608835574096
Jumbos                        0
0                              0
Dropped                       0          19028847730
19028847730
Pause Frames                  0
0                              0
Errors                        0
0                              0
CRC/FCS                       0
n/a                            0
help: ?, quit: q
Help for Interface Monitor
h  Toggle human-readable mode
c  Clear interface statistics
Does not apply to rates
Arrows, PgUp, PgDn, Home, End
Navigate interface statistics
Delay: 2
help: ?, quit: q

```

Showing the output for interface 1/1/1 in human-readable format:



NOTE

In human-readable format, the **< 1** symbol for **Utilization** indicates that the amount of packets is between zero and one. This is true in cases where the number of bytes increases but the number of packets and the **Utilization** value is not displayed even in the normal output, where the human-readable parameter is not included in the command.

```

switch(config-if)# show interface 1/1/1 human-readable
Interface 1/1/1 is up
Rate                               RX                               TX                               Total
(RX+TX)
-----
-----
Bits / sec                        3M
3M                                6M
Pkts / sec                        316                               316
633
Unicast                           319                               319
638
Multicast                         0

```


0	0		
Broadcast		0	
0	0		
Utilization %		< 1	< 1
< 1			
Statistic		RX	TX
Total			

Packets		577K	
577K	1M		
Unicast		577K	
577K	1M		
Multicast		0	
51	51		
Broadcast		0	
15	15		
Bytes		744M	
745M	1G		
Jumbos		0	
0	0		
Dropped		0	
0	0		
Filtered		0	
0	0		
Pause Frames		0	
0	0		
Errors		0	
0	0		
CRC/FCS		0	
n/a	0		
Collision		n/a	
0	0		
Runts		0	
n/a	0		
Giants		0	
n/a	0		

Showing information about extended counters:



NOTE

The output of the `show interface extended` command varies depending on the switch model and configuration.

```
switch(config-if)# show interface 1/1/17 extended
```

```
Interface 1/1/17
```

Statistics	Value
Dot1d Tp Port In Frames	547
Dot1d Tp Port Out Frames	608
Dot3 In Pause Frames	0
Dot3 Out Pause Frames	0
Ethernet Stats Broadcast Packets	19
Ethernet Stats Bytes	40162
Ethernet Stats Packets	342

...

Error-Statistics	Value
Dot1d Base Port MTU Exceeded Discards	0
Dot3 Control In Unknown Opcodes	0
Dot3 Stats Alignment Errors	0
Dot3 Stats FCS Errors	0
Dot3 Stats Frame Too Longs	0
Dot3 Stats Internal Mac Transmit Errors	0
Ethernet RX Oversize Packets	0

...

Showing interface link-status:

```
switch# show interface link-status
```

Port	Type	Physical Link State	Link Transitions	Last Change
1/1/1	1G-BT	down	0	--
1/1/2	1G-BT	up	1	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)
1/1/3	1G-BT	up	1	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)
1/1/4	--	down	0	--
1/1/5	--	down	0	--

Showing interface loopback 1 link-status:

Port	Type	Physical Link State	Link Transitions	Last Change
------	------	------------------------	---------------------	----------------

```
-----
loopback1      --          up          --          --
-----
```

Showing interface 1/1/2-1/1/3 link-status:

Port	Type	Physical Link State	Link Transitions	Last Change
1/1/2	1G-BT	up	1	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)
1/1/3	1G-BT	up	1	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)

Showing interface link-status:

```
switch# show interface link-status
```

Port	Type	Physical Link State	Link Transitions	Link Flaps Ignored	Last Change
1/1/1	1G-BT	down	0	0	--
1/1/2	1G-BT	up	1	0	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)
1/1/3	1G-BT	up	1	0	1 minute ago (Fri Mar 09 12:36:56 UTC 2018)
1/1/4	--	down	0	0	--
1/1/5	--	down	0	0	--

Showing state information when interface is blocked:

```
8360(config-if)# show interface 1/1/1
Interface 1/1/1 is up (Blocked)
Admin state is up
State information: Blocked by UDLD
Link state: up for 1 minute (since Mon Jun 10 09:25:27 UTC 2024)
Link transitions: 1
Description:
Persona:
Hardware: Ethernet, MAC Address: 00:fd:45:67:85:91
MTU 1500
Type 10G-LR / 10G SFP+ LR
Full-duplex
qos trust none
Speed 10000 Mb/s
Auto-negotiation is off
Flow-control: off
Error-control: off
```

VLAN Mode: access

Access VLAN: 1

Rate collection interval: 300 seconds

Rate	RX	TX	Total
(RX+TX)			

Mbits / sec	0.00	0.00	
0.00			

KPkts / sec	0.00	0.00	
0.00			

Unicast	0.00	0.00	
0.00			

Multicast	0.00	0.00	
0.00			

Broadcast	0.00	0.00	
0.00			

Utilization %	0.00	0.00	
0.00			

Statistic	RX	TX	
Total			

Packets	15		
15	30		

Unicast	12		
12	24		

Multicast	3		
3	6		

Broadcast	0		
0	0		

Bytes	1350	1350	
2700			

Jumbos	0		
0	0		

Dropped	0		
0	0		

Pause Frames	0		
0	0		

Errors	0		
0	0		

CRC/FCS	0		
n/a	0		

Collision		n/a
0	0	
Runts		0
n/a	0	
Giants		0
n/a	0	

Command History

Release	Modification
10.15	Added state information when port goes into down state.
10.11	Added <code>monitor</code> parameter.
10.10	Added <code>human-readable</code> parameter.
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Operator (<code>></code>) or Manager (<code>#</code>)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (<code>></code>) only.

show interface downshift-enable

Syntax

```
show interface [<IFNAME>|<IFRANGE>] downshift-enable
```

Description

Displays speed downshift information, including the interface speed status and configuration.

Parameter	Description
	Specifies a interface name.

Parameter	Description
<IFNAME>	
<IFRANGE>	Specifies the port identifier range.

Examples

Showing automatic downshift information:

```
switch(config-if) # show interface downshift-enable
-----
Port          Downshift          Speed
             Enabled | Active   Status   | Config
-----
1/1/1         yes       yes     100M-FDx  auto
1/1/2         yes       no      1G       auto
1/1/3         yes       no     100M-FDx 100M-FDx
1/1/4         no        no      --       auto
```

Showing automatic downshift information on per interface:

```
switch(config-if) # show interface 1/1/2 downshift-enable
-----
Port          Downshift          Speed
             Enabled | Active   Status   | Config
-----
1/1/2         yes       no      1G       auto
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show running-config interface

Syntax

```
show running-config interface [<IFNNAME>|<IFRANGE>]  
show running-config interface [lag | loopback | tunnel | vlan ] [<ID>]
```

Description

Displays active configurations of various switch interfaces.

Parameter	Description
<IFNAME>	Specifies a interface name.
<IFRANGE>	Specifies the port identifier range.
LAG	Specifies LAG interface information
LOOPBACK	Specifies loopback interface information.
TUNNEL	Specifies tunnel interface information.
VLAN	Specifies VLAN interface information.
	Specifies the LAG number. Range: 1 - 256.

Parameter	Description
<LAG-ID>	
<LOOPBACK-ID>	Specifies the LOOPBACK number. Range: 0 - 255.
<TUNNEL-ID>	Specifies the tunnel ID. Range: 1 - 255.
<VLAN-ID>	Specifies the VLAN ID. Range: 1 - 4094.
VXLAN	Specifies the VXLAN interface information.
<VXLAN-ID>	Specifies the VXLAN interface identifier. Default: 1.

Examples

Showing 1/1/2 interface configuration:

```
switch(config-if)# show running-config interface 1/1/2
interface 1/1/2
  no shutdown
  description DC-23
  exit
```

Showing loopback interfaces configured:

```
switch(config-if)# show running-config interface loopback
interface loopback 1
  description lb interface 1
  exit
interface loopback 2
  description lb interface 2
  exit
```

Showing loopback interfaces not configured:

```
switch(config-if)# show running-config interface loopback
No loopback interfaces configured.
```


Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

Mirroring

Mirroring allows you to replicate all traffic arriving and/or leaving the selected system interfaces. This data can be used for collection or analysis.

The traffic replicated using mirroring can be sent to a separate interface on the same switch as the traffic source for analysis or inspection. Such a collection of interfaces and settings is called a mirror session.

A mirror session can be configured with many traffic sources but only a single output, or destination. In the initial configuration, the mirror session is disabled. You have enable the feature to start the replication.



CAUTION

Care must be taken in choosing the number and rates of sources to avoid over-saturating a session destination. A mirror session with multiple 10G sources can overwhelm a single 10G destination and important data may be lost.

This version of AOS-CX support the following mirror capabilities:

- Support for a VLAN as source for a mirror session
- 6100, 6000 and 4100i Switch series support of 2 simultaneously enabled Mirroring Sessions with LAG sources, regardless of direction
- Ability for a given Mirror source in one session to act as source in another Mirror Session
- Support for a Layer 2/bridged Link Aggregation Group (LAG) as Session destination

- Support for a Layer 3/Route-only Link Aggregation Group (LAG) as Session destination

**NOTE**

The following interface types are not supported as mirror source or destination:

- Management
- Persona
- Loopback
- VxLAN
- Subinterfaces

Hit Count Behavior for Policy Mirroring Actions

When using classifier policies with mirroring actions, it is important to note that packets mirrored via these policy actions will have their hit counts recorded within the Policy hit counts. These packets will not be recorded as output packets in the Mirror Session statistics, except in the case of Mirror-to-CPU sessions. This distinction means that traffic metrics for packets mirrored via Policy Actions should be obtained from Policy hit counts, as these packets will not appear in the Mirror Session output statistics.

Mirroring and CoPP

When configuring a Mirror Session with the destination set to the CPU, it is important to understand how mirrored traffic interacts with Control Plane Policing (CoPP).

Control plane packets that are already destined for the switch (for example, routing protocol packets and management traffic) will be processed by their respective CoPP classes. These packets will still be mirrored to the CPU as part of the Mirror-to-CPU session, but they will not be counted under the Mirror-to-CPU CoPP class. The Mirror-to-CPU CoPP class is specifically designed to manage dataplane traffic that is mirrored to the CPU. Any control plane traffic mirrored to the CPU will bypass this class and be handled by the CoPP class corresponding to its original purpose (e.g., OSPF, BGP, or ARP). Administrators should account for this distinction when analyzing traffic mirrored to the CPU.

For example, if a mirror session is configured to mirror all traffic from a source interface to the CPU, and that interface receives OSPF packets, the OSPF packets will be mirrored to the CPU. These packets will be processed by the OSPF CoPP class, not the Mirror-to-CPU CoPP class.

Subtopics

Mirror statistics

Classifier policies and mirroring sessions

Mirroring commands

Mirror statistics

Mirror statistics are reset for a Mirror-to-CPU session when an interface is added or removed from a LAG that is a source interface in the Mirror session and during a failover.

Classifier policies and mirroring sessions

About this task

Network traffic can be mirrored to a destination interface in two ways:

- Using a mirroring session alone.
- Using Classifier Policies with mirror actions in conjunction with a mirroring session.

Basic mirroring sessions provide coarse control over the type of traffic mirrored from a source: all received, all transmitted, or both. However, a traffic class within a Classifier Policy applied to a source can provide much finer grained control of mirrored traffic. For example, a policy can match on many different aspects of the Ethernet or IPv4 or IPv6 header information in each frame or packet received or transmitted on an interface.

The steps to configure a policy and class with a mirror action are the following:

Procedure

1. Configuring a mirroring session with a destination interface.
2. Enabling the mirroring session.
3. Configuring the Classifier Policy, specifying the mirroring session ID in the mirror action.

Results

If the packets being mirrored are received from a VLAN that is not allowed on the mirror destination, the mirrored packets would be dropped at the mirror destination interface. When the mirrored packets are dropped at the destination, the mirror output packet and byte count will increment, however the packets will not be received at the mirror destination.

The mirror destination port among the active mirror sessions must be unique. That is, if an interface is configured as a source or destination in an active mirror session, the same port cannot be used as a destination in another active mirror session.

Scenario 1

Scenario 2

Mirroring commands

Subtopics

- [clear mirror](#)
- [comment](#)
- [destination interface](#)
- [destination tunnel](#)
- [diagnostic](#)
- [disable](#)
- [enable](#)
- [mirror endpoint](#)
- [mirror session](#)
- [show mirror](#)
- [show mirror endpoint](#)
- [source interface](#)

clear mirror

Syntax

```
clear mirror [all | <SESSION-ID>]
```

Description

Clears the mirror statistics for all configured mirror sessions or a specified session

Parameter	Description
all	Specifies all configured sessions.
<SESSION-ID>	Specifies a numeric identifier for the session. Range: 1 to 4

Examples

Clearing mirror statistics for all configured mirror sessions:

```
switch# clear mirror all
```

Clearing mirror statistics for mirror session 1:

```
switch# clear mirror 1
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

comment

Syntax

```
comment <COMMENT>
no comment
```

Description

Specifies a comment for the mirroring session.

When used in mirror endpoint command context, specifies a comment for the mirror endpoint.

The **no** form of this command removes the comment.

Parameter	Description
<pre><COMMENT></pre>	A comment string of up to 64 characters composed of letters, numbers, underscores, dashes, spaces, and periods.

Usage

Comments are optional and can be added or removed at any time without affecting the state of the mirroring session.

Adding a comment to a session that already has a comment replaces the existing comment.

Examples

Adding a comment to a mirror session:

```
switch(config-mirror-3)# comment This Mirror will be removed during next
maintenance window
```

Removing the comment from mirror session 3:

```
switch(config-mirror-3)# no comment
```

Adding a comment to a mirror endpoint:

```
switch(config-mirror-endpoint-test)# comment Monitor endpoint traffic
```

Replacing the existing comment for mirror endpoint:

```
switch(config-mirror-endpoint-test)# comment Monitor statistics on each
endpoint interfaces
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-mirror- <SESSION-ID>	Administrators or local user group members with execution rights for this command.

destination interface

Syntax

```
destination interface {<INTERFACE-ID>|<LAG-NAME>}  
no destination interface {<INTERFACE-ID>|<LAG-NAME>}
```

Description

Configures the specified interface as the destination of the mirrored traffic.

The **no** form of this command immediately disables the mirroring session and removes the specified destination interface from the configuration.

Parameter	Description
<code><INTERFACE-ID></code>	Specifies a interface. Format: <code>member/slot/port</code> .
<code><LAG-NAME></code>	Specifies a LAG (link aggregation group) identifier.

Usage

Configuring a different destination interface in an enabled mirroring session causes all mirrored traffic to use the new destination interface. This action might cause a temporary suspension of mirrored source traffic during the reconfiguration. Mirroring traffic to a LAG destination with a device running LACP attached to the destination will cause the LAG link to flap if LACP packets are part of the mirrored traffic source.

Examples

Configuring a mirroring session and adding an interface as a destination:

```
switch(config)# mirror session 1  
switch(config-mirror-1)# destination interface 1/1/1
```

Replacing the existing destination with different interface:

```
switch(config-mirror-1)# destination interface 1/1/12
```

Removing a destination:

```
switch(config-mirror-1)# no destination interface 1/1/12
```

Switch	Destination interface limit per mirror session (4 possible sessions)
4100i	1
6000	1
6100	1
10040	1

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-mirror- <SESSION-ID>	Administrators or local user group members with execution rights for this command.

destination tunnel

Syntax

```
destination tunnel <TUNNEL-IPV4-ADDR> source <SOURCE-IPV4-ADDR>
    dscp <DSCP-VALUE> vrf <VRF-NAME> id <SPAN-ID>
no destination tunnel
```

Description

Specifies the tunnel where all mirrored traffic for the session is transmitted. Only one tunnel destination is allowed per session.

You may configure multiple mirror sessions with the same source/destination IP address pair, however, only one of those sessions sharing the same source/destination IP address pair can be enabled at a given time.

ERSPAN is not supported leaving the switch by the OOB port. If VRF management is configured for an ERSPAN session, the session will be in "mirror_err_tunnel_oob_port_not_supported" operation status.

ERSPAN is not supported leaving the switch encapsulated within another tunnel (e.g. GRE IPv4). When the path to the destination IP address will leave via a tunnel, the session will be in "tunnel_route_resolution_not_populated" operation status.



NOTE

The interface/LAG used to transmit ERSPAN packets should not be a source in the same mirror session.

The **no** form of this command will cease the use of the tunnel and disable the session.

Parameter	Description
<code><TUNNEL-IPv4-ADDR></code>	Specifies the tunnel address in IPv4 format (x.x.x.x), where x is a decimal number from 0 to 255.
<code><SOURCE-IPv4-ADDR></code>	Specifies the source address in IPv4 format (x.x.x.x), where x is a decimal number from 0 to 255.
<code><DSCP-VALUE></code>	Specifies the DSCP value to be carried within the DS field of E RSPAN packet header. Range: 0 to 63. Default: 0.
<code><VRF-NAME></code>	Specifies a VRF name. Default: default.

Examples

Creating a Mirror Session and adding tunnel destination, source, dscp, and VRF:

```
switch# config
switch(config)# mirror session 1
switch(config-mirror-1)# destination tunnel 1.1.1.1 source 2.2.2.2 dscp 10
vrf default
```

Replacing the existing tunnel destination:

```
switch(config-mirror-1)# destination tunnel 11.12.13.14 source 2.2.2.2 dscp
10 vrf default
```

Replacing the existing destination with a different DSCP value:

```
switch(config-mirror-1)# destination tunnel 11.12.13.14 source 2.2.2.2 dscp
2 vrf default
```

Removing the destination:

```
switch(config-mirror-1)# no destination tunnel
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-mirror- <SESSION-ID>	Administrators or local user group members with execution rights for this command.

diagnostic

Syntax

```
diagnostic
diag utilities tshark [file]
diag utilities tshark [delete-file]
```

Description

Captures packets from a mirror-to-cpu session, and save the most recent 32MB to pcap file which can then be copied and analyzed. When capturing a mirror-to-cpu session to a file, packets will not be dumped to the console.



NOTE

The `diagnostic` command must be entered prior to the `diag utilities tshark` command.

Use the **delete-file** form of this command to delete the most recent capture file.

Since **file** and **delete-file** are optional, the behavior of the base command **diag utilities tshark** does **not** save anything to a file, and instead dumps the tshark session to the console until **CTRL + c** is entered.

Parameter	Description
<code>file</code>	Saves captured packets to a temporary file.
<code>delete-file</code>	Deletes the most recent captured file.

Example

Performing diagnostic:

```
switch# diagnostic
switch# diagnostic utilities tshark file
Inspecting traffic mirrored to the CPU until Ctrl-C is entered
^CEnding traffic inspection.
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

disable

Syntax

```
disable
```

Description

Disables the mirroring session specified by the current command context.

Usage

By default, mirroring sessions are disabled.

When a mirroring session is disabled, the **show mirror** command for that session ID shows an **Admin Status** of **disable** and an **Operation Status** of **disabled**.

Example

Disabling a mirroring session:

```
switch(config)# mirror session 3
switch(config-mirror-3)# disable
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-mirror- <SESSION-ID>	Administrators or local user group members with execution rights for this command.

enable

Syntax

```
enable
```

Description

Enables the mirroring session for the current command context.

Usage

By default, mirroring sessions are disabled.

When a mirroring session is enabled, the **show mirror** command for that session ID shows an **Admin Status** of **enable** and an **Operation Status** of **enabled**.

If sFlow is enabled on an interface and a mirroring session specifies the same interface as the source of received traffic (the source is configured with a direction of

rx

or

both

):

- The attempt to enable the mirroring session fails and an error is returned.



NOTE

When adding, removing, or changing the configuration of a source interface in an enabled mirroring session, packets from other mirror sources using the same destination interface might be interrupted.

Example

Configuring and enabling a mirroring session:

```
switch(config)# mirror session 3
switch(config-mirror-3)# source interface 1/1/2 rx
switch(config-mirror-3)# destination interface 1/1/3
switch(config-mirror-3)# comment Monitor router port ingress-only traffic
switch(config-mirror-3)# enable
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	<code>config-mirror- <SESSION-ID></code>	Administrators or local user group members with execution rights for this command.

mirror endpoint

Syntax

```
mirror endpoint <NAME>  
no mirror endpoint <NAME>
```

Description

Creates the specified mirror endpoint or enters its context if it already exists. The specifics of a mirror endpoint are created or altered while in the mirror endpoint context and the mirror endpoint is enabled or disabled from this context. It may be possible to support different encapsulations by different ASICs. For example, UDP for PVOS compatibility. Termination of GRE encapsulation is also supported.

The **no** form of this command removes an existing mirror endpoint. An enabled mirror endpoint is automatically disabled first before removal.

Parameter	Description
<code><NAME></code>	Specifies mirror endpoint name.

Examples

Creating a mirror endpoint named test :

```
switch(config) # mirror endpoint test
```

Deleting mirror endpoint named test:

```
switch(config) # no mirror endpoint test
```

Configuring a mirror endpoint named test :

```
6100(config)# mirror endpoint test
6100(config-mirror-endpoint-test)#
6100(config-mirror-endpoint-test)# destination
    interface Specify interfaces to send traffic
6100(config-mirror-endpoint-test)# destination interface
    IFNAMELIST An interface, a range or a comma seperated list of interfaces
6100(config-mirror-endpoint-test)# destination interface 1/1/3
    <cr>
6100(config-mirror-endpoint-test)# destination interface 1/1/3
6100(config-mirror-endpoint-test)#
6100(config-mirror-endpoint-test)# source 1.1.1.1 destination 1.1.1.2 id 1
vrf default
6100(config-mirror-endpoint-test)#
```



NOTE

Only physical ports can be configured as interface for mirror-endpoint destination. LAG port is not supported as interface for mirror-endpoint destination.



NOTE

The maximum allowed number of destination interfaces for both mirror-session and mirror-endpoint is 1.

Command History

Release	Modification
10.13.1000	Added support for 4100i, 6000, and 6100 switches.
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config	Administrators or local user group members with execution rights for this command.

mirror session

Syntax

```
mirror session <SESSION-ID>
no mirror session <SESSION-ID>
```

Description

Creates a mirroring session configuration context or enters an existing mirroring session configuration context.

From this context, you can enter commands to configure and enable or disable the mirroring session.

The **no** form of this command removes an existing mirroring session from the configuration.

Parameter	Description
<SESSION-ID>	Specifies the session identifier. Range: 1 to 4

Examples

```
switch(config)# mirror session 1
switch(config-mirror-1)#
switch(config)# mirror session 3
switch(config-mirror-3)#
switch(config)# no mirror session 1
switch(config)#
```



NOTE

When configuring mirroring via the command-line interface, not all configuration errors will result in an immediate error message. After making configuration changes, always check the operation status of your mirror sessions using the **show mirror** command.

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

show mirror

Syntax

```
show mirror [<SESSION-ID>]
```

Description

Shows information about mirroring sessions. If `<SESSION-ID>` is not specified, then the command shows a summary of all configured mirroring sessions. If `<SESSION-ID>` is specified, then the command shows detailed information about the specified mirroring session.

Parameter	Description
<code><SESSION-ID></code>	Specifies the session identifier. Range: 1 to 4

Usage

Information in the **Admin Status** column of the command output indicates the configured status. The admin status is one of the following values:

- **enable**: The mirroring session is enabled.
- **disable**: The mirroring session has been configured but not yet enabled, or has been disabled.

Information in the **Operation Status** column indicates the status of the mirroring session. Operation status is one of the following values:

- **dest_doesnt_exist**: The configured destination interface is not found in the system. The mirroring session cannot be enabled.
- **destination_shutdown**: **The mirroring session is enabled, but the destination interface is shut down. No traffic** can be monitored.
- **disabled**: The mirroring session is disabled and is not in an error condition.
- **enabled**: The mirroring session is enabled.
- **external/driver_error**: An internal ASIC hardware error occurred.
- **hit_active_sessions_capacity**: The mirroring session could not be enabled because the maximum number of supported mirroring sessions are already enabled.
- **internal_error**: An invalid parameter was passed to the ASIC software layer.
- **no_dest_configured**: The mirroring session does not have a destination interface configured.
- **no_name_configured**: A software error occurred. The mirroring session does not have a session ID in its configuration.
- **null_mirror**: A software error occurred. The session object reference is invalid.
- **out_of_memory**: The system is out of memory, reboot recommended.
- **tunnel_route_resolution_not_populated**: If the destination tunnel IP address is not reachable.
- **unknown_error**: An unexpected error occurred.

Examples

Showing summary information about all configured mirroring sessions:

```
switch# show mirror
ID  Admin Status  Operation Status
---  -
1   enable       enabled
2   disable      disabled
3   disable      disabled
4   enable       internal_error
```

Showing detailed information about a single mirroring session:

```
switch# show mirror 3
Mirror Session: 3
Admin Status: disable
Operation Status: disabled
```

```
Comment: Monitor router port ingress-only traffic
Source: interface 1/1/2 rx
Destination: interface 1/1/3
switch#
```

Show the details of mirror session 1 with an empty LAG as destination:

```
switch: show mirror 1
Admin Status: enable
Operation Status: dest_doesnt_exist
Source: interface 1/1/1 rx
Source: interface tx none
Destination: interface lag1
Output Packets: 0
Output Bytes: 0
```

Show the details of mirror session 1 with a LAG and a LAG member of same LAG as sources. In this scenario, traffic received on all LAG member interfaces is mirrored, is it is not necessary to define 1/1/1 as a source since it is already part of LAG1; this does not impact the mirror output packet or byte counters.

```
switch: show mirror 1
Admin Status: enable
Operation Status: enabled
Source: interface 1/1/1 rx
Source: interface lag1 rx
Destination: interface 1/1/2
Output Packets: 0
Output Bytes: 0
```

Showing the details of mirror **session 1** for a mirror configuration enabled with invalid interface which is not part of a lag:

```
switch# show mirror 1
Mirror Session: 1
Admin Status: enable
Operation Status: disabled
Source: interface 1/1/1 (unknown lag) both
Destination: cpu
Output Packets: 0
Output Bytes: 0
```

Certain configurations can cause this condition while the mirror source configuration remains unchanged:

1. Removing of a port from a LAG (Link Aggregation Group).
2. Port **split** or **unsplit** operations that result in LAG membership removal.

To recover from this issue, unconfigure the affected interface (previously part of a LAG), or restore the LAG membership configuration.

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show mirror endpoint

Syntax

```
show mirror endpoint [<NAME>]
```

Description

Shows a list of all configured mirror endpoints, their Admin Status and their Operation Status.

The optional parameter will display the details of the specified mirror endpoint if it exists.

Parameter	Description
<NAME>	Specifies name of the mirror endpoint instance to be displayed.

Examples

Showing a summary of all configured mirror endpoints on the switch:

```
switch# show mirror endpoint
Name      Admin Status  Operation Status
-----
test      enable       enabled
monitor   disable      disabled
```

Showing the details of enabled mirror endpoint test:

```
switch# show mirror endpoint test
Mirror Endpoint: audit
Admin Status: enable
Operation Status: enabled
Comment: Mirror Endpoint Audit
Type: gre
Tunnel: source 1.1.1.1 destination 1.1.1.2 id 1 vrf default
Interface: 1/1/3
Output Packets: 123456789
Output Bytes: 0
```



NOTE

"Output Packets" in "show mirror endpoint [name]" is only supported for statistics.

"Output Bytes" in "show mirror endpoint [name]" is not supported due to ASIC limitation.

Command History

Release	Modification
10.13.1000	Added support for 4100i, 6000, and 6100 switches.
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	Operator (>) or Manager (#)	Administrators or local user group members with execution rights for this command.

source interface

Syntax

```
source interface {<PORT-NUM> | <LAG-NAME>} [<DIRECTION>]
no source interface {<PORT-NUM> | <LAG-NAME>} [<DIRECTION>]
```

Description

Configures the specified interface (either an Ethernet port or a LAG) as a source of traffic to be mirrored.

The **no** form of this command ceases mirroring traffic from the specified source interface and removes the source interface from the mirroring session configuration.

Parameter	Description
<PORT-NUM>	Specifies a physical port on the switch. Use the format member/slot/port (for example, 1/3/1).
<LAG-NAME>	Specifies the identifier for the LAG (link aggregation group).
<DIRECTION>	Selects the direction of traffic to be mirrored from this source interface. There is no default for this parameter. Valid values are the following: - both: Mirror both transmitted and received packets. - rx: Mirror only received packets. - tx: Mirror only transmitted packets.

Usage

There is a limit of source interfaces in each direction of a given mirror session:

Switch	Source interface limit per mirror session (4 possible sessions)
4100i	28
6000	52
6100	52

Switch	Source interface limit per mirror session (4 possible sessions)
10040	128

However, there is a practical limit to the amount of traffic that a mirror destination can transmit. For example, mirroring session with multiple 10G sources can overwhelm a single 10G destination.



NOTE

When adding, removing, or changing the configuration of a source port in an enabled mirroring session, packets from other mirror sources using the same destination port might be interrupted.

Examples

Configuring a mirrored traffic source interface:

```
switch(config-mirror-1)# source interface
LAG-NAME          Enter a LAG name. For example, lag10
PORT-NUM          Enter a port number
```

Creating a mirroring session and configuring a source interface to mirror both transmitted and received packets:

```
switch(config)# mirror session 1
switch(config-mirror-1)# source interface 1/1/1 both
```

Creating a second mirroring session and configuring two source interfaces. One port mirroring only transmitted packets and the other mirroring both transmitted and received packets:

```
switch(config)# mirror session 2
switch(config-mirror-2)# source interface 1/1/3 tx
switch(config-mirror-2)# source interface 1/2/1 both
```

Removing the first source interface:

```
switch(config-mirror-2)# no source interface 1/2/3
```

Configuring a source interface to mirror received packets only:

```
switch(config-mirror-3)# source interface 1/1/2 rx
```

Configuring a source interface to mirror both transmitted and received packets:

```
switch(config-mirror-1)# source interface 1/1/1 both
```

Configuring a LAG as source interface to mirror both transmitted and received packets:

```
switch(config-mirror-4)# source interface lag1 both
```

Stopping the mirroring of received packets from a configured source interface:

```
switch(config-mirror-4)# no source interface lag1 rx
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-mirror- <SESSION-ID>	Administrators or local user group members with execution rights for this command.

Monitoring a device using SNMP

Configuring SNMP: Refer to the SNMP/MIB Guide for information on how to add SNMP so a device can be monitored from a network management system (NMS).

Configuring an SNMP trap receiver: Refer to the SNMP/MIB Guide and specific information about the `show snmp trap` command to enable SNMP traps.

Packet Capture

The Packet Capture is a solution which enables the Central administrator to capture or view packets from clients connected to Halon switches. The solution serves as a tool which an admin can leverage to debug clients connected to managed devices across branches in an enterprise. The switch requires packet exchanges to be copied to the CPU (both ingress and egress packets) per client session, so that they can be streamed to Central where the admin can view the packet exchanges for further analysis.

This feature is supported on the following platforms:

- Rosewood (6200, 6300, 6400, 8360)
- Matrix (4100i, 6000, 6100)

Power-over-Ethernet

- The Power-over-Ethernet (PoE) subsystem manages power supplied to devices using standard Ethernet data cables. A Power Sourcing Equipment (PSE) supplies DC power as well as Ethernet connectivity to a Powered Device (PD) using a standard Ethernet cable. The maximum current depends on the PD Requested Class.
- A PoE subsystem contains two parts : a PSE and PD. A Power Sourcing Equipment (PSE) is a device that provides power through a standard Ethernet cable. A PoE capable switch functions as PSE. All Aruba PoE switches are considered as PSEs. A PD is a device powered by a PSE. Examples of PD are VoIP phones, Wireless APs, and IP cameras.
- When a PD or any network cable is connected to a PSE port, the PSE applies a detection voltage and measures the resistance value of the PD. If resistance is within IEEE 802.3 standard values (23 - 26k ohm), the connected device is treated as PD and classification begins. For legacy devices to be detected, you must enable prestandard detection on the switch.
- PDs are divided into different types and classes based on PD power requirements. The power supplied by the PSE is higher than the power PD draws to accommodate for the line losses that can result with the use of the standard maximum length cable(100m).
 - Type 1: PSE can supply maximum of 15.4W, and PD can draw a maximum of 13W.
 - Type 2: PSE can supply maximum of 30W, and PD can draw a maximum of 25.5W.
 - Type 3: PSE can supply maximum of 60W, and PD can draw a maximum of 51W.
 - Type 4: PSE can supply maximum of 90W, and PD can draw a maximum of 71W.
- Classes of PD:
 - Class 0: Type1 PD, it can draw a maximum of 13W.
 - Class 1: Type1 PD, it can draw a maximum of 3.84W.
 - Class 2: Type1 PD, it can draw a maximum of 6.49W.
 - Class 3: Type1 PD, it can draw a maximum of 13W.
 - Class 4: Type2 PD, it can draw a maximum of 25.5W.
 - Class 5: Type3 PD, it can draw a maximum of 40W.

- Class 6: Type3 PD, it can draw a maximum of 51W.
- Class 7: Type4 PD, it can draw a maximum of 62W.
- Class 8: Type4 PD, it can draw a maximum of 71.3W.
- IEEE 802.3bt introduced 4-Pair PoE as a means of supplying higher power to PDs that need more than the current 25.5W supplied by IEEE 802.3at. To increase the available power without damaging the Ethernet cable, the standard introduced the ability to use all four pairs within the Ethernet cable instead of the two pairs used by previous standards (802.3at, 802.3af).
- Supported protocols:
 - Compatibility with IEEE 802.3af, 802.3at, 802.3bt and prestandard.
 - Long first class event supported on Type 3-4 PSE.
 - Support for Single Signature (SS) Type 0-6 and Dual Signature (DS) Type 0-4 PDs.
 - Multi-Event classification permits mutual ID of SS Class 0-6 and DS Class 0-4.
 - Support LLDP Data Link Layer (DLL) Type 1-2 extension 12-octet TLV and Type 3-4 extension 29-octet TLV.
 - Default PSE assigned class delivers the maximum PSE capable power at initial power up based on PD requested class.
- Always-on PoE is a feature that provides the ability for a switch to continue to provide power across user initiated reboots through software. Always-on PoE is enabled by default and no additional configuration is needed.



NOTE

PDs only remain powered, no data transfer or PoE power negotiation can occur until the switch has completely booted up and in normal operation. PD faults occurring prior to full switch boot up will result in PoE power removal and restart the detection process only after switch returns to normal operation.

Subtopics

PoE commands

PoE commands

All PoE configuration commands except **quick-poe**, **threshold configuration** and **always-on poe configuration** are entered at the **config-if** context. The PoE threshold command is used at the system

level whereas the **always-on poe** and **power-over-ethernet quick-poe** commands are set at the slot level. These commands can only be configured in the global configuration context.

Subtopics

lldp dot3 poe

lldp med poe

power-over-ethernet

power-over-ethernet allocate-by

power-over-ethernet always-on

power-over-ethernet assigned-class

power-over-ethernet pre-std-detect

power-over-ethernet priority

power-over-ethernet quick-poe

power-over-ethernet threshold

power-over-ethernet trap

show lldp local

show lldp neighbor

show power-over-ethernet

lldp dot3 poe

Syntax

```
lldp dot3 poe
no lldp dot3 poe
```

Description

Enables 802.3 TLV list in LLDP to advertise for Power over Ethernet Data Link Layer Classification. LLDP dot3 TLV is by default enabled for PoE.

The **no** form of this command disables 802.3 TLV list in LLDP.

Examples

Enabling 802.3 TLV list in LLDP:

```
switch(config)# interface 1/1/1
switch(config-if)# lldp dot3 poe
```

Disabling 802.3 TLV list in LLDP:

```
switch(config-if)# no lldp dot3 poe
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

lldp med poe

Syntax

```
lldp med poe [priority-override]  
no lldp med poe [priority-override]
```

Description

Enables MED TLV list in LLDP to advertise for Power over Ethernet Data Link Layer Classification. Also enables the lldp-MED TLV priority to override user configured port priority for Power over Ethernet. When both dot3 and MED are enabled, dot 3 will take precedence. MED TLV is by default enabled for PoE. Priority over-ride is by default disabled.

The **no** form of this command disables MED TLV list in LLDP.

Parameter	Description
[priority-override]	System defined name of the interface.

Examples

Enabling and disabling LLDP MED PoE:

```
switch(config)# interface 1/1/1  
switch(config-if)# lldp med poe
```

```
switch(config-if) # no lldp med poe
```

Enabling and disabling LLDP MED PoE priority override:

```
switch(config-if) # lldp med poe priority-override
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet

Syntax

```
power-over-ethernet  
no power-over-ethernet
```

Description

Enables per-interface power distribution. Per-port power is enabled by default with priority low. PoE cannot be disabled for individual ports when Quick PoE is enabled for the entire switch or line module.

The **no** form of this command disables per-interface power distribution.

Examples

Enabling per-interface power distribution:

```
switch(config) # interface 1/1/1  
switch(config-if) # power-over-ethernet
```

Disabling per-interface power distribution:

```
switch(config-if) # no power-over-ethernet
```

Showing Quick PoE enabled:

```
switch(config) # power-over-ethernet quick-poe 1/1
switch(config) # no power-over-ethernet
Interface PoE cannot be disabled when Quick PoE is enabled.
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet allocate-by

Syntax

```
power-over-ethernet allocate-by {usage | class}
no power-over-ethernet allocate-by {usage | class}
```

Description

Configures the power allocation method. Power allocation method is initially based on usage. PSE Allocated power value will change to LLDP negotiated power if and when LLDP exchange takes place between PSE and PD. When there is no LLDP negotiation, PSE Allocated Power Value will be the actual instantaneous power draw and reserve power based on actual consumption. In allocate-by class, power allocation is based on PD requested class and PSE allocated power value will be the LLDP negotiated power when LLDP exchange takes place between PSE and PD. When there is no LLDP negotiation, PSE Allocate Power will be based on PD class. Reserve power is based on PD Class. By default, power allocation is by usage.

The power allocation method can be changed on an interface through port-access (User roles or RADIUS). An allocation method when configured through port-access will replace the user configured method.

The **no** form of this command resets the action to default.

Parameter	Description
usage	Configures the usage - based allocation method.
class	Configures the class - based allocation method.

Usage

If you enable **pd-class-override** for an interface, the **allocate-by** configuration of that interface will be automatically changed to **class**. However, if you change the allocation method to **usage** when **pd-class-override** is still enabled, you will receive an error message stating that "The power allocation method cannot be changed when pd-class-override is enabled."

To remove **pd-class-override**, you can use the **no power-over-ethernet pd-class-override** command . It is important to note that **pd-class-override** requires the allocation method to be set to **class** and is enforced when configured through CLI. However, if you override the allocation method to **usage** via port-access, **pd-class-override** will not be in effect. Therefore, it is recommended that you do not override the allocation method to **usage** through port-access on interfaces configured with **pd-class-override**.

Examples

Configuring the power allocation method:

```
switch(config)# interface 1/1/1
switch(config-if)# power-over-ethernet allocate-by usage
switch(config-if)# power-over-ethernet allocate-by class
```

Resetting power allocation method:

```
switch(config-if)# no power-over-ethernet allocate-by class
```

Command History

Release	Modification
10.07 or earlier	- -

Command History

Release	Modification
10.08	Command introduced

Command Information

Platforms	Command context	Authority
4100i	config	Administrators or local user group members with execution rights for this command.

power-over-ethernet assigned-class

Syntax

```
power-over-ethernet assigned-class {3 | 4 | 6}  
no power-over-ethernet assigned-class
```

Description

Limit PoE power based on the assigned class. When an user assigns a maximum class to an interface, the PSE will limit the maximum power delivered to the PD up to a total power draw not exceeding the PSE assigned-class power. Power demotion occurs when a PD requested class is higher than the PSE assigned class, permitting the PD to receive power and operate in a reduced power mode. PoE ports cannot set an assigned class when Quick PoE is enabled on the subsystem. The default assigned class is 4 for 2-pair capable PSE and 6 for 4-pair capable PSE.

The **no** form of this command resets the action to default.

Examples

Setting PoE assigned class:

```
switch(config)# interface 1/1/1  
switch(config-if)# power-over-ethernet assigned-class 4
```

Resetting PoE assigned class to default:

```
switch(config-if)# no power-over-ethernet assigned-class 4
```

Showing Quick PoE enabled:

```
switch(config) # power-over-ethernet quick-poe 1/1
switch(config) # interface 1/1/1
switch(config) # power-over-ethernet assigned-class 4
Interface assigned class cannot be configured when Quick PoE is enabled.
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet pre-std-detect

Syntax

```
power-over-ethernet pre-std-detect
no power-over-ethernet pre-std-detect
```

Description

Before IEEE 802.3 released the first Power over Ethernet standard (802.3af), vendors had shipped PoE capable switches and PD's. HPE Aruba Networking switches are backward compatible and will support both IEEE standard and pre-standard 802.3af Power over Ethernet PD's concurrently. This CLI allows the user to enable or disable pre-802.3af-standard device detection and powering on the specific port. When pre-std-detect is enabled, power will be delivered on PairA only. Default is disabled.

The **no** form of this command resets the action to default.

Examples

Enabling pre-standard device detection:

```
switch(config)# interface 1/1/1
switch(config-if)# power-over-ethernet pre-std-detect
```

Disabling pre-standard device detection:

```
switch(config-if)# no power-over-ethernet pre-std-detect
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet priority

Syntax

```
power-over-ethernet priority {critical | high | low}
no power-over-ethernet priority {critical | high | low}
```

Description

Sets PoE priority for an interface. Specifying critical, high, or low indicates the priority of the interface in the event of power over-subscription. Within the same priority level, higher power-priority line-module ports have higher precedence. With same PoE priority and same line-module priority, lower numbered line-module ports have higher precedence. Per-interface PoE priority is low by default.

The **no** form of this command resets the priority to default PoE priority "low".

Examples

Configuring PoE priority:

```
switch(config)# interface 1/1/1
switch(config-if)# power-over-ethernet priority critical
switch(config-if)# power-over-ethernet priority high
```

Resetting the PoE priority to default:

```
switch(config-if)# no power-over-ethernet priority high
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet quick-poe

Syntax

```
power-over-ethernet quick-poe <MODULE-ID>
no power-over-ethernet quick-poe <MODULE-ID>
```



NOTE

This command is not available on the 6000 or 6100 Switch Series.



NOTE

This command is available only on the 4100i Switch Series.

Description

Quick PoE is a feature that provides the ability for the switch to provide power to the connected powered device as soon as switch goes through cold reboot. When quick PoE is enabled on the subsystem PoE port disablement and PD demotion is not allowed. also quick PoE enablement is not allowed if any of the port is disabled on the subsystem. User should not over-subscribe the PoE power when quick PoE is enabled. Quick PoE saved configuration will work irrespective of the configuration change at reboot.

Enables quick PoE feature on the switch or the subsystem level. By default, quick-PoE is disabled for the subsystem.

The **no** form of this command disables quick PoE.

Parameter	Description
<code><MODULE-ID></code>	Specifies module number for quick PoE configuration .

Examples

Enabling and disabling quick PoE:

```
switch(config)# power-over-ethernet quick-poe 1/2
switch(config)# no power-over-ethernet quick-poe 1/2
switch(config-if)# power-over-ethernet quick-poe 1/1
PoE must be enabled on all interfaces before enabling Quick PoE
switch(config-if)# power-over-ethernet quick-poe 1/3
All interfaces must use the default assigned class before enabling Quick PoE
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i	config-if	Administrators or local user group members with execution rights for this command.

power-over-ethernet threshold

Syntax

```
power-over-ethernet threshold <PERCENTAGE>
no power-over-ethernet threshold <PERCENTAGE>
```

Description

Sets the threshold at which the system will send an excess power consumption notification trap. Default value is 80 percentage.

The **no** form of this command resets the action to default.

Parameter	Description
<PERCENTAGE>	Excess power consumption trap threshold. Range 1 - 99.

Examples

Setting the power-over-ethernet threshold:

```
switch(config)# power-over-ethernet threshold 75
```

Resetting the power-over-ethernet threshold to default:

```
switch(config-if)# no power-over-ethernet threshold 75
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000	config	Administrators or local user group members with execution rights for this command.

Platforms	Command context	Authority
6100		

power-over-ethernet trap

Syntax

```
power-over-ethernet trap
no power-over-ethernet trap
```

Description

This command enables/disables the SNMP trap generation for PoE related events at system level. PoE trap generation is enabled by default.

The **no** form of this command resets the priority to default PoE priority "low".

Examples

Enabling SNMP trap generation for PoE:

```
switch(config) # power-over-ethernet trap
```

Disabling SNMP trap generation for PoE:

```
switch(config-if) # no power-over-ethernet trap
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i	config-if	Administrators or local user group members with execution rights for this command.
6000		
6100		

show lldp local

Syntax

```
show lldp local-device [<INTERFACE-ID>]
```

Description

Displays information advertised by the switch if the LLDP feature is enabled by user.

Parameter	Description
<code><INTERFACE-ID></code>	Specifies an interface. Format: member/slot/port

Examples

Showing LLDP local device:

```
switch# show lldp local-device 1/1/10
Local Port Data
=====
Port-ID           : 1/1/10
Port-Desc         : "1/1/10"
Port VLAN ID      : 0
PoE Plus Information
PoE Device Type   : Type 2 PSE
Power Source      : Primary
Power Priority     : low
PSE Allocated Power: 25.0 W
PD Requested Power : 25.0 W
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i 6000 6100	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show lldp neighbor

Syntax

```
show lldp neighbor [<INTERFACE-ID>]
```

Description

Displays detailed information about a particular neighbor connected to a particular interface.

Parameter	Description
<INTERFACE-ID>	Specifies an interface. Format: member/slot/port

Examples

Showing LLDP neighbor information when there is only one neighbor:

```
switch# show lldp neighbor-info 1/1/10
Port                                     : 1/1/10
Neighbor Entries                       : 1
Neighbor Entries Deleted               : 0
Neighbor Entries Dropped               : 0
Neighbor Entries Aged-Out              : 0
Neighbor Chassis-Name                  : 84:d4:7e:ce:5d:68
Neighbor Chassis-Description           : ArubaOS (MODEL: 325), Version HPE_ANW IAP
Neighbor Chassis-ID                    : 84:d4:7e:ce:5d:68
Neighbor Management-Address            : 169.254.41.250
Chassis Capabilities Available         : Bridge, WLAN
Chassis Capabilities Enabled           :
```

```

Neighbor Port-ID           : 84:d4:7e:ce:5d:68
Neighbor Port-Desc         : eth0
TTL                         : 120
Neighbor Port VLAN ID      :
Neighbor PoEplus information : DOT3
Neighbor Device Type       : TYPE2 PD
Neighbor Power Priority     : Unkown
Neighbor Power Source      : Primary
Neighbor Power Requested   : 25.0 W
Neighbor Power Allocated   : 0.0 W
Neighbor Power Supported   : No
Neighbor Power Enabled     : No
Neighbor Power Class       : 5
Neighbor Power Paircontrol : No
Neighbor Power Pairs       : SIGNAL

```

Command History

Release	Modification
---------	--------------

10.07 or earlier	- -
------------------	-----

Command Information

Platforms	Command context	Authority
4100i 6000 6100	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show power-over-ethernet

Syntax

```
show power-over-ethernet [member <MEMBER-ID>] [brief]
```

Description

Displays the status information of the full system.

Parameter	Description
<code><MEMBER-ID></code>	Displays the detailed status of given member.
<code>brief</code>	Display the brief status of all ports or the given port.

Examples

Showing sample output for show power-over-ethernet :

```
switch# show power-over-ethernet
System Power Status
  PoE Power Status           : No redundancy
  Operational Power Status    : No redundancy
  Total Available Power       : 360 W
  Total Configured Power      : 0 W
  Total Failover Pwr Avl      : 0 W
  Total Redundancy Power      : 0 W
  Total Power Drawn           : 0 W
  Total Power Reserved        : 0 W
  Total Remaining Power       : 360 W
  Trap Threshold              : 80 %
  Trap Enabled                : Yes
  Always-on PoE Enabled       : 1/1
  Quick PoE Enabled           : None
Internal Power
  Total Power
  PS      (Watts)      Status
  ----  -
  1/1    0             Ok
  1/2    0             Absent
```

Showing sample output for power-over-ethernet brief per-port:

```
switch# show power-over-ethernet 1/1/1 brief
Status and Configuration Information for port 1/1/1
Member 1Power Status
  Available: 370 W  Reserved: 55.60 W  Remaining: 314.40 W
  Always-on PoE Enabled: 1/1
PoE      Pwr Power      Pre-std Alloc PSE Pwr PD Pwr PoE Port      PD      Cls
Type
Port     En  Priority Detect  Act   Rsrvd  Draw  Status      Sign
```

-----	---	-----	-----	-----	-----	-----	-----	-----	---	---

1/1/1	Yes	Low	Off	Class	0.0 W	0.0 W	Denied	None	4	2

Showing sample output for power-over-ethernet brief for interface range:

```
switch# show power-over-ethernet 1/1/1-1/1/2 brief
Status and Configuration Information for port 1/1/1-1/1/2
  Power Status
  Available: 360 W  Reserved: 0.00 W  Remaining: 360.00 W
  Always-on PoE Enabled: 1/1
  Quick PoE Enabled: None
PoE      Pwr Power      Pre-std Alloc PSE Pwr PD Pwr PoE Port      PD      Cls
Type
Port      En  Priority Detect   Act    Rsrvd   Draw   Status      Sign
-----
-----
1/1/1     Yes Low          Off      Usage  0.0 W   0.0 W Searching  N/A      N/A
N/A
1/1/2     Yes Low          Off      Usage  0.6 W   0.0 W Searching  N/A      N/A
N/A
```

Showing sample output for power-over-ethernet for a missing line card:

```
switch# show power-over-ethernet 1/3 brief
Module 1/3 is not physically present.
```

Showing sample output for power-over-ethernet port when physical interface is not present:

```
switch# show power-over-ethernet 2/1/1
Interface 2/1/1 is not present.
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
4100i	Operator (>) or Manage	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.
6000	r (#)	
6100		

Aruba AirWave

You can manage and monitor the AOS-CX switch through Aruba AirWave. The following benefits and functions include:

- Configuration (partial configuration)
- Device topology
- Immediate and historical trend reports
- Monitoring of the device and user connected to the network.
- Network discovery
- Syslogs and trap receiver

For information about which versions of Aruba AirWave support AOS-CX, see the AOS-CX Release Notes.

Subtopics

SNMP support and AirWave

Supported features with AirWave and the AOS-CX switch

Configuring the AOS-CX switch to be monitored by AirWave

AirWave commands

SNMP support and AirWave

For AirWave to discover and monitor the switch, you must:

- Enable the SNMP services on the switch.
- Configure the SNMP agent to use the SNMP version supported by the management station.

SNMP on the switch

The switch provides SNMP services through the management channel and the data interfaces. Functionality, such as device discovery from NMS, syslog and trap forwarding, can be any channel configured by you.

Although the SNMP server can be enabled on both VRFs (`mgmt` and `default`), only one instance of SNMP can be running. The highest priority is on the `default` VRF.

For example, assume that SNMP is first enabled on the `mgmt` VRF (`snmp-server vrf mgmt`). Then, SNMP is enabled on the `default` VRF (`snmp-server vrf default`) without disabling SNMP on the `mgmt` (using an equivalent `no` form of the command). The `show running-config`

command displays both `snmp-server vrf` commands; however, the SNMP instance is running only on the `default` VRF (highest priority).

```
switch# config
switch(config)# snmp-server vrf mgmt
switch(config)# snmp-server vrf default
switch(config)# show running-config
Current configuration:
!
!Version AOS-CX Virtual.10.01.
led locator on
!
!
!
snmp-server vrf default
snmp-server vrf mgmt
!
...
```

Supported features with AirWave and the AOS-CX switch

AirWave supports the following features with the AOS-CX switch:

Device management	Device discovery using SNMPv2C and SNMPv3
	Device dashboards
Monitoring management	Device health attributes (device status/reachability)
	Interface and VLAN management
	Initiates an SSH connection from Aruba AirWave to AOS-CX so that the device outputs from the AOS-CX CLI can be displayed in the Aruba AirWave user interface.
	Firmware versions
	Displays neighbor devices connected to AOS-CX switches
	Device topology

Configuration management	Partial configuration
Alarm management	Alarm triggers (device and interface up/down, new device discoveries, custom event triggers)
	Syslogs and traps
Report management	Device inventory, interface utilization, and device reachability reports
	Summary report of device model, firmware, and boot loader version

Configuring the AOS-CX switch to be monitored by AirWave

Prerequisites

Aruba AirWave is active on the network.

Procedure

1. Enable SNMP on the switch by entering the `snmp-server vrf` command.

```
switch(config)# snmp-server vrf mgmt
switch(config)# snmp-server vrf default
```

2. Configure the SNMPv2C community to public by entering the `snmp-server community public` command. In this instance, `public` is a read-only community string.

```
switch(config)# snmp-server community public
```

3. The community-string is used by SNMPv1 and SNMPv2C for unencrypted authentication. SNMPv3 lets you encrypt the authentication mechanism. To enable SNMPv3, enter the `snmpv3 user` and `snmpv3 context` commands.

```
switch(config)# snmpv3 user Admin auth sha auth-pass ciphertext
AQBapZHf2d20GYr/xcGUzYzm0zjNf/4VKHtSqbnImqtfYbJYCgAAALkGFJVcSp3nZ3o=
priv des priv-pass ciphertext
AQBapb0H2poBQKXPoVsC9L9qzZyfJQnzR7hmTr7LGsOsI7K3CgAAAKP98Rq2jfTrFwQ=
switch(config)# snmpv3 context Admin
```

For discovering devices in AirWave through the SNMPv3 community, the SNMPv3 context name is not mandatory. Devices can still be discovered in Aruba AirWave without the SNMPv3 context name.

4. Enter the `logging` command for enabling syslog forwarding to a remote syslog server, such as AirWave:

```
switch(config)# logging 10.0.10.2 severity debug
```

5. SNMP traps enable an agent to notify the management station of significant events by way of an unsolicited SNMP message. Enable SNMP traps by entering the `snmp-server host` command:

```
switch(config)# snmp-server host 10.10.10.10 trap version v2c vrf default
```

SNMP traps cannot be forwarded from AOS-CX 10.00 switches that have the VRF configured as mgmt. Later versions of AOS-CX support SNMP trap forwarding even when the VRF is configured as default or mgmt.

6. For information on how to add a device for monitoring in the Aruba AirWave user interface, see the documentation for Aruba AirWave.

AirWave commands

Subtopics

[logging](#)

[snmp-server community](#)

[snmp-server host](#)

[snmp-server vrf](#)

[snmpv3 context](#)

[snmpv3 user](#)

logging

Syntax

```
logging {<IPv4-ADDR> | <IPv6-ADDR> | <FQDN | HOSTNAME>} {udp [<PORT-NUM>]} |  
{tcp [<PORT-NUM>]} || {tls [<PORT-NUM>]}  
  auth-mode {certificate|subject-name}  
  disable  
  filter <FILTER-NAME>  
  include-auditable-events  
  legacy-tls-renegotiation]  
  rate-limit-burst <BURST>  
  rate-limit-interval <INTERVAL>] ]
```



```

severity <LEVEL>]
vrf <VRF-NAME>]
no logging {<IPV4-ADDR> | <IPV6-ADDR> | <FQDN | HOSTNAME> }

```

Description

Enables syslog forwarding to a remote syslog server.

The **no** form of this command disables syslog forwarding to a remote syslog server.

Starting with AOS-CX 10.11, payload information is present in accounting logs.

The maximum REST payload that can be sent to RADIUS/TACACS server is 1024 characters, and the maximum of REST payload that can be sent to syslog server is 3500 characters. If this limit is reached, the log will display three dots (...) to indicate that the log exceeded the character limit and is incomplete.

Parameter	Description
{<IPV4-ADDR> <IPV6-ADDR> <HOSTNAME>}	Selects the IPv4 address, IPv6 address, or host name of the remote syslog server. Required.
[udp [<PORT-NUM>] tcp [<PORT-NUM> tls [<PORT-NUM>]]	Specifies the UDP port, TCP port, or TLS port of the remote syslog server to receive the forwarded syslog messages.
udp [<PORT-NUM>]	Range: 1 to 65535. Default: 514
tcp [<PORT-NUM>]	Range: 1 to 65535. Default: 1470
tls [<PORT-NUM>]	Range: 1 to 65535. Default: 6514
auth-mode	Specifies the TLS authentication mode used to validate the certificate. • certificate: Validates the peer using trust anchor certificate based authentication. Default. • subject - name: Validates the peer using trust anchor certificates as well as subject - name based authentication.
disable	Disable remote syslog configuration. This does not delete the configuration, just disables/pauses the forwarding of syslog messages to the remote server. The config/forwarding can be reenabled (un - paused) again using the no logging <hostname> disable command.
filter <FILTER-NAME>	Specifies the name of the filter to be applied on the syslog messages.
include-auditable-events	Specifies that auditable messages are also logged to the remote syslog server.

Parameter	Description
<code>legacy-tls-renegotiation</code>	Enables the TLS connection with a remote syslog server supporting legacy renegotiation.
<code>rate-limit-burst <BURST></code>	Specifies the rate limit for the messages sent to the remote syslog server.
<code>rate-limit-interval <INTERVAL></code>	Specifies the rate limit interval in seconds. Default: 30 Seconds
<code>severity <LEVEL></code>	Specifies the severity of the syslog messages: • alert: Forwards syslog messages with the severity of alert (6) and emergency (7). • crit: Forwards syslog messages with the severity of critical (5) and above. • debug: Forwards syslog messages with the severity of debug (0) and above. • emerg: Forwards syslog messages with the severity of emergency (7) only. • err: Forwards syslog messages with the severity of err (4) and above. • info: Forwards syslog messages with the severity of info (1) and above. Default. • notice: Forwards syslog messages with the severity of notice (2) and above. • warning: Forwards syslog messages with the severity of warning (3) and above.
<code>vrf <VRF-NAME></code>	Specifies the VRF used to connect to the syslog server. Optional. Default: <code>default</code>

Examples

Enabling the syslog forwarding to remote syslog server 10.0.10.2:

```
switch(config)# logging 10.0.10.2
```

Enabling the syslog forwarding of messages with a severity of **err (4)** and above to TCP port 4242 on remote syslog server 10.0.10.9 with VRF **lab_vrf**:

```
switch(config)# logging 10.0.10.9 tcp 4242 severity err vrf lab_vrf
```

Disabling syslog forwarding to a remote syslog server:

```
switch(config)# no logging
```

Enabling syslog forwarding over TLS to a remote syslog server using subject-name authentication mode:

```
switch(config)# logging example.com tls auth-mode subject-name
```

Applying log filtering for syslog server forwarding:

```
switch(config)# logging 10.0.10.6 severity info filter filter_lldp_logs vrf mgmt
```

Applying log filtering and enabling the rate limit for syslog server forwarding over TCP port:

```
switch(config)# logging 10.0.10.2 tcp 3440 severity err vrf mgmt include-auditable-events filter filter_lldp_logs rate-limit-burst 3 rate-limit-interval 35
```

Command History

Release	Modification
10.12.1000	The disable parameter is introduced
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

snmp-server community

Syntax

```
snmp-server community <STRING>  
no snmp-server community <STRING>
```

Description

Adds an SNMPv1/SNMPv2c community string. A community string is like a password that controls read/write access to the SNMP agent. A network management program must supply this name when attempting to get SNMP information from the switch. A maximum of 10 community strings are supported. Once you create your own community string, the default community string (`public`) is deleted.

The **no** form of this command removes the specified SNMPv1/SNMPv2c community string. When no community string exists, a default community string with the value **public** is automatically defined.

Parameter	Description
<code><STRING></code>	Specifies the SNMPv1/SNMPv2c community string. Range: 1 to 32 printable ASCII characters, excluding space and question mark.

Subcommands

```
access-level {ro | rw}
no access-level {ro | rw}
```

This subcommand changes the access level of the SNMP community. The default access level is read-only (**ro**).

The **no** form of this subcommand changes the access level of the community to default.

Parameter	Description
<code>ro</code>	Specifies Read - Only access with the SNMP community.
<code>rw</code>	Specifies Read - Write access with the SNMP community.

```
access-list {ip | ipv6} <ACL-NAME>
no access-list {ip | ipv6} <ACL-NAME>
```

This subcommand associates an ACL with the SNMP community. If an ACL is not associated with the SNMP community, the default access is allowed for all the hosts.

The **no** form of this subcommand removes association of the ACL with the SNMP community.

Parameter	Description
<code>ip</code>	Specifies the IPv4 ACL type.
<code>ipv6</code>	Specifies the IPv6 ACL type.

Parameter	Description
<code><ACL-NAME></code>	Specifies the ACL name. It supports a maximum of 64 characters.

Examples

Setting the SNMPv1/SNMPv2c community string to **private**:

```
switch(config)# snmp-server community private
```

Removing SNMPv1/SNMPv2c community string **private**:

```
switch(config)# no snmp-server community private
```

Configuring the access level for the SMNP community to read-only:

```
switch(config-community)# access-level ro
```

Changing the access level of the SNMP community to default:

```
switch(config-community)# no access-level rw
```

Associating an IPv4 ACL named **my_acl** with the SMNP community:

```
switch(config-community)# access-list ip my_acl
```

Removing the associated IPv4 ACL named **my_acl** from the SNMP community:

```
switch(config-community)# no access-list ip my_acl
```

Configuration supported for SNMP ACL:

```
access-list ip ipv4_acl
  10 permit any 4.4.4.4 4.4.4.1
  20 permit any 3.3.3.3 3.3.3.1
access-list ipv6 ipv6_acl
  10 permit any 2001::2 2001::1
  20 permit any 3001::2 3001::1
snmp-server vrf default
snmp-server community my_comm_1
  access-list ip ipv4_acl
  access-list ipv6 ipv6_acl
```

Configuration not supported for SNMP ACL:

```
access-list ip ipv4_acl
  10 deny any 6.6.6.6 6.6.6.1
```

```

access-list ipv6 ipv6_acl
  10 deny any 6001::6 6000::1
snmp-server vrf default
snmp-server community my_comm_1
  access-list ip ipv4_acl
  access-list ipv6 ipv6_acl

```



NOTE

hitcounts for SNMP ACL will not be incremented.

Example: `show access-list hitcounts ip all` will not show the hit count of SNMP ACL.

Command History

Release	Modification
10.14	Replaced the ipv4 parameter with the ip parameter. The ipv4 parameter is deprecated.
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config config- community	Administrators or local user group members with execution rights for this command.

snmp-server host

Syntax

```

snmp-server host <IPv4-ADDR | IPv6-ADDR> trap version <VERSION> [community <STRING>]
[port <UDP-PORT>] [<VRF-NAME>] [notification-type <NOTIFICATION-TYPE>]
no snmp-server host <IPv4-ADDR | IPv6-ADDR> trap version <VERSION>
[community <STRING>]
[port <UDP-PORT>] [<VRF-NAME>] [notification-type <NOTIFICATION-TYPE>]
snmp-server host <IPv4-ADDR | IPv6-ADDR> inform version v2c [community

```

```

<STRING>]
[port <UDP-PORT>] [<VRF-NAME>] [notification-type <NOTIFICATION-TYPE>]
no snmp-server host <IPv4-ADDR | IPv6-ADDR> inform version v2c [community
<STRING>]
[port <UDP-PORT>] [<VRF-NAME>] [notification-type <NOTIFICATION-TYPE>]
snmp-server host <IPv4-ADDR | IPv6-ADDR> [trap version v3 | inform
version v3] user <NAME> [port <UDP-PORT>] [<VRF-NAME>] [notification-type
<NOTIFICATION-TYPE>]
no snmp-server host <IPv4-ADDR | IPv6-ADDR> [trap version v3 | inform
version v3] user <NAME> [port <UDP-PORT>] [<VRF-NAME>] [notification-type
<NOTIFICATION-TYPE>]

```

Description

Configures a trap/informs receiver to which the SNMP agent can send SNMP v1/v2c/v3 traps or v2c informs. A maximum of 30 SNMP traps/informs receivers can be configured.

The **no** form of this command removes the specified trap/inform receiver.



NOTE

Avoid configuring the same receiver for both SNMP traps and informs on the same UDP port for v1, v2, and v3.

Parameter	Description
<IPv4-ADDR>	Specifies the IP address of a trap receiver in IPv4 format (x.x.x.x), where x is a decimal number from 0 to 255. You can remove leading zeros. For example, the address 192.169.005.100 becomes 192.168.5.100 .
<IPv6-ADDR>	Specifies the IP address of a trap receiver in IPv6 format (x:x::x:x).
trap version <VERSION>	Specifies the trap notification type for SNMPv1, v2c or v3. Available options are: v1 , v2c or v3 .
inform version v2c	Specifies the inform notification type for SNMPv2c.
trap version v3	Specifies the trap notification type for SNMPv3.
user <NAME>	Specifies the SNMPv3 user name to be used in the SNMP trap notifications.

Parameter	Description
<code>community <STRING></code>	Specifies the name of the community string to use when sending trap notifications. Range: 1 - 32 printable ASCII characters, excluding space and question mark. Default: public .
<code><UDP-PORT></code>	Specifies the UDP port on which notifications are sent. Range: 1 - 65535. Default: 162.
<code><VRF-NAME></code>	Specifies the VRF on which the SNMP agent listens for incoming requests.
<code><notification-type></code>	Specifies the type of notification to be sent to the trap receiver. If no type is specified, all notifications are sent. The supported notification types are: • aaa - server • alarm • bgp • card • config • entity • fan • interface • lldp • loop - protect • mac - notify • mstp • mvrp • ospf • ospfv3 • port - security • power • power - ethernet • rmon • rpvst • stp • temperature • vrrp • vsf

- VSX

Examples

```

switch(config)# snmp-server host 10.10.10.10 trap version v1
switch(config)# no snmp-server host 10.10.10.10 trap version v1

switch(config)# snmp-server host a:b::c:d trap version v1
switch(config)# no snmp-server host a:b::c:d trap version v1

switch(config)# snmp-server host 10.10.10.10 trap version v2c community
public
switch(config)# no snmp-server host 10.10.10.10 trap version v2c community
public

switch(config)# snmp-server host a:b::c:d trap version v2c community public
switch(config)# no snmp-server host a:b::c:d trap version v2c community
public

switch(config)# snmp-server host 10.10.10.10 trap version v2c community
public port 5000
switch(config)# no snmp-server host 10.10.10.10 trap version v2c community
public port 5000

switch(config)# snmp-server host 10.10.10.10 trap version v2c community
public port 5000 vrf default
switch(config)# no snmp-server host 10.10.10.10 trap version v2c community
public port 5000 vrf default

switch(config)# snmp-server host a:b::c:d trap version v2c community public
port 5000
switch(config)# no snmp-server host a:b::c:d trap version v2c community
public port 5000

switch(config)# snmp-server host 10.10.10.10 inform version v2c community
public
switch(config)# no snmp-server host 10.10.10.10 inform version v2c
community public

switch(config)# snmp-server host a:b::c:d inform version v2c community
public

```

```

switch(config)# no snmp-server host a:b::c:d inform version v2c community
public

switch(config)# snmp-server host 10.10.10.10 inform version v2c community
public port 5000

switch(config)# no snmp-server host 10.10.10.10 inform version v2c
community public port 5000

switch(config)# snmp-server host 10.10.10.10 inform version v2c community
public port 5000 vrf default

switch(config)# no snmp-server host 10.10.10.10 inform version v2c
community public port 5000 vrf default

switch(config)# snmp-server host a:b::c:d inform version v2c community
public port 5000

switch(config)# no snmp-server host a:b::c:d inform version v2c community
public port 5000

switch(config)# snmp-server host 10.10.10.10 trap version v3 user Admin
switch(config)# no snmp-server host 10.10.10.10 trap version v3 user Admin

switch(config)# snmp-server host a:b::c:d trap version v3 user Admin
switch(config)# no snmp-server host a:b::c:d trap version v3 user Admin

switch(config)# snmp-server host 10.10.10.10 trap version v3 user Admin
port 2000

switch(config)# no snmp-server host 10.10.10.10 trap version v3 user Admin
port 2000

switch(config)# snmp-server host a:b::c:d trap version v3 user Admin port
2000

switch(config)# no snmp-server host a:b::c:d trap version v3 user Admin
port 2000

```

SNMP trap notification type examples:

```

switch(config)# snmp-server host 10.10.10.10 trap version v2c community
public notification-type bgp fan interface power entity

switch(config)# no snmp-server host 10.10.10.10 trap version v2c community
public notification-type bgp

switch(config)# snmp-server host a:b::c:d inform version v3 user Admin

```

```

notification-type bgp fan interface power-ethernet
switch(config)# no snmp-server host a:b::c:d inform version v3 user Admin
notification-type bgp interface
switch(config)# snmp-server host a:b::c:d inform version v3 user Admin
notification-type ?
    aaa-server      Sends AAA notifications.
    alarm           Sends Alarm notifications.
    bgp             Sends Border Gateway Protocol (BGP) state change
notifications.
    card            Sends Card notifications.
    config          Sends Configuration change notifications.
    entity          Sends Entity notifications.
    fan             Sends Fan notifications.
    interface       Sends Interface notifications.
    lldp            Sends Link Layer Discovery Protocol (LLDP) notifications.
    loop-protect    Sends Loop Protect notifications.
    mac-notify      Sends MAC Notify notifications.
    mstp            Sends Multiple Spanning Tree Protocol (MSTP)
notifications.
    mvrp            Sends Multiple VLAN Registration Protocol (MVRP)
notifications.
    ospf            Sends Open Shortest Path First (OSPFv2) notifications.
    ospfv3          Sends Open Shortest Path First version 3 (OSPFv3)
notifications.
    port-security   Sends Port Security notifications.
    power           Sends Power notifications.
    power-ethernet  Sends Power over Ethernet (PoE) notifications.
    rmon            Sends Remote Network Monitoring (RMON) notifications.
    rpvst           Sends Rapid Per VLAN Spanning Tree (RPVST) notifications.
    snmp            Sends Sends Simple Network Management Protocol (SNMP)
notifications.
    stp             Sends Spanning Tree Protocol (STP) notifications.
    temperature     Sends Temperature notifications.
    vrrp            Sends Virtual Router Redundancy Protocol (VRRP)
notifications.
    vsf             Sends Virtual Switching Framework (VSF) notifications.
    vsx             Sends Virtual System Extension (VSX) notifications.

```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	<code>config</code>	Administrators or local user group members with execution rights for this command.

`snmp-server vrf`

Syntax

```
snmp-server vrf <VRF-NAME>
no snmp-server vrf <VRF-NAME>
```

Description

Configures a VRF on which the SNMP agent listens for incoming requests. By default, the SNMP agent does not listen on any VRF. 4100i, 6000, and 6100 only support default VRF. **The SNMP agent can listen on multiple VRFs.**

The **no** form of this command stops the SNMP agent from listening for incoming requests on the specified VRF.

Parameter	Description
<code><VRF-NAME></code>	Specifies the name of a VRF.

Examples

Configuring the SNMP agent to listen on VRF **default**.

```
switch(config) # snmp-server vrf default
```

Configuring the SNMP agent to listen on VRF **mgmt**.

Stopping the SNMP agent from listening on VRF **default**.

```
switch(config) # no snmp-server vrf default
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

snmpv3 context

Syntax

```
snmpv3 context <NAME> vrf <VRF-NAME> [community <STRING>]
no snmpv3 context <NAME> [vrf <VRF-NAME>] [community <STRING>]
```

Description

Creates an SNMPv3 context on the specified VRF.

The **no** form of this command removes the specified SNMP context.

Parameter	Description
<NAME>	Specifies the name of the context. Range: 1 to 32 printable ASCII characters, excluding space and question mark (?).
vrf <VRF-NAME>	Specifies the VRF associated with the context. Default: default.
community <STRING>	Specifies the SNMP community string associated with the context. Range: 1 to 32 printable ASCII characters, excluding space and question mark. Default: public.

Examples

Creating an SNMPv3 context named **newContext**:

```
switch(config)# snmpv3 context newContext
```

Creating an SNMPv3 context named **newContext** on VRF **myVrf** and with community string **private**.

```
switch(config)# snmpv3 context newContext vrf myVrf community private
```

Removing the SNMPv3 context named **newContext** on VRF **myVrf**:

```
switch(config)# no snmpv3 context newContext vrf myVrf
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

snmpv3 user

Syntax

```
snmpv3 user <NAME>
    [auth <AUTH-PROTO> auth-pass [{plaintext | ciphertext} <AUTH-PASS>]]
    [priv <PRIV-PROTO> priv-pass [{plaintext | ciphertext} <PRIV-PASS>]]
    [access-level ro|rw]
no snmpv3 user <NAME>
    [auth <AUTH-PROTO> auth-pass [{plaintext | ciphertext} <AUTH-PASS>]]
    [priv <PRIV-PROTO> priv-pass [{plaintext | ciphertext} <PRIV-PASS>]]
    [access-level ro|rw]
```

Description

Creates an SNMPv3 user and adds it to an SNMPv3 context. The SNMPv3 security level (set with command **snmpv3 security-level**) determines which users are allowed to authenticate.

The **no** form of this command removes the specified SNMPv3 user.



NOTE

When updating the authentication protocols and privacy protocols for the existing SNMPv3 users, you must also update the access level. Otherwise, the access level will be set to read-only.

Parameter	Description
<code><NAME></code>	Specifies the SNMPv3 username. Range 1 to 32 printable ASCII characters, excluding space and question mark (?).
<code>access - level</code>	Configures the access level for the SNMPv3 user: • ro: Allow read - only access for the SNMPv3 user • rw: Allow read - write access for the SNMPv3 user
<code>auth <AUTH-PROTO></code>	Sets the authentication protocol used to validate user logins. Supported protocols are md5 , sha , sha224 , sha256 , sha384 , and sha512 .
<code>auth-pass [{plaintext ciphertext} <AUTH-PASS>]</code>	Specifies the SNMPv3 user authentication password. Range for plaintext is 8 to 32 printable ASCII characters, excluding space and question mark (?). Range for ciphertext is 1 to 256 printable ASCII characters. Ciphertext is used when copying user configuration settings between switches. NOTE Authentication passwords that include special characters must be enclosed in single quotation marks ('). For example, 'auth - pwd20246!@#'.
<code>priv <PRIV-PROTO></code>	Sets the SNMPv3 privacy protocol (encryption method). Supported privacy protocols are aes , aes192 , aes256 , and des .
<code>priv-pass [{plaintext ciphertext} <PRIV-PASS>]</code>	Specifies the SNMPv3 user privacy encryption password. Range for plaintext is 8 to 32 printable ASCII characters, excluding space and question mark (?). Range for ciphertext is 1 to 256 pri

Parameter

Description

ntable ASCII characters. Ciphertext is used when copying user c
onfiguration settings between switches.



NOTE

Authentication passwords that include special c
haracters must be enclosed in single quotation
marks ('). For example, '**priv - pwd20246!@#**'.



NOTE

When the authentication password is not provided on the command line,
plaintext authentication password prompting occurs upon pressing Enter,
followed by privacy encryption protocol prompting, and finally plaintext
encryption password prompting. The entered password characters are masked
with asterisks.



NOTE

When the authentication type and password plus the privacy protocol
(encryption method) are provided on the command line but the encryption
password is not provided, plaintext encryption password prompting occurs upon
pressing Enter. The entered password characters are masked with asterisks.

Examples

Defining SNMPv3 user **Admin1** using **sha** authentication and **des** privacy encryption with provided plaintext passwords:

```
switch(config)# snmpv3 user Admin1 auth sha auth-pass plaintext F82#450h  
priv des priv-pass plaintext F82#4eva
```

Defining SNMPv3 user **Admin2** using **MD5** authentication and **AES** privacy encryption with provided authentication password and privacy encryption type but prompted encryption password:

```
switch(config)# snmpv3 user Admin2 auth md5 auth-pass plaintext F82#450h  
priv aes priv-pass  
Enter the privacy encryption key: *****  
Re-Enter the privacy encryption key: *****
```

Defining SNMPv3 user **Admin2** using **MD5** authentication and **AES** privacy encryption with plaintext password prompting and privacy encryption selection:


```

switch(config)# snmpv3 user Admin2 auth md5 auth-pass
Enter the authentication password: *****
Re-Enter the authentication password: *****
Configure the privacy protocol (y/n)? y
Enter the privacy protocol (aes/des)? aes
Enter the privacy encryption key: *****
Re-Enter the privacy encryption key: *****

```

Removing SNMPv3 user **Admin1**:

```

switch(config)# no snmpv3 user Admin1

```

Creating an SNMP user on switch 1 and then creating the same user on switch 2 by copying from the switch 1 configuration:

On switch 1, configure a user named **Admin3**, and then use the **show running-config** command to display switch configuration. Save a copy of the full **snmpv3 user** command (shown by **show running-config**). This saved command is used on switch 2.

```

switch1(config)# snmpv3 user Admin3 auth sha auth-pass plaintext F82#450h
                    priv des priv-pass plaintext F82#4eva
switch1(config)# exit
switch1# show running-config
Current configuration:
!
!Version AOS-CX xx.xx.xx.xxxxxx
!
snmpv3 user Admin3 auth sha auth-pass ciphertext AQBaf2d...FJVcZ3o=
priv des priv-pass ciphertext AQBah2p...2jfTFwQ=
ssh server vrf mgmt
!
interface mgmt
no shutdown
ip dhcp
vlan 1

```

On switch 2, execute the **snmpv3 user** command that you saved from switch 1 (as shown by **show running-config**). This creates the user on switch 2 with the same configuration.

```

switch2(config)# snmpv3 user Admin3 auth sha auth-pass ciphertext
AQBaf2d...FJVcZ3o=
                    priv des priv-pass ciphertext AQBah2p...2jfTFwQ=

```

The following command sets a read-write access level for an SNMPv3 user with the user name **user1**.

```

switch(config)# snmpv3 user user1 auth md5 auth-pass plaintext abc1234
access-level rw

```

Command History

Release	Modification
10.13	Following authentication protocols are supported: sha224 , sha256 , sha384 , and sha512 . Following privacy protocols are supported: aes192 and aes256 .
10.09	The access - level parameter was introduced.
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	<code>config</code>	Administrators or local user group members with execution rights for this command.

Subtopics

snmpv3 user view

snmpv3 user view

Syntax

```
snmpv3 user <USER-NAME> view <VIEW-NAME>
no snmpv3 user <USER-NAME> view <VIEW-NAME>
```

Description

Associates a user with an existing SNMP MIB view.

The **no** form of this command removes the associated user from the specified SNMP MIB view.

Parameter	Description
	Specifies the user name for the SNMP MIB view. Accepts a maximum of 32 characters.

Parameter	Description
<code><USER-NAME></code>	
<code><VIEWNAME></code>	Specifies the view name for the SNMP MIB view. Accepts a maximum of 32 characters.

Examples

Adding a user in the existing SNMP MIB view:

```
switch(config)# snmpv3 user nw-admin view my-nw-view
```

Removing the user from the SNMP MIB view:

```
switch(config)# no snmpv3 user nw-admin view my-nw-view
```

Attaching unconfigured or unknown SNMP view to an SNMPv3 user:

```
switch(config)# snmpv3 user nw-admin view myView
View myView is not configured.
```

Command History

Release	Modification
10.10	Command introduced

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

Support and Other Resources

Subtopics

[Accessing HPE Aruba Networking Support](#)

Accessing HPE Aruba Networking Support

HPE Aruba Networking Support Services	<u>https://www.hpe.com/us/en/networking/hpe - aruba - networking - support - services.html</u>
AOS - CX Switch Software Documentation Portal	<u>https://arubanetworking.hpe.com/techdocs/ArubaDocPortal/content/new-portal/aoscx.html</u>
HPE Aruba Networking Support Portal	<u>https://networkingsupport.hpe.com/home</u>
North America telephone	1 - 800 - 943 - 4526 (US & Canada Toll - Free Number) +1 - 650 - 750 - 0350 (Backup—Toll Number)
International telephone	<u>https://www.hpe.com/psnow/doc/a50011948enw</u>

Be sure to collect the following information before contacting Support:

- Technical support registration number (if applicable)
- Product name, model or version, and serial number
- Operating system name and version
- Firmware version
- Error messages
- Product-specific reports and logs
- Add-on products or components
- Third-party products or components

Other useful sites

Other websites that can be used to find information:

HPE Aruba Networking Developer Hub	https://developer.arubanetworks.com/hpe - aruba - networking - aoscx/docs/about
Airheads social forums and Knowledge Base	https://community.arubanetworks.com/
AOS - CX Software Technical Update channel on YouTube.	Videos on new features introduced in this release : https://www.youtube.com/playlist?list=PLsYGHuNuBZcbWPEjjHuVMqP - Q_UL3CskS
HPE Aruba Networking Hardware Documentation and Translations Portal	
HPE Aruba Networking software	https://networkingsupport.hpe.com/downloads https://networkingsupport.hpe.com/downloads
Software licensing and Feature Packs	https://licensemanagement.hpe.com/
End - of - Life information	https://networkingsupport.hpe.com/end - of - life

Accessing Updates

You can access updates from the HPE Aruba Networking Support Portal at <https://networkingsupport.hpe.com>.

Some software products provide a mechanism for accessing software updates through the product interface. Review your product documentation to identify the recommended software update method.

To subscribe to eNewsletters and alerts:

<https://networkingsupport.hpe.com/notifications/subscriptions> (requires an active HPE Aruba Networking Support Portal account to manage subscriptions). Security notices are viewable without an HPE Aruba Networking Support Portal account.

Warranty Information

To view warranty information for your product, go to <https://www.arubanetworks.com/support-services/product-warranties/>.

Regulatory Information

To view the regulatory information for your product, view the Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products, available at [**https://www.hpe.com/support/Safety-Compliance-EnterpriseProducts**](https://www.hpe.com/support/Safety-Compliance-EnterpriseProducts)

Additional regulatory information

HPE Aruba Networking is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements, environmental data (company programs, product recycling, energy efficiency), and safety information and compliance data, (RoHS and WEEE). For more information, see [**https://www.arubanetworks.com/company/about-us/environmental-citizenship/**](https://www.arubanetworks.com/company/about-us/environmental-citizenship/).

Documentation Feedback

HPE Aruba Networking is committed to providing documentation that meets your needs. To help us improve the documentation, send any errors, suggestions, or comments to Documentation Feedback ([**docsfeedback-switching@hpe.com**](mailto:docsfeedback-switching@hpe.com)). When submitting your feedback, include the document title, part number, edition, and publication date located on the front cover of the document. For online help content, include the product name, product version, help edition, and publication date located on the legal notices page.