

AOS-CX 10.12 Event Log Message Reference Guide

All Switch Series



a Hewlett Packard
Enterprise company

Copyright Information

© Copyright 2023 Hewlett Packard Enterprise Development LP.

This product includes code licensed under certain open source licenses which require source compliance. The corresponding source for these components is available upon request. This offer is valid to anyone in receipt of this information and shall expire three years following the date of the final distribution of this product version by Hewlett Packard Enterprise Company. To obtain such source code, please check if the code is available in the HPE Software Center at <https://myenterpriselicense.hpe.com/cwp-ui/software> but, if not, send a written request for specific software version and product for which you want the open source code. Along with the request, please send a check or money order in the amount of US \$10.00 to:

Hewlett Packard Enterprise Company
Attn: General Counsel
WW Corporate Headquarters
1701 E Mossy Oaks Rd Spring, TX 77389
United States of America.

Notices

The information contained herein is subject to change without notice. The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise shall not be liable for technical or editorial errors or omissions contained herein.

Confidential computer software. Valid license from Hewlett Packard Enterprise required for possession, use, or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Links to third-party websites take you outside the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for information outside the Hewlett Packard Enterprise website.

Contents	3
About this document	9
Applicable products	9
Latest version available online	9
Command syntax notation conventions	9
About the examples	10
Identifying switch ports and interfaces	11
Identifying modular switch components	12
AAA events	13
Accounting events	15
ACLs events	16
Alarm events	17
ARP security events	20
ASIC table full error for L3PD events	21
BFD events	24
BGP events	29
Bluetooth Management events	34
CDP events	36
Certificate management events	38
Config Management events	43
Connectivity Fault Management (CFM) events	45
Console events	46
Container manager events	47
CoPP events	48
CPU_RX events	51
Credential Manager events	52

Device fingerprinting events	54
DHCP Relay events	55
DHCP server events	56
DHCPv4 snooping events	59
DHCPv6 Relay events	64
DHCPv6 snooping events	65
Discovery and Capability Exchange (DCBx) events	70
DNS client events	72
Dot1x supplicant events	73
DPSE events	74
ECMP events	76
ERPS events	78
EVPN events	82
External Storage events	86
Fan events	88
Fault monitor events	93
Firmware Update events	95
Hardware Health Monitor events	97
Hardware switch controller sync events	100
HTTPS Server events	103
In-System Programming events	105
Interface events	108
Internal storage events	110
IP source lockdown events	111
IP tunnels events	113
IP-SLA events	117
IPv6 Router Advertisement events	119

IRDP events	124
Job scheduler events	125
L3 Encap capacity events	126
L3 Resource Manager events	127
LACP events	128
LAG events	134
Layer 3 Interface events	137
LED events	144
LLDP events	145
Loop Protect events	148
Loopback events	150
MAC address management events	151
MAC Address mode configuration events	153
MACsec events	154
Management events	156
MDNS events	157
MGMD events	158
Mirroring events	163
Module events	165
MPLS events	173
MSDP events	174
Multicast Traffic Manager events	176
Multiple spanning tree protocol events	177
MVRP events	181
NAE Agents events	183
NAE events	184
NAE script generation events	187

NAE Scripts events	188
ND snooping events	191
NDM events	193
NTP events	200
OSPFv2 events	202
OSPFv3 events	205
Password Reset events	207
PIM events	208
Policies events	215
Port access events	216
Port access group based policy events	219
Port access roles events	221
Port events	222
Port security events	224
Port Statistics events	225
Power events	226
Power over Ethernet events	231
PTP events	240
QoS ASIC Provider events	244
Quality of Service events	246
Rapid per VLAN Spanning Tree Protocol events	247
RBAC events	250
Redundant Management events	251
Replication Manager events	253
REST events	254
Self Test events	266
sFlow events	267

SFTP Client events	274
Smartlink events	275
SNMP events	276
SSH client events	279
SSH server events	280
Supportability events	283
SYS events	290
SYSMON events	292
TCAM events	294
Telnet server events	298
Temperature events	300
Time management events	303
Transceiver events	304
UDLD events	307
UDP Broadcast Forwarder events	309
UFD events	310
User management events	311
User-based tunnels events	313
Virtual Switching Extension (VSX) events	321
Virtual Switching Framework (VSF) events	329
VLAN events	339
VLAN Interface events	343
VRF events	344
VRF Manager events	345
VRRP events	346
VSX Sync events	352
VXLAN agent events	353

VXLAN events	354
Zero touch provisioning events	358
Support and Other Resources	364
Accessing Aruba Support	364
Accessing Updates	365
Aruba Support Portal	365
My Networking	365
Warranty information	365
Regulatory Information	365
Documentation feedback	366

This document describes features of the AOS-CX network operating system. It is intended for administrators responsible for installing, configuring, and managing Aruba switches on a network.

Applicable products

This document applies to the following products:

- Aruba 4100i Switch Series (JL817A, JL818A)
- Aruba 6000 Switch Series (R8N85A, R8N86A, R8N87A, R8N88A, R8N89A, R9Y03A)
- Aruba 6100 Switch Series (JL675A, JL676A, JL677A, JL678A, JL679A)
- Aruba 6200 Switch Series (JL724A, JL725A, JL726A, JL727A, JL728A, R8Q67A, R8Q68A, R8Q69A, R8Q70A, R8Q71A, R8V08A, R8V09A, R8V10A, R8V11A, R8V12A, R8Q72A)
- Aruba 6300 Switch Series (JL658A, JL659A, JL660A, JL661A, JL662A, JL663A, JL664A, JL665A, JL666A, JL667A, JL668A, JL762A, R8S89A, R8S90A, R8S91A, R8S92A)
- Aruba 6400 Switch Series (R0X31A, R0X38B, R0X38C, R0X39B, R0X39C, R0X40B, R0X40C, R0X41A, R0X41C, R0X42A, R0X42C, R0X43A, R0X43C, R0X44A, R0X44C, R0X45A, R0X45C, R0X26A, R0X27A, JL741A)
- Aruba 8100 Switch Series (R9W94A, R9W95A, R9W96A, R9W97A)
- Aruba 8320 Switch Series (JL479A, JL579A, JL581A)
- Aruba 8325 Switch Series (JL624A, JL625A, JL626A, JL627A)
- Aruba 8360 Switch Series (JL700A, JL701A, JL702A, JL703A, JL706A, JL707A, JL708A, JL709A, JL710A, JL711A, JL700C, JL701C, JL702C, JL703C, JL706C, JL707C, JL708C, JL709C, JL710C, JL711C, JL704C, JL705C, JL719C, JL718C, JL717C, JL720C, JL722C, JL721C)
- Aruba 8400 Switch Series (JL366A, JL363A, JL687A)
- Aruba 9300 Switch Series (R9A29A, R9A30A, R8Z96A)
- Aruba 10000 Switch Series (R8P13A, R8P14A)

Latest version available online

Updates to this document can occur after initial publication. For the latest versions of product documentation, see the links provided in [Support and Other Resources](#).

Command syntax notation conventions

Convention	Usage
<code>example-text</code>	Identifies commands and their options and operands, code examples, filenames, pathnames, and output displayed in a command window. Items that appear like the example text in the previous column are to be entered exactly as shown and are required unless enclosed in brackets ([]).

Convention	Usage
example-text	In code and screen examples, indicates text entered by a user.
Any of the following: ▪ <code><example-text></code> ▪ <code><example-text></code> ▪ <i>example-text</i> ▪ <i>example-text</i>	Identifies a placeholder—such as a parameter or a variable—that you must substitute with an actual value in a command or in code: ▪ For output formats where italic text cannot be displayed, variables are enclosed in angle brackets (< >). Substitute the text—including the enclosing angle brackets—with an actual value. ▪ For output formats where italic text can be displayed, variables might or might not be enclosed in angle brackets. Substitute the text including the enclosing angle brackets, if any, with an actual value.
	Vertical bar. A logical OR that separates multiple items from which you can choose only one. Any spaces that are on either side of the vertical bar are included for readability and are not a required part of the command syntax.
{ }	Braces. Indicates that at least one of the enclosed items is required.
[]	Brackets. Indicates that the enclosed item or items are optional.
... or ...	Ellipsis: ▪ In code and screen examples, a vertical or horizontal ellipsis indicates an omission of information. ▪ In syntax using brackets and braces, an ellipsis indicates items that can be repeated. When an item followed by ellipses is enclosed in brackets, zero or more items can be specified.

About the examples

Examples in this document are representative and might not match your particular switch or environment.

The slot and port numbers in this document are for illustration only and might be unavailable on your switch.

Understanding the CLI prompts

When illustrating the prompts in the command line interface (CLI), this document uses the generic term `switch`, instead of the host name of the switch. For example:

```
switch>
```

The CLI prompt indicates the current command context. For example:

```
switch>
```

Indicates the operator command context.

```
switch#
```

Indicates the manager command context.

```
switch(CONTEXT-NAME)#
```

Indicates the configuration context for a feature. For example:

```
switch(config-if) #
```

Identifies the interface context.

Variable information in CLI prompts

In certain configuration contexts, the prompt may include variable information. For example, when in the VLAN configuration context, a VLAN number appears in the prompt:

```
switch(config-vlan-100)#
```

When referring to this context, this document uses the syntax:

```
switch(config-vlan-<VLAN-ID>)#
```

Where *<VLAN-ID>* is a variable representing the VLAN number.

Identifying switch ports and interfaces

Physical ports on the switch and their corresponding logical software interfaces are identified using the format:

```
member/slot/port
```

On the 4100i Switch Series

- *member*: Always 1. VSF is not supported on this switch.
- *slot*: Always 1. This is not a modular switch, so there are no slots.
- *port*: Physical number of a port on the switch.

For example, the logical interface 1/1/4 in software is associated with physical port 4 on the switch.

On the 6000 and 6100 Switch Series

- *member*: Always 1. VSF is not supported on this switch.
- *slot*: Always 1. This is not a modular switch, so there are no slots.
- *port*: Physical number of a port on the switch.

For example, the logical interface 1/1/4 in software is associated with physical port 4 on the switch.

On the 6200 Switch Series

- *member*: Member number of the switch in a Virtual Switching Framework (VSF) stack. Range: 1 to 8. The primary switch is always member 1. If the switch is not a member of a VSF stack, then member is 1.
- *slot*: Always 1. This is not a modular switch, so there are no slots.
- *port*: Physical number of a port on the switch.

For example, the logical interface 1/1/4 in software is associated with physical port 4 in slot 1 on member 1.

On the 6300 Switch Series

- *member*: Member number of the switch in a Virtual Switching Framework (VSF) stack. Range: 1 to 10. The primary switch is always member 1. If the switch is not a member of a VSF stack, then member is 1.
- *slot*: Always 1. This is not a modular switch, so there are no slots.
- *port*: Physical number of a port on the switch.

For example, the logical interface 1/1/4 in software is associated with physical port 4 on member 1.

On the 6400 Switch Series

- *member*: Always 1. VSF is not supported on this switch.
- *slot*: Specifies physical location of a module in the switch chassis.
 - Management modules are on the front of the switch in slots 1/1 and 1/2.
 - Line modules are on the front of the switch starting in slot 1/3.
- *port*: Physical number of a port on a line module.

For example, the logical interface 1/3/4 in software is associated with physical port 4 in slot 3 on member 1.

On the 83xx, 9300, and 10000 Switch Series

- *member*: Always 1. VSF is not supported on this switch.
- *slot*: Always 1. This is not a modular switch, so there are no slots.
- *port*: Physical number of a port on the switch.

For example, the logical interface 1/1/4 in software is associated with physical port 4 on the switch.



If using breakout cables, the port designation changes to x:y, where x is the physical port and y is the lane when split to 4 x 10G or 4 x 25G. For example, the logical interface 1/1/4:2 in software is associated with lane 2 on physical port 4 in slot 1 on member 1.

On the 8400 Switch Series

- *member*: Always 1. VSF is not supported on this switch.
- *slot*: Specifies physical location of a module in the switch chassis.
 - Management modules are on the front of the switch in slots 1/5 and 1/6.
 - Line modules are on the front of the switch in slots 1/1 through 1/4, and 1/7 through 1/10.
- *port*: Physical number of a port on a line module

For example, the logical interface 1/1/4 in software is associated with physical port 4 in slot 1 on member 1.

Identifying modular switch components

- Power supplies are on the front of the switch behind the bezel above the management modules. Power supplies are labeled in software in the format: *member/power supply*:
 - *member*: 1.
 - *power supply*: 1 to 4.
- Fans are on the rear of the switch and are labeled in software as: *member/tray/fan*:
 - *member*: 1.
 - *tray*: 1 to 4.
 - *fan*: 1 to 4.
- Fabric modules are not labeled on the switch but are labeled in software in the format: *member/module*:
 - *member*: 1.
 - *member*: 1 or 2.
- The display module on the rear of the switch is not labeled with a member or slot number.

The following are the events related to AAA.

Event ID: 2301

Message	AAA <code><aaa_config_type></code> update: <code><aaa_config_event></code>
Category	AAA
Severity	Information
Description	Logs AAA Authentication/Authorization/Accounting/fail-through

Event ID: 2302

Message	TACACS <code><tacacs_type></code> <code><tacacs_action></code> : <code><tacacs_event></code>
Category	AAA
Severity	Information
Description	Logs TACACS+ server update, server group update and global default update

Event ID: 2303

Message	RADIUS <code><radius_type></code> <code><radius_action></code> : <code><radius_event></code>
Category	AAA
Severity	Information
Description	Logs RADIUS server update, server group update and global default update

Event ID: 2304

Message	RADIUS Server with Address: <code><server_address></code> , Authport: <code><server_authport></code> , VRF_ID: <code><server_vrfid></code> is " <code><status></code> "
Category	AAA
Severity	Information
Description	Logs changes in RADIUS server reachability status

Event ID: 2305

Message	TACACS server host <server_address> port <server_port> vrf <server_vrf> <status>
Category	AAA
Severity	Information
Description	Logs changes in TACACS server reachability status

Event ID: 2306

Message	RADIUS Server route with Address:<server_address>, VRF_ID:<server_vrfid> is "<status>"
Category	AAA
Severity	Information
Description	Logs changes in RADIUS server route reachability status

The following are the events related to accounting.

Event ID: 13101

Message	SSH session from <code><ip_address></code> with User <code><user_name></code> timed out due to idle timeout.
Category	Accounting
Severity	Information
Description	Logs a message when a SSH session timed out due to the session being idle

Event ID: 13102

Message	TELNET session from <code><ip_address></code> with User <code><user_name></code> timed out due to idle timeout.
Category	Accounting
Severity	Information
Description	Logs a message when a TELNET session timed out due to the session being idle

Event ID: 13103

Message	CONSOLE session from <code><ip_address></code> with User <code><user_name></code> timed out due to idle timeout.
Category	Accounting
Severity	Information
Description	Logs a message when a CONSOLE session timed out due to the session being idle

The following are the events related to ACLs.

Event ID: 10001

Message	<code><log></code>
Category	ACLs
Severity	Information
Description	ACL log

Event ID: 10002

Message	<code><acl_name> on <interface_name> (<direction>): <hit_delta> <ace_string></code>
Category	ACLs
Severity	Information
Description	ACL log statistics

Event ID: 10003

Message	<code>ACL <acl_type> <acl_name> failed to apply on <application></code>
Category	ACLs
Severity	Error
Description	ACL application failure

The following are the events related to alarm.

Event ID: 11701

Message	Input alarm <id> config change: name: <name>, relay: <relay>, log_and_trap: <log_and_trap>, trigger: <trigger>
Category	Alarm
Severity	Information
Description	Event reported when there is a change in input alarm configuration.

Event ID: 11702

Message	System alarm (<type>) config change: relay: <relay>, log_and_trap: <log_and_trap>
Category	Alarm
Severity	Information
Description	Event reported when there is a change in system alarm configuration.

Event ID: 11703

Message	System alarm <name> has activated through log-and-trap': yes
Category	Alarm
Severity	Information
Description	Event reported when system alarm has activated

Event ID: 11704

Message	Input alarm <name> has activated through log-and-trap, triggered at <trigger>': yes
Category	Alarm
Severity	Information
Description	Event reported when input alarm has activated

Event ID: 11705

Message	Snooze alarm activated, disabling relay function for <i><length></i> min': yes
Category	Alarm
Severity	Information
Description	Event reported when alarm snooze timer has activated

Event ID: 11706

Message	Snooze alarm has expired': yes
Category	Alarm
Severity	Information
Description	Event reported when alarm snooze timer has expired

Event ID: 11707

Message	Alarm relay function is re-enabled': yes
Category	Alarm
Severity	Information
Description	Event reported when alarm relay function is re-enabled

Event ID: 11708

Message	Snooze alarm repeats, disabling relay function for <i><length></i> min': yes
Category	Alarm
Severity	Information
Description	Event reported when alarm snooze timer repeats

Event ID: 11709

Message	System alarm <i><name></i> has activated through relay
Category	Alarm
Severity	Information
Description	Event reported when system alarm has activated through relay

Event ID: 11710

Message	Input alarm <i><name></i> has activated through relay, triggered at
---------	---

	<code><trigger></code>
Category	Alarm
Severity	Information
Description	Event reported when input alarm has activated through relay

The following are the events related to ARP security.

Event ID: 10401

Message	ARP inspection <status> on vlan <vlan_id>.
Category	ARP security
Severity	Information
Description	ARP inspection configuration on VLAN

Event ID: 10402

Message	ARP inspection <status> on port <port_name>.
Category	ARP security
Severity	Information
Description	ARP inspection port mode configuration

The following are the events related to ASIC table full error for L3PD.

Event ID: 10801

Message	Neighbor add failure due to neighbor hardware full.' throttle_count: 1
Category	ASIC table full error for L3PD
Severity	Error
Description	Hardware table for NEIGHBOR entries are full, no new neighbors will be added.

Event ID: 10802

Message	Route add failure due to route hardware full' throttle_count: 1
Category	ASIC table full error for L3PD
Severity	Error
Description	Hardware table for ROUTE entries are full, no new route will be added.

Event ID: 10803

Message	Self IP add failure due to self ip hardware full
Category	ASIC table full error for L3PD
Severity	Error
Description	Hardware table for SELFIP entries are full, no new selfip will be added.

Event ID: 10804

Message	Custom route prefix tables configured from customer_override.yaml
Category	ASIC table full error for L3PD
Severity	Information
Description	Custom route prefix tables configured from customer_override.yaml

Event ID: 10805 (Severity: Warning)

Message	Error parsing LIST_ROUTE_IPV4_PREFIX in customer_override.yaml file
Category	ASIC table full error for L3PD
Severity	Warning
Description	Error parsing LIST_ROUTE_IPV4_PREFIX in customer_override.yaml file

Event ID: 10806 (Severity: Warning)

Message	Error parsing LIST_ROUTE_IPV6_PREFIX in customer_override.yaml file
Category	ASIC table full error for L3PD
Severity	Warning
Description	Error parsing LIST_ROUTE_IPV6_PREFIX in customer_override.yaml file

Event ID: 10807

Message	Using configured IPv4 prefix-priority list <prefix_list>.
Category	ASIC table full error for L3PD
Severity	Information
Description	Log configured ip prefix-priority list.

Event ID: 10808

Message	Using configured IPv6 prefix-priority list <prefix_list>.
Category	ASIC table full error for L3PD
Severity	Information
Description	Log configured ipv6 prefix-priority list.

Event ID: 10809

Message	HW programming failed for IPv4 prefix-priority <route_prefix>
Category	ASIC table full error for L3PD
Severity	Error
Description	Logs failure while configuring hardware for ipv4 prefix-priority.

Event ID: 10810

Message	HW programming failed for IPv6 prefix-priority <route_prefix>
---------	---

Category	ASIC table full error for L3PD
Severity	Error
Description	Logs failure while configuring hardware for ipv6 prefix-priority.

The following are the events related to BFD.

Event ID: 7301

Message	BFD was enabled
Category	BFD
Severity	Information
Description	Event raised when BFD is enabled globally

Event ID: 7302

Message	BFD was disabled
Category	BFD
Severity	Information
Description	Event raised when BFD is disabled globally

Event ID: 7303

Message	BFD echo was enabled
Category	BFD
Severity	Information
Description	Event raised when BFD echo is enabled globally

Event ID: 7304

Message	BFD echo was disabled
Category	BFD
Severity	Information
Description	Event raised when BFD is disabled globally

Event ID: 7305

Message	BFD echo was enabled on interface <intf>
Category	BFD
Severity	Information
Description	Event raised when BFD echo is enabled on an interface

Event ID: 7306

Message	BFD echo was disabled on interface <intf>
Category	BFD
Severity	Information
Description	Event raised when BFD is disabled on an interface

Event ID: 7307

Message	BFD session is up. session_id=<session_id>, vrf=<vrf>, op_mode=<op_mode>, src_port=<src_port>, dest_ip=<dest_ip>, local_state=<local_state>, local_diag=<local_diag>, remote_state=<remote_state>, remote_diag=<remote_diag>
Category	BFD
Severity	Information
Description	Event raised when a BFD session state becomes up

Event ID: 7308

Message	BFD session is down. session_id=<session_id>, vrf=<vrf>, op_mode=<op_mode>, src_port=<src_port>, dest_ip=<dest_ip>, local_state=<local_state>, local_diag=<local_diag>, remote_state=<remote_state>, remote_diag=<remote_diag>
Category	BFD
Severity	Information
Description	Event raised when a BFD session state becomes down

Event ID: 7309

Message	BFD session is administratively down. session_id=<session_id>, vrf=<vrf>, op_mode=<op_mode>, src_port=<src_port>, dest_ip=<dest_ip>, local_state=<local_state>, local_diag=<local_diag>, remote_state=<remote_state>, remote_diag=<remote_diag>
Category	BFD

Severity	Information
Description	Event raised when a BFD session is administratively down

Event ID: 7310

Message	BFD session was created without a source port
Category	BFD
Severity	Information
Description	Event raised when a BFD session is created without a source port

Event ID: 7311

Message	Port <name> can forward BFD traffic
Category	BFD
Severity	Information
Description	Event raised when a port used by BFD session can forward traffic

Event ID: 7312

Message	Port <name> can not forward BFD traffic
Category	BFD
Severity	Information
Description	Event raised when a port used by BFD session can not forward traffic

Event ID: 7313

Message	BFD sessions maximum active capacity reached
Category	BFD
Severity	Information
Description	Event raised when the maximum number of active BFD sessions is reached

Event ID: 7314 (Severity: Warning)

Message	The echo function for the BFD session <session_id> will not become active until a global echo source IP address is configured
Category	BFD

Severity	Warning
Description	Event raised when an Echo session is created without a valid echo_source IP address configured

Event ID: 7315

Message	BFD session is unidirectional. session_id=<session_id>, vrf=<vrf>, op_mode=<op_mode>, src_port=<src_port>, dest_ip=<dest_ip>, local_state=<local_state>, local_diag=<local_diag>, remote_state=<remote_state>, remote_diag=<remote_diag>
Category	BFD
Severity	Error
Description	Event raised when a BFD session state becomes unidirectional

Event ID: 7316 (Severity: Warning)

Message	BFD echo cannot be enabled on tunnels. interface=<intf>
Category	BFD
Severity	Warning
Description	Event raised when BFD echo is enabled on a Tunnel interface

Event ID: 7317 (Severity: Warning)

Message	BFD echo is not supported on IPv6 sessions
Category	BFD
Severity	Warning
Description	Event raised when BFD echo is enabled for a session using IPv6

Event ID: 7318

Message	IP Version mismatch for BFD. session_id=<session_id>, vrf=<vrf>, op_mode=<op_mode>, src_port=<src_port>, dest_ip=<dest_ip>, local_state=<local_state>, local_diag=<local_diag>, remote_state=<remote_state>, remote_diag=<remote_diag>, from=<from>, ip_version=<ip_version>, Invalid IP address: <addr>
Category	BFD
Severity	Error
Description	"Event raised when SRC or DST IP Version doesn't match the session's IP Version"

Event ID: 7319 (Severity: Warning)

Message	BFD single-hop is not supported on interface <i><intf></i>
Category	BFD
Severity	Warning
Description	"Event raised when a BFD single-hop session source port is a loopback"

Event ID: 7320 (Severity: Warning)

Message	BFD session interval override not supported for protocol <i><from></i>
Category	BFD
Severity	Warning
Description	"Event raised when a BFD session specifies an interval for a protocol that does not support override"

Event ID: 7321 (Severity: Warning)

Message	BFD session <i><direction></i> interval override of <i><requested_interval></i> ms is out of bounds for protocol <i><from></i> , using <i><applied_interval></i> ms instead
Category	BFD
Severity	Warning
Description	"Event raised when a BFD session specifies an interval outside the specified bounds"

The following are the events related to BGP.

Event ID: 2901

Message	<code><remote-addr>: Peer up. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs the changes in BGP connection state.

Event ID: 2902

Message	<code><remote-addr>: Peer down. error-code: <error-code>, error-sub-code: <error-subcode>. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs the failure in BGP connection state changes.

Event ID: 2903

Message	<code><remote-addr>: Peer has received prefix equal to Maximum Prefix value configured. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Trap when the number of received prefix reaches the maximum prefix value.

Event ID: 2904

Message	<code><remote-addr>: Peer has received prefix equal to Threshold value configured. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Trap when the number of received prefix reached the threshold value.

Event ID: 2905

Message	BGP AS <code><as_number></code> configured. vrf-name: <code><vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP enable event.

Event ID: 2906

Message	BGP AS <code><as_number></code> unconfigured. vrf-name: <code><vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP disable event.

Event ID: 2907

Message	BGP router-id changed. vrf-name: <code><vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP router-id change.

Event ID: 2908

Message	<code><remote_addr></code> : Peer configured, AS <code><remote_as></code> . vrf-name: <code><vrf-name></code>
Category	BGP
Severity	Information
Description	Logs creation of BGP peer.

Event ID: 2909

Message	<code><remote_addr></code> : User reset request. vrf-name: <code><vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP peer session reset event.

Event ID: 2910

Message	<code><remote_addr></code> : Peer password changed. vrf-name: <code><vrf-name></code>
---------	---

Category	BGP
Severity	Information
Description	Logs BGP peer password change event.

Event ID: 2911

Message	<code><remote_addr>: Peer deleted. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs deletion of BGP peer.

Event ID: 2912

Message	<code><remote_addr>: Peer admin disabled. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP peer admin disable event

Event ID: 2913

Message	<code><remote_addr>: Peer admin enabled. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP peer admin enable event.

Event ID: 2914

Message	<code><remote_addr>: Peer remote-as changed to <remote_as>. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP peer remote-as change event.

Event ID: 2915

Message	<code><remote_addr>: Peer local-as changed to <local_as>. vrf-name: <vrf-name></code>
---------	---

Category	BGP
Severity	Information
Description	BGP peer local-as change event.

Event ID: 2916

Message	<code><remote_addr>: Peer source-address changed to <src_ipaddr>. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs peer source address change event.

Event ID: 2917

Message	<code><remote_addr>: Peer remove-private-as configuration changed. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs configuration of peer remove-private-as.

Event ID: 2918

Message	<code><bgp_id>: BGP identifier sent by Peer <remote_addr> matches ours. BGP session may not established. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs peer identifier has been matched with local identifier.

Event ID: 2919 (Severity: Critical)

Message	<code>The BGP RIB has reached the threshold limit of <threshold_limit> for VRF <vrf-name>': yes</code>
Category	BGP
Severity	Critical
Description	Trap when the rib size reaches the threshold value.

Event ID: 2920

Message	<code><pg_name>: Peer-group configured with remote-as <remote_as>. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs BGP peer-group remote-as configuration event.

Event ID: 2921

Message	<code><remote_addr>: Peer ignore-leading-as configuration changed. vrf-name: <vrf-name></code>
Category	BGP
Severity	Information
Description	Logs configuration of peer ignore-leading-as.

The following are the events related to Bluetooth management.

Event ID: 8001

Message	Bluetooth has been <code><enabled_disabled></code>
Category	Bluetooth Management
Severity	Information
Description	Event raised when Bluetooth is enabled or disabled

Event ID: 8002 (Severity: Warning)

Message	Bluetooth unable to trust pairing device
Category	Bluetooth Management
Severity	Warning
Description	Event raised when Bluetooth is unable to trust pairing device

Event ID: 8003

Message	Bluetooth adapter <code><inserted_removed></code>
Category	Bluetooth Management
Severity	Information
Description	Event raised when btd receives signal for Bluetooth adapter event

Event ID: 8004

Message	Bluetooth device <code><connected_disconnected></code> : <code><mac_address></code>
Category	Bluetooth Management
Severity	Information
Description	Event raised when btd receives signal for Bluetooth device event

Event ID: 8005 (Severity: Warning)

Message	Bluetooth device rejected because another device is already connected
Category	Bluetooth Management
Severity	Warning
Description	Event raised when btd disconnects a newly paired device because another device is already connected

The following are the events related to CDP.

Event ID: 8901

Message	CDP Enabled
Category	CDP
Severity	Information
Description	Logs CDP enabled

Event ID: 8902

Message	CDP Disabled
Category	CDP
Severity	Information
Description	Logs CDP disabled

Event ID: 8903

Message	CDP neighbor <mac> is added on <interface>
Category	CDP
Severity	Information
Description	Log to indicate CDP neighbor addition

Event ID: 8904

Message	CDP neighbor <mac> is updated on <interface>' throttle_count: 100
Category	CDP
Severity	Information
Description	Log to indicate CDP neighbour modification

Event ID: 8905

Message	CDP neighbor <mac> is deleted on <interface>
Category	CDP
Severity	Information
Description	Log to indicate CDP neighbor deletion

Event ID: 8906

Message	All CDP neighbor info cleared
Category	CDP
Severity	Information
Description	Log to indicate all CDP neighbor info is cleared

The following are the events related to certificate management.

Event ID: 7701

Message	TA Profile <name> created
Category	Certificate management
Severity	Information
Description	Event raised when a ta profile is created

Event ID: 7702

Message	TA Profile <name> deleted
Category	Certificate management
Severity	Information
Description	Event raised when a ta profile is removed

Event ID: 7703

Message	Leaf certificate <name> imported
Category	Certificate management
Severity	Information
Description	Event raised when a leaf certificate is imported

Event ID: 7704

Message	Leaf certificate <name> deleted
Category	Certificate management
Severity	Information
Description	Event raised when a leaf certificate is deleted

Event ID: 7705 (Severity: Warning)

Message	Certificate <name> will expire within <days> days
Category	Certificate management
Severity	Warning
Description	Event raised when an installed certifiante will expire within 60 days

Event ID: 7706 (Severity: Warning)

Message	Certificate <name> has not yet reached its start date
Category	Certificate management
Severity	Warning
Description	Event raised when an installed certifiante is not yet past its start date

Event ID: 7707 (Severity: Warning)

Message	Certificate <name> has expired and can no longer be used
Category	Certificate management
Severity	Warning
Description	Event raised when an installed certifiante has expired

Event ID: 7708

Message	Certificate <name> verified and accepted' throttle_count: 100
Category	Certificate management
Severity	Information
Description	Event raised when a certificate chain is verified

Event ID: 7709 (Severity: Warning)

Message	Certificate <name> rejected due to verification failure (<error>)' throttle_count: 100
Category	Certificate management
Severity	Warning
Description	Event raised when a certificate chain is rejected

Event ID: 7710

Message	Certificate signing request <name> created
Category	Certificate management
Severity	Information
Description	Event raised when a certificate signing request is created on the switch

Event ID: 7711

Message	Self-signed certificate <name> created
Category	Certificate management
Severity	Information
Description	Event raised when a self-signed certificate is created on the switch

Event ID: 7712

Message	Application association with the <name> certificate is not permitted
Category	Certificate management
Severity	Error
Description	Event raised when an invalid certificate association is made

Event ID: 7713 (Severity: Warning)

Message	Certificate <name> failed OCSP verification (<status>), but was accepted because OCSP enforcement is set to optional.' throttle_count: 100
Category	Certificate management
Severity	Warning
Description	Event raised when a certificate is verified due to optional OCSP enforcement

Event ID: 7714

Message	CA certificates successfully downloaded from EST server <name>
Category	Certificate management
Severity	Information
Description	Event raised when CA certificates were successfully downloaded from an EST server

Event ID: 7715

Message	Failed to download CA certificates from EST server <name>
Category	Certificate management
Severity	Error
Description	Event raised when CA certificates could not be downloaded from an EST server

Event ID: 7716

Message	Certificate <name> successfully enrolled by EST server <est_name>
Category	Certificate management
Severity	Information
Description	Event raised when a certificate is successfully enrolled with EST

Event ID: 7717

Message	Failed to enroll certificate <name> with EST server <est_name>
Category	Certificate management
Severity	Error
Description	Event raised when certificate enrollment with an EST server fails

Event ID: 7718

Message	Certificate <name> successfully reenrolled by EST server <est_name>
Category	Certificate management
Severity	Information
Description	Event raised when a certificate is successfully reenrolled with EST

Event ID: 7719

Message	Failed to reenroll certificate <name> with EST server <est_name>
Category	Certificate management
Severity	Error
Description	Event raised when certificate reenrollment with an EST server fails

Event ID: 7720 (Severity: Warning)

Message	Certificate <name> is not set for signing purpose
---------	---

Category	Certificate management
Severity	Warning
Description	Event raised when a signer certificate is not set for signing

Event ID: 7721 (Severity: Warning)

Message	Certificate <name> is invalid or malformed
Category	Certificate management
Severity	Warning
Description	Event raised when an installed certificate is invalid or malformed

The following are the events related to config management.

Event ID: 6801

Message	Copying configs from: <i><from></i> to: <i><to></i>
Category	Config Management
Severity	Information
Description	Logs a message when configs copying from one format to another

Event ID: 6802

Message	Error while copying configs. Error: <i><error></i>
Category	Config Management
Severity	Error
Description	Logs a message when copying config has some error

Event ID: 6803

Message	<i><type>: <value></i>
Category	Config Management
Severity	Information
Description	Logs a message when config validation prunes tables/columns in startup-config or when errors are encountered

Event ID: 6804

Message	Error while copying configs. Error: <i><error></i>
Category	Config Management
Severity	Error
Description	Logs a message when copying config to shadowdb has some error

Event ID: 6805

Message	Information while copying configs. Info: <i><info></i>
Category	Config Management
Severity	Information
Description	Logs a message when copying config has some information

The following are the events related to Connectivity Fault Management (CFM).

Event ID: 11601

Message	Connection lost for Maintenance Endpoint <id> on <interface>.
Category	Connectivity Fault Management (CFM)
Severity	Error
Description	Event reported when connection is lost on the Maintenance Endpoint.

Event ID: 11602

Message	Connection restored for Maintenance Endpoint <id> on <interface>.
Category	Connectivity Fault Management (CFM)
Severity	Information
Description	Event reported when connection is restored on the Maintenance Endpoint.

The following are the events related to console.

Event ID: 13001

Message	User <user_name> logged in from <ip_address> through CONSOLE session.
Category	Console
Severity	Information
Description	Logs a message when a user login is successful

Event ID: 13002

Message	User <user_name> login from <ip_address> for CONSOLE session has failed.
Category	Console
Severity	Error
Description	Logs a message when a user login fails

Event ID: 13003

Message	User <user_name> logged out of CONSOLE session from <ip_address>.
Category	Console
Severity	Information
Description	Logs a message when a user logs out of a session

Event ID: 13004 (Severity: Warning)

Message	CONSOLE session from User <user_name> is closed because maximum number of sessions per user is reached.
Category	Console
Severity	Warning
Description	Logs a message when a user tries to login while maximum number of sessions per user are reached.

The following are the events related to container manager.

Event ID: 11801

Message	Container <i><name></i> is created
Category	Container manager
Severity	Information
Description	Event reported when container is created

Event ID: 11802

Message	Container <i><name></i> is removed
Category	Container manager
Severity	Information
Description	Event reported when container is removed

Event ID: 11803

Message	Container <i><name></i> is operational
Category	Container manager
Severity	Information
Description	Event reported when container is operational

The following are the events related to control plane policing.

Event ID: 1501

Message	COPP initialization failed
Category	CoPP
Severity	Error
Description	Logs COPP initialization failure.

Event ID: 1502

Message	COPP initialization successful
Category	CoPP
Severity	Information
Description	Logs COPP initialization success.

Event ID: 1503

Message	Ingress FP Group create failed
Category	CoPP
Severity	Error
Description	Logs ingress field processor group creation failure.

Event ID: 1504

Message	Egress FP Group create failed
Category	CoPP
Severity	Error
Description	Logs egress field processor group creation failure.

Event ID: 1505

Message	Programming defaults failed
Category	CoPP
Severity	Error
Description	Logs failure for initialization of default values.

Event ID: 1506

Message	Packet class programming failed for <class>
Category	CoPP
Severity	Error
Description	Logs failure of programming queue for a CoPP packet class.

Event ID: 1507

Message	Failed to program ingress field processor rule for <class>
Category	CoPP
Severity	Error
Description	Logs failure of programming ingress field processor for a CoPP class.

Event ID: 1508

Message	Failed to program egress rule for <class>
Category	CoPP
Severity	Error
Description	Logs failure of programming egress field processor for a CoPP class.

Event ID: 1509

Message	CoPP initial initialization failed on slot <slot>
Category	CoPP
Severity	Error
Description	Logs CoPP initial initialization failure on a slot.

Event ID: 1510

Message	CoPP final initialization failed on slot <slot>
---------	---

Category	CoPP
Severity	Error
Description	Logs CoPP final initialization failure on a slot.

Event ID: 1511

Message	CoPP deinitialization failed on slot <i><slot></i>
Category	CoPP
Severity	Error
Description	Logs CoPP deinitialization failure on a slot.

Event ID: 1512

Message	Failed to configure hardware for CoPP on slot <i><slot></i> class <i><class></i>
Category	CoPP
Severity	Error
Description	Logs failure while configuring hardware on a slot for a CoPP class.

Event ID: 1513

Message	Failed to retrieve CoPP statistics from slot <i><slot></i> class <i><class></i>
Category	CoPP
Severity	Error
Description	Logs failure while retrieving statistics on a slot for a CoPP class.

The following are the events related to CPU_RX.

Event ID: 7501

Message	Kernel filter "<action>" failed on unit <unit> for <filter_description>
Category	CPU_RX
Severity	Information
Description	Event raised when a kernel filter cannot be created or deleted

Event ID: 7502

Message	Cannot create kernel filter on unit <unit> for <filter_description>. All filters are in use. Configuring fewer per-port features can help with this issue.
Category	CPU_RX
Severity	Error
Description	Event raised when a kernel filter cannot be created because all filters are in use

The following are the events related to credential manager.

Event ID: 6501 (Severity: Warning)

Message	An internal error occurred while reading the export password and default export password was used instead.
Category	Credential Manager
Severity	Warning
Description	Warns the user that export password file was corrupted and default passwd was used instead.

Event ID: 6502 (Severity: Warning)

Message	A critical system file has been corrupted. Please configure your export password to the one used by your most recent configuration export and import your most recent configuration.
Category	Credential Manager
Severity	Warning
Description	Warns the user that the chassis secret has been corrupted.

Event ID: 6504

Message	Self-signed certificate successfully created for the https-server.
Category	Credential Manager
Severity	Information
Description	Logs a message when the self-signed cert is created by credmgr.

Event ID: 6505

Message	User admin password changed from ServiceOS
Category	Credential Manager
Severity	Information
Description	Logs a message when a user changes admin password from ServiceOS

Event ID: 6506

Message	SSH authorized keys were added for user <user>
Category	Credential Manager
Severity	Information
Description	Logs a message when SSH authorized keys are added for a user

Event ID: 6507

Message	Failed to write SSH authorized keys for user <user>
Category	Credential Manager
Severity	Error
Description	Logs a message after a failure to write SSH authorized keys for a user

Event ID: 6508

Message	SSH authorized keys deleted for user <user>
Category	Credential Manager
Severity	Information
Description	Logs a message afte deleting SSH authorized keys for a user

Event ID: 6509

Message	User <user> has configured an invalid SSH authorized key with key identifier <key-id>
Category	Credential Manager
Severity	Error
Description	Logs a message when SSH authorized key fails validation chack

The following are the events related to device fingerprinting.

Event ID: 12401 (Severity: Warning)

Message	Reached the maximum number of clients limit on the switch for device fingerprinting.
Category	Device fingerprinting
Severity	Warning
Description	Log the event when the maximum client limit for device fingerprinting is reached on the switch.

Event ID: 12402 (Severity: Warning)

Message	Reached the maximum clients limit of <code><client_limit></code> on the interface <code><interface></code> for device fingerprinting.
Category	Device fingerprinting
Severity	Warning
Description	Log the event when the per port clients limit for device fingerprinting is reached.

The following are the events related to DHCP relay.

Event ID: 3401

Message	DHCP Relay Enabled
Category	DHCP Relay
Severity	Information
Description	This command enables the DHCP Relay feature in the device.

Event ID: 3402

Message	DHCP Relay Disabled
Category	DHCP Relay
Severity	Information
Description	This command disables the DHCP Relay feature in the device.

The following are the events related to DHCP server.

Event ID: 1901

Message	DHCP Lease added <expiry_time> <mac> <ip> <host> <client_id>
Category	DHCP server
Severity	Information
Description	Logs DHCP lease addition

Event ID: 1902

Message	DHCP Lease deleted <expiry_time> <mac> <ip> <host> <client_id>
Category	DHCP server
Severity	Information
Description	Logs DHCP lease deletion

Event ID: 1903

Message	DHCP Lease updated <expiry_time> <mac> <ip> <host> <client_id>
Category	DHCP server
Severity	Information
Description	Logs DHCP lease updation

Event ID: 1904

Message	DHCP Lease addition failed <expiry_time> <mac> <ip> <host> <client_id>
Category	DHCP server
Severity	Error
Description	Logs failure in DHCP lease addition

Event ID: 1905

Message	DHCP Lease deletion failed <code><expiry_time> <mac> <ip> <host> <client_id></code>
Category	DHCP server
Severity	Error
Description	Logs failure in DHCP lease deletion

Event ID: 1906

Message	DHCP Lease update failed <code><expiry_time> <mac> <ip> <host> <client_id></code>
Category	DHCP server
Severity	Error
Description	Logs failure in DHCP lease updation

Event ID: 1907

Message	DHCP server enabled on VRF <code><vrf_name></code>
Category	DHCP server
Severity	Information
Description	Event raised when DHCP server gets enabled on the VRF

Event ID: 1908

Message	DHCP server disabled on VRF <code><vrf_name></code>
Category	DHCP server
Severity	Information
Description	Event raised when DHCP server gets disabled on the VRF

Event ID: 1909

Message	Invalid DHCP configuration: <code><config></code> provided on DHCP Server instance running on VRF <code><vrf_name></code> . Ignoring this config.
Category	DHCP server
Severity	Error
Description	Event raised when user configures an invalid DHCP configuration

Event ID: 1910

Message	DHCP Server Lease cleared on vrf <vrf>.
Category	DHCP server
Severity	Information
Description	Event raised when DHCP Server Lease on the VRF is cleared

Event ID: 1911

Message	DHCPv6 Server Lease cleared on vrf <vrf>.
Category	DHCP server
Severity	Information
Description	Event raised when DHCPv6 Server Lease on the VRF is cleared

The following are the events related to DHCPv4 snooping.

Event ID: 8201 (Severity: Warning)

Message	Server <code><ip_address></code> packet received on untrusted port <code><port></code> dropped.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when packet dropped while server packet received on untrusted port.

Event ID: 8202 (Severity: Warning)

Message	Client packet destined to untrusted port <code><port></code> dropped.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when client packet dropped while packet destined to untrusted port.

Event ID: 8203 (Severity: Warning)

Message	Packet received from unauthorized server <code><ip_address></code> on port <code><port></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when packet dropped while packet received from unauthorized server.

Event ID: 8204 (Severity: Warning)

Message	Received untrusted relay info from client <code><mac></code> on port <code><port></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when client packet received with untrusted relay info.

Event ID: 8205 (Severity: Warning)

Message	Client address <code><client_mac></code> not equal to source MAC <code><source_mac></code> detected on port <code><port></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when client address not equal to source MAC.

Event ID: 8206 (Severity: Warning)

Message	Binding for <code><ip_address>:<mac></code> exists on port <code><existing_port></code> . Dropping release request received for the binding on <code><new_port></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when release packet received on incorrect port.

Event ID: 8207 (Severity: Warning)

Message	The dynamic binding for <code><mac></code> on port <code><port></code> was replaced with a manual binding.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when dynamic binding for a port was replaced with a manual binding.

Event ID: 8208 (Severity: Warning)

Message	Drop request from <code><mac></code> for already assigned address <code><ip_address></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when drop client request for already assigned ip.

Event ID: 8209 (Severity: Warning)

Message	Drop offer from <code><server_ip_address></code> of already assigned address <code><lease_ip_address></code> to <code><mac></code> .
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when drop server offer for already assigned ip.

Event ID: 8210 (Severity: Warning)

Message	Drop offer from <server_ip_address> of <lease_ip_address> address is illegal.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when drop server offer for illegal ip.

Event ID: 8211 (Severity: Warning)

Message	Maximum bindings limit reached on port <port>, dropping request from <mac>.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when binding limit reached on port.

Event ID: 8212

Message	All the dynamic binding entries were cleared.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when all dynamic binding entries are cleared.

Event ID: 8213

Message	Dynamic binding entries on the port <port> were cleared.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when all dynamic binding entries on a port are cleared.

Event ID: 8214

Message	Dynamic binding entries on the VLAN <vid> were cleared.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when all dynamic binding entries on a vlan are cleared.

Event ID: 8215

Message	Dynamic binding entry with ip <ip> on the VLAN <vid> was cleared.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when a specific dynamic binding entry on a vlan is cleared.

Event ID: 8216

Message	Failed to import dynamic ip binding entries from external storage. volume: <volume_name>, filename: <file_name>.
Category	DHCPv4 snooping
Severity	Error
Description	Log event when failed to import dynamic ip binding entries from external storage.

Event ID: 8217

Message	Failed to import dynamic ip binding entries from local storage. filepath: <file_path>.
Category	DHCPv4 snooping
Severity	Error
Description	Log event when failed to import dynamic ip binding entries from local storage.

Event ID: 8218 (Severity: Warning)

Message	Flash-storage is active for DHCPv4-Snooping.
Category	DHCPv4 snooping
Severity	Warning
Description	Log event when flash-storage becomes active after external-storage unconfiguration.

Event ID: 8219

Message	Successfully imported <bindings_imported> dynamic ip binding entries from external storage. volume: <volume_name>, filename: <file_name>.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when dynamic ip binding entries from external storage are successfully imported.

Event ID: 8220

Message	Successfully imported <bindings_imported> dynamic ip binding entries from local storage.
Category	DHCPv4 snooping
Severity	Information
Description	Log event when dynamic ip binding entries from local storage are successfully imported.

Event ID: 8221

Message	Client <mac> on vlan <vid>, port <port> received <client_ip> from server <server_ip> with lease <lease>. Nameserver: <nameserver_ip>, Gateway:<gateway_ip>.
Category	DHCPv4 snooping
Severity	Information
Description	Client received an IP address from DHCP server.

Event ID: 8222

Message	Client <mac> on vlan <vid>, port <port> released <client_ip>.
Category	DHCPv4 snooping
Severity	Information
Description	Client releases IP address.

Event ID: 8223

Message	Client <mac> on vlan <vid>, port <port> lease period expired for <client_ip>.
Category	DHCPv4 snooping
Severity	Information
Description	Client's lease period expired.

Event ID: 8224

Message	Client <mac> on vlan <vid>, port <port> with <client_ip>. Client attributes updated: Gateway <gateway_ip>, Nameserver: <nameserver_ip>, Lease period <lease>.
Category	DHCPv4 snooping
Severity	Information
Description	Client attributes received for DHCP client.

The following are the events related to DHCPv6 relay.

Event ID: 3301

Message	DHCPv6 Relay Enabled
Category	DHCPv6 Relay
Severity	Information
Description	This command enables the DHCPv6 Relay feature in the device.

Event ID: 3302

Message	DHCPv6 Relay Disabled
Category	DHCPv6 Relay
Severity	Information
Description	This command disables the DHCPv6 Relay feature in the device.

The following are the events related to DHCPv6 snooping.

Event ID: 8301 (Severity: Warning)

Message	Server <code><ipv6_address></code> packet received on untrusted port <code><port></code> dropped.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when packet dropped while server packet received on untrusted port.

Event ID: 8302 (Severity: Warning)

Message	Client packet destined to untrusted port <code><port></code> dropped.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when client packet dropped while packet destined to untrusted port.

Event ID: 8303 (Severity: Warning)

Message	Packet received from unauthorized server <code><ipv6_address></code> on port <code><port></code> .
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when packet dropped while packet received from unauthorized server.

Event ID: 8304 (Severity: Warning)

Message	Received untrusted relay info from client <code><mac></code> on port <code><port></code> .
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when client packet received with untrusted relay info.

Event ID: 8305 (Severity: Warning)

Message	Binding for <ipv6_address>:<mac> exists on port <existing_port>. Dropping release request received for the binding on <new_port>.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when release packet received on incorrect port.

Event ID: 8306 (Severity: Warning)

Message	The dynamic binding for <mac> on port <port> was replaced with a manual binding.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when dynamic binding for a port was replaced with a manual binding.

Event ID: 8307 (Severity: Warning)

Message	Drop request from <mac> for already assigned address <ipv6_address>.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when drop client request for already assigned ip.

Event ID: 8308 (Severity: Warning)

Message	Maximum bindings limit reached on port <port>, dropping request from <mac>.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when binding limit reached on port.

Event ID: 8309

Message	All the dynamic binding entries were cleared.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when all dynamic binding entries are cleared.

Event ID: 8310

Message	Dynamic binding entries on the port <i><port></i> were cleared.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when all dynamic binding entries on a port are cleared.

Event ID: 8311

Message	Dynamic binding entries on the VLAN <i><vid></i> were cleared.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when all dynamic binding entries on a vlan are cleared.

Event ID: 8312

Message	Dynamic binding entry with ip <i><ip></i> on the VLAN <i><vid></i> was cleared.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when a specific dynamic binding entry on a vlan is cleared.

Event ID: 8313

Message	Failed to import dynamic ip binding entries from external storage. volume:" <i><volume_name></i> , filename:" <i><file_name></i> .
Category	DHCPv6 snooping
Severity	Error
Description	Log event when import of dynamic binding entries from external storage is failed.

Event ID: 8314

Message	Failed to import dynamic ip binding entries from local storage. filepath:" <i><file_path></i> .
Category	DHCPv6 snooping
Severity	Error
Description	Log event when import of dynamic binding entries from local storage is failed.

Event ID: 8315 (Severity: Warning)

Message	Flash-storage is active for DHCPv6-Snooping.
Category	DHCPv6 snooping
Severity	Warning
Description	Log event when flash-storage becomes active after external-storage unconfiguration.

Event ID: 8316

Message	Successfully imported <bindings_imported> dynamic ip binding entries from external storage. volume: <volume_name>, filename: <file_name>.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when dynamic ip binding entries from external storage are successfully imported.

Event ID: 8317

Message	Successfully imported <bindings_imported> dynamic ip binding entries from local storage.
Category	DHCPv6 snooping
Severity	Information
Description	Log event when dynamic ip binding entries from local storage are successfully imported.

Event ID: 8318

Message	Client <mac> on vlan <vid>, port <port> received <client_ip> from server <server_ip> with lease <lease>. Nameserver: <nameserver_ip>.
Category	DHCPv6 snooping
Severity	Information
Description	Client received an IPv6 address from DHCP server.

Event ID: 8319

Message	Client <mac> on vlan <vid>, port <port> released <client_ip>.
Category	DHCPv6 snooping
Severity	Information
Description	Client sent a release to DHCP server.

Event ID: 8320

Message	Client <mac> on vlan <vid>, port <port> lease period expired for <client_ip>.
Category	DHCPv6 snooping
Severity	Information
Description	Lease period expired for DHCP client.

Event ID: 8321

Message	Client <mac> on vlan <vid>, port <port> with <client_ip>. Client attributes updated: Nameserver <nameserver_ip>, Lease period <lease>.
Category	DHCPv6 snooping
Severity	Information
Description	Client attributes received for DHCP client.

The following are the events related to DCBx.

Event ID: 9201

Message	DCBX Enabled
Category	Dicoverry and Capability Exchange (DCBx)
Severity	Information
Description	Logs event when DCBX is globally enabled

Event ID: 9202

Message	DCBX Disabled
Category	Dicoverry and Capability Exchange (DCBx)
Severity	Information
Description	Log event when DCBX is globally disabled

Event ID: 9203

Message	DCBX is enabled on interface <code><intf_name></code>
Category	Dicoverry and Capability Exchange (DCBx)
Severity	Information
Description	Log event when DCBX is enabled on the interface

Event ID: 9204

Message	DCBX is disabled on interface <code><intf_name></code>
Category	Dicoverry and Capability Exchange (DCBx)
Severity	Information
Description	Log event when DCBX is disabled on the interface

Event ID: 9205

Message	DCBX status active on interface <code><intf_name></code>
Category	Discovery and Capability Exchange (DCBx)
Severity	Information
Description	Log event when DCBX oper status is active on an interface

Event ID: 9206

Message	DCBX status inactive on interface <code><intf_name></code>
Category	Discovery and Capability Exchange (DCBx)
Severity	Information
Description	Log event when DCBX oper status is inactive on an interface

Event ID: 9207

Message	PFC TLV status active on interface <code><intf_name></code>
Category	Discovery and Capability Exchange (DCBx)
Severity	Information
Description	Log event when PFC TLVs are active on an interface

Event ID: 9208

Message	PFC TLV status inactive on interface <code><intf_name></code>
Category	Discovery and Capability Exchange (DCBx)
Severity	Information
Description	Log event when PFC TLVs are inactive on an interface

Event ID: 9209 (Severity: Warning)

Message	PFC TLV status priority mismatch on interface <code><intf_name></code>
Category	Discovery and Capability Exchange (DCBx)
Severity	Warning
Description	Log event when there is PFC TLV priority mismatch on an interface

The following are the events related to DNS client.

Event ID: 11901

Message	<code><type> event for VRF <vrf_name></code>
Category	DNS client
Severity	Information
Description	Event reported when DNS event triggered

The following are the events related to dot1x supplicant.

Event ID: 12301

Message	802.1X supplicant has blocked the interface <i><ifname></i> .
Category	Dot1x supplicant
Severity	Information
Description	The 802.1X supplicant is blocking the interface on the data-plane.

Event ID: 12302

Message	802.1X supplicant has unblocked the interface <i><ifname></i> .
Category	Dot1x supplicant
Severity	Information
Description	The 802.1X supplicant is opening the interface on the data-plane.

Event ID: 12303

Message	802.1X supplicant PAE restarted on interface <i><ifname></i> due to change in policy <i><policy></i> .
Category	Dot1x supplicant
Severity	Information
Description	The 802.1X supplicant PAE is restarted due to a change in the policy used on the interface.

Event ID: 12304

Message	802.1X supplicant is not supported on the port <i><port></i> .
Category	Dot1x supplicant
Severity	Information
Description	The 802.1X supplicant is enabled on a port that is not supported (Ex: LAG, ROP).

The following are the events related to DPSE.

Event ID: 10901 (Severity: Critical)

Message	Line card module <code><linecard_name></code> triggered backplane sequence recovery
Category	DPSE
Severity	Critical
Description	A line card hit a backplane sequence error that triggered a recovery operation

Event ID: 10902

Message	HA event triggered backplane sequence recovery
Category	DPSE
Severity	Information
Description	A backplane sequence reset was triggered due to an HA event

Event ID: 10903

Message	HA event completed backplane sequence recovery
Category	DPSE
Severity	Information
Description	The system completed a backplane sequence reset triggered by an HA event

Event ID: 10904 (Severity: Critical)

Message	Line card module <code><linecard_name></code> completed backplane sequence recovery
Category	DPSE
Severity	Critical
Description	The system completed backplane sequence recovery triggered by line card error

Event ID: 10905

Message	No active modules have been detected in the system.
Category	DPSE
Severity	Information
Description	No active modules have been detected in the system.

Event ID: 10906 (Severity: Critical)

Message	Control Plane (<operation_name>) failure during (<plugin_name>) configuration
Category	DPSE
Severity	Critical
Description	An ops-switchd plugin failed executing an operation

The following are the events related to ECMP.

Event ID: 1801

Message	Failed to update ecmp object for route <code><route></code> , error: <code><err></code>
Category	ECMP
Severity	Error
Description	logs errors while creating ecmp group.

Event ID: 1802

Message	Update ecmp object for route <code><route></code>
Category	ECMP
Severity	Information
Description	logs while creating ecmp group.

Event ID: 1803

Message	Failed to delete ecmp egress object <code><egressid></code> , error: <code><err></code>
Category	ECMP
Severity	Error
Description	logs errors while deleting ecmp group.

Event ID: 1804

Message	Delete ecmp egress object <code><egressid></code>
Category	ECMP
Severity	Information
Description	logs while deleting ecmp group.

Event ID: 1805

Message	ECMP error: <err>
Category	ECMP
Severity	Error
Description	logs for ECMP setup errors.

The following are the events related to ERPS.

Event ID: 8501 (Severity: Warning)

Message	Expected R-APS packets not received on <code><ifID></code> in ring <code><ringID></code> with control VLAN <code><ccvlan></code>
Category	ERPS
Severity	Warning
Description	Log event when RAPS messages are not received for a certain time interval

Event ID: 8502 (Severity: Warning)

Message	Misconfiguration detected on ring <code><ringID></code> with control VLAN <code><ccvlan></code> . Another node in the ring with mac <code><node></code> is also operating as an RPL owner
Category	ERPS
Severity	Warning
Description	Log event when a ring misconfiguration happens

Event ID: 8503

Message	Operational state of the ring <code><ringID></code> , instance <code><instanceID></code> changed to <code><state></code>
Category	ERPS
Severity	Information
Description	Log state transition of ring instance

Event ID: 8504

Message	<code><interfaceName></code> is not an L2 port
Category	ERPS
Severity	Information
Description	Log event when ring is configured with a non-L2 port

Event ID: 8505

Message	<code><interfaceName> is already associated with <portName> of ERPS ring <ringID></code>
Category	ERPS
Severity	Information
Description	Log event when an interface which is already associated to a ring port is getting mapped to other ring port as well

Event ID: 8506

Message	<code>Configured control-channel VLAN <ccVlan> is already protected by ERPS ring <ringID>, instance <instanceID></code>
Category	ERPS
Severity	Information
Description	Log event when control-channel VLAN is part of the protected-vlans

Event ID: 8507

Message	<code>VLAN <ccVlan> is already configured as control-channel for instance <instanceID> of ring <ringID></code>
Category	ERPS
Severity	Information
Description	Log event when control-channel VLAN overlaps with another control-channel of same ring

Event ID: 8508

Message	<code>Vlan <dataVlan> is already part of the protected VLAN set of ring <ringID> instance <instanceID></code>
Category	ERPS
Severity	Information
Description	Log event when protected-vlan(s) overlap

Event ID: 8509

Message	<code>Control VLAN must not be same on parent and sub rings</code>
Category	ERPS

Severity	Information
Description	Log event when same control-channel VLAN is configured on both major and sub-rings

Event ID: 8510

Message	Parent-ring <i><ringID></i> is same as sub-ring
Category	ERPS
Severity	Information
Description	Log event when parent-ring id is configured to be the same as sub-ring

Event ID: 8511

Message	VLAN <i><vlanID></i> in the protected VLANs list is also configured as the control-channel
Category	ERPS
Severity	Information
Description	Log event when VLAN from the protected-vlans list is already configured as control-channel VLAN

Event ID: 8512

Message	<i><portName></i> is already configured as RPL port for instance <i><instanceID></i>
Category	ERPS
Severity	Information
Description	Log event if the same ring port is configured as RPL port for more than one instance

Event ID: 8513

Message	RPL configuration is not allowed on ISL port <i><interfaceName></i>
Category	ERPS
Severity	Information
Description	Log event if ring port which is also an ISL is being configured as RPL

Event ID: 8514

Message	Protected VLAN set of instance in sub-ring should map to same instance in the parent ring
---------	---

Category	ERPS
Severity	Information
Description	Log event if protected-vlan set of sub-ring is not a subset of the major-ring

Event ID: 8515

Message	Operational state of the ring <i><ringID></i> , instance <i><instanceID></i> changed to Initializing with reason <i><reason></i>
Category	ERPS
Severity	Information
Description	Log transition of state of ring instance to initializing and the reason for it

The following are the events related to EVPN.

Event ID: 9501

Message	EVPN EVI: <code><evi></code> created
Category	EVPN
Severity	Information
Description	Logs EVPN EVI create event.

Event ID: 9502

Message	EVPN EVI: <code><evi></code> deleted
Category	EVPN
Severity	Information
Description	Logs EVPN EVI delete event.

Event ID: 9503

Message	EVPN RD: <code><rd></code> updated for EVI: <code><evi></code>
Category	EVPN
Severity	Information
Description	Logs EVPN RD update event for an EVI.

Event ID: 9504

Message	EVPN RD deleted for EVI: <code><evi></code>
Category	EVPN
Severity	Information
Description	Logs EVPN RD delete event for an EVI.

Event ID: 9505

Message	EVPN RT: <code><rt></code> created for EVI: <code><evi></code>
Category	EVPN
Severity	Information
Description	Logs EVPN RT create event for an EVI.

Event ID: 9506

Message	EVPN RT: <code><rt></code> deleted for EVI: <code><evi></code>
Category	EVPN
Severity	Information
Description	Logs EVPN RT delete event for an EVI.

Event ID: 9507

Message	EVPN RT: <code><rt></code> updated for EVI: <code><evi></code>
Category	EVPN
Severity	Information
Description	Logs EVPN RT update event for an EVI.

Event ID: 9508

Message	VNI: <code><vni></code> is added for EVPN Peer VTEP: <code><vtep_ip></code>
Category	EVPN
Severity	Information
Description	Logs EVPN VTEP VNI add event.

Event ID: 9509

Message	VNI: <code><vni></code> is deleted for EVPN Peer VTEP: <code><vtep_ip></code>
Category	EVPN
Severity	Information
Description	Logs EVPN VTEP VNI delete event.

Event ID: 9510

Message	EVPN static MAC conflict <code><action></code> , MAC: <code><mac_addr></code> , IP address: <code><ip_addr></code> , VTEP: <code><vtep_ip></code>
---------	---

Category	EVPN
Severity	Error
Description	Logs EVPN static MAC conflict event.

Event ID: 9511

Message	EVPN static MAC conflict <i><action></i> , MAC: <i><mac_addr></i>
Category	EVPN
Severity	Error
Description	Logs EVPN static MAC conflict event.

Event ID: 9512

Message	EVPN duplicate MAC dampening <i><action></i> , MAC: <i><mac_addr></i>
Category	EVPN
Severity	Error
Description	Logs EVPN duplicate MAC dampening event.

Event ID: 9513

Message	EVPN VRF: <i><vrf></i> created
Category	EVPN
Severity	Information
Description	Logs EVPN VRF create event.

Event ID: 9514

Message	EVPN VRF: <i><vrf></i> deleted
Category	EVPN
Severity	Information
Description	Logs EVPN VRF delete event.

Event ID: 9515

Message	EVPN RD: <i><rd></i> updated for VRF: <i><vrf></i>
Category	EVPN

Severity	Information
Description	Logs EVPN VRF RD update event.

Event ID: 9516

Message	EVPN RT: <code><rt></code> created for VRF: <code><vrf></code>
Category	EVPN
Severity	Information
Description	Logs EVPN VRF RT create event.

Event ID: 9517

Message	EVPN RT: <code><rt></code> deleted for VRF: <code><vrf></code>
Category	EVPN
Severity	Information
Description	Logs EVPN VRF RT delete event.

Event ID: 9518

Message	EVPN RT: <code><rt></code> updated for VRF: <code><vrf></code>
Category	EVPN
Severity	Information
Description	Logs EVPN VRF RT update event.

Event ID: 9519

Message	EVPN dynamic vxlan tunnel bridging mode ibgp-ebgp enabled
Category	EVPN
Severity	Information
Description	Log event when dynamic vxlan tunnel bridging mode ibgp-ebgp is enabled

Event ID: 9520

Message	EVPN dynamic vxlan tunnel bridging mode ibgp-ebgp disabled
Category	EVPN
Severity	Information
Description	Log event when dynamic vxlan tunnel bridging mode ibgp-ebgp is disabled

The following are the events related to external storage.

Event ID: 7801

Message	Share <name> mount failure' throttle_count: 10
Category	External Storage
Severity	Error
Description	Event raised when a share fails to mount

Event ID: 7802

Message	Share <name> dismount failure
Category	External Storage
Severity	Error
Description	Event raised when a share fails to dismount

Event ID: 7803

Message	Share <name> is mounted
Category	External Storage
Severity	Information
Description	Event raised when a share mounts

Event ID: 7804

Message	Share <name> is dismounted
Category	External Storage
Severity	Information
Description	Event raised when a share dismounts

Event ID: 7805

Message	Share <name> mount is aborted
Category	External Storage
Severity	Error
Description	Event raised when a mount times out or aborts due to a config change

Event ID: 7806

Message	USB device <status>.
Category	External Storage
Severity	Information
Description	USB device mounted or unmounted.

The following are the events related to fan.

Event ID: 201

Message	There are <code><count></code> total fans in subsystem <code><subsystem></code> .
Category	Fan
Severity	Information
Description	Log the total number of fans in the subsystem

Event ID: 202

Message	Subsystem <code><subsystem></code> setting fan speed control register to <code><speedval></code> : <code><value></code> .
Category	Fan
Severity	Information
Description	Log the fan speed set

Event ID: 203

Message	Air flow direction: <code><value></code> .
Category	Fan
Severity	Information
Description	Log the air flow direction

Event ID: 204 (Severity: Warning)

Message	Fan tray <code><FT_Name></code> was removed.
Category	Fan
Severity	Warning
Description	Log event when a fan tray is removed from the chassis

Event ID: 205

Message	Fan tray <FT_Name> was inserted.
Category	Fan
Severity	Information
Description	Log event when a fan tray is inserted into the chassis

Event ID: 206

Message	Fan module <FMod_Name> was removed.
Category	Fan
Severity	Information
Description	Log event when a fan module is removed from a fan tray

Event ID: 207

Message	Fan module <FMod_Name> was inserted.
Category	Fan
Severity	Information
Description	Log event when a fan module is inserted into a fan tray

Event ID: 208

Message	Unsupported fan tray <FT_Name> detected. Please insert a standard fan tray.
Category	Fan
Severity	Error
Description	Log event when an unsupported fan tray is inserted

Event ID: 209

Message	Shutting down system now because <num_of_failure> <failure_type> <compare_mode> limit of <num_of_failure_limit>': yes
Category	Fan
Severity	Error
Description	Log error when system shutdown is initiated due to critical fan faults

Event ID: 211 (Severity: Warning)

Message	Shutting down system in <seconds> seconds because <num_of_failure> <failure_type> <compare_mode> limit of <num_of_failure_limit>
Category	Fan
Severity	Warning
Description	Log error when the number of failures exceed the allowable limit

Event ID: 212 (Severity: Warning)

Message	System shutdown timer is cancelled.': yes
Category	Fan
Severity	Warning
Description	Log event when the shutdown timer is cancelled

Event ID: 213

Message	<num_of_failure> <failure_type> in the system.': yes
Category	Fan
Severity	Error
Description	Log error when there are fan faults

Event ID: 214

Message	<function>: Fan <fan_name> faulted, reason: <reason>.': yes
Category	Fan
Severity	Error
Description	List out the faulty or missing fan names

Event ID: 215

Message	<FanName> fan is <FanStatus>.
Category	Fan
Severity	Information
Description	Log the fan status

Event ID: 216

Message	Status of fan <FanName> has changed from <OldStatus> to <NewStatus>.
Category	Fan
Severity	Information
Description	Log the change in fan status

Event ID: 217 (Severity: Warning)

Message	Operational fan count below minimum. <FanCount> fans operating, but <FanMinimum> are required.
Category	Fan
Severity	Warning
Description	Log when minimum number of fans are not present.

Event ID: 218

Message	Fan speed index for thermal zone <ZoneIdx> is <FanSpdIdxStatus>.
Category	Fan
Severity	Information
Description	Log when the fan speed index changes to and from the maximum for each thermal zone

Event ID: 219

Message	Fan tray <FT_Name> powered <Status>.
Category	Fan
Severity	Information
Description	Log event when a fan tray is powered on or off

Event ID: 220

Message	Fan tray <FT_Name> airflow is <FT_Dir>.
Category	Fan
Severity	Information
Description	Log event when a fan tray is inserted specifying its airflow direction

Event ID: 221 (Severity: Warning)

Message	<FT_air_curr> airflow fan tray <FT_Name> unsupported; this system
---------	---

	requires <code><FT_air_req></code> airflow.
Category	Fan
Severity	Warning
Description	Log event when a fan tray airflow is not matching with system airflow

Event ID: 222

Message	<code><num_of_failure> <failure_type> <compare_mode> limit of <num_of_failure_limit>': yes</code>
Category	Fan
Severity	Error
Description	Log error when number of faulty/supported fans does not meet the allowable limit

Event ID: 223 (Severity: Warning)

Message	Fan tray <code><FT_Name></code> FRU EPPROM is incorrectly programmed.
Category	Fan
Severity	Warning
Description	Log when fan tray SKU ID in FRU is mismatched

Event ID: 224 (Severity: Warning)

Message	<code><FT_air_curr> airflow fan tray <FT_Name> disabled; this system requires <FT_air_req> airflow.</code>
Category	Fan
Severity	Warning
Description	Log event when a fan tray airflow is not matching with system airflow and is disabled

Event ID: 225 (Severity: Warning)

Message	fan tray <code><FT_Name></code> misconfigured; this fan tray has been <code><En_Dis></code> .
Category	Fan
Severity	Warning
Description	Log event when a misconfigured fan tray is enabled or disabled

The following are the events related to fault monitor.

Event ID: 11101 (Severity: Warning)

Message	Interface <interface>: <fault> fault detected': yes
Category	Fault monitor
Severity	Warning
Description	Logs event when a fault is detected on an interface.

Event ID: 11102 (Severity: Warning)

Message	Interface <interface>: <fault> fault detected and port disabled': yes
Category	Fault monitor
Severity	Warning
Description	Logs event and shutdown the interface when a fault is detected on an interface.

Event ID: 11103

Message	Interface <interface>: <fault> fault re-enable time expired, port enabled': yes
Category	Fault monitor
Severity	Information
Description	Interface is auto-enabled on timer expiry.

Event ID: 11104

Message	Interface <interface>: <fault> fault disable cancelled due to configuration change': yes
Category	Fault monitor
Severity	Information
Description	Interface is auto-enabled on profile configuration change.

Event ID: 11105

Message	Admin state changed and interface: <code><interface></code> is auto-enabled': yes
Category	Fault monitor
Severity	Information
Description	Interface is auto-enabled on admin state change.

Event ID: 11106 (Severity: Warning)

Message	Interface <code><interface></code> : <code><fault></code> fault detected, port is already disabled by another fault.': yes
Category	Fault monitor
Severity	Warning
Description	Logs event when disabling of a faulty interface failed.

Event ID: 11107

Message	MAC Lockout packet drop detected for <code><mac></code> as source address: <code><sa_diff_count></code> .
Category	Fault monitor
Severity	Information
Description	Logs event when a packet drop is detected for MAC Lockout MAC as source address.

Event ID: 11108

Message	MAC Lockout packet drop detected for <code><mac></code> as destination address: <code><da_diff_count></code> .
Category	Fault monitor
Severity	Information
Description	Logs event when a packet drop is detected for MAC Lockout MAC as destination address.

Event ID: 11109

Message	MAC Lockout packet drop detected for <code><mac></code> as source: <code><sa_diff_count></code> and destination: <code><da_diff_count></code> address.
Category	Fault monitor
Severity	Information
Description	Logs event when a packet drop is detected for MAC Lockout.

The following are the events related to firmware update.

Event ID: 4401

Message	User <user>: <image_profile> image updated via <dnld_type> from <host>. Firmware version, Before Update: <before> After Update: <after>
Category	Firmware Update
Severity	Information
Description	Indicates that the switch firmware was succesfully updated from a remote source

Event ID: 4402

Message	User <user>: <image_profile> image updated via <dnld_type>. Firmware version, Before Update: <before> After Update: <after>
Category	Firmware Update
Severity	Information
Description	Indicates that the switch firmware was succesfully updated from a local source

Event ID: 4403

Message	User <user>: <image_profile> image update failed via <dnld_type> from <host>
Category	Firmware Update
Severity	Error
Description	Indicates that a switch firmware update failed from a remote source

Event ID: 4404

Message	User <user>: <image_profile> image update failed via <dnld_type>
Category	Firmware Update
Severity	Error
Description	Indicates that a switch firmware update failed from a local source

Event ID: 4405

Message	Firmware image signature not valid
Category	Firmware Update
Severity	Error
Description	Indicates that a the signature verification check during switch firmware update failed

Event ID: 4406

Message	Firmware image is not compatible with hardware
Category	Firmware Update
Severity	Error
Description	Indicates that firmware image downloaded for update is not compatible with hardware

Event ID: 4407

Message	Firmware image is invalid
Category	Firmware Update
Severity	Error
Description	Indicates that image downloaded for update is not a switch image

The following are the events related to hardware health monitor.

Event ID: 3001

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> on management module <code><slot></code> : yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in management module

Event ID: 3002

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> on line card <code><slot></code> : yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in line card

Event ID: 3003

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> on fabric card <code><slot></code> : yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in fabric card

Event ID: 3004

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> on fan tray <code><slot></code> : yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in fan tray

Event ID: 3005

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> on rear display card <code><slot></code> : yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in rear display card

Event ID: 3006

Message	Diagnostic <code><test_name></code> failed with error code <code><error_code></code> for the system': yes
Category	Hardware Health Monitor
Severity	Error
Description	Event raised when hardware diagnostics detects error in the system

Event ID: 3007 (Severity: Warning)

Message	There are <code><origin></code> happening on <code><location></code> ': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Logs MCE BUS error

Event ID: 3008 (Severity: Warning)

Message	There are IO errors on <code><location></code> from <code><seg>:<bus>:<device>:<function></code> ': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Logs MCE IO error

Event ID: 3009

Message	There are unknown errors on <code><location></code> from <code><status>:<addr>:<misc>:<mcgstatus>:<cap></code> ': yes
Category	Hardware Health Monitor
Severity	Information
Description	Logs MCE unknown error

Event ID: 3010 (Severity: Warning)

Message	CPUs <cpus> L<level> <type> cache error detected. CPUs <offlined> offlined': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Logs CPU cache error

Event ID: 3011 (Severity: Warning)

Message	Socket <socket> correctable memory error count <cecount> exceeded threshold <threshold>': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Log when socket correctable memory error count is exceeded threshold

Event ID: 3012 (Severity: Warning)

Message	Module <channel> correctable memory error count <cecount> exceeded threshold <threshold>': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Log when module correctable memory error count is exceeded threshold

Event ID: 3013 (Severity: Warning)

Message	Page <page> correctable memory error count <cecount> exceeded threshold <threshold> and <offlined>': yes
Category	Hardware Health Monitor
Severity	Warning
Description	Log when page correctable memory error count is exceeded threshold

The following are the events related to hardware switch controller.

Event ID: 8801

Message	Hardware VTEP DB setup is completed
Category	Hardware switch controller sync
Severity	Information
Description	Log when hardware VTEP DB setup is completed

Event ID: 8802

Message	Physical Port <port> is created in Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Log when physical port is created in hardware VTEP DB

Event ID: 8803

Message	Physical Port <port> is deleted from Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Log when physical port is deleted from hardware VTEP DB

Event ID: 8804

Message	HSC configuration is completed on the switch and pushed to Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when HSC configuration is completed on the switch and pushed to Hardware VTEP DB

Event ID: 8805

Message	HSC configuration is deleted from the switch and Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when HSC configuration is deleted from the switch and Hardware VTEP DB

Event ID: 8806

Message	Local MAC <mac> learnt on VLAN <vlan> is updated in the Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when local MAC learn on VLAN is updated in the Hardware VTEP DB

Event ID: 8807

Message	Local MAC <mac> learnt on VLAN <vlan> is removed from the Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when local MAC learnt on VLAN is removed from the Hardware VTEP DB

Event ID: 8808

Message	VXLAN IP <ip> is updated in the Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when VXLAN IP is updated in the Hardware VTEP DB

Event ID: 8809

Message	VXLAN IP <ip> is removed from Switch and Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information

Event ID: 8810

Message	Unicast Remote MAC <mac> learnt on VNI <vni> is added to the switch
---------	---

Category	Hardware switch controller sync
Severity	Information
Description	Logs when unicast remote MAC learnt on VNI is added to the switch

Event ID: 8811

Message	Unicast Remote MAC <mac> learnt on VNI <vni> is removed from the switch
Category	Hardware switch controller sync
Severity	Information
Description	Logs when unicast remote MAC learnt on VNI is removed from the switch

Event ID: 8812

Message	Tunnel <ip> is removed from Hardware VTEP DB
Category	Hardware switch controller sync
Severity	Information
Description	Logs when tunnel is removed from Hardware VTEP DB

The following are the events related to HTTPS server.

Event ID: 5601

Message	User <code><user></code> has enabled <code><mode></code> for REST mode
Category	HTTPS Server
Severity	Information
Description	Logs a message when a user changes the status of the REST mode

Event ID: 5602

Message	User <code><user></code> has <code><status></code> HTTPS Server on VRF <code><vrf></code>
Category	HTTPS Server
Severity	Information
Description	Logs a message when a user enables/disables the https-server VRF configuration

Event ID: 5603

Message	User <code><user></code> closed all HTTPS sessions
Category	HTTPS Server
Severity	Information
Description	Logs a message when a user closes all HTTPS sessions

Event ID: 5604

Message	User <code><user></code> changed the HTTPS Server max user sessions amount to <code><sessions></code>
Category	HTTPS Server
Severity	Information
Description	Logs a message when a user changes the maximum amount of sessions per user

Event ID: 5605

Message	User <i><user></i> changed the HTTPS Server idle timeout to <i><timeout></i>
Category	HTTPS Server
Severity	Information
Description	Logs a message when a user changes the value of the session idle timeout

The following are the events related to in-system programming.

Event ID: 7200

Message	Internal fatal error at <code><file>:<line></code>
Category	In-System Programming
Severity	Error
Description	ISP internal fatal error

Event ID: 7210

Message	Non-failsafe update needed for <code><devspec></code> . Please run the <code>allow-unsafe-updates</code> command
Category	In-System Programming
Severity	Error
Description	A non-failsafe device update is needed, but the <code>allow-unsafe-updates</code> command has not yet been run

Event ID: 7211

Message	Do not interrupt non-failsafe update for <code><devspec></code>
Category	In-System Programming
Severity	Error
Description	A non-failsafe device update is about to start, so do not interrupt it

Event ID: 7212

Message	Starting update for <code><devspec></code> from version <code><fromver></code> to version <code><tover></code>
Category	In-System Programming
Severity	Information
Description	A device update is about to start

Event ID: 7213

Message	Update successful for <devspec> from version <fromver> to version <tover>
Category	In-System Programming
Severity	Information
Description	A device update was successful or in some cases was successfully arranged to be performed later

Event ID: 7214 (Severity: Critical)

Message	Update failed for <devspec>
Category	In-System Programming
Severity	Critical
Description	A device update failed

Event ID: 7215

Message	Deferred update for <devspec> will be performed after an automatic module reset
Category	In-System Programming
Severity	Information
Description	A device update was postponed until after an automatic reset of its module

Event ID: 7216

Message	Approximately <time> minute(s) remaining to update <numdevs> device (s) on <modspec>
Category	In-System Programming
Severity	Information
Description	Indicates the approximate remaining update time for a module

Event ID: 7217

Message	Insufficient redundant power is available to update <devspec>
Category	In-System Programming
Severity	Information
Description	Unable to update non-redundant power supply

Event ID: 7218

Message	Programmable device updates are pending that require a power cycle. Wait for all fabric and line modules to be ready, then power the system off and back on again
Category	In-System Programming
Severity	Information
Description	ISP needs the chassis power-cycled manually when it cannot be done automatically

Event ID: 7219 (Severity: Critical)

Message	Failed to write-protect <devspec> (pass <pass>)
Category	In-System Programming
Severity	Critical
Description	Failed to write-protect a module or device

The following are the events related to interface.

Event ID: 401

Message	Interface port_admin set to up for <interface> interface
Category	Interface
Severity	Information
Description	Log when interface port_admin set to up

Event ID: 402

Message	Interface port_admin set to down for <interface> interface
Category	Interface
Severity	Information
Description	Log when interface port_admin set to down

Event ID: 403

Message	Link status for interface <interface> is up': yes
Category	Interface
Severity	Information
Description	Log when interface link status is up

Event ID: 404

Message	Link status for interface <interface> is <state>': yes
Category	Interface
Severity	Information
Description	Log when interface link status is down

Event ID: 405

Message	Reserved for future use
Category	Interface
Severity	Error

Event ID: 406

Message	Interface <code><interface></code> encountered a hardware error that caused a link reset
Category	Interface
Severity	Information
Description	Log when interface encountered an error that requires user intervention

Event ID: 407

Message	Interface <code><interface></code> downshifted to speed <code><port_speed></code> Mbps because link attempt failed at higher speed.
Category	Interface
Severity	Information
Description	Log when interface encountered a downshift

Event ID: 408 (Severity: Warning)

Message	Interface <code><interface></code> is down because MACsec and PFC features are mutually exclusive.
Category	Interface
Severity	Warning
Description	Log when interface is down due to incompatible MACsec and PFC configuration

The following are the events related to internal storage.

Event ID: 9101

Message	Failed to report storage <name> details for module <module_num>. Error: <error>': yes
Category	Internal storage
Severity	Error
Description	Event raised when there is a storage reporting failure

Event ID: 9102

Message	Storage <name> health alert. Endurance utilization at <usage>% in module <module_num>': yes
Category	Internal storage
Severity	Information
Description	Event raised when the storage health deteriorates

Event ID: 9103

Message	Storage <name> endurance utilization at <usage>% in module <module_num>': yes
Category	Internal storage
Severity	Information
Description	Event raised when there is a change in storage endurance

Event ID: 9104

Message	Storage <name> health alert. Endurance utilization at <usage>% in module <module_num>. Failure is imminent. Please backup data': yes
Category	Internal storage
Severity	Error
Description	Event raised when storage failure is imminent

The following are the events related to IP source lockdown.

Event ID: 9801 (Severity: Warning)

Message	IP source-lockdown resource utilization has reached 80 percent of the supported limit of <code><max_supported_limit></code> on the system
Category	IP source lockdown
Severity	Warning
Description	This log event informs the user that IP_SOURCE_LOCKDOWN resource utilization has reached 80 percent of the supported limits

Event ID: 9802 (Severity: Critical)

Message	IP source-lockdown resource utilization has exceeded maximum supported limit of <code><max_supported_limit></code> on the system. IP source-lockdown functionality will not work for new entries
Category	IP source lockdown
Severity	Critical
Description	This log event informs the user that IP_SOURCE_LOCKDOWN resource utilization has exceeded the supported limits

Event ID: 9803

Message	IP source-lockdown resource utilization has reduced below 80 percent of the supported limit of <code><max_supported_limit></code> on the system
Category	IP source lockdown
Severity	Information
Description	This log event informs the user that IP_SOURCE_LOCKDOWN resource utilization has reduced below 80 percent of the supported limits

Event ID: 9804

Message	IPv4 source-lockdown is enabled on interface <code><interface></code>
Category	IP source lockdown

Severity	Information
Description	Log event when IPV4_SOURCE_LOCKDOWN is enabled on an interface

Event ID: 9805

Message	IPv4 source-lockdown is disabled on interface <interface>
Category	IP source lockdown
Severity	Information
Description	Log event when IPV4_SOURCE_LOCKDOWN is disabled on an interface

Event ID: 9806

Message	IPv6 source-lockdown is enabled on interface <interface>
Category	IP source lockdown
Severity	Information
Description	Log event when IPV6_SOURCE_LOCKDOWN is enabled on an interface

Event ID: 9807

Message	IPv6 source-lockdown is disabled on interface <interface>
Category	IP source lockdown
Severity	Information
Description	Log event when IPV6_SOURCE_LOCKDOWN is disabled on an interface

The following are the events related to IP tunnels.

Event ID: 9601

Message	Tunnel Creation Failed - Name (<tunnel_name>) Type (<type>) VRF (<vrf>) Local IP (<src_ip>) Remote IP (<dst_ip>)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel creation fails

Event ID: 9602

Message	Tunnel Created - Name (<tunnel_name>) Type (<type>) VRF (<vrf>) Local IP (<src_ip>) Remote IP (<dst_ip>)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel created

Event ID: 9603

Message	Tunnel Deletion Failed - Name (<tunnel_name>) Type (<type>) VRF (<vrf>) Local IP (<src_ip>) Remote IP (<dst_ip>)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel deletion failed

Event ID: 9604

Message	Tunnel Deleted - Name (<tunnel_name>) Type (<type>) VRF (<vrf>) Local IP (<src_ip>) Remote IP (<dst_ip>)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel deleted

Event ID: 9605

Message	Tunnel Modification Failed - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >) TTL (< ttl >)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel modification failed

Event ID: 9606

Message	Tunnel Source IP Modified - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel source ip modified

Event ID: 9607

Message	Tunnel Destination IP Modified - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel destination ip modified

Event ID: 9608

Message	Tunnel TTL Modified - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >) TTL (< ttl >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel TTL modified

Event ID: 9609

Message	Tunnel MTU Modification Failed - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >) MTU (< ip_mtu >)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel mtu modification failed

Event ID: 9610

Message	Tunnel MTU Modified - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >) MTU (< ip_mtu >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel mtu modified

Event ID: 9611

Message	Tunnel Nexthop Add Failed - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel nexthop add failed

Event ID: 9612

Message	Tunnel Nexthop Added - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel nexthop gets added

Event ID: 9613

Message	Tunnel Nexthop Modify Failed - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel nexthop modify failed

Event ID: 9614

Message	Tunnel Nexthop Modified - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel nexthop gets modified

Event ID: 9615

Message	Tunnel Nexthop Delete Failed - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Error
Description	Event raised when tunnel nexthop delete failed

Event ID: 9616

Message	Tunnel Nexthop Deleted - Name (< tunnel_name >) Type (< type >) VRF (< vrf >) Local IP (< src_ip >) Remote IP (< dst_ip >)
Category	IP tunnels
Severity	Information
Description	Event raised when tunnel nexthop gets deleted

The following are the events related to IP-SLA.

Event ID: 7401

Message	IP-SLA session:<name> state changed to failed <state> due to reason <reason>
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA session state is changed to any failed state

Event ID: 7402

Message	IP-SLA session:<name> state changed to <state> due to reason <reason>
Category	IP-SLA
Severity	Information
Description	Event raised when an IP-SLA session state is changed to any info state

Event ID: 7403

Message	IP-SLA <name>: <operation>
Category	IP-SLA
Severity	Information
Description	Event raised when an IP-SLA session is added or deleted

Event ID: 7404

Message	IP-SLA session:<name> is incomplete to schedule
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA incomple config is added

Event ID: 7405

Message	IP-SLA session:<name> interface <interface> is not ready and SLA is disabled
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA session stopped due to source IP or interface changes

Event ID: 7406

Message	IP-SLA session:<name> interface <interface> is ready and SLA is enabled
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA session started due to source IP or interface changes

Event ID: 7407

Message	IP-SLA session:<name> failed to bind source, reason:<reason>
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA session failed to bind source

Event ID: 7408

Message	IP-SLA session:<name> failed to initialize socket, reason:<reason>
Category	IP-SLA
Severity	Error
Description	Event raised when an IP-SLA session failed to initialize socket

The following are the events related to IPv6 router advertisement.

Event ID: 3901

Message	ipv6 ra enabled on interface: <i><intf></i>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra enabled

Event ID: 3902

Message	ipv6 ra disabled on interface: <i><intf></i>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra disabled

Event ID: 3903

Message	Disabled sending MTU in Router-Advertisement messages on <i><intf></i>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress mtu is configured

Event ID: 3904

Message	Enabled sending MTU in Router-Advertisement messages on <i><intf></i>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress mtu configured

Event ID: 3905

Message	Disabled sending RDNSS in Router-Advertisement messages on <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress rdns is configured

Event ID: 3906

Message	Enabled sending RDNSS in Router-Advertisement messages on <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress rdns is removed

Event ID: 3907

Message	Disabled sending DNSSL in Router-Advertisement messages on <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress dnss is configured

Event ID: 3908

Message	Enabled sending DNSSL in Router-Advertisement messages on <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra suppress dnss is removed

Event ID: 3909

Message	Interface: <code><intf></code> is added to router discovery
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra interface is added

Event ID: 3910

Message	Interface: <code><intf></code> is deleted from router discovery
---------	---

Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 ra interface is deleted

Event ID: 3911

Message	Added ipv6 prefix: <code><ipv6_addr>/<prefixlen></code> on interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 address is added on interface

Event ID: 3912

Message	Deleted ipv6 prefix: <code><ipv6_addr>/<prefixlen></code> from interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 address is deleted from interface

Event ID: 3913

Message	Added RA Prefix: <code><prefix></code> on interface: <code><intf></code> to prefix list
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RA Prefix is added on interface

Event ID: 3914

Message	Deleted RA Prefix: <code><prefix></code> on interface: <code><intf></code> from prefix list
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RA Prefix is deleted from interface

Event ID: 3915

Message	default prefix is configured on interface <code><intf></code>
Category	IPv6 Router Advertisement

Severity	Information
Description	Event raised when default prefix is configured

Event ID: 3916

Message	RDNSS is added on interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RDNSS is added

Event ID: 3917

Message	RDNSS is deleted on interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RDNSS is deleted

Event ID: 3918

Message	DNSSL is added on interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when DNSSL is added

Event ID: 3919

Message	DNSSL is deleted on interface: <code><intf></code>
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when DNSSL is deleted

Event ID: 3920

Message	Added RA Route: <code><route></code> on interface: <code><intf></code> to route list
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RA Route is added on interface

Event ID: 3921

Message	Deleted RA Route: <code><route></code> on interface: <code><intf></code> from route list
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when RA Route is deleted from interface

Event ID: 3922

Message	Interface: <code><intf></code> has been configured with the invalid IPv6 nd ra maxInterval or minInterval
Category	IPv6 Router Advertisement
Severity	Information
Description	Event raised when ipv6 nd ra maxInterval or minInterval is improper

The following are the events related to IRDP.

Event ID: 3501

Message	IRDP enabled on interface <i><interface></i>
Category	IRDP
Severity	Information
Description	This command enables the IRDP (ICMP Router Discovery Protocol) feature on interface.

Event ID: 3502

Message	IRDP disabled on interface <i><interface></i>
Category	IRDP
Severity	Information
Description	This command disables the IRDP (ICMP Router Discovery Protocol) feature on interface.

Event ID: 3503

Message	Interface: <i><interface></i> has been configured with the invalid irdp holdtime or minInterval or maxInterval
Category	IRDP
Severity	Information
Description	Event raised when irdp holdtime or maxInterval or minInterval is improper

The following are the events related to job scheduler.

Event ID: 12201

Message	Creating schedule <name>, trigger time(s): <start_datetime><details>
Category	Job scheduler
Severity	Information
Description	Event reported when a schedule is created

Event ID: 12202

Message	Schedule <name> triggered, trigger_count: <trigger_count>
Category	Job scheduler
Severity	Information
Description	Event reported when a schedule triggers

Event ID: 12203

Message	Timezone changed. Re-creating schedule <name>, trigger time(s): <start_datetime><details>
Category	Job scheduler
Severity	Information
Description	Event reported when the schedules are recreated due to timezone change.

The following are the events related to L3 Encap capacity.

Event ID: 10601 (Severity: Warning)

Message	L3 resources critical for neighbor and route forwarding are low. Used: <code><encaps_allocated></code> , Available: <code><encaps_free></code>
Category	L3 Encap capacity
Severity	Warning
Description	L3 resources needed for neighbor and route forwarding are running low. Large-scale neighbor moves could cause traffic loss.

Event ID: 10602

Message	L3 resources critical for neighbor and route forwarding are at safe levels. Used: <code><encaps_allocated></code> , Available: <code><encaps_free></code>
Category	L3 Encap capacity
Severity	Information
Description	L3 resources needed for neighbor and route forwarding are back to a safe level.

Event ID: 10603

Message	Out of L3 resources critical for neighbor and route forwarding. Used: <code><encaps_allocated></code> , Available: <code><encaps_free></code>
Category	L3 Encap capacity
Severity	Error
Description	L3 resources needed for neighbor and route forwarding have run out. Traffic loss is imminent.

The following are the events related to L3 Resource Manager.

Event ID: 11501 (Severity: Warning)

Message	IPv6 route prefix <code><prefix></code> is not supported on this platform.
Category	L3 Resource Manager
Severity	Warning
Description	logs warning for route addition attempt.

Event ID: 11502

Message	"Exceeded resource ' <code><resource></code> ' capacity adding <code><object></code> . Use 'show capacities-status' for more information." throttle_count: 40
Category	L3 Resource Manager
Severity	Error
Description	logs error for running out of resources.

Event ID: 11503 (Severity: Warning)

Message	"Resource ' <code><resource></code> ' usage is at <code><percent></code> % of capacity. Use 'show capacities-status' for more information." throttle_count: 40
Category	L3 Resource Manager
Severity	Warning
Description	logs warning for hitting certain capacity limits.

The following are the events related to LACP.

Event ID: 1301

Message	Dynamic LAG <lag_id> created
Category	LACP
Severity	Information
Description	Dynamic LAG has been created

Event ID: 1302

Message	Dynamic LAG <lag_id> deleted
Category	LACP
Severity	Information
Description	Dynamic LAG has been deleted

Event ID: 1303

Message	Interface <intf_id> added to LAG <lag_id>. Existing configuration on interface <intf_id> will be removed.
Category	LACP
Severity	Information
Description	Log when interface has been added to LAG

Event ID: 1304

Message	Interface <intf_id> removed from LAG <lag_id>. It will be set with default configuration with admin down state.
Category	LACP
Severity	Information
Description	Log when interface has been removed from LAG

Event ID: 1305

Message	LACP system priority set to <code><system_priority></code>
Category	LACP
Severity	Information
Description	Log when LACP system priority is set

Event ID: 1306

Message	LACP mode set to <code><lacp_mode></code> for LAG <code><lag_id></code>
Category	LACP
Severity	Information
Description	Log when LACP mode is set

Event ID: 1307

Message	LACP system ID set to <code><system_id></code>
Category	LACP
Severity	Information
Description	Log when LACP system ID is set

Event ID: 1308

Message	LACP rate set to <code><lacp_rate></code> for LAG <code><lag_id></code>
Category	LACP
Severity	Information
Description	Log when LACP rate is set

Event ID: 1309

Message	Partner is detected for interface <code><intf_id></code> LAG <code><lag_id></code> : <code><partner_sys_id></code> . Actor state: <code><actor_state></code> , partner state <code><partner_state></code>
Category	LACP
Severity	Information
Description	Log when LACP partner is detected

Event ID: 1310 (Severity: Warning)

Message	Partner is out of sync for interface <code><intf_id></code> LAG <code><lag_id></code> . Actor
---------	---

	state: <code><actor_state></code> , partner state <code><partner_state></code>
Category	LACP
Severity	Warning
Description	Log when LACP parter is out of sync

Event ID: 1311 (Severity: Warning)

Message	Partner is lost (timed out) for interface <code><intf_id></code> LAG <code><lag_id></code> . State: <code><fsm_state></code>
Category	LACP
Severity	Warning
Description	Log to indicate that LACP partner is lost

Event ID: 1312

Message	Failed to create LAG <code><lag_id></code>
Category	LACP
Severity	Error
Description	Log when LAG creation is failed

Event ID: 1313

Message	LAG <code><lag_id></code> set as VSX
Category	LACP
Severity	Information
Description	Log when VSX is created

Event ID: 1314

Message	LAG <code><lag_id></code> not sending LACPDUs through interface <code><intf_id></code> because VSX information is not complete
Category	LACP
Severity	Information
Description	Log when LAG is not sending LACPDUs through interface because VSX information is incomplete

Event ID: 1315

Message	LACP fallback mode set to <code><lacp_fallback_mode></code> for lag <code><lag_id></code>
Category	LACP
Severity	Error
Description	Log when LACP fallback mode is set

Event ID: 1316

Message	LACP fallback timeout set to <code><lacp_fallback_timeout></code> for lag <code><lag_id></code>
Category	LACP
Severity	Error
Description	Log when LACP fallback timeout is set

Event ID: 1317

Message	LACP fallback timeout <code><lacp_fallback_timeout></code> expired for lag <code><lag_id></code>
Category	LACP
Severity	Error
Description	Log when LACP fallback timeout is expired

Event ID: 1318

Message	Interface <code><intf_id></code> enabled by fallback for lag <code><lag_id></code>
Category	LACP
Severity	Error
Description	Log when interface is enabled by fallback

Event ID: 1319

Message	LAG global load balancing mode is set to <code><mode></code>
Category	LACP
Severity	Information
Description	Logs to set global load balancing mode for LAG interfaces.

Event ID: 1320

Message	LAG load balancing mode is set to <mode> for lag <lag_id>
Category	LACP
Severity	Information
Description	Logs to set per port load balancing mode for LAG interface.

Event ID: 1321

Message	LAG <lag_id> State change for interface <intf_id>: Actor state: <actor_state>, Partner state <partner_state>
Category	LACP
Severity	Information
Description	Logs that capture changes to LACP state for LAG interface.

Event ID: 1322

Message	Interface <intf_name> cannot be part of Lag <lag_number>. Speed mismatched (Interface speed <port_speed>Mbps Lag base speed <lag_speed>Mbps).' throttle_count: 100
Category	LACP
Severity	Information
Description	Logs to capture if LACP protocol does not allow interface to be part of lag due to speed mismatch.

Event ID: 1323

Message	Fallback is <fallback> for LAG <lag_id>
Category	LACP
Severity	Information
Description	Logs to capture if fallback is changed for LAG interface

Event ID: 1324

Message	LACP Graceful Shut is initiated
Category	LACP
Severity	Information
Description	Logs that capture LACP Graceful Shut for LAG interface

Event ID: 1325

Message	LACP Graceful Shut is completed
Category	LACP
Severity	Information
Description	Logs that capture LACP Graceful Shut for LAG interface

The following are the events related to LAG.

Event ID: 1401

Message	Trunk set succeeds unit <code><unit></code> lag_id <code><lag_id></code>
Category	LAG
Severity	Debug
Description	Logs the creation of trunk.

Event ID: 1402

Message	Lag creation failed unit <code><unit></code> lag_id <code><lag_id></code> rc <code><rc></code> error <code><error></code>
Category	LAG
Severity	Error
Description	Logs the failure of trunk creation.

Event ID: 1403

Message	Destroy lag failed on unit <code><unit></code> lag_id <code><lag_id></code> rc <code><rc></code> error <code><error></code>
Category	LAG
Severity	Error
Description	Logs the failure of trunk destroy.

Event ID: 1404

Message	Trunk member add port succeeds on unit <code><unit></code> hw_port <code><hw_port></code> tid <code><tid></code>
Category	LAG
Severity	Debug
Description	Logs the addition of port to trunk.

Event ID: 1405

Message	Trunk port attach error on hw_port <hw_port> tid <tid> rc <rc> <error>
Category	LAG
Severity	Error
Description	Logs the failure of addition of port to trunk.

Event ID: 1406

Message	Failed to set egress enable on hw_port <hw_port> tid <tid> rc <rc> error <error>
Category	LAG
Severity	Error
Description	Logs the failure to set egress enable.

Event ID: 1407

Message	Failed to delete hw_port <hw_port> from tid <tid> rc <rc> error <error>
Category	LAG
Severity	Error
Description	Logs the failure to delete a port.

Event ID: 1408

Message	Trunk psc set failed on unit <unit> lag_id <lag_id> psc <psc> rc <rc> error <error>
Category	LAG
Severity	Error
Description	Logs the failure to set port selection criteria.

Event ID: 1409

Message	LAG <interface>, set to load balance mode to <mode>
Category	LAG
Severity	Information
Description	logs to set load balancing mode for LAG L2/L3 interfaces.

Event ID: 1410

Message	Add port <i><port></i> to LAG <i><interface></i>
Category	LAG
Severity	Information
Description	logs to add port to LAG.

Event ID: 1411

Message	Remove port <i><port></i> from LAG <i><interface></i>
Category	LAG
Severity	Information
Description	logs to remove port from LAG.

Event ID: 1412

Message	Add port <i><port></i> to vlan <i><vlan></i> for L3 LAG <i><interface></i>
Category	LAG
Severity	Information
Description	logs to add port to L3 LAG.

Event ID: 1413

Message	Remove port <i><port></i> to vlan <i><vlan></i> for L3 LAG <i><interface></i>
Category	LAG
Severity	Information
Description	logs to remove port from LAG.

Event ID: 1414

Message	Destroy L3 LAG interface <i><interface></i>
Category	LAG
Severity	Information
Description	logs to destroy L3 LAG.

The following are the events related to layer 3 interface.

Event ID: 1701

Message	L3-Interface <i><interface></i> , created
Category	Layer 3 Interface
Severity	Information
Description	logs to create L3 interface.

Event ID: 1702

Message	L3-Interface <i><interface></i> , deleted
Category	Layer 3 Interface
Severity	Information
Description	logs to delete L3 interface.

Event ID: 1703

Message	Interface <i><interface></i> , configured administratively <i><state></i>
Category	Layer 3 Interface
Severity	Information
Description	logs for admin state of L3 interface.

Event ID: 1704

Message	Failed to create <i><vlanid></i> for layer 3 interface <i><interface></i>
Category	Layer 3 Interface
Severity	Error
Description	logs errors while creating vlan for layer 3 interfaces.

Event ID: 1705

Message	Failed to destroy layer 3 interface <interface> vlan <vlanid>, error: <err>
Category	Layer 3 Interface
Severity	Error
Description	logs errors while destroying vlan for layer 3 interfaces.

Event ID: 1706

Message	Failed to delete an l3 interface <interface>, error: <err>
Category	Layer 3 Interface
Severity	Error
Description	logs errors while destroying layer 3 interface.

Event ID: 1707

Message	Failed to add L3 host entry for ip <ipaddr>, error: <err>' throttle_count: 1
Category	Layer 3 Interface
Severity	Error
Description	logs errors while adding l3 hosts.

Event ID: 1708

Message	Added L3 host entry for ip <ipaddr>
Category	Layer 3 Interface
Severity	Information
Description	logs while adding l3 hosts.

Event ID: 1709

Message	Failed to delete L3 host entry for ip <ipaddr>, error: <err>
Category	Layer 3 Interface
Severity	Error
Description	logs errors while deleting l3 hosts.

Event ID: 1710

Message	Deleted L3 host entry for ip <i><ipaddr></i>
Category	Layer 3 Interface
Severity	Information
Description	logs while deleting l3 hosts.

Event ID: 1711

Message	Failed to get L3 host hit for ip <i><ipaddr></i>
Category	Layer 3 Interface
Severity	Error
Description	logs errors to get L3 host hit for a specific ip.

Event ID: 1712

Message	L3 interface error: <i><err></i>
Category	Layer 3 Interface
Severity	Error
Description	logs for L3 setup errors.

Event ID: 1713

Message	Added Nexthop <i><nexthop></i> , egress_id <i><egress_id></i> , for route <i><prefix></i>
Category	Layer 3 Interface
Severity	Information
Description	logs for nexthop addition.

Event ID: 1714

Message	Delete Nexthop <i><nexthop></i> for route <i><prefix></i>
Category	Layer 3 Interface
Severity	Information
Description	logs for nexthop deletion.

Event ID: 1715

Message	Added route <i><prefix></i>
---------	-----------------------------------

Category	Layer 3 Interface
Severity	Information
Description	logs for route addition.

Event ID: 1716

Message	Update: route state: <code><state></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for route update.

Event ID: 1717

Message	Delete route <code><prefix></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for route deletion.

Event ID: 1718

Message	Delete route <code><prefix></code> , error: <code><err></code>
Category	Layer 3 Interface
Severity	Error
Description	logs error for route deletion.

Event ID: 1719

Message	Add route <code><prefix></code> , error: <code><err></code> ' throttle_count: 1
Category	Layer 3 Interface
Severity	Error
Description	logs error for route addition.

Event ID: 1720

Message	Error creating egress object for port <code><port></code> , error: <code><err></code>
Category	Layer 3 Interface

Severity	Error
Description	logs errors for egress object creation.

Event ID: 1721

Message	Created L3 egress ID <code><egress_id></code> for port <code><port></code> intf <code><intf></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for egress object creation.

Event ID: 1722

Message	Error deleting egress object for port <code><port></code> , error: <code><err></code>
Category	Layer 3 Interface
Severity	Error
Description	logs errors for egress object deletion.

Event ID: 1723

Message	Deleted L3 egress ID <code><egress_id></code> for port <code><port></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for egress object deletion.

Event ID: 1724

Message	Interface <code><interface></code> , configured with ipv4 address <code><value></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for ipv4 address update on interface.

Event ID: 1725

Message	Interface <code><interface></code> , configured with ipv6 address <code><value></code>
Category	Layer 3 Interface
Severity	Information
Description	logs for ipv6 address update on interface.

Event ID: 1726

Message	Interface <interface>, ipv4 address deleted <value>
Category	Layer 3 Interface
Severity	Information
Description	logs for ipv4 address delete from interface.

Event ID: 1727

Message	Interface <interface>, ipv6 address deleted <value>
Category	Layer 3 Interface
Severity	Information
Description	logs for ipv6 address delete from interface.

Event ID: 1728

Message	IPv6 Address Status: Interface <intf>, address <addr>, status <addr_status>
Category	Layer 3 Interface
Severity	Information
Description	Event raised when ipv6 address status changes

Event ID: 1729

Message	Interface <interface>, configured with secondary ipv4 address <value>
Category	Layer 3 Interface
Severity	Information
Description	logs for secondary ipv4 address update on interface.

Event ID: 1730

Message	Interface <interface>, secondary ipv4 address deleted <value>
Category	Layer 3 Interface
Severity	Information
Description	logs for secondary ipv4 address delete from interface.

Event ID: 1731

Message	IP MTU <mtu> not applied due to hardware resource limitation
Category	Layer 3 Interface
Severity	Error
Description	Logs failure while configuring hardware for IPMTU.

The following are the events related to LED.

Event ID: 501

Message	There are <i><count></i> LED types in subsystem <i><subsystem></i>
Category	LED
Severity	Information
Description	Log about number of LED types in subsystem

Event ID: 502

Message	There are <i><count></i> LED configs in subsystem <i><subsystem></i>
Category	LED
Severity	Information
Description	Log about number of LED config in subsystem

The following are the events related to LLDP.

Event ID: 101

Message	LLDP Enabled
Category	LLDP
Severity	Information
Description	Logs event when LLDP (Link Layer Discovery Protocol) feature is enabled in the switch.

Event ID: 102

Message	LLDP Disabled
Category	LLDP
Severity	Information
Description	Logs event when LLDP (Link Layer Discovery Protocol) feature is disabled in the switch.

Event ID: 103

Message	Configured LLDP tx-timer to <i><value></i>
Category	LLDP
Severity	Information
Description	Logs event when the LLDP status update interval is configured by the user.

Event ID: 104

Message	LLDP neighbor <i><chassisid></i> added on <i><interface></i>
Category	LLDP
Severity	Information
Description	Logs event when a new neighbor entry is added to the switch.

Event ID: 105

Message	LLDP neighbor <chassisid> updated on <interface>' throttle_count: 100
Category	LLDP
Severity	Information
Description	Logs event when an existing neighbor entry is updated in the switch.

Event ID: 106

Message	LLDP neighbor <chassisid> deleted on <interface>
Category	LLDP
Severity	Information
Description	Logs event when an existing neighbor entry is deleted from switch.

Event ID: 107

Message	Configured LLDP Management IP <value>
Category	LLDP
Severity	Information
Description	Logs event when a new management IP address is configured by the user.

Event ID: 108

Message	Configured LLDP tx-hold to <hold>
Category	LLDP
Severity	Information
Description	Logs event when LLDP transmit multiplier value is configured by the user.

Event ID: 109

Message	Configured LLDP tx-delay to <value>
Category	LLDP
Severity	Information
Description	Logs event when LLDP transmit delay value is configured by the user.

Event ID: 110

Message	Configured LLDP reinit-delay to <value>
---------	---

Category	LLDP
Severity	Information
Description	Logs event when LLDP interface reinitialization value is configured by the user.

Event ID: 111

Message	LLDP statistics cleared
Category	LLDP
Severity	Information
Description	Logs event when LLDP statistics are cleared from the switch.

Event ID: 112

Message	LLDP neighbor info cleared
Category	LLDP
Severity	Information
Description	Logs event when LLDP neighbor information is cleared from the switch.

Event ID: 113

Message	PVID mismatch on <interface> pvid = <pvid>, Neighbor <chassisid> port_id = <ninterface> pvid = <npvid>
Category	LLDP
Severity	Information
Description	Log event when the PVID mismatches between the switch and neighbor over an interface.

The following are the events related to loop protect.

Event ID: 2801 (Severity: Warning)

Message	Port <code><portName></code> is disabled by Loop-protection after loop detection on VLAN <code><vlan></code>
Category	Loop Protect
Severity	Warning
Description	Logs port disabled by Loop protect

Event ID: 2802 (Severity: Warning)

Message	Ports TX <code><txportName></code> and RX <code><rxportName></code> are disabled by Loop-protect after loop detection on VLAN <code><vlan></code>
Category	Loop Protect
Severity	Warning
Description	Logs port disabled by Loop protect

Event ID: 2803 (Severity: Warning)

Message	Loop detected on port <code><portName></code> on VLAN <code><vlan></code>
Category	Loop Protect
Severity	Warning
Description	Logs port which receives PDU of its own

Event ID: 2804

Message	Port <code><portName></code> enabled after disable time expired
Category	Loop Protect
Severity	Information
Description	Logs port enabled after disabled time expired

Event ID: 2805

Message	Port <code><portName></code> added for loop-protection
Category	Loop Protect
Severity	Information
Description	Logs port added

Event ID: 2806

Message	Port <code><portName></code> deleted from loop-protection
Category	Loop Protect
Severity	Information
Description	Logs port deleted

Event ID: 2807

Message	Loop-Protection stats cleared for port <code><portName></code>
Category	Loop Protect
Severity	Information
Description	Loop-Protection stats cleared for port

Event ID: 2808

Message	Ports TX <code><txportName></code> and RX <code><rxportName></code> are involved during TX port disabling
Category	Loop Protect
Severity	Information
Description	Logs TX and RX ports after TX disabled by Loop protect

The following are the events related to loopback.

Event ID: 901

Message	Loopback Interface <i><interface></i> , created
Category	Loopback
Severity	Information
Description	Log when loopback interface is created

Event ID: 902

Message	Loopback Interface <i><interface></i> , deleted
Category	Loopback
Severity	Information
Description	Log when loopback interface is deleted

Event ID: 903

Message	Loopback Interface <i><interface></i> , configured administratively <i><state></i>
Category	Loopback
Severity	Information
Description	Log about loopback interface admin state

The following are the events related to MAC address management.

Event ID: 4801

Message	MAC <mac> moved from port <from-intf> to port <to-intf> on VLAN <vlan>
Category	MAC address management
Severity	Information
Description	Event raised when L2 mac move

Event ID: 4802

Message	All dynamic MAC addresses on VLAN <vlan> were flushed
Category	MAC address management
Severity	Information
Description	Event raised when L2 MAC table is flushed with vlan delete event or clear mac-address command from vtysh

Event ID: 4803

Message	All dynamic MAC addresses on port <intf> were flushed
Category	MAC address management
Severity	Information
Description	Event raised when L2 MAC table is flushed with port move to L3 event or clear mac-address command from vtysh

Event ID: 4804

Message	All dynamic MAC addresses on port <intf> were flushed
Category	MAC address management
Severity	Information
Description	Event raised when L2 MAC table is flushed with port down event or clear mac-address command from vtysh

Event ID: 4805

Message	All dynamic MAC addresses on VLAN <vlan> were flushed
Category	MAC address management
Severity	Information
Description	Event raised when L2 MAC table is flushed with vlan down event or clear mac-address command from vtysh

Event ID: 4806 (Severity: Warning)

Message	L2X thread not running. Attempting to recover
Category	MAC address management
Severity	Warning
Description	Event raised when BCM L2X thread is identified as not running

Event ID: 4807 (Severity: Warning)

Message	L2X thread recovered
Category	MAC address management
Severity	Warning
Description	Event raised when BCM L2X thread is successfully recovered

Event ID: 4808

Message	L2X thread recovery failed
Category	MAC address management
Severity	Error
Description	Event raised when BCM L2X thread is failed to be recovered

The following are the events related to MAC Address mode configuration.

Event ID: 11001

Message	The MAC Address configured mode changed from <code><old_mode></code> to <code><new_mode></code>
Category	MAC Address mode configuration
Severity	Information
Description	Log event when the MAC Address configured mode is changed

Event ID: 11002

Message	The MAC Address operational mode changed from <code><old_mode></code> to <code><new_mode></code>
Category	MAC Address mode configuration
Severity	Information
Description	Log event when the MAC Address operational mode is changed

Event ID: 11003

Message	Station MAC add failure due to hardware full, mac= <code><mac></code> vlan= <code><vlan></code>
Category	MAC Address mode configuration
Severity	Error
Description	Log event when a local station MAC address cannot be added because the table is full

Event ID: 11004

Message	The MAC Address operational mode changed from <code><old_mode></code> to <code><new_mode></code> due to reaching SVI threshold. Current= <code><current></code> Max= <code><max></code>
Category	MAC Address mode configuration
Severity	Error
Description	Log event when the MAC Address operational mode is changed due to out of resources

The following are the events related to MACsec.

Event ID: 11201

Message	MACsec session established on Rx Secure Channel <sci> on interface <ifname>.
Category	MACsec
Severity	Information
Description	A MACsec session established on an interface.

Event ID: 11202

Message	MKA session secured for Connectivity Association <ckn> on interface <ifname>.
Category	MACsec
Severity	Information
Description	A Connectivity Association was successfully established on an interface.

Event ID: 11203

Message	Secure Association key updated for Connectivity Association <ckn> on interface <ifname> - Latest AN/KN <latest_an>/<latest_kn>, Old AN/KN <old_an>/<old_kn>.
Category	MACsec
Severity	Information
Description	A new Secure Association key created for a Connectivity Association.

Event ID: 11204

Message	Possible replay attempt detected on the Secure Channel <sci>.
Category	MACsec
Severity	Information
Description	A possible replay attempt detected on a Secure Channel.

Event ID: 11205

Message	The data traffic on interface <ifname> is now secured by MACsec.
Category	MACsec
Severity	Information
Description	The data plane traffic on an interface is secured by MACsec.

Event ID: 11206

Message	The data traffic on interface <ifname> is no longer secured by MACsec.
Category	MACsec
Severity	Information
Description	The data plane traffic on an interface is not secured by MACsec anymore.

Event ID: 11204

Message	Possible replay attempt detected on the Secure Channel <sci>.
Category	MACsec
Severity	Information
Description	A possible replay attempt detected on a Secure Channel.

The following are the events related to management.

Event ID: 4301

Message	MGMT_INTF: <i><mgmt_intf_config_param></i>
Category	Management
Severity	Information
Description	Logs related to management interface configurations

Event ID: 4302

Message	MGMT_INTF: <i><mgmt_intf_config_err></i>
Category	Management
Severity	Error
Description	Logs related to management interface configurations error

Event ID: 4303 (Severity: Critical)

Message	MGMT_INTF: <i><mgmt_intf_config_crit></i>
Category	Management
Severity	Critical
Description	Logs related to management interface critical configurations

The following are the events related to MDNS.

Event ID: 11401

Message	mDNS-SD enabled
Category	MDNS
Severity	Information
Description	Logs event when mDNS-SD feature is enabled in the switch.

Event ID: 11402

Message	mDNS-SD disabled
Category	MDNS
Severity	Information
Description	Logs event when mDNS-SD feature is disabled in the switch.

The following are the events related to MGMD.

Event ID: 2601 (Severity: Fatal)

Message	Failed to alloc a <code><pkt_type></code> pkt(interface <code><vlan></code>)
Category	MGMD
Severity	Fatal
Description	This log event informs packet allocation failed in MGMD subsystem.

Event ID: 2602

Message	Received IGMPv1 query from <code><ip_address></code> when the device is configured for IGMPv2.
Category	MGMD
Severity	Information
Description	This log event used to log IGMP warning when IGMPv1 query is received.

Event ID: 2603 (Severity: Fatal)

Message	Unable to alloc a buf of size <code><size_value></code> for <code><sub_system></code>
Category	MGMD
Severity	Fatal
Description	This log event informs the user that MGMD could not allocate memory.

Event ID: 2604

Message	Interface <code><if_name></code> : Other Querier detected for <code><mgmd_type></code>
Category	MGMD
Severity	Information
Description	This log event informs the user that IGMP/MLD detected other querier.

Event ID: 2605

Message	<code><mgmd_type> Querier Election in progress for interface <if_name> with IP address <ip_address></code>
Category	MGMD
Severity	Information
Description	This log event informs the user that IGMP/MLD has started querier election on interface.

Event ID: 2606

Message	<code>Interface <if_name>: End <mgmd_type> Querier role</code>
Category	MGMD
Severity	Information
Description	This log event informs the user that IGMP/MLD ended querier role on interface.

Event ID: 2607

Message	<code>Interface <if_name>: Start <mgmd_type> Querier role addr: <ip_address></code>
Category	MGMD
Severity	Information
Description	This log event informs the user that MGMD started querier role on interface.

Event ID: 2608 (Severity: Warning)

Message	<code>Received packet from <ip_address>, type <type>, on invalid port <port></code>
Category	MGMD
Severity	Warning
Description	This log event informs the user that MGMD received packet on invalid port.

Event ID: 2609

Message	<code>Received IGMPv1 query from <ip_address> when the device is configured for IGMPv3.' throttle_count: 1</code>
Category	MGMD
Severity	Information
Description	This log event used to log IGMP warning when configured mode is IGMPv3 and IGMPv1 query is received.

Event ID: 2610

Message	Received IGMPv2 query from <ip_address> when the device is configured for IGMPv3.' throttle_count: 1
Category	MGMD
Severity	Information
Description	This log event used to log IGMP warning when configured mode is IGMPv3 and IGMPv2 query is received.

Event ID: 2611

Message	<mgmd_type> snooping is <status> on VLAN <vlan>
Category	MGMD
Severity	Information
Description	This log event informs the user that IGMP/MLD status on VLAN.

Event ID: 2612

Message	<mgmd_type> is <status> on Interface <if_name>
Category	MGMD
Severity	Information
Description	This log event informs the user the IGMP/MLD status on the Interface.

Event ID: 2613

Message	Port <port> on vlan <vlan> is set to <status> mode for <mgmd_type>.
Category	MGMD
Severity	Information
Description	This log event informs the user that the port mode has changed.

Event ID: 2614

Message	<mgmd_type> is not operational on VLAN <vlan> due to resource unavailability
Category	MGMD
Severity	Error
Description	This log event informs the user that the IGMP/MLD is disabled on a VLAN due to internal errors.

Event ID: 2615

Message	<code><mgmd_type></code> is not operational on interface <code><l3Port></code> due to resource unavailability
Category	MGMD
Severity	Error
Description	This log event informs the user that the IGMP/MLD is disabled on a L3 interface due to internal errors.

Event ID: 2616

Message	IGMP/MLD Resource utilization has exceeded the supported limits on the system. Membership reports for the new groups will be dropped.
Category	MGMD
Severity	Information
Description	This log event informs the user that MGMD resource utilization has exceeded the supported limits

Event ID: 2617

Message	IGMP/MLD Resource utilization has reached 90 percent of the supported limits on the system.
Category	MGMD
Severity	Information
Description	This log event informs the user that MGMD resource utilization has reached 90 percent of the supported limits

Event ID: 2618

Message	<code><mgmd_type></code> snooping is <code><status></code> on VLAN <code><vlan></code> .
Category	MGMD
Severity	Information
Description	This log event informs the user that whether IGMP/MLD snooping is operational.

Event ID: 2619

Message	Received IGMPv3 query from <code><ip_address></code> when the device is configured for IGMPv2.' throttle_count: 1
Category	MGMD
Severity	Information
Description	This log event used to log IGMP warning when IGMPv2 query is received.

Event ID: 2620

Message	Received MLDV1 query from <ip_address> when the device is configured for MLDV2.' throttle_count: 1
Category	MGMD
Severity	Information
Description	This log event used to log MLD warning when configured mode is MLDV2 and MLDV1 query is received.

Event ID: 2621

Message	Received MLDV2 query from <ip_address> when the device is configured for MLDV1.' throttle_count: 1
Category	MGMD
Severity	Information
Description	This log event used to log MLD warning when configured mode is MLDv2 and MLDv1 query is received.

Event ID: 2622

Message	Flood mode is temporarily activated on ERPS ports <port0> and <port1> as ring state for ring id <ring_id> changed to <state>.
Category	MGMD
Severity	Information
Description	This log event used to log if ERPS Ring state changed to idle or protection.

The following are the events related to mirroring.

Event ID: 6701

Message	Failed to create mirror session <number>
Category	Mirroring
Severity	Error
Description	Logs a message when the creation of a mirror session fails

Event ID: 6702

Message	Mirror session <number> created
Category	Mirroring
Severity	Information
Description	Logs a message when the creation of a mirror session succeeds

Event ID: 6703

Message	Failed to delete mirror session <number>
Category	Mirroring
Severity	Error
Description	Logs a message when the deletion of a mirror session fails

Event ID: 6704

Message	Mirror session <number> deleted
Category	Mirroring
Severity	Information
Description	Logs a message when mirror session is successfully deleted

Event ID: 6705

Message	Failed to update mirror session <number>
Category	Mirroring
Severity	Error
Description	Logs a message when an update of a mirror session fails

Event ID: 6706

Message	Mirror session <number> updated
Category	Mirroring
Severity	Information
Description	Logs a message when the update of a mirror session succeeds

The following are the events related to module.

Event ID: 3201

Message	<code><type> module <name> inserted': yes</code>
Category	Module
Severity	Information
Description	Indicates that the module has been physically inserted

Event ID: 3202 (Severity: Warning)

Message	<code><type> module <name> removed': yes</code>
Category	Module
Severity	Warning
Description	Indicates that the module has been physically removed

Event ID: 3203

Message	<code>Initiating <type> module <name> reboot': yes</code>
Category	Module
Severity	Information
Description	Indicates that the module is about to reboot

Event ID: 3204

Message	<code><type> module <name> is ready</code>
Category	Module
Severity	Information
Description	Indicates that the module is initialized and ready

Event ID: 3205

Message	<code><type> module <name> is down: <reason></code>
Category	Module
Severity	Information
Description	Indicates that the module is down

Event ID: 3206

Message	<code><type> module <name> is in diagnostics mode</code>
Category	Module
Severity	Information
Description	Indicates that a module is in diagnostics mode

Event ID: 3207

Message	<code><type> module <name> has failed: <reason>': yes</code>
Category	Module
Severity	Error
Description	Indicates that a module has failed

Event ID: 3208

Message	<code><type> module <name> admin state set to up</code>
Category	Module
Severity	Information
Description	Indicates that the module administrative state is set to up

Event ID: 3209

Message	<code><type> module <name> admin state set to down</code>
Category	Module
Severity	Information
Description	Indicates that the module administrative state is set to down

Event ID: 3210

Message	<code><type> module <name> admin state set to diagnostics</code>
---------	--

Category	Module
Severity	Information
Description	Indicates that the module administrative state is set to diagnostics

Event ID: 3211

Message	<code><type> module <name> ISP passed</code>
Category	Module
Severity	Information
Description	Indicates that ISP has passed for the module

Event ID: 3212

Message	<code><type> module <name> ISP failed': yes</code>
Category	Module
Severity	Error
Description	Indicates that ISP has failed for the module

Event ID: 3213 (Severity: Warning)

Message	<code><type> module <name> ISP skipped</code>
Category	Module
Severity	Warning
Description	Indicates that ISP has been skipped for the module

Event ID: 3214

Message	<code><type> module <name> has enabled standby power</code>
Category	Module
Severity	Debug
Description	Indicates that the module is in standby (low-power) mode

Event ID: 3215

Message	<code><type> module <name> is requesting to power on with priority <priority></code>
---------	--

Category	Module
Severity	Debug
Description	Indicates that the module is requesting to power on

Event ID: 3216

Message	<code><type> module <name> power request has been granted</code>
Category	Module
Severity	Debug
Description	Indicates that the power request for the module has been granted

Event ID: 3217

Message	<code><type> module <name> power request has been denied</code>
Category	Module
Severity	Error
Description	Indicates that the power request for the module has been denied

Event ID: 3218

Message	<code><type> module <name> enabling main power</code>
Category	Module
Severity	Debug
Description	Indicates that main power for the module is being enabled

Event ID: 3219

Message	<code><type> module <name> main power enabled</code>
Category	Module
Severity	Debug
Description	Indicates that main power for the module has been enabled

Event ID: 3220

Message	<code><type> module <name> main power failed': yes</code>
Category	Module

Severity	Error
Description	Indicates that main power for the module has failed

Event ID: 3221

Message	<code><type> module <name> device initialization started</code>
Category	Module
Severity	Debug
Description	Indicates that device initialization for the module has started

Event ID: 3222

Message	<code><type> module <name> device initialization passed</code>
Category	Module
Severity	Debug
Description	Indicates that device initialization for the module has passed

Event ID: 3223

Message	<code><type> module <name> device initialization failed: <reason>': yes</code>
Category	Module
Severity	Error
Description	Indicates that device initialization for the module has failed

Event ID: 3224

Message	<code><type> module <name> ASIC initialization started</code>
Category	Module
Severity	Information
Description	Indicates that an ASIC for the module is being initialized

Event ID: 3225

Message	<code><type> module <name> ASIC initialization completed</code>
Category	Module
Severity	Debug
Description	Indicates that ASIC initialization for the module has completed

Event ID: 3226

Message	<code><type> module <name> ASIC initialization failed: <reason>': yes</code>
Category	Module
Severity	Error
Description	Indicates that ASIC initialization for the module has failed

Event ID: 3227

Message	<code><type> module <name> ASIC deinitialization started</code>
Category	Module
Severity	Debug
Description	Indicates that an ASIC for the module is being deinitialized

Event ID: 3228

Message	<code><type> module <name> ASIC deinitialization completed</code>
Category	Module
Severity	Debug
Description	Indicates that ASIC deinitialization for the module has completed

Event ID: 3229

Message	<code><type> module <name> ASIC denitIALIZation failed: <reason>': yes</code>
Category	Module
Severity	Error
Description	Indicates that ASIC deinitialization for the module has failed

Event ID: 3230

Message	<code><name> is starting zeroization': yes</code>
Category	Module
Severity	Information
Description	Indicates that the module is about to start zeroization

Event ID: 3231

Message	<code><name> zeroization completed.</code>
Category	Module
Severity	Information
Description	Indicates that the module zeroization has completed

Event ID: 3232

Message	<code><name> zeroization failed.': yes</code>
Category	Module
Severity	Information
Description	Indicates that the module zeroization failed to complete

Event ID: 3233

Message	<code><type> module <name> configured with product number <part_number></code>
Category	Module
Severity	Information
Description	Indicates that the module has been configured

Event ID: 3234

Message	<code><type> module <name> has been unconfigured</code>
Category	Module
Severity	Information
Description	Indicates that the module has been unconfigured

Event ID: 3235

Message	<code><type> module <name> initiating failover</code>
Category	Module
Severity	Information
Description	Indicates that the module has started failover

Event ID: 3236

Message	<code><type> module <name> failover completed</code>
---------	--

Category	Module
Severity	Information
Description	Indicates that the module has completed failover

Event ID: 3237

Message	<code><type> module <name> initiating ISP</code>
Category	Module
Severity	Information
Description	Indicates that ISP has started for the module

Event ID: 3238

Message	<code><type> module <name> enabling front-end power</code>
Category	Module
Severity	Information
Description	Indicates that front-end power is being enabled

Event ID: 3239 (Severity: Warning)

Message	<code><type> module <name> disabling front-end power: <reason></code>
Category	Module
Severity	Warning
Description	Indicates that front-end power is being disabled

Event ID: 3240

Message	<code><type> module <name> has persistent hardware error</code>
Category	Module
Severity	Error
Description	Indicates that persistent hardware error has occurred

The following are the events related to MPLS.

Event ID: 13301

Message	MPLS LDP session with local identifier <code><local_ldp_id></code> and peer identifier <code><peer_ldp_id></code> has come up.
Category	MPLS
Severity	Information
Description	Logs a message when an LDP neighbor comes up

Event ID: 13302

Message	MPLS LDP session with local identifier <code><local_ldp_id></code> and peer identifier <code><peer_ldp_id></code> has gone down.
Category	MPLS
Severity	Information
Description	Logs a message when an LDP neighbor goes down

The following are the events related to MSDP.

Event ID: 8601

Message	Router MSDP is <status> on VRF <vrf_name>
Category	MSDP
Severity	Information
Description	Router msdp configuration status

Event ID: 8602

Message	Forwarding state of interface <if_name> has been changed to <state>
Category	MSDP
Severity	Information
Description	MSDP Source Interface operational status

Event ID: 8603

Message	MSDP Peer <peer_ip>(<tcp_entity>) with connection source <if_name> has entered <state> state
Category	MSDP
Severity	Information
Description	Logs the changes in MSDP Peer connection state.

Event ID: 8604

Message	Port <port> is <status> to MSDP Peer <peer_ip>
Category	MSDP
Severity	Information
Description	Log event when port is added or deleted for a peer.

Event ID: 8606

Message	MSDP Peer <i><peer_ip></i> is <i><status></i> on VRF <i><vrf_name></i> . Interface <i><if_name></i> is added to the Peer
Category	MSDP
Severity	Information
Description	Log event when peer is enabled or disabled

Event ID: 8607

Message	Start <i><tcp_entity></i> role for MSDP peer <i><peer_ip></i>
Category	MSDP
Severity	Information
Description	Log event when client or server is elected

Event ID: 8608

Message	Finish packet was received on MSDP Peer <i><peer_ip></i>
Category	MSDP
Severity	Information
Description	Log event when TCP final packet is received.

Event ID: 8609 (Severity: Warning)

Message	Failed to add SA Cache entry: S= <i><src_ip></i> , G= <i><grp_ip></i> , R= <i><rp_ip></i> for Peer <i><peer_ip></i> as MSDP SA Cache Limit is reached
Category	MSDP
Severity	Warning
Description	Log event when MSDP SA cache limit is reached.

The following are the events related to Multicast Traffic Manager.

Event ID: 4001 (Severity: Warning)

Message	The Multicast L3 Bridge Control Forwarding entries limit was reached: <limit>' throttle_count: 100
Category	Multicast Traffic Manager
Severity	Warning
Description	Event raised when the maximum number of multicast L3 Bridge Control Forwarding entries is reached

The following are the events related to multiple spanning tree protocol.

Event ID: 2001

Message	MSTP Enabled
Category	Multiple spanning tree protocol
Severity	Information
Description	This command enables the MSTP (Multiple Spanning-tree Protocol) feature in the device.

Event ID: 2002

Message	MSTP Disabled
Category	Multiple spanning tree protocol
Severity	Information
Description	This command disables the MSTP (Multiple Spanning-tree Protocol) feature in the device.

Event ID: 2003 (Severity: Warning)

Message	<code><config_parameter> should be <value></code>
Category	Multiple spanning tree protocol
Severity	Warning
Description	This log event informs the user that the MSTP config parameter is bad

Event ID: 2004 (Severity: Warning)

Message	BPDU has <code><config_parameter></code> from port <code><value></code>
Category	Multiple spanning tree protocol
Severity	Warning
Description	This log event informs the user that the Switch received a BPDU with a bad config

Event ID: 2005 (Severity: Warning)

Message	Bad reconfiguration request: <code><reconfig_parameter></code>
Category	Multiple spanning tree protocol
Severity	Warning
Description	This log event informs the user that the MSTP reconfig parameter is bad

Event ID: 2006

Message	<code><proto> - Root changed from <old_priority>: <old_mac> to <new_priority>: <new_mac></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTP root has changed

Event ID: 2007 (Severity: Warning)

Message	Port <code><port></code> disabled - BPDU received on protected port
Category	Multiple spanning tree protocol
Severity	Warning
Description	This log event informs the user that BPDU was received on protected port

Event ID: 2008

Message	<code><proto> starved for <pkt_type> on port <port> from <priority_mac></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the Rx queue is starved in the particular port

Event ID: 2009

Message	BPDU loss- port <code><port></code> moved to inconsistent state for <code><proto></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the port is in inconsistent state

Event ID: 2010

Message	Port <code><port></code> moved out of inconsistent state for <code><proto></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTP is out of inconsistent state

Event ID: 2011

Message	Topology Change received on port <code><port></code> for <code><proto></code> from source: <code><mac></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTP topology change is received

Event ID: 2012

Message	<code><proto></code> - Topology Change generated on port <code><port></code> going in to <code><state></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTP topology change is generated

Event ID: 2013

Message	BPDU received on admin edge port <code><port></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that a BPDU was received on admin edge port

Event ID: 2014

Message	Port <code><port></code> blocked on CIST
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the CIST port is blocked

Event ID: 2015

Message	Port <code><port></code> unblocked on CIST
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the CIST port is unblocked

Event ID: 2016

Message	Port <code><port></code> blocked on MST <code><instance></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTI port is blocked

Event ID: 2017

Message	Port <code><port></code> unblocked on MST <code><instance></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the MSTI port is unblocked

Event ID: 2018

Message	<code><proto></code> Root Port changed from <code><old_port></code> to <code><new_port></code>
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the root port is changed

Event ID: 2019

Message	spanning tree mode changed from <code><old_mode></code> to <code><new_mode></code> , it will trigger the reconvergence
Category	Multiple spanning tree protocol
Severity	Information
Description	This log event informs the user that the spanning tree mode is changed.

The following are the events related to MVRP.

Event ID: 3101

Message	MVRP enabled on port <code><port></code>
Category	MVRP
Severity	Information
Description	This command enables the MVRP (Multiple VLAN Registration Protocol) feature on interface.

Event ID: 3102

Message	MVRP disabled on port <code><port></code>
Category	MVRP
Severity	Information
Description	This command disables the MVRP (Multiple VLAN Registration Protocol) feature on interface.

Event ID: 3103

Message	MVRP failed to create VLAN <code><vlan></code> . Maximum VLANs <code><max_vlan></code> already created' throttle_count: 100
Category	MVRP
Severity	Information
Description	This log event informs user that the vlan create is failed.

Event ID: 3104

Message	MVRP statistics have been cleared for port <code><port></code>
Category	MVRP
Severity	Information
Description	This log event informs user that the mvrp statistics have been cleared.

Event ID: 3105

Message	MVRP statistics have been cleared for <i><port></i> ports
Category	MVRP
Severity	Information
Description	This log event informs user that the mvrp statistics have been cleared.

The following are the events related to NAE agents.

Event ID: 6901

Message	An action has been triggered by the NAE agent <name>': yes
Category	NAE Agents
Severity	Information
Description	Action has been triggered by an NAE agent

The following are the events related to Network Analytics Engine.

Event ID: 6001

Message	NAE agent <code><name></code> started to collect samples from <code><uri></code> .
Category	NAE
Severity	Information
Description	NAE agent started to collect samples.

Event ID: 6002

Message	NAE agent <code><name></code> stopped to collect samples from <code><uri></code> .
Category	NAE
Severity	Information
Description	NAE agent stopped to collect samples.

Event ID: 6003

Message	NAE agent <code><name></code> with URI <code><uri></code> has error and cannot collect samples.
Category	NAE
Severity	Error
Description	NAE agent with URI has error and cannot collect samples.

Event ID: 6004

Message	NAE agent <code><name></code> is watching for condition <code><condition></code> .
Category	NAE
Severity	Information
Description	NAE agent is watching for condition.

Event ID: 6005

Message	NAE agent <name> stopped to watch for condition <condition>.
Category	NAE
Severity	Information
Description	NAE agent stopped to watch for condition.

Event ID: 6006

Message	NAE agent <name> with condition <condition> has error and is not watched.
Category	NAE
Severity	Error
Description	NAE agent with condition has error and is not watched.

Event ID: 6007

Message	NAE agent <name> generated an alert based on condition <condition>.
Category	NAE
Severity	Information
Description	NAE agent generated an alert based on condition.

Event ID: 6008 (Severity: Warning)

Message	NAE experiencing a spike in data points to process for NAE monitor <monitorName>. NAE will temporarily stop monitoring new data points for <monitorName>.
Category	NAE
Severity	Warning
Description	NAE experiencing a spike in data points to process. Temporarily disabling processing updates from specific NAE monitor.

Event ID: 6009

Message	NAE resuming to monitor data points from NAE monitor <monitorName>
Category	NAE
Severity	Information
Description	NAE resuming to monitor data points from specific NAE monitor.

Event ID: 6010

Message	User <user> has cleard NAE time series database
Category	NAE
Severity	Information
Description	Logs a message when a user clears the NAE time series database

The following are the events related to NAE script generation.

Event ID: 12701

Message	NAE agent <i><agent></i> creation failed. Reason <i><reason></i>
Category	NAE script generation
Severity	Error
Description	NAE agent creation failed

The following are the events related to Network Analytics Engine scripts.

Event ID: 5501

Message	NAE script <code><name></code> has been validated.
Category	NAE Scripts
Severity	Information
Description	NAE script has been validated.

Event ID: 5502

Message	Error found in NAE Script <code><name></code> .
Category	NAE Scripts
Severity	Error
Description	Error found in NAE Script.

Event ID: 5503

Message	Error found in NAE Agent <code><name></code> .
Category	NAE Scripts
Severity	Error
Description	Error found in NAE Agent.

Event ID: 5504

Message	Error executing NAE action <code><action_type></code> belonging to condition <code><condition></code> and agent <code><agent></code> due to <code><description></code> .
Category	NAE Scripts
Severity	Error
Description	NAE Action error.

Event ID: 5505

Message	NAE Script <name> has been created by the system.
Category	NAE Scripts
Severity	Information
Description	NAE Script has been created by the system.

Event ID: 5506

Message	NAE Agent <name> has been created by the system.
Category	NAE Scripts
Severity	Information
Description	NAE Agent has been created by the system.

Event ID: 5507

Message	<msg>
Category	NAE Scripts
Severity	Information
Description	Log event when instantiated from active NAE agent.

Event ID: 5508

Message	<msg>
Category	NAE Scripts
Severity	Information
Description	Log event when instantiated from active NAE agent.

Event ID: 5509 (Severity: Critical)

Message	<msg>
Category	NAE Scripts
Severity	Critical
Description	Log event when instantiated from active NAE agent.

Event ID: 5510

Message	<msg>
---------	-------

Category	NAE Scripts
Severity	Error
Description	Log event when instantiated from active NAE agent.

Event ID: 5511 (Severity: Warning)

Message	<msg>
Category	NAE Scripts
Severity	Warning
Description	Log event when instantiated from active NAE agent.

Event ID: 5512 (Severity: Emergency)

Message	<msg>
Category	NAE Scripts
Severity	Emergency
Description	Log event when instantiated from active NAE agent.

Event ID: 5513 (Severity: Emergency)

Message	<msg>
Category	NAE Scripts
Severity	Emergency
Description	Log event when instantiated from active NAE agent.

Event ID: 5514

Message	<msg>
Category	NAE Scripts
Severity	Debug
Description	Log event when instantiated from active NAE agent.

The following are the events related to ND snooping.

Event ID: 8401

Message	All the dynamic binding entries were cleared.
Category	ND snooping
Severity	Information
Description	Log event when all dynamic binding entries are cleared.

Event ID: 8402

Message	Dynamic binding entries on the port <code><port></code> were cleared.
Category	ND snooping
Severity	Information
Description	Log event when all dynamic binding entries on a port are cleared.

Event ID: 8403

Message	Dynamic binding entries on the VLAN <code><vid></code> were cleared.
Category	ND snooping
Severity	Information
Description	Log event when all dynamic binding entries on a vlan are cleared.

Event ID: 8404

Message	Dynamic binding entry with ip <code><ip></code> on the VLAN <code><vid></code> was cleared.
Category	ND snooping
Severity	Information
Description	Log event when a specific dynamic binding entry on a vlan is cleared.

Event ID: 8405

Message	ND packet of type=<type> received on port:<port> vlan:<vlan> with src_mac:<src_mac> is <status>. count=<count>
Category	ND snooping
Severity	Information
Description	Log event when ND packet received on port.

The following are the events related to NDM.

Event ID: 6101

Message	Static Neighbor <ip> created on Port <port>, VRF <vrf> mac <mac>
Category	NDM
Severity	Information
Description	Static neighbor created

Event ID: 6102

Message	Static Neighbor <ip> deleted on Port <port>, VRF <vrf> and mac <mac>
Category	NDM
Severity	Information
Description	Static neighbor deleted

Event ID: 6103

Message	Static Neighbor <ip> modified on Port <port> and VRF <vrf> from mac <old_mac> to new mac <new_mac>
Category	NDM
Severity	Information
Description	Static neighbor modified

Event ID: 6104

Message	IPDB neighbor <ip> added in port <port>, VRF <vrf>
Category	NDM
Severity	Information
Description	IPDB neighbor added to the neighbor Table

Event ID: 6105

Message	IPDB Neighbor <ip> Deleted
Category	NDM
Severity	Information
Description	IPDB neighbor deleted from the neighbor Table

Event ID: 6106

Message	Clear all Arp entries requested on Port <port> and VRF <vrf>
Category	NDM
Severity	Information
Description	Clear all arp entries requested on Specific Port

Event ID: 6107

Message	Clear all VSX Peer ARP entries requested on Port <port> and vrf <vrf>
Category	NDM
Severity	Information
Description	Clear all VSX Peer ARP entries requested on Specific Port

Event ID: 6108

Message	Clear all Arp entries requested on VRF <vrf>
Category	NDM
Severity	Information
Description	Clear all arp entries requested on Specific VRF

Event ID: 6109

Message	Clear all VSX Peer Arp entries requested on VRF <vrf>
Category	NDM
Severity	Information
Description	Clear all VSX Peer arp entries requested on Specific VRF

Event ID: 6110

Message	Clear all Arp entries requested
---------	---------------------------------

Category	NDM
Severity	Information
Description	Clear all arp entries requested

Event ID: 6111

Message	Clear all VSX Peer Arp entries requested
Category	NDM
Severity	Information
Description	Clear all VSX Peer arp entries requested

Event ID: 6112

Message	EVPN Virtual Tunnel EndPoint Neighbor <ip> added to Port<port> on VRF <vrf>
Category	NDM
Severity	Information
Description	EVPN Virtual Tunnel EndPoint Neighbor added to the neighbor table

Event ID: 6113

Message	EVPN Virtual Tunnel EndPoint Neighbor <ip> updated on Port<port> and VRF <vrf> with mac <mac>
Category	NDM
Severity	Information
Description	EVPN Virtual Tunnel EndPoint Neighbor Updated in the neighbor table

Event ID: 6114

Message	EVPN VTEP Neighbor <ip> deleted from Port<port> and VRF <vrf>
Category	NDM
Severity	Information
Description	EVPN VTEP Neighbor deleted from the neighbor table

Event ID: 6115

Message	Management Role set to <role>
---------	-------------------------------

Category	NDM
Severity	Information
Description	Processing Redundancy management

Event ID: 6116

Message	Management role changed from old <code><role1></code> to new role <code><role2></code>
Category	NDM
Severity	Information
Description	Management role changed to new role

Event ID: 6117

Message	IPv4 neighbor ageout time changed to <code><time></code> seconds on port <code><port></code>
Category	NDM
Severity	Information
Description	IPv4 neighbor ageout time changed to new value

Event ID: 6118

Message	IPv6 neighbor ageout time changed to <code><time></code> seconds on port <code><port></code>
Category	NDM
Severity	Information
Description	IPv6 neighbor ageout time changed to new value

Event ID: 6119

Message	VSX neighbor datapath init sync status is neighbor sync completed
Category	NDM
Severity	Information
Description	VSX neighbor datapath init sync status is neighbor sync completed

Event ID: 6120

Message	VSX neighbor datapath init sync status is neighbor sync in progress
Category	NDM

Severity	Information
Description	VSX neighbor datapath init sync status is neighbor sync in progress

Event ID: 6121

Message	<code>static neighbor <ip> add failed, Subnet match failed</code>
Category	NDM
Severity	Error
Description	Static Neighbor add failed, subnet not matched

Event ID: 6122

Message	<code>static neighbor <ip> add failed, it is own ip</code>
Category	NDM
Severity	Error
Description	Static Neighbor add failed, it is own ip

Event ID: 6123

Message	<code>static neighbor <ip> Subnet match add failed, port is down</code>
Category	NDM
Severity	Error
Description	Static Neighbor add failed, port is down

Event ID: 6124

Message	<code>Neighbor table VSX peer DB connection terminated</code>
Category	NDM
Severity	Information
Description	Neighbor table VSX peer DB connection terminated

Event ID: 6125

Message	<code>Neighbor table VSX peer DB connection established</code>
Category	NDM
Severity	Information
Description	Neighbor table VSX peer DB connection established

Event ID: 6126

Message	VSX Peer IP <ip> added the port <port> and VRF <vrf>
Category	NDM
Severity	Information
Description	VSX Peer IP added in port vsxPeerIpCache

Event ID: 6127

Message	VSX Peer IP <ip> deleted from the port <port> and VRF <vrf>
Category	NDM
Severity	Information
Description	VSX Peer IP deleted in port vsxPeerIpCache

Event ID: 6128

Message	Proxy arp enabled for the port <port>
Category	NDM
Severity	Information
Description	Proxy arp enabled for the given interface

Event ID: 6129

Message	Proxy arp disabled for the port <port>
Category	NDM
Severity	Information
Description	Proxy arp disabled for the given interface

Event ID: 6130

Message	Neighbor <ip> modified on Port <port> and VRF <vrf> from mac <old_mac> to new mac <new_mac>
Category	NDM
Severity	Information
Description	Neighbor modified

Event ID: 6131

Message	Neighbor Discovery daemon started
Category	NDM
Severity	Information
Description	Neighbor Discovery daemon started

Event ID: 6132

Message	Duplicate IPv4 address <ip> is detected on port <port> with a MAC address of <mac>' throttle_count: 40
Category	NDM
Severity	Error
Description	Duplicate IP detected from ARP reply

Event ID: 6133

Message	Duplicate IPv6 address <ip> is detected on port <port> with a MAC address of <mac>
Category	NDM
Severity	Error
Description	Duplicate IPv6 address detected from Neighbour advertisement

Event ID: 6134

Message	Duplicate IPv4 address <ip> is detected on port <port> with a MAC address of <mac>' throttle_count: 40
Category	NDM
Severity	Error
Description	Duplicate IP detected from ARP request

The following are the events related to NTP.

Event ID: 1101

Message	NTP Association <code><event></code> : <code><server></code> <code><server_info></code>
Category	NTP
Severity	Information
Description	Logs NTP Association configuration changes

Event ID: 1102

Message	NTP Trusted keys <code><trusted_keys></code> and Untrusted keys <code><untrusted_keys></code>
Category	NTP
Severity	Information
Description	Logs NTP Trusted and Untrusted authentication-keys

Event ID: 1103

Message	NTP Authentication state change: <code><old></code> -> <code><new></code>
Category	NTP
Severity	Information
Description	Logs NTP Authentication state changes

Event ID: 1104

Message	NTP VRF state change: <code><old></code> -> <code><new></code>
Category	NTP
Severity	Information
Description	Logs NTP VRF configuration state changes

Event ID: 1105

Message	NTP primary server connection established to <server>
Category	NTP
Severity	Information
Description	Logs NTP primary server connection established state change

Event ID: 1106

Message	NTP primary server connection lost to <server>
Category	NTP
Severity	Information
Description	Logs NTP primary server connection lost state change

Event ID: 1107

Message	NTP enable state change: <old> -> <new>
Category	NTP
Severity	Information
Description	Event raised when NTP is changed to enabled or disabled

The following are the events related to OSPFv2.

Event ID: 2401

Message	AdjChg: Nbr <router-id> on <ospf-interface>(<area>): <old_state> -> <new_state>
Category	OSPFv2
Severity	Information
Description	Logs the changes in OSPFv2 neighbour state machine.

Event ID: 2402

Message	Interface <interface>(<area>) changed from <old_state> to <new_state>, input: <input>
Category	OSPFv2
Severity	Information
Description	Logs the changes in the interface FSM state.

Event ID: 2403

Message	<event> with <destination> <nexthops>
Category	OSPFv2
Severity	Information
Description	Logs OSPFv2 route add and delete.

Event ID: 2404

Message	AdjChg: Nbr <router-id> on <ospf-interface>: <state> -> <next_state> (<event>)
Category	OSPFv2
Severity	Information
Description	Logs the changes in OSPFv2 neighbour state machine.

Event ID: 2405

Message	Router-id updated from <code><old></code> to <code><new></code>
Category	OSPFv2
Severity	Information
Description	Logs the changes in the router-id.

Event ID: 2406

Message	Failed to <code><action></code> <code><rule></code> error: <code><err></code>
Category	OSPFv2
Severity	Error
Description	Logs errors for OSPFv2 FP creation/installation.

Event ID: 2407

Message	OSPF all routers field entry added: <code>group_id=<group_id></code> <code>fp_id=<fp_id></code> <code>stat_id=<stats_id></code>
Category	OSPFv2
Severity	Information
Description	Logs for OSPFv2 FP creation/installation.

Event ID: 2408

Message	OSPF designated routers field entry added: <code>group_id=<group_id></code> <code>fp_id=<fp_id></code> <code>stat_id=<stats_id></code>
Category	OSPFv2
Severity	Information
Description	Logs for OSPFv2 DR FP creation/installation.

Event ID: 2409

Message	Graceful Restart state changed, <code><old_state></code> -> <code><new_state></code> , reason: <code><reason></code>
Category	OSPFv2
Severity	Information
Description	Logs the changes of OSPFv2 Graceful Restart state.

Event ID: 2410

Message	Duplicate router-id for <ospf-interface> from source <source-ip>
Category	OSPFv2
Severity	Error
Description	Logs when router-id is duplicate.

Event ID: 2411

Message	Distance External <external>, Inter-area <inter>, and Intra-area <intra> applied to all the OSPF processes in <vrf> VRF
Category	OSPFv2
Severity	Information
Description	Logs the changes of OSPFv2 distance.

The following are the events related to OSPFv3.

Event ID: 4901

Message	Failed to <action> <rule> error: <err>
Category	OSPFv3
Severity	Error
Description	Logs errors for OSPFv3 FP creation/installation.

Event ID: 4902

Message	OSPF3 all routers field entry added: group_id=<group_id> fp_id=<fp_id> stat_id=<stats_id>
Category	OSPFv3
Severity	Information
Description	Logs for OSPFv3 FP creation/installation.

Event ID: 4903

Message	OSPF3 designated routers field entry added: group_id=<group_id> fp_id=<fp_id> stat_id=<stats_id>
Category	OSPFv3
Severity	Information
Description	Logs for OSPFv3 DR FP creation/installation.

Event ID: 4904

Message	AdjChg: Nbr<router-id> on interface <link-local> on <interface> (<area>): <old_state> -> <new_state>
Category	OSPFv3
Severity	Information
Description	Logs the changes in OSPFv3 neighbour state machine.

Event ID: 4905

Message	Interface <code><link-local></code> on <code><interface></code> (<code><area></code>) changed from <code><old_state></code> to <code><new_state></code> , input: <code><input></code>
Category	OSPFv3
Severity	Information
Description	Logs the changes in the interface FSM state.

Event ID: 4906

Message	Graceful Restart state changed, <code><old_state></code> -> <code><new_state></code> , reason: <code><reason></code>
Category	OSPFv3
Severity	Information
Description	Logs the changes of OSPFv3 Graceful Restart state.

Event ID: 4907

Message	Duplicate router-id for <code><link-local></code> from source <code><source-ip></code>
Category	OSPFv3
Severity	Error
Description	Logs when router-id is duplicate.

Event ID: 4908

Message	Distance External <code><external></code> , Inter-area <code><inter></code> , and Intra-area <code><intra></code> applied to all the OSPFv3 processes in <code><vrf></code> VRF
Category	OSPFv3
Severity	Information
Description	Logs the changes of OSPFv3 distance.

The following are the events related to password reset.

Event ID: 5901

Message	Password reset succeeded for admin user.
Category	Password Reset
Severity	Information
Description	Log message when admin user password reset is successful

Event ID: 5902

Message	Password reset failed for admin user.
Category	Password Reset
Severity	Information
Description	Log message when admin user password reset fails

The following are the events related to PIM.

Event ID: 5101

Message	Failed to send <pkt_type> packet on Interface <InterfaceName>' throttle_count: 100
Category	PIM
Severity	Error
Description	Send error packet

Event ID: 5102

Message	PIM interface <InterfaceName> is configured with IP <ip_address>
Category	PIM
Severity	Information
Description	Pim IP config

Event ID: 5103

Message	Packet dropped from <ip_address> on interface <InterfaceName> <error> <value>' throttle_count: 100
Category	PIM
Severity	Error
Description	Packet dropped

Event ID: 5104

Message	Received packet from router <ip_address>, unkwn pkt type <pkt_type>' throttle_count: 100
Category	PIM
Severity	Error
Description	Received packet from router

Event ID: 5105

Message	Failed to add flow <dip0>.<dip1>.<dip2>.<dip3>, <sip0>.<sip1>.<sip2>.<sip3> (<status> <srcport> <srcvid> <totalvid> <flowtype> <callerid>)
Category	PIM
Severity	Error
Description	Failed to add flow

Event ID: 5106

Message	Failed to remove flow g <dip0>.<dip1>.<dip2>.<dip3>, s <sip0>, <sip1>.<sip2>.<sip3> (<status> <srcport> <srcvid> <flowtype> <callerid>)
Category	PIM
Severity	Error
Description	Failed to remove flow for Hardware

Event ID: 5107 (Severity: Warning)

Message	Failed to add a mroute for s=<source>, g=<group> on interface <interfaceName> as the configured mroute limits are reached' throttle_count: 100
Category	PIM
Severity	Warning
Description	Failed to program mroute as the limits are reached

Event ID: 5108 (Severity: Warning)

Message	Failed to add a mroute for s=<source>, g=<group> on interface <interfaceName> as the configured sources per group limit is reached' throttle_count: 100
Category	PIM
Severity	Warning
Description	Failed to program mroute as the sources per group limit is reached

Event ID: 5109

Message	This router is elected as the <ip_version> <state> for interface <ifname>
Category	PIM

Severity	Information
Description	PIM DR election log

Event ID: 5110

Message	<code><type> <reason> failed with Fd: <fd> on Port: <port>. Error description: <err></code>
Category	PIM
Severity	Error
Description	Multicast socket creation error

Event ID: 5111

Message	<code>OVSDB operation failed with <err>' throttle_count: 100</code>
Category	PIM
Severity	Error
Description	DB Operation failed

Event ID: 5112

Message	<code>New Elected BSR for VRF <vrf_name> is <ebsr_ip> with priority <priority></code>
Category	PIM
Severity	Information
Description	Elected BSR

Event ID: 5113

Message	<code>Elected BSR removed on VRF <vrf_name></code>
Category	PIM
Severity	Information
Description	Elected BSR removed

Event ID: 5114

Message	<code>Candidate BSR <ip_address> with priority <priority> is <status> on interface <ifname></code>
---------	--

Category	PIM
Severity	Information
Description	Configured candidate BSR

Event ID: 5115

Message	PIM Neighbor <code><neighbor_ip></code> is <code><event></code> on interface <code><ifname></code>
Category	PIM
Severity	Information
Description	Neighbor status

Event ID: 5116 (Severity: Warning)

Message	<code><pkt></code> packet is discarded on interface <code><ifname></code> . Reason: <code><reason></code> ' throttle_count: 100
Category	PIM
Severity	Warning
Description	Packet drop

Event ID: 5117

Message	Forwarding state has changed to <code><state></code> on <code><ip_version></code> enabled interface <code><ifname></code>
Category	PIM
Severity	Information
Description	Interface operational status

Event ID: 5118

Message	<code><pim_version></code> <code><mode></code> mode is <code><status></code> on interface <code><ifname></code>
Category	PIM
Severity	Information
Description	Interface PIM mode

Event ID: 5119

Message	Router <code><pim_version></code> is <code><mode></code> on VRF <code><vrfname></code>
---------	--

Category	PIM
Severity	Information
Description	Router pim configuration status

Event ID: 5120

Message	Candidate RP <code><ip_address></code> is <code><event></code> on VRF <code><vrf_name></code>
Category	PIM
Severity	Information
Description	Learnt or removed candidate RP

Event ID: 5121

Message	Software Packet Queue <code><limit></code> threshold value <code><val></code> reached. Queue size: <code><qsize></code>
Category	PIM
Severity	Information
Description	Software Packet Queue reaches threshold

Event ID: 5122

Message	This router is elected as the <code><ip_version></code> VSX <code><state></code> for interface <code><ifname></code>
Category	PIM
Severity	Information
Description	PIM VSX DR Election log

Event ID: 5123

Message	VSX ISL Status changed to <code><isl_status></code>
Category	PIM
Severity	Information
Description	VSX ISL Status update log

Event ID: 5124

Message	Candidate RP <code><ip_address></code> is configured on interface <code><ifname></code>
---------	---

Category	PIM
Severity	Information
Description	Configured candidate RP

Event ID: 5125

Message	BFD Session created for neighbor <code><ip_address></code> on interface <code><ifname></code>
Category	PIM
Severity	Information
Description	BFD Session created

Event ID: 5126

Message	BFD Session deleted for neighbor <code><ip_address></code> on interface <code><ifname></code>
Category	PIM
Severity	Information
Description	BFD Session deleted

Event ID: 5127

Message	PIM Resource utilization of <code><capacity_type></code> has reached/exceeded the supported limits on the system.
Category	PIM
Severity	Information
Description	This log event informs the user that PIM resource utilization has exceeded the supported limits

Event ID: 5128

Message	PIM Resource utilization of <code><capacity_type></code> has reached 90 percent of the supported limits on the system.
Category	PIM
Severity	Information
Description	This log event informs the user that PIM resource utilization has reached 90 percent of the supported limits

Event ID: 5129

Message	PIM Resource utilization of <i><capacity_type></i> has dropped below 90 percent of the supported limits on the system.
Category	PIM
Severity	Information
Description	This log event informs the user that PIM resource utilization drops below 90 percent of the supported limits

Event ID: 5130

Message	Router <i><pim_version></i> PIM-SSM is <i><mode></i> on VRF <i><vrfname></i>
Category	PIM
Severity	Information
Description	Router PIM-SSM configuration status

Event ID: 5131

Message	Router <i><pim_version></i> PIM-SSM range ACL is <i><mode></i> on VRF <i><vrfname></i>
Category	PIM
Severity	Information
Description	Router PIM-SSM range ACL configuration status

The following are the events related to policies.

Event ID: 10101

Message	Policy <i><policy_name></i> failed to apply on <i><application></i>
Category	Policies
Severity	Error
Description	Policy application failure

The following are the events related to port access.

Event ID: 10501

Message	Client <code><mac_address></code> was logged-off administratively through command-line interface
Category	Port access
Severity	Information
Description	Client was logged-off administratively through command-line interface

Event ID: 10502

Message	Port <code><port></code> is blocked by port-access
Category	Port access
Severity	Information
Description	The port is blocked by port-access daemon

Event ID: 10503

Message	Port <code><port></code> is unblocked by port-access
Category	Port access
Severity	Information
Description	The port is unblocked by port-access daemon

Event ID: 10504

Message	Clients were logged-off on the port <code><port></code> due to a change in authentication mode from <code><old_mode></code> to <code><new_mode></code>
Category	Port access
Severity	Information
Description	The authentication mode associated with the port is changed

Event ID: 10505

Message	Clients were logged-off on the port <i><port></i> due to a change in client limit from <i><old_limit></i> to <i><new_limit></i>
Category	Port access
Severity	Information
Description	The client limit associated with the port is changed

Event ID: 10506

Message	The name associated with VLAN <i><vlan_id></i> changed from <i><old_name></i> to <i><new_name></i>
Category	Port access
Severity	Information
Description	The name associated with a VLAN in use by port-access daemon changed

Event ID: 10507

Message	Clients using policy <i><policy_name></i> were logged-off due to a configuration change in the policy
Category	Port access
Severity	Information
Description	The policy configuration is updated by the user

Event ID: 10508

Message	VLAN conflict detected on port <i><port></i>
Category	Port access
Severity	Error
Description	VLAN is configured as Trunk for some clients and access for others. This could potentially result in traffic loss

Event ID: 10509

Message	Client limit exceeded on port <i><port></i> , caused by an unauthenticated client <i><mac_addr></i> ' throttle_count: 30: yes
Category	Port access
Severity	Information
Description	Log event when an intruder is detected on the port

Event ID: 10510

Message	All clients except client with MAC address <i><mac_addr></i> logged-off on the port <i><port></i> due to a change in authentication mode from <i><old_mode></i> to <i><new_mode></i>
Category	Port access
Severity	Information
Description	The authentication mode associated with the port is changed

The following are the events related to port access group based policy.

Event ID: 12601

Message	Configuration change in the policy <code><pac_gbp_name> <operation></code>
Category	Port access group based policy
Severity	Information
Description	The group based policy configuration is updated by the user

Event ID: 12602

Message	Configuration update in the policy due to class change <code><pac_gbp_name> <operation></code>
Category	Port access group based policy
Severity	Information
Description	The group based policy class configuration is updated by the user

Event ID: 12603

Message	Trigger received to <code><operation></code> policy: <code><pac_gbp_name></code> for client: <code><client></code>
Category	Port access group based policy
Severity	Information
Description	The group based policy applying/unapplying for client

Event ID: 12604

Message	Trigger received to <code><operation></code> policy: <code><pac_gbp_name></code> for client: <code><client></code> is <code><result></code>
Category	Port access group based policy
Severity	Information
Description	The group based policy apply/unapply for client result

Event ID: 12605

Message	Trigger received on <i><operation></i> of line_card: <i><line_card></i> to <i><action></i> policy: <i><pac_gbp_name></i>
Category	Port access group based policy
Severity	Information
Description	The group based policy apply/unapply on new linecard

Event ID: 12606

Message	Trigger received on <i><operation></i> of line_card: <i><line_card></i> to <i><action></i> policy: <i><pac_gbp_name></i> is <i><result></i>
Category	Port access group based policy
Severity	Information
Description	The group based policy apply/unapply on new linecard result

The following are the events related to port access roles.

Event ID: 9301

Message	Failed to apply ClearPass role - <code><cprole_error_string></code>
Category	Port access roles
Severity	Error
Description	Logs an event if there are errors when applying a ClearPass role

Event ID: 9302

Message	Failed to create the role - <code><role_name></code> , maximum limit reached' throttle_count: 100
Category	Port access roles
Severity	Error
Description	Logs an event if the maximum limit is reached while creating a Port Access Role

The following are the events related to port.

Event ID: 601

Message	Netlink socket creation failed <error>
Category	Port
Severity	Information
Description	Log when netlink socket creation failed

Event ID: 602

Message	Netlink socket bind failed <error>
Category	Port
Severity	Information
Description	Log when netlink socket bind failed

Event ID: 603

Message	Netlink failed to set mtu <mtu> for interface <interface>
Category	Port
Severity	Information
Description	Log when netlink failed to set mtu for interface

Event ID: 604

Message	Netlink failed to bring <status> the interface <interface>
Category	Port
Severity	Information
Description	Log when netlink failed to change the interface status

Event ID: 605

Message	Unknown internal vlan policy <i><policy></i>
Category	Port
Severity	Information
Description	Unknown internal vlan policy

Event ID: 606

Message	Error allocating internal vlan for port <i><vlan></i>
Category	Port
Severity	Information
Description	Log when allocation failed for internal vlan for port

Event ID: 607

Message	Overlapping networks observed for <i><ip_address></i>
Category	Port
Severity	Error
Description	Log when a duplicate address is received on a port

The following are the events related to port security.

Event ID: 9401

Message	Client limit exceeded on port <code><if_name></code> , caused by an unauthorized client <code><mac_addr></code> ' throttle_count: 30: yes
Category	Port security
Severity	Information
Description	Log event when an intruder is detected on the port

Event ID: 9402

Message	Port security sticky client move violation triggered on port <code><port></code> for client with MAC address <code><mac_addr></code> .' throttle_count: 30: yes
Category	Port security
Severity	Information
Description	Log event when sticky mac is moved to other port

The following are the events related to port statistics.

Event ID: 6601

Message	Failed to create layer 3 IPv4 RX statistic for port:<name>
Category	Port Statistics
Severity	Error
Description	Logs a message when the creation of a Layer 3 IPv4 RX counter fails

Event ID: 6602

Message	Failed to create layer 3 IPv6 RX statistic for port:<name>
Category	Port Statistics
Severity	Error
Description	Logs a message when the creation of a Layer 3 IPv6 RX counter fails

Event ID: 6603

Message	Failed to create layer 3 IPv4 TX statistic for port:<name>
Category	Port Statistics
Severity	Error
Description	Logs a message when the creation of a Layer 3 IPv4 TX counter fails

Event ID: 6604

Message	Failed to create layer 3 IPv6 TX statistic for port:<name>
Category	Port Statistics
Severity	Error
Description	Logs a message when the creation of a Layer 3 IPv6 TX counter fails

The following are the events related to power.

Event ID: 301

Message	PSU <i><name></i> changed state to <i><state></i>
Category	Power
Severity	Information
Description	Log the change in PSU status.

Event ID: 302 (Severity: Warning)

Message	PSUs inserted in the system are of <i><Type></i> types. This is <i><Support></i> configuration.
Category	Power
Severity	Warning
Description	Log the identification of mixed PSU types

Event ID: 303

Message	PSU <i><name></i> encountered a warning. Total warning count: <i><warnings></i>
Category	Power
Severity	Error
Description	Log the warnings encountered by the PSU

Event ID: 304

Message	PSU <i><name></i> faulted. Total fault count: <i><failures></i>
Category	Power
Severity	Error
Description	Log the failures encountered by the PSU

Event ID: 305 (Severity: Warning)

Message	PSU <name>: Internal communication <status>
Category	Power
Severity	Warning
Description	Log PSU internal communication failure

Event ID: 306 (Severity: Warning)

Message	PSU <name>: Fan-<fanidx> <status>
Category	Power
Severity	Warning
Description	Log PSU fan fault

Event ID: 307 (Severity: Warning)

Message	PSU <name>: <sensorid> sensor <status> threshold limit
Category	Power
Severity	Warning
Description	Log when PSU temperature sensor exceeded threshold

Event ID: 308

Message	PSU <name> has shutdown due to over temperature in <sensorid> sensor
Category	Power
Severity	Error
Description	Log when PSU temperature sensor triggered PSU shutdown

Event ID: 309 (Severity: Warning)

Message	PSU <name>: Output current <status> threshold limit
Category	Power
Severity	Warning
Description	Log when PSU output current exceeds threshold

Event ID: 310

Message	PSU <name> has shutdown due to output overcurrent
---------	---

Category	Power
Severity	Error
Description	Log when PSU output current triggered PSU shutdown

Event ID: 311

Message	PSU <code><name></code> has shutdown due to output overvoltage
Category	Power
Severity	Error
Description	Log when PSU output voltage triggered PSU shutdown

Event ID: 312

Message	PSU Redundancy set to <code><redund></code>
Category	Power
Severity	Information
Description	Log a change in the PSU redundancy user configuration

Event ID: 313

Message	PSU Redundancy operating at <code><redund></code>
Category	Power
Severity	Information
Description	Log a change in the PSU redundancy operational state

Event ID: 314 (Severity: Warning)

Message	PSU <code><name></code> disabled: PSU airflow does not match system-airflow
Category	Power
Severity	Warning
Description	Log when PSU is disabled due to airflow direction mismatch

Event ID: 315

Message	PSU <code><name></code> disabled: PSU communication error
Category	Power

Severity	Error
Description	Log when PSU is disabled due to communication error

Event ID: 316 (Severity: Warning)

Message	<code><type> module <name> denied power due to insufficient power. Configured PoE power can be deconfigured to allow card to be granted power.</code>
Category	Power
Severity	Warning
Description	There is insufficient power to power a card. Power can be removed from configured PoE PDs to be able to power the card.

Event ID: 317 (Severity: Warning)

Message	<code>PSU <name> disabled: PSU inserted is not supported by the system</code>
Category	Power
Severity	Warning
Description	Log when PSU is disabled due to an unsupported PSU

Event ID: 318

Message	<code>Power over Ethernet status has faulted</code>
Category	Power
Severity	Error
Description	Log 54V Power over Ethernet status fault

Event ID: 319

Message	<code>Power over Ethernet status is good</code>
Category	Power
Severity	Information
Description	Log 54V Power over Ethernet status is good

Event ID: 320

Message	<code>PSU <name> <alert> occurred</code>
---------	--

Category	Power
Severity	Error
Description	Log when PSU voltage alert occurs

Event ID: 321

Message	PSU <name> <alert> recovered
Category	Power
Severity	Information
Description	Log when PSU voltage alert recovers

Event ID: 322 (Severity: Warning)

Message	Invalid PoE power configuration, using default maximum PoE power
Category	Power
Severity	Warning
Description	Log when configured PoE power is invalid

Event ID: 323

Message	PSU <name> is not supported by the system. Please insert a supported PSU. Refer to the Installation Guide for supported configurations.
Category	Power
Severity	Error
Description	Log event for an unsupported PSU, recorded periodically for each PSU.

The following are the events related to power over Ethernet.

Event ID: 7901

Message	Detected powered device on interface <code><interface_name></code> . Type: <code><pd_type></code> , Class: <code><pd_class></code>
Category	Power over Ethernet
Severity	Information
Description	Detected powered device on interface. Type, Class.

Event ID: 7902

Message	Powered device power delivery on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device power delivery on interface.

Event ID: 7903 (Severity: Warning)

Message	Powered device power denied on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Warning
Description	Powered device power denied on interface.

Event ID: 7904 (Severity: Warning)

Message	Powered device fault on interface <code><interface_name></code> . Fault type <code><fault_type></code>
Category	Power over Ethernet
Severity	Warning
Description	Powered device fault on interface. Fault type.

Event ID: 7905

Message	Powered device disconnected on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device disconnected on interface.

Event ID: 7906

Message	PoE disabled on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	PoE disabled on interface

Event ID: 7907

Message	Powered device mps absent on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device mps absent on interface

Event ID: 7908

Message	Detected dual signature powered device on interface <code><interface_name></code> . Type: <code><pd_type></code> , ClassA: <code><paira_class></code> , ClassB: <code><pairb_class></code>
Category	Power over Ethernet
Severity	Information
Description	Detected dual signature powered device on interface. Type, ClassA, ClassB

Event ID: 7909

Message	Dual signature powered device power delivery on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Dual signature powered device power delivery on interface.

Event ID: 7910 (Severity: Warning)

Message	Dual signature powered device fault on interface <code><interface_name></code> pair <code><pair></code> . Fault type <code><fault_type></code>
Category	Power over Ethernet
Severity	Warning
Description	Dual signature powered device fault on interface. Fault type.

Event ID: 7911

Message	Dual signature powered device mps absent on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Dual signature powered device mps absent on interface

Event ID: 7912

Message	Powered device FET bad fault recovered on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device FET bad fault recovered on interface

Event ID: 7913

Message	Powered device FET bad fault recovery failed on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device FET bad fault recovery failed on interface

Event ID: 7914

Message	Powered device got class demoted on interface <code><interface_name></code> . Requested_class <code><req_class></code> Assigned_class <code><assigned_class></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device got class demoted on interface

Event ID: 7915

Message	Dual signature powered device got class demoted on interface <code><interface_name></code> . Requested_classA <code><req_class_A></code> Requested_classB <code><req_class_B></code> Assigned_classA <code><assigned_class_A></code> Assigned_classB <code><assigned_class_B></code>
Category	Power over Ethernet
Severity	Information
Description	Dual signature powered device got class demoted on interface

Event ID: 7916

Message	Powered device pre std detect enabled on interface <code><interface_name></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device pre std detect enabled on interface

Event ID: 7917

Message	PoE usage exceeded threshold limit of <code><threshold_limit></code>
Category	Power over Ethernet
Severity	Information
Description	PoE usage exceeded threshold limit

Event ID: 7918

Message	PoE controller <code><cntrl_name></code> got into fault
Category	Power over Ethernet
Severity	Information
Description	PoE controller got into fault

Event ID: 7919

Message	PoE controller <code><cntrl_name></code> got reset
Category	Power over Ethernet
Severity	Information
Description	PoE controller got reset

Event ID: 7920

Message	Powered device got class promoted on interface <interface_name>.Requested_class <req_class> Assigned_class <assigned_class>
Category	Power over Ethernet
Severity	Information
Description	Powered device got class promoted

Event ID: 7921

Message	Dual signature powered device got class promoted on interface <interface_name>.Requested_classA <req_class_A> Requested_classB <req_class_B> Assigned_classA <assigned_class_A> Assigned_classB <assigned_class_B>
Category	Power over Ethernet
Severity	Information
Description	Dual signature powered device got class promoted

Event ID: 7922

Message	Powered device is drawing power more than its class on interface <interface_name>, type:<pd_type> class:<pd_class> power:<power> is exceeding the max average power of the PD class. Check the PD max power draw, cabling type and length to improve interoperability
Category	Power over Ethernet
Severity	Information
Description	Powered device is drawing power more than its class

Event ID: 7923

Message	Powered device UVLO fault on interface <interface_name>, will attempt to recover itself by toggling power
Category	Power over Ethernet
Severity	Information
Description	Powered device UVLO fault on interface

Event ID: 7924

Message	Powered device FET BAD fault on interface <interface_name>
Category	Power over Ethernet

Severity	Information
Description	Powered device FET BAD fault

Event ID: 7925

Message	Dual signature powered device is drawing power more than its class on interface <code><interface_name></code> , type: <code><pd_type></code> classA: <code><paira_class></code> classB: <code><pairb_class></code> power: <code><power></code>
Category	Power over Ethernet
Severity	Information
Description	Dual signature powered device is drawing power more than its class

Event ID: 7926

Message	PoE usage is below threshold of <code><threshold_limit></code>
Category	Power over Ethernet
Severity	Information
Description	PoE usage is below threshold

Event ID: 7927 (Severity: Warning)

Message	Total power drawn: <code><power_drawn></code> W by powered device is exceeding the total available PoE power: <code><power_available></code> W. Check the PD max power draw, cabling type and length to avoid system crowbar.
Category	Power over Ethernet
Severity	Warning
Description	PoE drawn power is more than available PoE power

Event ID: 7928 (Severity: Warning)

Message	Powered device invalid signature indication on interface <code><interface_name></code> .
Category	Power over Ethernet
Severity	Warning
Description	Powered device invalid signature indication

Event ID: 7929

Message	PoE hardware access daemon exiting
Category	Power over Ethernet
Severity	Information
Description	PoE hardware access daemon exiting

Event ID: 7930

Message	POE proto daemon exiting
Category	Power over Ethernet
Severity	Information
Description	POE proto daemon exiting

Event ID: 7931

Message	Always-on PoE detected a powered device on interface <code><interface_name></code> and delivered power
Category	Power over Ethernet
Severity	Information
Description	Always-on PoE detected a powered device on interface

Event ID: 7932

Message	Powered device disconnected on interface <code><interface_name></code> due to LLDP dot3 disable
Category	Power over Ethernet
Severity	Information
Description	Powered device disconnected on interface due to LLDP dot3 disable

Event ID: 7933

Message	Subsystem <code><subsys_name></code> came up with quick PoE
Category	Power over Ethernet
Severity	Information
Description	Subsystem came up with quick PoE

Event ID: 7934

Message	Quick PoE detected a powered device on interface <code><interface_name></code> and delivered power
Category	Power over Ethernet
Severity	Information
Description	Quick PoE detected a powered device on interface

Event ID: 7935 (Severity: Warning)

Message	Powered device denied on interface <code><interface_name></code> of line module with Quick PoE enabled. Remove device to avoid crowbar on reboot.
Category	Power over Ethernet
Severity	Warning
Description	Powered device denied on interface of line module with Quick PoE enabled.

Event ID: 7936 (Severity: Warning)

Message	Powered device demoted on interface <code><interface_name></code> of line module with Quick PoE enabled. Remove device to avoid crowbar on reboot.
Category	Power over Ethernet
Severity	Warning
Description	Powered device demoted on interface of line module with Quick PoE enabled

Event ID: 7937 (Severity: Warning)

Message	PoE disable ignored on interface <code><interface_name></code> because Quick PoE is enabled
Category	Power over Ethernet
Severity	Warning
Description	PoE disable ignored on interface because Quick PoE is enabled

Event ID: 7938 (Severity: Warning)

Message	PoE assigned class configuration is ignored on interface <code><interface_name></code> because Quick PoE is enabled
Category	Power over Ethernet
Severity	Warning
Description	PoE assigned class configuration is ignored on interface because Quick PoE is enabled

Event ID: 7939

Message	Powered device requested power down on interface <code><interface_name></code> <code><duration></code>
Category	Power over Ethernet
Severity	Information
Description	Powered device requested power down on interface.

Event ID: 7940

Message	Powered device disconnected on interface <code><interface_name></code> due to pd-class-override config change
Category	Power over Ethernet
Severity	Information
Description	Powered device disconnected on interface due to pd-class-override config change

Event ID: 7941

Message	Powered device disconnected on interface <code><interface_name></code> due to power-pairs config change
Category	Power over Ethernet
Severity	Information
Description	Powered device disconnected on interface due to power-pairs config change

The following are the events related to PTP.

Event ID: 12101

Message	PTP <code><type></code> <code><delay_mechanism></code> <code><clock_step></code> clock started with profile <code><profile></code> and transport <code><transport></code> .
Category	PTP
Severity	Information
Description	Event reported when PTP clock is started.

Event ID: 12102

Message	PTP clock stopped. Reason: <code><reason></code>
Category	PTP
Severity	Information
Description	Event reported when PTP clock is stopped.

Event ID: 12103

Message	Interface <code><name></code> enabled for PTP exchange.
Category	PTP
Severity	Information
Description	Event reported when PTP port is enabled for tx and rx.

Event ID: 12104

Message	Interface <code><name></code> disabled for PTP exchange. Reason: <code><reason></code>
Category	PTP
Severity	Information
Description	Event reported when PTP enabled port is disabled.

Event ID: 12105

Message	PTP clock is in <i><state></i> state
Category	PTP
Severity	Information
Description	Event reported for different PTP clock state.

Event ID: 12106

Message	Interface <i><name></i> is in <i><state></i> state
Category	PTP
Severity	Information
Description	Event reported for different PTP port state.

Event ID: 12107

Message	New GrandSource/Parent is selected: Parent: <i><parent></i> , GrandSource: <i><grandsource></i> , Quality: <i><quality></i> , Priority1: <i><priority1></i> , Priority2: <i><priority2></i>
Category	PTP
Severity	Information
Description	Event reported when PTP parent is updated/modified.

Event ID: 12108

Message	PTP operational log_announce_interval is changed to <i><value></i> on interface <i><name></i> for profile <i><profile></i>
Category	PTP
Severity	Information
Description	Event reported when PTP log announce interval is modified.

Event ID: 12109

Message	PTP operational log_min_pdelay_request_interval is changed to <i><value></i> on interface <i><name></i> for profile <i><profile></i>
Category	PTP
Severity	Information
Description	Event reported when PTP log min pdelay request interval is modified.

Event ID: 12110

Message	PTP operational log_min_delay_request_interval is changed to <value> on interface <name> for profile <profile>
Category	PTP
Severity	Information
Description	Event reported when PTP log min delay request interval is modified.

Event ID: 12111

Message	PTP operational sync_request_timeout is changed to <value> on interface <name> for profile <profile>
Category	PTP
Severity	Information
Description	Event reported when PTP sync request timeout is modified.

Event ID: 12112

Message	PTP operational sync_interval is changed to <value> on interface <name> for profile <profile>
Category	PTP
Severity	Information
Description	Event reported when PTP sync interval is modified.

Event ID: 12113

Message	PTP operational announce_request_timeout is changed to <value> on interface <name> for profile <profile>
Category	PTP
Severity	Information
Description	Event reported when PTP announce request timeout is modified.

Event ID: 12114

Message	PTP config invalid. Reason: <reason>
Category	PTP
Severity	Information
Description	Event reported if PTP configuration is invalid.

Event ID: 12115

Message	PTP domain modified from <old> to <new> value
Category	PTP
Severity	Information
Description	Event reported if PTP domain configuration is modified.

Event ID: 12116

Message	PTP vlan modified from <old> to <new> on port <port>
Category	PTP
Severity	Information
Description	Event reported if PTP vlan configuration is modified.

Event ID: 12117

Message	PTP source_ip_interface <action>. Port: <value>
Category	PTP
Severity	Information
Description	Event reported if PTP source_ip_interface configuration is modified.

Event ID: 12118

Message	PTP source_ip <action>. IP: <value>
Category	PTP
Severity	Information
Description	Event reported if PTP source_ip configuration is modified.

The following are the events related to quality of service ASIC provider.

Event ID: 5801 (Severity: Warning)

Message	QoS failed initial initialization for slot <code><local_slot></code> . Error: <code><error></code>
Category	QoS ASIC Provider
Severity	Warning
Description	QoS initial initialization failed

Event ID: 5802 (Severity: Critical)

Message	QoS failed final initialization on new slot <code><new_slot></code> for peer slot <code><existing_slot></code>
Category	QoS ASIC Provider
Severity	Critical
Description	QoS final initialization failed for new slot

Event ID: 5803

Message	QoS error after card removal from slot <code><slot></code>
Category	QoS ASIC Provider
Severity	Error
Description	QoS error after card removal

Event ID: 5804

Message	Error during QoS feature configuration: <code><error_string></code>
Category	QoS ASIC Provider
Severity	Error
Description	Error while attempting QoS feature configuration

Event ID: 5805

Message	Error during QoS HW configuration: <code><error_string> error <val></code>
Category	QoS ASIC Provider
Severity	Error
Description	Error while attempting QoS HW configuration

Event ID: 5806 (Severity: Warning)

Message	Port: <code><port_name></code> PFC priority <code><pri></code> using queue <code><queue></code> should not be sharing the queue with other local-priorities
Category	QoS ASIC Provider
Severity	Warning
Description	Warning PFC priority sharing a queue

The following are the events related to quality of service.

Event ID: 5701

Message	QoS failed to retrieve default information. Error: <code><error></code>
Category	Quality of Service
Severity	Information
Description	QoS failed to retrieve default configuration

Event ID: 5702

Message	QoS error: <code><error_string></code>
Category	Quality of Service
Severity	Error
Description	QoS error occurred

Event ID: 5703 (Severity: Warning)

Message	The PFC configuration for interface <code><ifname></code> exceeds the system limit of <code><limit></code> unique combinations and was not applied
Category	Quality of Service
Severity	Warning
Description	Logged when there are more unique combinations of flow controlled priorities than the system allows.

Chapter 94

Rapid per VLAN Spanning Tree Protocol events

The following are the events related to rapid per VLAN spanning tree protocol.

Event ID: 5001

Message	RPVST Enabled
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event indicates that RPVST has been enabled on the switch.

Event ID: 5002

Message	RPVST Disabled
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event indicates that RPVST has been disabled on the switch.

Event ID: 5003

Message	RPVST - Root changed from <i><old_priority></i> : <i><old_mac></i> to <i><new_priority></i> : <i><new_mac></i> on VLAN <i><vlan></i> .
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event indicates that RPVST root on a VLAN has changed

Event ID: 5004 (Severity: Warning)

Message	Port <i><port></i> disabled - BPDU received on protected port on VLAN <i><vlan></i> .
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Warning
Description	This log event informs the user BPDU received on protected port

Event ID: 5005

Message	<code><proto> starved for <pkt_type> on port <port> from <priority_mac> on VLAN <vlan>.</code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event informs the user that the Rx is starved in particular port

Event ID: 5006

Message	<code>Topology change received on port <port> from source: <mac> on VLAN <vlan>.</code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event informs the user that the RPVST topology change is received

Event ID: 5007

Message	<code>Topology change generated on port <port> on VLAN <vlan>.</code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event informs the user that the RPVST topology change is generated

Event ID: 5008 (Severity: Warning)

Message	<code>Port <port> blocked on RPVST <instance></code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Warning
Description	This log event informs the user that the port is blocked on the instance

Event ID: 5009 (Severity: Warning)

Message	<code>Port <port> unblocked on RPVST <instance></code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Warning
Description	This log event informs the user that the port is unblocked on the instance

Event ID: 5010

Message	Root port changed from <code><old_port></code> to <code><new_port></code> on VLAN <code><vlan></code> .
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event informs the user that the root port is changed

Event ID: 5011

Message	PVID mismatch detected on <code><interface></code> with pvid = <code><pvid></code> , Neighbor pvid = <code><npvid></code> ' throttle_count: 100
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	Log event when the PVID mismatches between the switch and neighbor over an interface

Event ID: 5012

Message	spanning tree mode changed from <code><old_mode></code> to <code><new_mode></code> , it will trigger the reconvergence
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	This log event informs the user that the spanning tree mode is changed.

Event ID: 5013

Message	Current Virtual Ports <code><Current_Virtual_Ports></code> exceeds the max supported limit <code><Maximum_Virtual_Ports></code>
Category	Rapid per VLAN Spanning Tree Protocol
Severity	Information
Description	Log event when the current virtual port count crosses the maximum allowed value

The following are the events related to RBAC.

Event ID: 10301

Message	Local authorization has been <tac_status>d
Category	RBAC
Severity	Information
Description	Log event when local tac_plus server has been started

Event ID: 10302

Message	Failed to <tac_status> local authorization
Category	RBAC
Severity	Error
Description	Log event when local tac_plus server failed to start

The following are the events related to redundant management.

Event ID: 2201

Message	Failover detected: Reason <i><reason></i>
Category	Redundant Management
Severity	Information
Description	This log event informs that failover event is detected

Event ID: 2202

Message	Lost <i><mgmt_module></i> as Standby Management Module, redundancy disabled
Category	Redundant Management
Severity	Information
Description	This log event informs that standby mgmt module has been removed

Event ID: 2203

Message	Detected the removal of the Standby Management Module
Category	Redundant Management
Severity	Information
Description	This log event informs that standby mgmt module has been removed

Event ID: 2204

Message	<i><mgmt_module></i> is Active
Category	Redundant Management
Severity	Information
Description	This log event informs about the status of Active mgmt module

Event ID: 2205

Message	<code><mgmt_module> is Standby</code>
Category	Redundant Management
Severity	Information
Description	This log event informs about the status of Standby mgmt module

Event ID: 2206

Message	<code>Detected <mgmt_module> as Standby Management Module, redundancy enabled</code>
Category	Redundant Management
Severity	Information
Description	This log event informs that standby mgmt module is added to the system

Event ID: 2207

Message	<code>Remote Standby Management module recover detected. Reason: Heartbeat loss</code>
Category	Redundant Management
Severity	Information
Description	This log event informs the user that Active mgmt module has detected heartbeat loss

Event ID: 2208

Message	<code><mgmt_module> is waiting for filesync</code>
Category	Redundant Management
Severity	Information
Description	This log event informs the user that filesync is in progress

Event ID: 2209

Message	<code><mgmt_module> is starting ISSU operation</code>
Category	Redundant Management
Severity	Information
Description	This log event informs the user that an ISSU operation has begun

The following are the events related to replication manager.

Event ID: 2701 (Severity: Warning)

Message	All bitmaps have been allocated
Category	Replication Manager
Severity	Warning
Description	Log to indicate all bitmaps have been allocated

Event ID: 2702 (Severity: Warning)

Message	Over 80 percent of bitmaps have been allocated
Category	Replication Manager
Severity	Warning
Description	Log to indicate over 80 percent of bitmaps have been allocated

Event ID: 2705 (Severity: Warning)

Message	Multicast L3 Bridge Control Forwarding entry with uuid <uuid_str> has no reference to a VLAN
Category	Replication Manager
Severity	Warning
Description	Log indicates Mutlicast L3 Bridge Control Forwarding entry with uuid has no reference to a VLAN

The following are the events related to REST.

Event ID: 4601

Message	Authentication failed for user <code><user></code> in session <code><sessionid></code>
Category	REST
Severity	Error
Description	logs a failed authentication attempt of a user via REST

Event ID: 4602

Message	Authentication succeeded for user <code><user></code> in session <code><sessionid></code>
Category	REST
Severity	Information
Description	logs a successful authentication attempt of a user via REST

Event ID: 4603 (Severity: Critical)

Message	Conflict in authorization configuration. Existing config::URL (<code><match></code>), type(<code><value></code>) New config::(<code><url></code>), type(<code><autztype></code>)
Category	REST
Severity	Critical
Description	logs an authorization configuration conflict

Event ID: 4606

Message	Authorization failed for user <code><user></code> , for resource <code><resource></code> , with action <code><action></code>
Category	REST
Severity	Error
Description	logs a failed authorization attempt of a user via REST

Event ID: 4607

Message	Authorization succeeded for user <code><user></code> , for resource <code><resource></code> , with action <code><action></code>
Category	REST
Severity	Information
Description	logs a successful authorization attempt of a user via REST

Event ID: 4608

Message	Authorization allowed for user <code><user></code> , for resource <code><resource></code> , with action <code><action></code>
Category	REST
Severity	Information
Description	logs an allowed authorization attempt of a user via REST

Event ID: 4609

Message	User <code><user></code> added <code><added_user></code> with role <code><added_user_role></code>
Category	REST
Severity	Information
Description	logs a successful add of a user via REST

Event ID: 4610

Message	User <code><user></code> deleted <code><deleted_user></code>
Category	REST
Severity	Information
Description	logs a successful deletion of a user via REST

Event ID: 4611

Message	User <code><user></code> successfully changed password
Category	REST
Severity	Information
Description	logs a successful password change for a user via REST

Event ID: 4612 (Severity: Warning)

Message	User <user> password change failed
Category	REST
Severity	Warning
Description	logs an unsuccessful password change for a user via REST

Event ID: 4613

Message	<user> has written a new switch configuration to <config_name>
Category	REST
Severity	Information
Description	logs a success config write operation

Event ID: 4614

Message	<user> has copied switch configuration <from_name> to <to_name>
Category	REST
Severity	Information
Description	logs a success copy of saved

Event ID: 4615

Message	<user> has configured <dns_nameserver> DNS nameserver to <dns>
Category	REST
Severity	Information
Description	logs a success when the nameserver is written to ovssdb

Event ID: 4616

Message	<user> has deleted all DNS nameservers
Category	REST
Severity	Information
Description	logs a success when the nameserver is deleted from ovssdb

Event ID: 4617

Message	<user> created <uri>
---------	----------------------

Category	REST
Severity	Information
Description	A user has successfully created a new resource in OVSDb.

Event ID: 4618

Message	<code><user> deleted <uri></code>
Category	REST
Severity	Information
Description	A user has successfully deleted a resource in OVSDb.

Event ID: 4619

Message	<code><user> modified <uri></code>
Category	REST
Severity	Information
Description	A user has successfully modified a resource in OVSDb.

Event ID: 4620

Message	User: <code><user></code> added subscriber: <code><subscriber></code> .
Category	REST
Severity	Information
Description	A user has added new notification subscriber.

Event ID: 4621

Message	User: <code><user></code> removed subscriber: <code><subscriber></code> .
Category	REST
Severity	Information
Description	A user has removed notification subscriber.

Event ID: 4622

Message	Subscriber: <code><subscriber></code> added subscription: <code><subscription></code> .
Category	REST

Severity	Information
Description	A subscriber has added new subscription.

Event ID: 4623

Message	Subscriber: <code><subscriber></code> removed subscription: <code><subscription></code> .
Category	REST
Severity	Information
Description	A subscriber has removed subscription.

Event ID: 4624 (Severity: Warning)

Message	Unable to add new subscriber. Max number of subscribers has been reached.
Category	REST
Severity	Warning
Description	Unable to add new subscriber as max number reached.

Event ID: 4625 (Severity: Warning)

Message	Unable to add new subscription. Max number of subscriptions for <code><subscriber></code> has been reached.
Category	REST
Severity	Warning
Description	Unable to add new subscription as max number reached for the specified subscriber.

Event ID: 4626

Message	NAE Script <code><name></code> has been created by user <code><user></code> .
Category	REST
Severity	Information
Description	NAE Script has been created successfully.

Event ID: 4627

Message	NAE Script <code><name></code> has been deleted by user <code><user></code> .
Category	REST

Severity	Information
Description	NAE Script has been deleted successfully.

Event ID: 4628

Message	NAE Agent <code><name></code> has been created by user <code><user></code> .
Category	REST
Severity	Information
Description	NAE Agent has been created successfully.

Event ID: 4629

Message	NAE Agent <code><name></code> has been updated by user <code><user></code> .
Category	REST
Severity	Information
Description	NAE Agent has been updated successfully.

Event ID: 4630

Message	NAE Agent <code><name></code> has been deleted by user <code><user></code> .
Category	REST
Severity	Information
Description	NAE Agent has been deleted successfully.

Event ID: 4631

Message	Error rebooting switch, reboot command: <code><command></code> , error received: <code><error></code>
Category	REST
Severity	Error
Description	Logs an error if a reboot fails.

Event ID: 4632

Message	Connection to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code> has been successfully established.
Category	REST

Severity	Information
Description	Connection is established with Aruba Central.

Event ID: 4633

Message	Connection to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> and Source IP <code><source_ip></code> has been closed by Aruba Central. Requesting new Aruba Central location from CLI/DHCP/Activate.
Category	REST
Severity	Information
Description	Connection to Aruba Central has been closed by Aruba Central. Request to get new location from CLI/DHCP/Activate.

Event ID: 4634

Message	Connection to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> and Source IP <code><source_ip></code> has been closed by Aruba Central. Trying to reconnect.
Category	REST
Severity	Information
Description	Connection to Aruba Central has been closed by Aruba Central. Trying to reconnect.

Event ID: 4635

Message	Received Aruba Central location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code>
Category	REST
Severity	Information
Description	Received new Aruba Central location.

Event ID: 4636

Message	Received new Aruba Central location. Closing existing connection with Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code> .
Category	REST
Severity	Information
Description	Received new Aruba Central location. Closing existing connection with Aruba Central.

Event ID: 4637

Message	Internal error. Closing connection to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code> .
Category	REST
Severity	Error
Description	Internal error. Closing connection to Aruba Central.

Event ID: 4638

Message	Waiting for Aruba Central location from CLI/DHCP/Aruba Activate Server.
Category	REST
Severity	Information
Description	Waiting for Aruba Central location from Central Source (CLI/DHCP/Aruba Activate Server).

Event ID: 4639

Message	Connecting to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code> .
Category	REST
Severity	Information
Description	Connecting to Aruba Central.

Event ID: 4640

Message	Failed to connect to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code>
Category	REST
Severity	Error
Description	Failed to connect to Aruba Central.

Event ID: 4641

Message	Aruba Central is disabled.
Category	REST
Severity	Information
Description	The Aruba Central feature is disabled.

Event ID: 4642

Message	Aruba Central is disabled. Closing connection to Aruba Central on location <code><central_location></code> on VRF <code><vrf></code> with Source IP <code><source_ip></code>
Category	REST
Severity	Information
Description	The Aruba Central feature is disabled.

Event ID: 4643

Message	Aruba Central is enabled.
Category	REST
Severity	Information
Description	The Aruba Central feature is enabled.

Event ID: 4645

Message	Aruba Activate server <code><activate_address></code> is reachable via VRF <code><vrf></code> .
Category	REST
Severity	Information
Description	Aruba Activate server is reachable via an active VRF.

Event ID: 4646

Message	Aruba Activate server <code><activate_address></code> is not reachable through any supported VRF.
Category	REST
Severity	Information
Description	Aruba Activate server is not reachable through any supported VRF.

Event ID: 4647

Message	Switch time is synced with NTP Servers.
Category	REST
Severity	Information
Description	Switch time is synced with NTP Servers.

Event ID: 4648

Message	Switch time is synced with Aruba Activate Server <code><activate_address></code> .
Category	REST
Severity	Information
Description	Switch time is synced with Aruba Activate Server.

Event ID: 4649

Message	Unable to sync switch time with Aruba Activate Server <code><activate_address></code> via VRF <code><vrf></code> .
Category	REST
Severity	Error
Description	Unable to sync switch time with Aruba Activate Server.

Event ID: 4650

Message	Unable to fetch Aruba Central location <code><central_location></code> from <code><central_source></code> via VRF <code><vrf></code> .
Category	REST
Severity	Information
Description	Unable to fetch Aruba Central location from Central Source (CLI/DHCP/Aruba Activate Server).

Event ID: 4651

Message	Aruba Central location <code><central_location></code> successfully fetched from <code><central_source></code> via VRF <code><vrf></code>
Category	REST
Severity	Information
Description	Aruba Central location successfully fetched from Central Source (CLI/DHCP/Aruba Activate Server) via VRF.

Event ID: 4652 (Severity: Warning)

Message	Aruba Central connected, any config change through rest <code><rest_operation></code> operation may not be persistent. If central reapplies the config, change can be overwritten
Category	REST
Severity	Warning

Description	Aruba Central connected, any config change through rest may not be persistent, aruba central can overwrite the change
-------------	---

Event ID: 4653

Message	User <user> has configured <mode> for configuration lockout
Category	REST
Severity	Information
Description	Logs a message when a user changes the REST configuration lockout mode

Event ID: 4654

Message	Aruba Central support mode is <mode> for a vtysh session
Category	REST
Severity	Information
Description	Logs a message when a Aruba Central support mode is enabled or disabled

Event ID: 4655

Message	User <user_name> logged in from <identity> through REST session
Category	REST
Severity	Information
Description	Logs a message when a user login is successful

Event ID: 4656

Message	User <user_name> login from <identity> for REST session has failed
Category	REST
Severity	Error
Description	Logs a message when a user login fails

Event ID: 4657

Message	User <user_name> logged out of REST session from <identity>
Category	REST
Severity	Information
Description	Logs a message when a user logs out of a session

Event ID: 4658 (Severity: Warning)

Message	REST session from <identity> with User <user_name> is rejected because maximum session limit is reached
Category	REST
Severity	Warning
Description	Logs a message when a user tries to login while maximum number of sessions are reached

Event ID: 4659

Message	REST session from <identity> with User <user_name> timed out due to idle timeout
Category	REST
Severity	Information
Description	Logs a message when a REST session timed out due to the session being idle

Event ID: 4660

Message	REST server is enabled on VRF <vrf_name>
Category	REST
Severity	Information
Description	Logs a message when the REST server is enabled on a VRF

Event ID: 4661

Message	REST server is disabled on VRF <vrf_name>
Category	REST
Severity	Information
Description	Logs a message when the REST server is disabled on a VRF

The following are the events related to self test.

Event ID: 4501

Message	Selftest has started on subsystem <i><subsystem></i>
Category	Self Test
Severity	Information
Description	logs the start of selftest on a particular subsystem

Event ID: 4502

Message	Selftest has completed on subsystem <i><subsystem></i>
Category	Self Test
Severity	Information
Description	logs the completion of selftest on a particular subsystem

Event ID: 4503

Message	Selftest has failed on subsystem <i><subsystem></i> with error code <i><value></i> : yes
Category	Self Test
Severity	Error
Description	logs the selftest failure of a particular subsystem

Event ID: 4504

Message	Selftest has failed on <i><stack>/<slot>/<interface></i> with error code <i><value></i> : yes
Category	Self Test
Severity	Error
Description	logs the port selftest failure on a given subsystem

The following are the events related to sFlow.

Event ID: 1001

Message	Failed to <code><operation></code> host sFlow agent: <code><error></code>
Category	sFlow
Severity	Error
Description	Log a failure when trying to start/stop/restart host sFlow daemon.

Event ID: 1002

Message	Failed to <code><operation></code> host sFlow configuration file <code><file></code> : <code><error></code>
Category	sFlow
Severity	Error
Description	Log a failure when trying to read/write to host sFlow configuration file.

Event ID: 1003

Message	Failed to <code><operation></code> sFlow configuration from bridge <code><bridge></code> : <code><error></code>
Category	sFlow
Severity	Error
Description	Log a failure when trying to configure sFlow on SIM OVS.

Event ID: 1004

Message	Failed to delete all iptable rules: <code><error></code>
Category	sFlow
Severity	Error
Description	Log a failure when trying to delete all iptable rules added for sFlow.

Event ID: 1005

Message	Failed to <code><operation></code> <code><chain></code> iptable rules for <code><port></code> : <code><error></code>
Category	sFlow
Severity	Error
Description	Log a failure when trying to add/delete an iptable rule for sFlow.

Event ID: 1006

Message	sFlow initialization failed.
Category	sFlow
Severity	Error
Description	Logs an error if sFlow initialization fails.

Event ID: 1007

Message	Invalid packet sent by ASIC in sFlow callback.
Category	sFlow
Severity	Error
Description	Logs an error for an invalid packet in sFlow callback.

Event ID: 1008

Message	Unable to get netdev for interface <code><interface></code>
Category	sFlow
Severity	Error
Description	Logs an error if an interface does not have a netdev class.

Event ID: 1009

Message	Failed to create KNET filter as description is blank
Category	sFlow
Severity	Error
Description	Logs an error if the description to create a filter is blank.

Event ID: 1010

Message	Failed to create KNET filter for: <code><desc></code>
---------	---

Category	sFlow
Severity	Error
Description	Logs an error if sFlow KNET filter creation fails.

Event ID: 1011

Message	The received sampled packet is null
Category	sFlow
Severity	Error
Description	Logs an error if sampled packet is null.

Event ID: 1012

Message	The sFlow agent is not initialized
Category	sFlow
Severity	Error
Description	Logs an error if sFlow agent is not initialized.

Event ID: 1013

Message	The sFlow sampler is not initialized
Category	sFlow
Severity	Error
Description	Logs an error if sFlow sampler is not initialized.

Event ID: 1014

Message	Cannot enable/disable sFlow on an invalid port: <port>
Category	sFlow
Severity	Error
Description	Logs an error if sFlow is enabled/disabled on an invalid port.

Event ID: 1015

Message	sFlow sampler is not available on port: <port>
Category	sFlow

Severity	Error
Description	Logs an error if sFlow sampler is missing on a port.

Event ID: 1016

Message	sFlow receiver is not available
Category	sFlow
Severity	Error
Description	Logs an error if sFlow receiver is not available.

Event ID: 1017

Message	Failed to retrieve port configuration: <i><error></i>
Category	sFlow
Severity	Error
Description	Logs an error if port configuration is not available.

Event ID: 1018

Message	Failed to set sampling rate on port <i><port></i> : <i><error></i>
Category	sFlow
Severity	Error
Description	Logs an error if setting a sampling rate on a port fails.

Event ID: 1019

Message	Failed to get sampling rate on port <i><port></i> : <i><error></i>
Category	sFlow
Severity	Error
Description	Logs an error if unable to retrieve sampling rate on a port.

Event ID: 1020

Message	Invalid agent interface IP address: <i><ip_address></i>
Category	sFlow
Severity	Error
Description	Logs an error in case of invalid agent interface IP address configuration.

Event ID: 1021

Message	Invalid collector IP address: <code><ip_address></code>
Category	sFlow
Severity	Error
Description	Logs an error in case of invalid collector IP address configuration.

Event ID: 1022

Message	Failed to get interface statistics for unit <code><unit></code> port <code><port></code> : <code><error></code>
Category	sFlow
Severity	Error
Description	Logs an error if unable to retrieve interface statistics.

Event ID: 1023

Message	sFlow agent created.
Category	sFlow
Severity	Information
Description	Logs creation of sFlow agent.

Event ID: 1024

Message	sFlow agent deleted.
Category	sFlow
Severity	Information
Description	Logs deletion of sFlow agent.

Event ID: 1025

Message	Changed sFlow sampling rate from <code><old_rate></code> to <code><new_rate></code> .
Category	sFlow
Severity	Information
Description	Logs a change in sFlow sampling rate.

Event ID: 1026

Message	Set sFlow agents header len to <code><hdrlen></code> .
Category	sFlow
Severity	Information
Description	Logs sFlow agents header length event.

Event ID: 1027

Message	Set sFlow agents IP to <code><ip_addr></code> .
Category	sFlow
Severity	Information
Description	Logs setting IP address to sFlow agent.

Event ID: 1028

Message	Set max datagram size on sFlow agent to <code><dgramsize></code> .
Category	sFlow
Severity	Information
Description	Log setting max datagram size on sFlow agent.

Event ID: 1029

Message	Add sFlow poller on <code><port_name></code> with ifIndex <code><ifIndex></code> at interval <code><intvl></code> .
Category	sFlow
Severity	Information
Description	Add sFlow poller on a port.

Event ID: 1030

Message	Remove sFlow poller on <code><ifIndex></code> .
Category	sFlow
Severity	Information
Description	Delete sFlow poller on a port.

Event ID: 1031

Message	Set polling interval of <code><intvl></code> on sFlow agent.
Category	sFlow
Severity	Information
Description	Set polling interval for sFlow agent.

Event ID: 1032

Message	sFlow sampling mode set to <code><mode></code> .
Category	sFlow
Severity	Information
Description	Logs change in sFlow mode.

The following are the events related to SFTP client.

Event ID: 5301

Message	SFTP file transfer from <i><from></i> to <i><to></i> completed.
Category	SFTP Client
Severity	Information
Description	SFTP file transfer completed

Event ID: 5302

Message	SFTP file transfer from <i><from></i> to <i><to></i> failed - <i><status></i> .
Category	SFTP Client
Severity	Information
Description	SFTP file transfer failed

The following are the events related to smartlink.

Event ID: 11301

Message	Flush message received on <ifName> with control VLAN <id>
Category	Smartlink
Severity	Information
Description	Event raised when flush message received on interface with control vlan

Event ID: 11302

Message	Active link of the smartlink group <id> changed to <ifName>
Category	Smartlink
Severity	Information
Description	Event raised when active link changed in the smartlink group

Event ID: 11303

Message	Backup link of the smartlink group <id> changed to <ifName>
Category	Smartlink
Severity	Information
Description	Event raised when backup link changed in the smartlink group

The following are the events related to SNMP.

Event ID: 7101

Message	<code>Snmp agent is up and running in namespace <vrf></code>
Category	SNMP
Severity	Information
Description	SNMP agent is enabled.

Event ID: 7102

Message	<code>Snmp sub agent is up and running in namespace <vrf></code>
Category	SNMP
Severity	Information
Description	SNMP sub agent is enabled.

Event ID: 7103

Message	<code>Snmp agent is disabled for namespace <vrf></code>
Category	SNMP
Severity	Information
Description	SNMP agent is disabled.

Event ID: 7104

Message	<code>Snmp sub agent is disabled for namespace <vrf></code>
Category	SNMP
Severity	Information
Description	SNMP sub agent is disabled.

Event ID: 7105

Message	Failed to poll snmp
Category	SNMP
Severity	Information
Description	SNMP poll thread creation failed.

Event ID: 7106

Message	Snmp and credential manager integration failed
Category	SNMP
Severity	Information
Description	SNMP failed to synchronize with credential manager

Event ID: 7107

Message	Snmp system now configured
Category	SNMP
Severity	Information
Description	SNMP system is configured.

Event ID: 7108

Message	Snmp and database Integration has been initialized
Category	SNMP
Severity	Information
Description	Snmp successfully synchronized with database

Event ID: 7109

Message	Successfully initialized all SNMP plugins
Category	SNMP
Severity	Information
Description	SNMP plugins successfully initialized.

Event ID: 7110

Message	Destroyed all SNMP plugins
---------	----------------------------

Category	SNMP
Severity	Information
Description	SNMP plugin successfully deinitialized.

Event ID: 7111

Message	SNMP cache sync on-demand is set to: <i><truth_value></i>
Category	SNMP
Severity	Information
Description	SNMP on demand idl sync.

The following are the events related to SSH client.

Event ID: 9001

Message	Connection to SSH server <ipaddr> on VRF <vrf_name> is established for user <username> over port <port_num>
Category	SSH client
Severity	Information
Description	SSH client session is successful.

Event ID: 9002

Message	Connection to SSH server <ipaddr> on VRF <vrf_name> over port <port_num> is denied
Category	SSH client
Severity	Error
Description	SSH client session is denied

Event ID: 9003

Message	Connection to SSH server <ipaddr> on VRF <vrf_name> is successfully closed for user <username> over port <port_num>
Category	SSH client
Severity	Information
Description	SSH client session is successful.

The following are the events related to SSH server.

Event ID: 5201

Message	SSH host-key <key_name> is installed.
Category	SSH server
Severity	Information
Description	Logs a message when the SSH host-key generated

Event ID: 5202

Message	SSH server is enabled on VRF <vrf_name>.
Category	SSH server
Severity	Information
Description	Logs a message when the SSH server is enabled on a VRF

Event ID: 5203

Message	SSH server is disabled on VRF <vrf_name>.
Category	SSH server
Severity	Information
Description	Logs a message when the SSH server is disabled on a VRF

Event ID: 5204

Message	SSH client-public-key <key_name> was installed for the user <username>.
Category	SSH server
Severity	Information
Description	Logs a message when add ssh client-public-key into authorized_keys file

Event ID: 5205

Message	SSH client-public-key <key_name> was removed for the user <username>.
Category	SSH server
Severity	Information
Description	Logs a message when delete ssh client-public-key into authorized_keys file

Event ID: 5207

Message	An internal error occurred while reading the SSH host-key <key_name>.
Category	SSH server
Severity	Information
Description	Logs a message when the SSH host-key is corrupted

Event ID: 5208

Message	Failed to enable SSH server on VRF <vrf_name>. Admin password is not set.
Category	SSH server
Severity	Error
Description	Logs a message when a user tries to enable SSH server without setting admin password

Event ID: 5209

Message	User <user_name> logged in from <ip_address> through SSH session.
Category	SSH server
Severity	Information
Description	Logs a message when a user login is successful

Event ID: 5210

Message	User <user_name> login from <ip_address> for SSH session has failed.
Category	SSH server
Severity	Error
Description	Logs a message when a user login fails

Event ID: 5211

Message	User <user_name> logged out of SSH session from <ip_address>.
Category	SSH server
Severity	Information
Description	Logs a message when a user logs out of a session

Event ID: 5212 (Severity: Warning)

Message	SSH session from <ip_address> is rejected because maximum number of SSH sessions is reached.
Category	SSH server
Severity	Warning
Description	Logs a message when a user tries to login while maximum number of sessions are reached.

Event ID: 5213 (Severity: Warning)

Message	SSH session from User <user_name> is closed because maximum number of sessions per user is reached.
Category	SSH server
Severity	Warning
Description	Logs a message when a user session is closed while maximum number of sessions per user are reached.

Event ID: 5214 (Severity: Warning)

Message	SSH session from <ip_address> is closed because of host key failure.
Category	SSH server
Severity	Warning
Description	Logs a message when a user session is closed due to host key failure.

The following are the events related to supportability.

Event ID: 1201 (Severity: Critical)

Message	<code><process> crashed due to <signal>, <timestamp></code>
Category	Supportability
Severity	Critical
Description	A daemon has crashed and generated core dump

Event ID: 1202

Message	<code>Kernel panic occurred</code>
Category	Supportability
Severity	Error
Description	Logs kernel crash

Event ID: 1203

Message	<code>Kernel failed to compress vmcore. Error log:<err_desc></code>
Category	Supportability
Severity	Error
Description	Logs kernel failed to compress vmcore

Event ID: 1204

Message	<code>Kernel panic occurred and secondary kernel failed to save uncompressed core. Error log:<err_desc></code>
Category	Supportability
Severity	Error
Description	Logs kernel panic occurred and secondary kernel core failed to save uncompressed core

Event ID: 1205

Message	Kernel panic occurred and system is restored back to normal state
Category	Supportability
Severity	Error
Description	Logs kernel panic occurred

Event ID: 1206 (Severity: Critical)

Message	Module rebooted. Reason: <code><reason></code> , Boot-ID: <code><boot_id></code>
Category	Supportability
Severity	Critical
Description	Logs reboot information

Event ID: 1207 (Severity: Warning)

Message	Available system memory is back to normal state
Category	Supportability
Severity	Warning
Description	Event raised when available system memory is restored to normal level.

Event ID: 1208

Message	High system memory usage detected. High memory usage daemons are <code><daemons></code>
Category	Supportability
Severity	Error
Description	Event raised when system memory usage goes beyond high threshold.

Event ID: 1209 (Severity: Emergency)

Message	Available system memory is critically low': yes
Category	Supportability
Severity	Emergency
Description	Event raised when system memory usage crosses critical threshold.

Event ID: 1210 (Severity: Warning)

Message	Memory reservation for reboot library failed
Category	Supportability
Severity	Warning
Description	Event raised when memory reservation for reboot library fails.

Event ID: 1211 (Severity: Emergency)

Message	Unable to get current system memory usage
Category	Supportability
Severity	Emergency
Description	Event raised when system memory read is failing.

Event ID: 1212 (Severity: Emergency)

Message	Available system memory is critically low. Reboot will be triggered soon.
Category	Supportability
Severity	Emergency
Description	Available memory is critically low, system will be rebooted.

Event ID: 1213

Message	RMON alarm <index> - Rising threshold value of <threshold> reached for <oid>.
Category	Supportability
Severity	Information
Description	Event raised when the sampled value has reached the rising threshold.

Event ID: 1214

Message	RMON alarm <index> - Falling threshold value of <threshold> reached for <oid>.
Category	Supportability
Severity	Information
Description	Event raised when the sampled value has reached the falling threshold.

Event ID: 1215

Message	<code><process> exiting. Reason: <reason></code>
Category	Supportability
Severity	Error
Description	A process is exiting due to an unrecoverable error

Event ID: 1216 (Severity: Emergency)

Message	<code><process> exiting. Reason: <reason></code>
Category	Supportability
Severity	Emergency
Description	A critical process is exiting due to an unrecoverable error

Event ID: 1217

Message	Coredump(s) are deleted by user
Category	Supportability
Severity	Information
Description	Coredump(s) are deleted by user

Event ID: 1218

Message	Remote logging to <code><remote_host></code> over <code><vrf></code> vrf added.
Category	Supportability
Severity	Information
Description	Event raised when a new syslog server is added for remote logging.

Event ID: 1219

Message	Remote logging to <code><remote_host></code> over <code><vrf></code> vrf removed.
Category	Supportability
Severity	Information
Description	Event raised when a syslog server is removed from remote logging.

Event ID: 1220

Message	Configuration of remote logging to <code><remote_host></code> over <code><vrf></code> vrf modified.
---------	---

Category	Supportability
Severity	Information
Description	Event raised when an existing syslog server configuration is modified.

Event ID: 1221

Message	<code>Watchdog timeout is increased due to high memory usage</code>
Category	Supportability
Severity	Information
Description	Event raised when available RAM memory goes below the threshold and watchdog timeout is increased.

Event ID: 1222

Message	<code>Watchdog timeout is restored to default value</code>
Category	Supportability
Severity	Information
Description	Event raised when the available RAM memory is restored to normal range and the watchdog timeout is restored to default value.

Event ID: 1223 (Severity: Warning)

Message	<code>The <log_type> buffer is almost full.': yes</code>
Category	Supportability
Severity	Warning
Description	Event raised the log buffer is almost full. User can copy these logs before the logs being overwritten.

Event ID: 1224 (Severity: Warning)

Message	<code>The <log_type> buffer has wrapped, older logs will be overwritten.': yes</code>
Category	Supportability
Severity	Warning
Description	Event raised the log buffer has wrapped; older logs will be overwritten.

Event ID: 1225

Message	Collection of support-files named <code><name></code> of type <code><type></code> is requested for the module <code><module></code> .
Category	Supportability
Severity	Information
Description	Event raised when support-files collection is requested.

Event ID: 1226

Message	Support-files named <code><name></code> is requested for deletion.
Category	Supportability
Severity	Information
Description	Event raised when a request is received to delete given support-files.

Event ID: 1227

Message	Support-files named <code><name></code> is deleted.
Category	Supportability
Severity	Information
Description	Event raised when support-files are deleted.

Event ID: 1228

Message	Collection of support-files named <code><name></code> failed due to <code><reason></code> .
Category	Supportability
Severity	Error
Description	Event raised when collection support-files failed.

Event ID: 1229

Message	Deletion of support-files named <code><name></code> failed due to <code><reason></code> .
Category	Supportability
Severity	Error
Description	Event raised when failed to delete a given support-files.

Event ID: 1230

Message	Collection of support-files named <name> is <state>.
Category	Supportability
Severity	Information
Description	Event raised when collection of support-files state changes.

Event ID: 1231

Message	Syslog client restarted due to configuration change.
Category	Supportability
Severity	Information
Description	Event raised when remote syslog is restarted due to configuration change.

Event ID: 1232

Message	The security log buffer is cleared
Category	Supportability
Severity	Information
Description	Event raised as the security log buffer is cleared

The following are the events related to SYS.

Event ID: 701

Message	Failed to read FRU data from base system
Category	SYS
Severity	Information
Description	Log when failed to read FRU data from base system

Event ID: 702

Message	Failed to read FRU header
Category	SYS
Severity	Information
Description	Log when failed to read FRU header

Event ID: 703

Message	Error reading FRU EEPROM Header
Category	SYS
Severity	Information
Description	log when FRU EEPROM Header failed

Event ID: 704

Message	Failed to initialize devices
Category	SYS
Severity	Information
Description	Log when failed to initialize devices

Event ID: 705

Message	Failed to allocate memory for <value>
Category	SYS
Severity	Information
Description	Log when failed to allocate memory

Event ID: 706

Message	Initiating system reboot
Category	SYS
Severity	Information
Description	Indicates that the chassis is about to reboot.

Event ID: 707

Message	Initiating chassis thermal reboot
Category	SYS
Severity	Error
Description	Indicates that the chassis experienced a thermal event and will reboot

Event ID: 708

Message	Invalid Device Version Programmed. Please check MFG data programmed on the device.
Category	SYS
Severity	Error
Description	Indicates invalid device version is programmed on the device

Event ID: 709

Message	Failed to read assembly revision
Category	SYS
Severity	Error
Description	Indicates device has failed to read assembly revision that is programmed

The following are the events related to SYSMON.

Event ID: 6301

Message	System resource utilization poll interval is changed to <code><poll></code> ' throttle_count: 40
Category	SYSMON
Severity	Information
Description	System resource utilization poll change event

Event ID: 6302 (Severity: Warning)

Message	Failed to read system memory usage for module <code><module_num></code>
Category	SYSMON
Severity	Warning
Description	Warns a user when system memory usage read failed

Event ID: 6303

Message	Current system memory usage for module <code><module_num></code> is <code><mem_usage></code> %
Category	SYSMON
Severity	Information
Description	Reports current system memory usage in percentage

Event ID: 6304 (Severity: Warning)

Message	Storage utilization for <code><partition_name></code> partition is at <code><utilization></code> % in module <code><module_name></code> : yes
Category	SYSMON
Severity	Warning
Description	Warns a user when the storage utilization has exceeded the warning limit.

Event ID: 6305

Message	Storage <code><partition_name></code> partition high utilization alert. Utilization is at <code><utilization>%</code> in module <code><module_name>': yes</code>
Category	SYSMON
Severity	Error
Description	Raises high storage utilization alert when the utilization crosses higher utilization limit.

Event ID: 6306 (Severity: Warning)

Message	Excessive write to <code><partition_name></code> partition in module <code><module_name></code> observed. <code><mem_usage>GB</code> written over past <code><unit_count></code> <code><unit>': yes</code>
Category	SYSMON
Severity	Warning
Description	Warns a user when higher write to the storage observed

Event ID: 6307 (Severity: Warning)

Message	Excessive write to swap in module <code><module_name></code> observed. <code><mem_usage>GB</code> written over past <code><unit_count></code> <code><unit>': yes</code>
Category	SYSMON
Severity	Warning
Description	Warns a user when higher write to the swap observed.

Event ID: 6308

Message	Excessive write to <code><partition_name></code> partition in module <code><module_name></code> observed. <code><mem_usage>GB</code> written over past <code><unit_count></code> <code><unit>': yes</code>
Category	SYSMON
Severity	Error
Description	Warns a user when excessive write to the storage observed

Event ID: 6309

Message	Excessive write to swap in module <code><module_name></code> observed. <code><mem_usage>GB</code> written over past <code><unit_count></code> <code><unit>': yes</code>
Category	SYSMON
Severity	Error
Description	Warns a user when excessive write to the swap observed.

The following are the events related to TCAM.

Event ID: 10201

Message	"Policer installation has failed"
Category	TCAM
Severity	Error
Description	Policer installation failure

Event ID: 10202

Message	"TCAM entry installation has failed in table <table_name>"
Category	TCAM
Severity	Error
Description	TCAM entry installation failure

Event ID: 10203

Message	"Installation of TCAM table <table_name> has failed"
Category	TCAM
Severity	Error
Description	TCAM table installation failure

Event ID: 10204

Message	"High-capacity TCAM/LPM entry installation failed in table <table_name>"
Category	TCAM
Severity	Error
Description	High-capacity TCAM/LPM entry installation failure

Event ID: 10205

Message	"High-capacity TCAM/LPM table <table_name> installation failed"
Category	TCAM
Severity	Error
Description	High-capacity TCAM/LPM table installation failure

Event ID: 10206

Message	"Counter installation has failed"
Category	TCAM
Severity	Error
Description	TCAM Counter installation failure

Event ID: 10207

Message	"Range Checker installation has failed"
Category	TCAM
Severity	Error
Description	TCAM Range Checker installation failure

Event ID: 10208

Message	"Policer uninstallation has failed"
Category	TCAM
Severity	Error
Description	Policer uninstallation failure

Event ID: 10209

Message	"TCAM entry uninstallation has failed in table <table_name>"
Category	TCAM
Severity	Error
Description	TCAM entry uninstallation failure

Event ID: 10210

Message	"High-capacity TCAM/LPM entry uninstallation failed in table <table_name>"
---------	--

Category	TCAM
Severity	Error
Description	High-capacity TCAM/LPM entry uninstallation failure

Event ID: 10211

Message	"High-capacity TCAM/LPM table uninstallation failed"
Category	TCAM
Severity	Error
Description	High-capacity TCAM/LPM table uninstallation failure

Event ID: 10212

Message	"Counter uninstallation has failed"
Category	TCAM
Severity	Error
Description	TCAM Counter uninstallation failure

Event ID: 10213

Message	"Range Checker uninstallation has failed"
Category	TCAM
Severity	Error
Description	TCAM Range Checker uninstallation failure

Event ID: 10214

Message	"TCAM Context Group selectors have been exhausted"
Category	TCAM
Severity	Error
Description	TCAM Context Group selectors have been exhausted

Event ID: 10215

Message	"TCAM Context Group IDs have been exhausted"
Category	TCAM

Severity	Error
Description	TCAM Context Group IDs have been exhausted

The following are the events related to telnet server.

Event ID: 12901

Message	TELNET server is enabled on VRF <vrf_name>.
Category	Telnet server
Severity	Information
Description	Logs a message when the Telnet server is enabled on a VRF

Event ID: 12902

Message	TELNET server is disabled on VRF <vrf_name>.
Category	Telnet server
Severity	Information
Description	Logs a message when the Telnet server is disabled on a VRF

Event ID: 12903

Message	Failed to enable Telnet server on VRF <vrf_name>. Admin password is not set.
Category	Telnet server
Severity	Error
Description	Logs a message when a user tries to enable Telnet server without setting admin password

Event ID: 12904

Message	User <user_name> logged in from <ip_address> through TELNET session.
Category	Telnet server
Severity	Information
Description	Logs a message when a user login is successful

Event ID: 12905

Message	User <user_name> login from <ip_address> for TELNET session has failed.
Category	Telnet server
Severity	Error
Description	Logs a message when a user login fails

Event ID: 12906

Message	User <user_name> logged out of TELNET session from <ip_address>.
Category	Telnet server
Severity	Information
Description	Logs a message when a user logs out of a session

Event ID: 12907 (Severity: Warning)

Message	TELNET session from <ip_address> is rejected because maximum number of TELNET sessions is reached.
Category	Telnet server
Severity	Warning
Description	Logs a message when a user tries to login while maximum number of sessions are reached.

Event ID: 12908 (Severity: Warning)

Message	TELNET session from User <user_name> is closed because maximum number of sessions per user is reached.
Category	Telnet server
Severity	Warning
Description	Logs a message when a user session is closed when maximum number of sessions per user are reached.

The following are the events related to temperature.

Event ID: 801 (Severity: Warning)

Message	Unrecognized sensor type <code><type></code>
Category	Temperature
Severity	Warning
Description	Log event when sensor type is unrecognized

Event ID: 802 (Severity: Warning)

Message	Module <code><module></code> shutdown initiated for sensor <code><name></code> with critical temperature, <code><temp></code> degC.: yes
Category	Temperature
Severity	Warning
Description	Log event when sensor temperature is above the critical threshold

Event ID: 803 (Severity: Warning)

Message	Over-temperature for sensor <code><name></code> , <code><temp></code> degC.: yes
Category	Temperature
Severity	Warning
Description	Log event when sensor temperature is above the over-temperature threshold

Event ID: 804

Message	Sensor <code><name></code> back to safe temperature, <code><temp></code> degC.
Category	Temperature
Severity	Information
Description	Log event when a sensor returns to safe operating conditions

Event ID: 805

Message	System derate changed from <old> to <new>
Category	Temperature
Severity	Information
Description	Log when the system derate changes.

Event ID: 806 (Severity: Warning)

Message	Ambient temperature for sensor <name> above <temp> degC
Category	Temperature
Severity	Warning
Description	Log when ambient temperature is above the ambient temperature limits.

Event ID: 807

Message	Ambient temperature for sensor <name> back to safe temperature, between <t_low> and <t_high> degC
Category	Temperature
Severity	Information
Description	Log when ambient temperature returns to safe operating conditions.

Event ID: 808

Message	Sensor <name> <limit_type> limit configuration <status>
Category	Temperature
Severity	Information
Description	Log failures in configuring sensor temperature warning/critical limits.

Event ID: 809 (Severity: Warning)

Message	Ambient temperature <temp> degC is above the commercial grade transceiver limit of <limit_high> degC
Category	Temperature
Severity	Warning
Description	Log when ambient temperature is above commercial grade transceiver upper limit when non-industrial transceivers are installed.

Event ID: 810 (Severity: Warning)

Message	Ambient temperature <code><temp></code> degC is below the commercial grade transceiver range of <code><limit_low></code> degC
Category	Temperature
Severity	Warning
Description	Log when ambient temperature is below commercial grade transceiver lower limit when non-industrial transceivers are installed.

Event ID: 811

Message	Ambient temperature <code><temp></code> degC returned to within the commercial grade transceiver range of <code><limit_low>-<limit_high></code> degC
Category	Temperature
Severity	Information
Description	Log when ambient temperature returns to commercial grade transceiver range when non-industrial transceivers are installed.

Event ID: 812 (Severity: Warning)

Message	Ambient temperature for sensor <code><name></code> below <code><temp></code> degC
Category	Temperature
Severity	Warning
Description	Log when ambient temperature is below the ambient temperature limits.

Event ID: 813 (Severity: Warning)

Message	Under-temperature for sensor <code><name></code> , <code><temp></code> degC.: yes
Category	Temperature
Severity	Warning
Description	Log event when sensor temperature is below the under-temperature threshold

Event ID: 814 (Severity: Warning)

Message	Module <code><module></code> shutdown initiated for sensor <code><name></code> with low critical temperature, <code><temp></code> degC.: yes
Category	Temperature
Severity	Warning
Description	Log event when sensor temperature is below the low critical threshold

The following are the events related to time management.

Event ID: 6201

Message	System timezone changed from <oldtz> to <newtz>
Category	Time management
Severity	Information
Description	Change the system timezone

Event ID: 6202

Message	System date/time changed from <old_time> to <new_time>
Category	Time management
Severity	Information
Description	Change the system date/time

The following are the events related to transceiver.

Event ID: 3801

Message	<code>allow-unsupported-transceiver feature enabled</code>
Category	Transceiver
Severity	Information
Description	Event raised when unsupported transceiver mode is enabled

Event ID: 3802

Message	<code>allow-unsupported-transceiver feature disabled</code>
Category	Transceiver
Severity	Information
Description	Event raised when unsupported transceiver mode is disabled

Event ID: 3803

Message	<code>allow-unsupported-transceiver feature enabled: Unsupported transceivers found in: <list></code>
Category	Transceiver
Severity	Information
Description	Event raised to list unsupported transceivers in unsupported transceiver mode

Event ID: 3804

Message	<code>Transceiver hot-swap insert for interface <interface></code>
Category	Transceiver
Severity	Information
Description	Event raised to indicate transceiver hotswap insertion

Event ID: 3805

Message	Transceiver hot-swap remove for interface <i><interface></i>
Category	Transceiver
Severity	Information
Description	Event raised to indicate transceiver hotswap removal

Event ID: 3806 (Severity: Warning)

Message	Interface <i><interface></i> transceiver attempted link recovery <i><count></i> times' throttle_count: 100
Category	Transceiver
Severity	Warning
Description	Event raised to indicate transceiver link recovery attempts

Event ID: 3807

Message	<i><path></i>
Category	Transceiver
Severity	Information
Description	Event raised to indicate detection path of unsupported transceivers

Event ID: 3808

Message	Transceiver <i><xcvr_desc></i> inserted in <i><interface></i> is <i><status></i> . <i><reason></i>
Category	Transceiver
Severity	Information
Description	Event raised to indicate status of transceivers that are allowed to be operational and its reason

Event ID: 3809 (Severity: Warning)

Message	Transceiver <i><xcvr_desc></i> inserted in <i><interface></i> is <i><status></i> . <i><reason></i>
Category	Transceiver
Severity	Warning
Description	Event raised to indicate status of transceivers that are not allowed to be operational and its reason

Event ID: 3810 (Severity: Warning)

Message	Unknown transceiver inserted in interface <code><interface></code>
Category	Transceiver
Severity	Warning
Description	Event raised to indicate an unknown transceiver was inserted

Event ID: 3811 (Severity: Warning)

Message	Transceiver in <code><interface></code> is incompatible with the interface group speed
Category	Transceiver
Severity	Warning
Description	Event raised to indicate a transceiver was inserted in a port that is a member of a group configured to operate at a different speed

Event ID: 3812

Message	Adapter <code><adapter_desc></code> inserted in <code><interface></code> is <code><status></code> . <code><reason></code>
Category	Transceiver
Severity	Information
Description	Event raised to indicate status of adapters that are allowed to be operational and its reason

Event ID: 3813 (Severity: Warning)

Message	Adapter <code><adapter_desc></code> inserted in <code><interface></code> is <code><status></code> . <code><reason></code>
Category	Transceiver
Severity	Warning
Description	Event raised to indicate status of adapters that are not allowed to be operational and its reason

The following are the events related to UDLD.

Event ID: 4101

Message	UDLD is enabled on interface: <i><intf></i>
Category	UDLD
Severity	Information
Description	Event raised when UDLD is enabled

Event ID: 4102

Message	UDLD is disabled on interface: <i><intf></i>
Category	UDLD
Severity	Information
Description	Event raised when UDLD is disabled

Event ID: 4103

Message	UDLD interface <i><intf></i> is unblocked
Category	UDLD
Severity	Information
Description	Event raised when UDLD sets the interface as unblocked

Event ID: 4104

Message	UDLD interface <i><intf></i> is blocked
Category	UDLD
Severity	Error
Description	Event raised when UDLD sets the interface as blocked

Event ID: 4105

Message	UDLD interface <i><intf></i> is undetermined
Category	UDLD
Severity	Error
Description	Event raised when UDLD moves from bidirectional state to undetermined (RFC5171 mode only)

Event ID: 4106 (Severity: Warning)

Message	UDLD interface <i><intf></i> interval <i><intvl_a></i> clamped to <i><intvl_b></i>
Category	UDLD
Severity	Warning
Description	Logs a warning when UDLD clamps the interval when operating in RFC5171 mode

Event ID: 4107

Message	UDLD link is enabled on interface: <i><intf></i>
Category	UDLD
Severity	Information
Description	Event raised when UDLD link is enabled

Event ID: 4108

Message	UDLD link is disabled on interface: <i><intf></i>
Category	UDLD
Severity	Information
Description	Event raised when UDLD link is disabled

The following are the events related to UDP Broadcast Forwarder.

Event ID: 3601

Message	UDP Broadcast Forwarder Enabled
Category	UDP Broadcast Forwarder
Severity	Information
Description	This command enables the UDP Broadcast Forwarder feature in the device.

Event ID: 3602

Message	UDP Broadcast Forwarder Disabled
Category	UDP Broadcast Forwarder
Severity	Information
Description	This command disables the UDP Broadcast Forwarder feature in the device.

The following are the events related to UFD.

Event ID: 12001 (Severity: Critical)

Message	Uplink Failure Detection session-id <id>, state changed from <from_state> to <to_state>.
Category	UFD
Severity	Critical
Description	Event reported when Links-to-Disable go down.

Event ID: 12002

Message	Uplink Failure Detection session-id <id>, state changed from <from_state> to <to_state>.
Category	UFD
Severity	Information
Description	Event reported when Links-to-Disable ports are restored.

The following are the events related to user management.

Event ID: 4701

Message	User <user> added <added_user> with role <user_role>
Category	User management
Severity	Information
Description	Logs a message when a new user is added to the switch

Event ID: 4702

Message	User <user> deleted <deleted_user> with role <user_role>
Category	User management
Severity	Information
Description	Logs a message when a user is deleted from the switch

Event ID: 4703

Message	User <username> successfully changed password
Category	User management
Severity	Information
Description	Logs a message when a user changes his/her password

Event ID: 4704

Message	User <username> password change failed
Category	User management
Severity	Error
Description	Logs a message when a user fails to change his/her password

Event ID: 4705

Message	User <username> set export password
Category	User management
Severity	Information
Description	Logs a message when a user sets export password

Event ID: 4706

Message	User <username> restored default export password
Category	User management
Severity	Information
Description	Logs a message when a user restores default export password

The following are the events related to user-based tunnels.

Event ID: 9701

Message	Tunnel Node Server SAC (<sac_ip>) is selected as (<state>)
Category	User-based tunnels
Severity	Information
Description	Event raised when controller is selected as Active/Standby

Event ID: 9702

Message	Tunnel Node Server Heartbeat has failed for SAC (<sac_ip>)
Category	User-based tunnels
Severity	Error
Description	Event raised when heartbeat not received from a SAC

Event ID: 9703

Message	Tunnel Node Server keepalive has failed for UAC (<uac_ip>)
Category	User-based tunnels
Severity	Error
Description	Event raised when keepalive not received from a UAC

Event ID: 9704

Message	Tunnel Node Server SAC bootstrapping has reinitialized to (<sac_ip>)
Category	User-based tunnels
Severity	Information
Description	Event raised when SAC bootstrapping to a SAC is re-initialized

Event ID: 9705

Message	Tunnel Node Server PAPI key has mismatched
Category	User-based tunnels
Severity	Error
Description	Event raised when papi msg key sent and received is different ({key_id})

Event ID: 9706 (Severity: Critical)

Message	Tunnel Node Server UAC node is down (<uac_ip>)
Category	User-based tunnels
Severity	Critical
Description	Event raised when UAC node is down

Event ID: 9707

Message	Tunnel is Created - Gre Key (<gre_key>) VRF (<vrf>) Source IP (<src_ip>) Destination IP (<dst_ip>)
Category	User-based tunnels
Severity	Information
Description	Event raised when user based tunnel is created

Event ID: 9708

Message	Tunnel Creation has Failed - Gre Key (<gre_key>) VRF (<vrf>) Source IP (<src_ip>) Destination IP (<dst_ip>)
Category	User-based tunnels
Severity	Error
Description	Event raised when user based tunnel creation fails

Event ID: 9709

Message	Tunnel is Deleted - Tunnel Id (<tunnel_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised when user based tunnel is deleted

Event ID: 9710

Message	Tunnel Deletion has Failed - Tunnel Id (< tunnel_id >)
Category	User-based tunnels
Severity	Error
Description	Event raised when user based tunnel deletion fails

Event ID: 9711

Message	Tunnel is UP - Tunnel Id (< tunnel_id >) Gre Key (< gre_key >) Source IP (< src_ip >) Destination IP (< dst_ip >)
Category	User-based tunnels
Severity	Information
Description	Event raised when user based tunnel state is up

Event ID: 9712

Message	Tunnel is DOWN - Tunnel Id (< tunnel_id >) Gre Key (< gre_key >) Source IP (< src_ip >) Destination IP (< dst_ip >)
Category	User-based tunnels
Severity	Error
Description	Event raised when user based tunnel state is down

Event ID: 9713

Message	Client (< client_mac >) is bound to tunnel id (< tunnel_id >)
Category	User-based tunnels
Severity	Information
Description	Event raised when user is gets binded to tunnel

Event ID: 9714

Message	Client (< client_mac >) binding to tunnel id (< tunnel_id >) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised when user bind to tunnel id failed

Event ID: 9715

Message	Client (<client_mac>) is removed from tunnel.
Category	User-based tunnels
Severity	Information
Description	Event raised when user is gets binded to tunnel

Event ID: 9716

Message	Client (<client_mac>) unbinding to tunnel id (<tunnel_id>) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised when user unbind to tunnel id failed

Event ID: 9717

Message	Client (<client_mac>) is getting modified to bind to tunnel id (<tunnel_id>)' throttle_count: 100
Category	User-based tunnels
Severity	Information
Description	Event raised when already binded user to a tunnel gets modified

Event ID: 9718

Message	Modification of Client (<client_mac>) binded to (<tunnel_id>) has failed' throttle_count: 100
Category	User-based tunnels
Severity	Error
Description	Event raised when modification of already binded user to a tunnel fails

Event ID: 9719

Message	NFD port (<nfd_id>) is created for client (<client_mac>) vlan id (<vlan_id>) port (<port>) ecmp id (<ecmp_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised on NFD port creation

Event ID: 9720

Message	NFD port (<nfd_id>) creation for client (<client_mac>) vlan id (<vlan_id>) port (<port>) ecmp id (<ecmp_id>) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised on NFD port creation failure

Event ID: 9721

Message	NFD port (<nfd_id>) is deleted for ecmp id(<ecmp_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised on NFD port deletion

Event ID: 9722

Message	NFD port (<nfd_id>) deletion for ecmp id (<ecmp_id>) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised when NFD port deletion fails

Event ID: 9723

Message	ECMP group is created for ecmp id (<ecmp_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised on ECMP group creation

Event ID: 9724

Message	ECMP group creation for ecmp id (<ecmp_id>) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised on ECMP group creation failure

Event ID: 9725

Message	ECMP group is deleted for ecmp id (<ecmp_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised on ECMP group deletion

Event ID: 9726

Message	ECMP group deletion for ecmp id(<ecmp_id>) has failed
Category	User-based tunnels
Severity	Error
Description	Event raised when ECMP group deletion fails

Event ID: 9727

Message	MDestRx Tunnel is Created - Gre Key (<gre_key>) VLAN (<vlan>) VRF (<vrf>) Source IP (<src_ip>) Destination IP (<dst_ip>)
Category	User-based tunnels
Severity	Information
Description	Event raised when mdest rx user based tunnel is created

Event ID: 9728

Message	MDestRx Tunnel Creation has Failed - Gre Key (<gre_key>) VLAN (<vlan>) VRF (<vrf>) Source IP (<src_ip>) Destination IP (<dst_ip>)
Category	User-based tunnels
Severity	Error
Description	Event raised when mdest rx user based tunnel creation fails

Event ID: 9729

Message	MDest Rx Tunnel is Deleted - Tunnel Id (<tunnel_id>)
Category	User-based tunnels
Severity	Information
Description	Event raised when mdest rx user based tunnel is deleted

Event ID: 9730

Message	MDest Rx Tunnel Deletion has Failed - Tunnel Id (< tunnel_id >)
Category	User-based tunnels
Severity	Error
Description	Event raised when mdest rx user based tunnel deletion fails

Event ID: 9731

Message	MDestRx Tunnel is UP - Tunnel Id (< tunnel_id >) Gre Key (< gre_key >) Source IP (< src_ip >) Destination IP (< dst_ip >)
Category	User-based tunnels
Severity	Information
Description	Event raised when mdest rx user based tunnel state is up

Event ID: 9732

Message	MDestRx Tunnel is DOWN - Tunnel Id (< tunnel_id >) Gre Key (< gre_key >) Source IP (< src_ip >) Destination IP (< dst_ip >)
Category	User-based tunnels
Severity	Error
Description	Event raised when mdest rx user based tunnel state is down

Event ID: 9733

Message	User bootstrap is failed for client (< mac_addr >) on port (< port >) due to < reason >.
Category	User-based tunnels
Severity	Error
Description	Event raised when user bootstrap is failed

Event ID: 9734

Message	Operational state of < zone > zone is UP.
Category	User-based tunnels
Severity	Information
Description	Event raised when zone operational state is up

Event ID: 9735 (Severity: Warning)

Message	Operational state of <zone> zone is DOWN due to <reason>.
Category	User-based tunnels
Severity	Warning
Description	Event raised when zone operational state is down

The following are the events related to VSX.

Event ID: 7001

Message	VSX ISL port <port> is down
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX ISL link is down.

Event ID: 7002

Message	VSX ISL port <port> is up
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX ISL link is up.

Event ID: 7003

Message	VSX ISL port <port> is In-Sync with the peer.
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX ISL is In Sync with the peer.

Event ID: 7004

Message	VSX ISL port <port> is Out-Of-Sync with the peer: <reason>
Category	Virtual Switching Extension (VSX)
Severity	Error
Description	VSX ISL is Out-Of-Sync with the peer

Event ID: 7005 (Severity: Warning)

Message	VSX Keepalive failed
Category	Virtual Switching Extension (VSX)
Severity	Warning
Description	VSX Keepalive is not able to reach the peer device

Event ID: 7006

Message	VSX Keepalive succeeded
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX Keepalive is able to reach the peer device

Event ID: 7007

Message	VSX role is primary
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Operational role of this device derived based on device priority of the 2 devices.

Event ID: 7008

Message	VSX role is secondary
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Operational role of this device derived based on device priority of the 2 devices.

Event ID: 7009

Message	VSX Software version mismatch: peer version <peer_sw_ver>, local version <local_sw_ver>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX Software version mismatch: peer sw version is not same as local sw version.

Event ID: 7010

Message	VSX Device mismatch: peer device <peer_device_type>, local device
---------	---

	<code><local_device_type></code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX Device type mismatch: peer device type is not same as local device type.

Event ID: 7011

Message	<code>VSX <vsx_id> state local up, remote down</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX local up remote down.

Event ID: 7012

Message	<code>VSX <vsx_id> state local down, remote up</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX local down remote up.

Event ID: 7013

Message	<code>VSX <vsx_id> state local up, remote up</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX local up remote up.

Event ID: 7014

Message	<code>VSX <vsx_id> state local down, remote down</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX local down remote down.

Event ID: 7015

Message	<code>VSX ISL sliding window parameters are reset.</code>
---------	---

Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX resetting the ISL protocol sliding window.

Event ID: 7016

Message	VSX own ISL hello packet received, ignoring the packet.
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX switch receives own ISL hello packet from network.

Event ID: 7017

Message	Rebooting the VSX <code><vsx_role></code> device with newly updated <code><bank_name></code> image.
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Switch reboot due to VSX software update.

Event ID: 7018

Message	VSX primary ISL version <code><primary_version></code> dose not match with VSX secondary ISL version <code><secondary_version></code> . Performing a non-hitless image update.
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX inter-switch-link protocol version mismatch after secondary reboot.

Event ID: 7019

Message	VSX <code><vsx_role></code> image update failed due to <code><reason></code> .
Category	Virtual Switching Extension (VSX)
Severity	Error
Description	VSX image update failed.

Event ID: 7020

Message	ISL out-of-sync and keepalive is in established
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	ISL out-of-sync and keepalive is in established, handled split brain

Event ID: 7021

Message	ISL out-of-sync and keepalive also failed
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	ISL out-of-sync and keepalive also failed

Event ID: 7022

Message	Linkup delay timer started
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Linkup delay timer started

Event ID: 7023

Message	Linkup delay timer expired
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Linkup delay timer expired

Event ID: 7024

Message	VSX <vsx_role> state changed from <prev_state> to <state>.
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX software update state change.

Event ID: 7025

Message	Bailout timer started
---------	-----------------------

Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Bailout timer started

Event ID: 7026

Message	<code>Bailout timer expired</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Bailout timer expired

Event ID: 7027

Message	<code>Bailout timer stopped</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Bailout timer stopped

Event ID: 7028

Message	<code>Linkup-delay timer stopped</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	Linkup-delay timer stopped

Event ID: 7029

Message	<code>VSX device roles are inconsistent: local VSX device role <local_vsx_role>, peer VSX device role <peer_vsx_role></code>
Category	Virtual Switching Extension (VSX)
Severity	Error
Description	VSX device roles are said to be consistent only if one VSX device is configured as primary and other VSX device is configured as secondary

Event ID: 7029

Message	<code>VSX <vsx_role> state changed to <state>-<sub_state>.</code>
---------	---

Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VSX software update sub-state change.

Event ID: 7030

Message	<code>VSX Keepalive is configured without creating VRF</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	VRF needs to be created before configuring VSX Keepalive

Event ID: 7031

Message	<code>VSX Keepalive is configured without configuring IP address</code>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	IP address needs to be configured before configuring VSX Keepalive

Event ID: 7032

Message	<code>Active-gateway is enabled on <port>. Cannot program Active-forwarding</code>
Category	Virtual Switching Extension (VSX)
Severity	Error
Description	Failed to program active-forwarding.

Event ID: 7033

Message	<code>Active-forwarding is enabled on <port>. Cannot program Active-gateway</code>
Category	Virtual Switching Extension (VSX)
Severity	Error
Description	Failed to program active-gateway.

Event ID: 7034

Message	<code>Netdev <ifname> configured with ipv4 address <value></code>
Category	Virtual Switching Extension (VSX)

Severity	Information
Description	programmed active-gateway IP4 address successfully.

Event ID: 7035

Message	Netdev <ifname> configured with ipv6 address <value>
Category	Virtual Switching Extension (VSX)
Severity	Information
Description	programmed active-gateway IP6 address successfully.

The following are the events related to VSF.

Event ID: 9901

Message	Member <code><member_id></code> boot complete
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for member boot complete

Event ID: 9902

Message	Standby <code><member_id></code> boot complete
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for standby boot complete

Event ID: 9903

Message	Conductor <code><member_id></code> boot complete
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for Conductor boot complete

Event ID: 9905

Message	Resetting member <code><member_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	Event log indicates that member is resetting

Event ID: 9906 (Severity: Warning)

Message	Member <code><member_id></code> conflict detected on link <code><link></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	Event log for Failed processing Hello packet because of member number conflict

Event ID: 9907 (Severity: Warning)

Message	Incompatible version detected
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	Event log for indicates that we got a packet with a diff proto ver

Event ID: 9908

Message	Topology is <code><topo_type></code>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	Event log indicates the current topology

Event ID: 9910

Message	Member <code><member_id></code> removed
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	Event log indicates the member has been removed due to user request

Event ID: 9911 (Severity: Warning)

Message	Maximum number of switches in the stack has reached. Cannot add MAC <code><mac_address></code> product type <code><type></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	Event log indicates that we would exceed the MAX switches if we add this new switch

Event ID: 9912

Message	Stack state is no-split with conductor id <code><member_id></code> ' throttle_
---------	--

	count: 100
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for stack state active

Event ID: 9913 (Severity: Warning)

Message	Lost member <member_id> with <reason>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	Event log for lost member

Event ID: 9914

Message	Reboot of MAC <mac_address> status-<status>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	Event log for status of a reboot request

Event ID: 9915

Message	Member <member_id> elected as conductor reason-<reason>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for the switch won as conductor

Event ID: 9916

Message	Member <member_id> elected as standby reason-<reason>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for the switch won as standby

Event ID: 9917 (Severity: Warning)

Message	Switch with MAC <mac_address> cannot join stack due to incorrect product id <product_id>
---------	--

Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event for the member was not allowed to join due to a mismatched product-id

Event ID: 9919 (Severity: Warning)

Message	Found Unsupported switch with MAC <code><mac_address></code> and Product type <code><product_type></code> , connected to switch with MAC <code><mac_addr></code> on stack port <code><port_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event for switch running on a different platform and trying to join the stack

Event ID: 9920 (Severity: Warning)

Message	Heart beat lost for member <code><member_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event for heart beat lost

Event ID: 9921 (Severity: Warning)

Message	OS version mismatch detected for member <code><member_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when os_version_mismatch happened on standby and member

Event ID: 9922 (Severity: Warning)

Message	Attempt to connect member <code><member_id></code> from a different stack
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when member attempt to connect to a different stack

Event ID: 9923

Message	VSF link <code><link></code> is up
---------	--

Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when vsf link is up

Event ID: 9924

Message	VSF link <code><link></code> is down
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when vsf link is down

Event ID: 9925 (Severity: Warning)

Message	Invalid MAC <code><mac_address></code> detected on link <code><link></code> with peer MAC <code><mac_add></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when different MAC address on the same link

Event ID: 9926 (Severity: Warning)

Message	2 member loop detected on ring topology
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when there is a 2 member loop in topology

Event ID: 9927

Message	Fragment with conductor <code><member_id></code> is Active' throttle_count: 100
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for active fragment

Event ID: 9928

Message	Fragment with conductor <code><member_id></code> is Inactive
---------	--

Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for Inactive fragment

Event ID: 9929

Message	Active fragment detection timeout
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for active stack detection timeout

Event ID: 9930

Message	Member <member_id> is configured as Secondary
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for standby configuration

Event ID: 9931

Message	Secondary configuration removed
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event for standby unconfiguration

Event ID: 9932

Message	Attempt to connect a member with MAC <mac_address> and product type <product_id> having different airflows
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when Mater SKU device joins the stack

Event ID: 9933 (Severity: Warning)

Message	Peer timeout on interface <port_id>
---------	-------------------------------------

Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event for peer time out as it did not receive any packet

Event ID: 9934 (Severity: Warning)

Message	Loop detected on interface <code><port_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event for loop detection in link

Event ID: 9935 (Severity: Warning)

Message	Interface <code><port_id></code> detected a peer with a different VSF handshake version
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when peer switch is in different VSF handshake version

Event ID: 9936

Message	Interface <code><port_id></code> added to VSF link <code><link></code>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when interface added to a particular link

Event ID: 9937

Message	Interface <code><port_id></code> removed from VSF link <code><link></code>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when interface removed from a particular link

Event ID: 9938 (Severity: Warning)

Message	Switch with mac <code><mac_address></code> not able to autojoin as it is connected on interface <code><port></code> which is a non default autojoin VSF interface
---------	---

Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when the switch is not able to autojoin as it is connected with a non default VSF interface

Event ID: 9939 (Severity: Warning)

Message	Switch with MAC <code><mac_address></code> not able to autojoin as it is connected to interface <code><port></code> which is not provisioned on the conductor for member <code><member_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when there is an inconsistency detected between conductors provisioned VSF link configuration and the interface on which switch is attempting to autojoin

Event ID: 9940 (Severity: Warning)

Message	Switch with MAC <code><mac_address></code> is not autojoin eligible
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when peer switch is not autojoin eligible

Event ID: 9941 (Severity: Warning)

Message	Switch with MAC <code><mac_address></code> attempting to autojoin via multiple interfaces
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when there is more than one interface physically connected to same switch VSF link for autojoin

Event ID: 9942 (Severity: Warning)

Message	Switch with MAC <code><mac_address></code> failed to autojoin as there is no free member number available
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log even when switch is not allowed to autojoin because of insufficient resources

Event ID: 9943 (Severity: Warning)

Message	Switch with mac <mac_address> failed to autojoin on link <link>, port <port>
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when two different switches are attempting to autojoin by connecting to the same VSF link on the peer

Event ID: 9944 (Severity: Warning)

Message	Switch has VSF configurations present. Force autojoin will not take into effect. Remove all VSF configurations followed by unconfiguring and reconfiguring force autojoin for it to take into effect
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when VSF force autojoin fails as VSF configurations exists

Event ID: 9945

Message	VSF force autojoin enabled
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when VSF force autojoin is enabled

Event ID: 9946

Message	VSF force autojoin disabled
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when VSF force autojoin is disabled

Event ID: 9947 (Severity: Warning)

Message	Switch with MAC <mac_addr1> failed to autojoin. Connect the device <mac_addr2> to member <mbr_id> link <link_id> to proceed
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when member connected to an unsupported interface

Event ID: 9948 (Severity: Warning)

Message	Interface <code><port_id></code> in VSF link <code><link></code> detected a peer with inconsistent VSF link configuration
Category	Virtual Switching Framework (VSF)
Severity	Warning
Description	log event when interface is in inconsistent link configuration error

Event ID: 9949

Message	Secondary member changed from <code><old_standby_id></code> to <code><new_standby_id></code>
Category	Virtual Switching Framework (VSF)
Severity	Information
Description	log event when existing secondary changes to new specified secondary member

The following are the events related to VLAN.

Event ID: 2101

Message	VLAN <vid> created in hardware
Category	VLAN
Severity	Information
Description	This log event informs the user that VLAN is created in Hardware

Event ID: 2102

Message	Failed to create VLAN <vid> in Hardware
Category	VLAN
Severity	Error
Description	This log event informs the user that VLAN is not created in Hardware

Event ID: 2103

Message	VLAN <vid> removed from hardware
Category	VLAN
Severity	Information
Description	This log event informs the user that VLAN is removed from Hardware

Event ID: 2104

Message	Failed to remove VLAN <vid> from hardware
Category	VLAN
Severity	Error
Description	This log event informs the user that VLAN is not removed from Hardware

Event ID: 2105

Message	Internal VLAN <vid> is allocated to port <port>
Category	VLAN
Severity	Information
Description	This log event informs that internal VLAN is allocated to port

Event ID: 2106

Message	Failed to allocate internal VLAN to port <port>
Category	VLAN
Severity	Error
Description	This log event informs that internal VLAN is not allocated

Event ID: 2107

Message	The mode for port <port> changed from <from> to <to> on VLAN <vid>
Category	VLAN
Severity	Information
Description	This log event informs that the port mode has changed from one of the trunk types to access or vice versa

Event ID: 2108

Message	Created Mac based VLAN entry. VLAN <vid> is mapped to client <mac> on port <port>
Category	VLAN
Severity	Information
Description	This log event informs the user that Mac based VLAN is created in Hardware

Event ID: 2109

Message	Failed to create Mac based VLAN entry for <mac> with VLAN <vid> on port <port>
Category	VLAN
Severity	Error
Description	This log event informs the user that Mac based VLAN is not created in Hardware

Event ID: 2110

Message	Deleted Mac based VLAN entry for <mac> with VLAN <vid> on port <port>
Category	VLAN
Severity	Information
Description	This log event informs the user that MAC based VLAN is removed from Hardware

Event ID: 2111

Message	Failed to remove Mac based VLAN entry for <mac> with VLAN <vid> on port <port>
Category	VLAN
Severity	Error
Description	This log event informs the user that MAC based VLAN is not removed from Hardware

Event ID: 2112

Message	Updated MAC based VLAN entry. VLAN <vid> is mapped to client <mac> on port <port>
Category	VLAN
Severity	Information
Description	This log event informs the user that MAC based VLAN is updated in Hardware

Event ID: 2113

Message	Failed to update Mac based VLAN entry for <mac> with VLAN <vid> on port <port>
Category	VLAN
Severity	Error
Description	This log event informs the user that MAC based VLAN is not updated in Hardware

Event ID: 2114

Message	Internal VLAN changed to <vlan>
Category	VLAN
Severity	Information
Description	This log event informs that internal VLAN range is changed

Event ID: 2115

Message	VLAN <vid> is down due to pvlan misconfig reason <reason>
Category	VLAN
Severity	Information
Description	This log event informs the user that VLAN is down due to pvlan misconfig

Event ID: 2116

Message	VLAN <vid> is recovered from pvlan misconfig
Category	VLAN
Severity	Information
Description	This log event informs the user that VLAN is recovered from pvlan misconfig

Event ID: 2117

Message	Remote node <remote_node> add for VLAN <vid> on node <local_node> failed
Category	VLAN
Severity	Error
Description	This log event informs the user that remote node add for a vlan failed

Event ID: 2118

Message	Remote node <remote_node> remove for VLAN <vid> on node <local_node> failed
Category	VLAN
Severity	Error
Description	This log event informs the user that remote node remove for a vlan failed

Event ID: 2119

Message	VLAN translation rule addition failed for port:<port_name>, in_vlan:<orig_vlan>, out_vlan:<trans_vlan>, reason=<rst>
Category	VLAN
Severity	Error
Description	Logs a message when vlan translation rule addition failed in hardware

The following are the events related to VLAN interface.

Event ID: 1601

Message	Vlaninterface vlan<vlan>, failed to create an l3 interface, error: <err>
Category	VLAN Interface
Severity	Error
Description	logs errors while creating vlaninterface.

Event ID: 1602

Message	Vlan Interface <interface>, created
Category	VLAN Interface
Severity	Information
Description	logs to create vlan interface.

The following are the events related to VRF.

Event ID: 6401

Message	VRF with vrf name <code><vrf_name></code> is configured in the switch
Category	VRF
Severity	Information
Description	Logs a message when VRF is configured in the switch

Event ID: 6402

Message	Failed to configure VRF with vrf name <code><vrf_name></code> in the switch
Category	VRF
Severity	Error
Description	Logs a message when VRF configuration failed in the switch

Event ID: 6403

Message	VRF with vrf name <code><vrf_name></code> is deleted from the switch
Category	VRF
Severity	Information
Description	Logs a message when VRF is deleted from the switch

Event ID: 6404

Message	Failed to delete VRF with vrf name <code><vrf_name></code> from the switch
Category	VRF
Severity	Error
Description	Logs a message when VRF deletion failed in the switch

The following are the events related to VRF Manager.

Event ID: 5401

Message	Created a vrf entity <vrf_entity>
Category	VRF Manager
Severity	Information

Event ID: 5402

Message	Deleted a vrf entity <vrf_entity>
Category	VRF Manager
Severity	Information

Event ID: 5403

Message	vrf entity creation failed <vrf_entity>
Category	VRF Manager
Severity	Error

The following are the events related to VRRP.

Event ID: 3701

Message	VRRP has been enabled on this router
Category	VRRP
Severity	Information
Description	Logs VRRP global enable event

Event ID: 3702

Message	VRRP has been disabled on this router
Category	VRRP
Severity	Information
Description	Logs VRRP global disable event

Event ID: 3703

Message	<code><inet_type> virtual router <vrid> on interface <interface> has taken owner IP</code>
Category	VRRP
Severity	Information
Description	Logs virtual router has taken control of owner IP

Event ID: 3704

Message	<code><inet_type> virtual router <vrid> on interface <interface> has taken standby IP</code>
Category	VRRP
Severity	Information
Description	Logs virtual router has taken control of standby IP

Event ID: 3705

Message	<code><inet_type> virtual router <vrid> on interface <interface> lost standby IP</code>
Category	VRRP
Severity	Information
Description	Logs virtual router has lost control of standby IP

Event ID: 3706

Message	<code><inet_type> virtual router <vrid> created on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs creation of virtual router on interface

Event ID: 3707

Message	<code><inet_type> virtual router <vrid> deleted from interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs deletion of virtual router from interface

Event ID: 3708

Message	<code><type> address <address> is added to virtual router <vrid> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs addition of IP address to virtual router

Event ID: 3709

Message	<code><type> address <address> is deleted from virtual router <vrid> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs deletion of IP address from virtual router

Event ID: 3710

Message	<code><inet_type> virtual router <vrid> version changed to <value> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs version change for virtual router

Event ID: 3711

Message	<code><inet_type> virtual router <vrid> advertisement interval has changed to <value> milliseconds on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs advertisement timer has changed for virtual router

Event ID: 3712

Message	<code><inet_type> virtual router <vrid> preempt delay time has changed to <value> seconds on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs preempt delay timer has changed for virtual router

Event ID: 3713

Message	<code><inet_type> virtual router <vrid> state change from <old_state> to <new_state> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs state has changed for virtual router on interface

Event ID: 3714

Message	<code>Enabled preempt option for <inet_type> virtual router <vrid> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs preempt option has been enabled for virtual router

Event ID: 3715

Message	Enabled virtual IP ping for <code><inet_type></code> virtual router <code><vrid></code> on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs virtual IP ping has been enabled for virtual router

Event ID: 3716

Message	Enabled <code><inet_type></code> virtual router <code><vrid></code> on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs virtual router has been enabled on interface

Event ID: 3717

Message	Disabled preempt option for <code><inet_type></code> virtual router <code><vrid></code> on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs preempt option has been disabled for virtual router

Event ID: 3718

Message	Disabled virtual IP ping for <code><inet_type></code> virtual router <code><vrid></code> on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs virtual IP ping has been disabled for virtual router

Event ID: 3719

Message	Disabled <code><inet_type></code> virtual router <code><vrid></code> on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs virtual router has been disabled on interface

Event ID: 3720

Message	<code><inet_type> virtual router <vrid> priority changed to <value> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs priority has been changed for virtual router

Event ID: 3721

Message	<code><inet_type> virtual router <vrid> mode changed to <value> on interface <interface></code>
Category	VRRP
Severity	Information
Description	Logs virtual router mode has been changed

Event ID: 3722

Message	<code>Track object <track> is associated with <inet_type> virtual router <vrid></code>
Category	VRRP
Severity	Information
Description	Logs track object has been associated with virtual router

Event ID: 3723

Message	<code>Track object <track> is de-associated from <inet_type> virtual router <vrid></code>
Category	VRRP
Severity	Information
Description	Logs track object has been de-associated from virtual router

Event ID: 3724

Message	<code>Track object <track> is created</code>
Category	VRRP
Severity	Information
Description	Logs track object has been created

Event ID: 3725

Message	Track object <code><track></code> is deleted
Category	VRRP
Severity	Information
Description	Logs track object has been deleted

Event ID: 3726

Message	Track object <code><track></code> state changed <code><old_state></code> to <code><new_state></code>
Category	VRRP
Severity	Information
Description	Logs track object state change

Event ID: 3727

Message	Track object <code><track></code> associated with interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs track object association with interface

Event ID: 3728

Message	<code><inet_type></code> virtual router <code><vrid></code> recieved packet with authentication type mismatch on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs authentication failures on virtual router

Event ID: 3729

Message	<code><inet_type></code> virtual router <code><vrid></code> recieved packet with authentication key mismatch on interface <code><interface></code>
Category	VRRP
Severity	Information
Description	Logs authentication failures on virtual router

The following are the events related to VSX sync.

Event ID: 7601

Message	Configuration sync error: <id>
Category	VSX Sync
Severity	Error
Description	Logs event when error in synchronizing config between two VSX peers

Event ID: 7602

Message	Configuration sync update: <id>
Category	VSX Sync
Severity	Information
Description	Logs event when there is an update for config sync

Event ID: 7603

Message	Configuration-persistence: <id>
Category	VSX Sync
Severity	Information
Description	Logs event when config is copied to startup-config on any of the VSX peer

The following are the events related to VXLAN agent.

Event ID: 12501

Message	Netvp add failed for vni_id: <vni_id>, tunnel_id: <tunnel_id>, vlan: <vlan>.
Category	VXLAN agent
Severity	Error
Description	Event raised when netvp add fails in agent

Event ID: 12502

Message	Tunnel add failed for tunnel_id: <tunnel_id>, ecmp_id: <ecmp_id>.
Category	VXLAN agent
Severity	Error
Description	Event raised when tunnel add fails in agent

The following are the events related to VXLAN.

Event ID: 8101

Message	VNI id <vni_id> creation failed
Category	VXLAN
Severity	Error
Description	Event raised when VNI creation fails

Event ID: 8102

Message	VNI id <vni_id> created
Category	VXLAN
Severity	Information
Description	Event raised when VNI created

Event ID: 8103

Message	VNI id <vni_id> deletion fails
Category	VXLAN
Severity	Error
Description	Event raised when VNI deletion fails

Event ID: 8104

Message	VNI id <vni_id> has been deleted
Category	VXLAN
Severity	Information
Description	Event raised when VNI is deleted

Event ID: 8105

Message	Vtep-Peer <vtep_peer> is created
Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer is created

Event ID: 8106

Message	Vtep-Peer <vtep_peer> has been deleted
Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer has been deleted

Event ID: 8107

Message	Vtep-Peer <vtep_peer> deletion failed
Category	VXLAN
Severity	Error
Description	Event raised when Vtep-Peer deletion fails

Event ID: 8108

Message	Access-Port with vlan <vlan_id> and port <port_name> has been created
Category	VXLAN
Severity	Information
Description	Event raised when Access-Port has been created

Event ID: 8109

Message	Access-Port with port <port_name> and vlan <vlan_id> has been deleted
Category	VXLAN
Severity	Information
Description	Event raised when Access-Port has been deleted

Event ID: 8110

Message	Vtep-Peer <vtep> state is operational
---------	---------------------------------------

Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer status is changed to operational

Event ID: 8111

Message	Vtep-Peer <vtep> state is configuration_error
Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer status is changed to configuration error

Event ID: 8112

Message	Vtep-Peer <vtep> state is no_hw_resources
Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer status is changed to no hardware resources

Event ID: 8113

Message	Vtep-Peer <vtep> state is activating
Category	VXLAN
Severity	Information
Description	Event raised when Vtep-Peer status is changed to activating

Event ID: 8114

Message	Tunnel <remote_ip> added to hardware
Category	VXLAN
Severity	Information
Description	Event raised when a VxLAN tunnel is added to hardware

Event ID: 8115

Message	Tunnel <remote_ip> deleted from hardware
Category	VXLAN

Severity	Information
Description	Event raised when a VxLAN tunnel is deleted from hardware

Event ID: 8116

Message	Tunnel <remote_ip> delete deferred
Category	VXLAN
Severity	Information
Description	Event raised when a VxLAN tunnel has its deletion deferred by L3PD

Event ID: 8117

Message	Tunnel <remote_ip> deferred delete canceled
Category	VXLAN
Severity	Information
Description	Event raised when a VxLAN tunnel has its deferred deletion canceled

The following are the events related to zero touch provisioning.

Event ID: 8701

Message	ZTP service has started
Category	Zero touch provisioning
Severity	Information
Description	Log event when ZTP service starts

Event ID: 8702

Message	ZTP service has stopped
Category	Zero touch provisioning
Severity	Information
Description	Log event when ZTP service stops

Event ID: 8703

Message	ZTP service status changed to in-progress
Category	Zero touch provisioning
Severity	Information
Description	Log event when ZTP change status to in-progress

Event ID: 8704

Message	ZTP service status changed to success
Category	Zero touch provisioning
Severity	Information
Description	Log event when ZTP change status to success

Event ID: 8705 (Severity: Critical)

Message	ZTP service status changed to failed because of invalid configuration file
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because of invalid config file

Event ID: 8706 (Severity: Critical)

Message	ZTP service status changed to failed because of invalid image file
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because of invalid image file

Event ID: 8707 (Severity: Warning)

Message	ZTP service status changed to failed because TFTP info is not available
Category	Zero touch provisioning
Severity	Warning
Description	Log event when ZTP fails because no TFTP info is available

Event ID: 8708 (Severity: Warning)

Message	ZTP service status changed to failed because TFTP server is not reachable
Category	Zero touch provisioning
Severity	Warning
Description	Log event when ZTP fails because TFTP server is not reachable

Event ID: 8709 (Severity: Critical)

Message	ZTP service status changed to failed because of non-default startup configuration
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP failed because of non-default startup config

Event ID: 8710 (Severity: Critical)

Message	ZTP service status changed to failed because running configuration is modified
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP failed because of modified running config

Event ID: 8711 (Severity: Warning)

Message	ZTP service status changed to failed because of timeout
Category	Zero touch provisioning
Severity	Warning
Description	Log event when ZTP failed because of timeout

Event ID: 8712

Message	ZTP: Image file not provided
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ZTP configurations - image file not provided

Event ID: 8713

Message	ZTP: Config file not provided
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - config file not provided

Event ID: 8714

Message	ZTP: TFTP server option not provided
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - TFTP server name not provided

Event ID: 8715

Message	ZTP: Exceeded max path length of TFTP server
Category	Zero touch provisioning
Severity	Error
Description	Logs related to ztp configurations - path length exceeded of TFTP server name

Event ID: 8718

Message	ZTP: Received TFTP server <tftp_ip> from dhcp server
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - TFTP IP received

Event ID: 8719

Message	ZTP: Received image file <image_file> from dhcp server
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - Image filename received

Event ID: 8720

Message	ZTP: Received config file <config_file> from dhcp server
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - Config filename received

Event ID: 8721

Message	ZTP: Received Aruba Central location <central_location> from DHCP server
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - Aruba Central FQDN or IPv4 received

Event ID: 8723

Message	ZTP: Aruba Central location option not provided
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - Aruba Central FQDN or IPv4 not provided

Event ID: 8724

Message	ZTP: Received HTTP proxy location <code><http_proxy_location></code> from DHCP server.
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - Aruba HTTP proxy FQDN or IPv4 received

Event ID: 8726

Message	ZTP: HTTP proxy location was not received in the DHCP offer.
Category	Zero touch provisioning
Severity	Information
Description	Logs related to ztp configurations - HTTP Proxy FQDN or IPv4 not provided

Event ID: 8727 (Severity: Critical)

Message	ZTP service status changed to failed because <code><filename></code> file download encountered unexpected error.
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because of unexpected error in config/image file download

Event ID: 8728 (Severity: Critical)

Message	ZTP service status changed to failed because <code><filename></code> file did not get downloaded.
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because of config/image file download error

Event ID: 8729 (Severity: Critical)

Message	ZTP service status changed to failed because the downloaded configuration could not be copied to start-up configuration.
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because downloaded config did not get copied to start-up config

Event ID: 8730 (Severity: Critical)

Message	ZTP service status changed to failed because <filename> file download encountered unexpected error. Reason: <reason>
Category	Zero touch provisioning
Severity	Critical
Description	Log event when ZTP fails because of unexpected error in config file download

Accessing Aruba Support

Aruba Support Services	https://www.arubanetworks.com/support-services/
AOS-CX Switch Software Documentation Portal	https://www.arubanetworks.com/techdocs/AOS-CX/help_portal/Content/home.htm
Aruba Support Portal	https://asp.arubanetworks.com/
North America telephone	1-800-943-4526 (US & Canada Toll-Free Number) +1-408-754-1200 (Primary - Toll Number) +1-650-385-6582 (Backup - Toll Number - Use only when all other numbers are not working)
International telephone	https://www.arubanetworks.com/support-services/contact-support/

Be sure to collect the following information before contacting Support:

- Technical support registration number (if applicable)
- Product name, model or version, and serial number
- Operating system name and version
- Firmware version
- Error messages
- Product-specific reports and logs
- Add-on products or components
- Third-party products or components

Other useful sites

Other websites that can be used to find information:

Airheads social forums and Knowledge Base	https://community.arubanetworks.com/
AOS-CX Switch Software Documentation Portal	https://www.arubanetworks.com/techdocs/AOS-CX/help_portal/Content/home.htm
Aruba Hardware Documentation and Translations	https://www.arubanetworks.com/techdocs/hardware/DocumentationPortal/Content/home.htm

Portal	
Aruba software	https://asp.arubanetworks.com/downloads
Software licensing	https://lms.arubanetworks.com/
End-of-Life information	https://www.arubanetworks.com/support-services/end-of-life/
Aruba Developer Hub	https://developer.arubanetworks.com/

Accessing Updates

You can access updates from the Aruba Support Portal or the HPE My Networking Website.

Aruba Support Portal

<https://asp.arubanetworks.com/downloads>

If you are unable to find your product in the Aruba Support Portal, you may need to search My Networking, where older networking products can be found:

My Networking

<https://www.hpe.com/networking/support>

To view and update your entitlements, and to link your contracts and warranties with your profile, go to the Hewlett Packard Enterprise Support Center **More Information on Access to Support Materials** page:

<https://support.hpe.com/portal/site/hpsc/aae/home/>

Access to some updates might require product entitlement when accessed through the Hewlett Packard Enterprise Support Center. You must have an HP Passport set up with relevant entitlements.

Some software products provide a mechanism for accessing software updates through the product interface. Review your product documentation to identify the recommended software update method.

To subscribe to eNewsletters and alerts:

<https://asp.arubanetworks.com/notifications/subscriptions> (requires an active Aruba Support Portal (ASP) account to manage subscriptions). Security notices are viewable without an ASP account.

Warranty information

To view warranty information for your product, go to <https://www.arubanetworks.com/support-services/product-warranties/>.

Regulatory Information

To view the regulatory information for your product, view the *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products*, available at <https://www.hpe.com/support/Safety-Compliance-EnterpriseProducts>

Additional regulatory information

Aruba is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements, environmental data (company programs, product recycling, energy efficiency), and safety information and compliance data, (RoHS and WEEE). For more information, see <https://www.arubanetworks.com/company/about-us/environmental-citizenship/>.

Documentation feedback

Aruba is committed to providing documentation that meets your needs. To help us improve the documentation, send any errors, suggestions, or comments to Documentation Feedback (docsfeedback-switching@hpe.com). When submitting your feedback, include the document title, part number, edition, and publication date located on the front cover of the document. For online help content, include the product name, product version, help edition, and publication date located on the legal notices page.