



AOS-CX 10.17.xxxx CoPP Guide (8100, 83xx, 93xx, 100xx Switch series)

AOS-CX 10.17.xxxx CoPP Guide (8100, 83xx, 93xx, 100xx Switch series)

Published: February 2026

© Copyright 2026 – Hewlett Packard Enterprise Development LP

Notices

The information provided here is subject to change without notice. Hewlett Packard Enterprise's products and services are covered only by the express warranty statements that come with them. This document does not constitute an additional warranty. Hewlett Packard Enterprise is not responsible for any technical or editorial errors or omissions in this document.

Confidential computer software. You must have a valid license from Hewlett Packard Enterprise to possess, use, or copy the software. In accordance with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under the vendor's standard commercial license.

Links to third-party websites will take you outside of the Hewlett Packard Enterprise website. Hewlett Packard Enterprise has no control over and is not responsible for the information outside the Hewlett Packard Enterprise website.

Open source code

This product includes code licensed under certain open source licenses which require source compliance. The corresponding source for these components is available upon request. This offer is valid to anyone in receipt of this information and shall expire three years following the date of the final distribution of this product version by Hewlett Packard Enterprise Company. To obtain such source code, please check if the code is available in the HPE Software Center at <https://myenterpriselicense.hpe.com/cwp-ui/software> but, if not, send a written request for specific software version and product for which you want the open source code. Along with the request, please send a check or money order in the amount of US \$10.00 to:

Hewlett Packard Enterprise Company

Attn: General Counsel

WW Corporate Headquarters

1701 E Mossy Oaks Rd, Spring, TX 77389

United States of America.



Legal disclaimer

The resource assets in this document may include abbreviated and/or legacy terminology for products. See [**www.arubanetworks.com**](http://www.arubanetworks.com) for current and complete product lines and names.

Table of contents

About this document.....	5
Applicable products.....	5
Latest version available online.....	6
Command syntax notation conventions.....	6
About the examples.....	7
Identifying switch ports and interfaces.....	8
Control Plane Policing (CoPP) Overview.....	8
Configuring CoPP	9
CoPP commands.....	10
Classes of traffic.....	10
apply copp-policy	16
class	17
clear copp-policy statistics	19
copp-policy	21
default-class	22
reset copp-policy	23
show copp-policy	28
show copp-policy factory-default	31
show copp-policy statistics	36
show tech copp	40
Support and Other Resources.....	41
Accessing HPE Aruba Networking Support.....	41
Accessing Updates.....	43
Warranty Information.....	43
Regulatory Information.....	43
Documentation Feedback.....	44

About this document

This document describes features of the AOS-CX network operating system. It is intended for administrators responsible for installing, configuring, and managing HPE Aruba Networking switches on a network.

Subtopics

Applicable products

Latest version available online

Command syntax notation conventions

About the examples

Identifying switch ports and interfaces

Applicable products

This document applies to the following products:

- HPE Aruba Networking 8100 Switch Series (R9W94A, R9W95A, R9W96A, R9W97A)
- HPE Aruba Networking 8320 Switch Series (JL479A, JL579A, JL581A)
- HPE Aruba Networking 8325 Switch Series (JL624A, JL625A, JL626A, JL627A)
- HPE Aruba Networking 8325H Switch Series (S4B20A, S4B21A, S4B22A, S4B23A, S2T42A, S2T46A, S2T47A, S2T48A)
- HPE Aruba Networking 8325P Switch Series (S0G12A, S4A48A)
- HPE Aruba Networking 8360 Switch Series (JL700A, JL701A, JL702A, JL703A, JL706A, JL707A, JL708A, JL709A, JL710A, JL711A, JL700C, JL701C, JL702C, JL703C, JL706C, JL707C, JL708C, JL709C, JL710C, JL711C, JL704C, JL705C, JL719C, JL718C, JL717C, JL720C, JL722C, JL721C)
- HPE Aruba Networking 9300 Switch Series (R9A29A, R9A30A, R8Z96A, S0F81A, S0F82A, S0F83A)
- HPE Aruba Networking 9300S Switch Series (S0F81A, S0F82A, S0F83A, S0F84A, S0F85A, S0F86A, S0F88A, S0F95A, S0F96A)
- HPE Aruba Networking 10000 Switch Series (R8P13A, R8P14A)
- HPE Aruba Networking 10040 Switch Series (S4R58A, S4R59A)

Latest version available online

Updates to this document can occur after initial publication. For the latest versions of product documentation, see the links provided in [Support and Other Resources](#).

Command syntax notation conventions

Convention	Usage
example - text	Identifies commands and their options and operands, code examples, filenames, pathnames, and output displayed in a command window. Items that appear like the example text in the previous column are to be entered exactly as shown and are required unless enclosed in brackets ([]).
example - text	In code and screen examples, indicates text entered by a user.
Any of the following: <example - text> <example - text> - example - text - example - text	Identifies a placeholder—such as a parameter or a variable—that you must substitute with an actual value in a command or in code: - For output formats where italic text cannot be displayed, variables are enclosed in angle brackets (< >). Substitute the text—including the enclosing angle brackets—with an actual value. - For output formats where italic text can be displayed, variables might or might not be enclosed in angle brackets. Substitute the text including the enclosing angle brackets, if any, with an actual value.
	Vertical bar. A logical OR that separates multiple items from which you can choose only one. Any spaces that are on either side of the vertical bar are included for readability and are not a required part of the command syntax.
{ }	Braces. Indicates that at least one of the enclosed items is required.

Convention	Usage
[]	Brackets. Indicates that the enclosed item or items are optional.
... or	Ellipsis:
...	- In code and screen examples, a vertical or horizontal ellipsis indicates an omission of information. - In syntax using brackets and braces, an ellipsis indicates items that can be repeated. When an item followed by ellipses is enclosed in brackets, zero or more items can be specified.

About the examples

Examples in this document are representative and might not match your particular switch or environment.

The slot and port numbers in this document are for illustration only and might be unavailable on your switch.

Understanding the CLI prompts

When illustrating the prompts in the command line interface (CLI), this document uses the generic term **switch**, instead of the host name of the switch. For example:

```
switch>
```

The CLI prompt indicates the current command context. For example:

```
switch>
```

Indicates the operator command context.

```
switch#
```

Indicates the manager command context.

```
switch(CONTEXT-NAME) #
```

Indicates the configuration context for a feature. For example:

```
switch(config-if) #
```

Identifies the **interface** context.

Variable information in CLI prompts

In certain configuration contexts, the prompt may include variable information. For example, when in the VLAN configuration context, a VLAN number appears in the prompt:

```
switch(config-vlan-100) #
```

When referring to this context, this document uses the syntax:

```
switch(config-vlan-<VLAN-ID>) #
```

Where <VLAN-ID> is a variable representing the VLAN number.

Identifying switch ports and interfaces

Physical ports on the switch and their corresponding logical software interfaces are identified using the format: **member/slot/port**.

On the HPE Aruba Networking 8xxx, 93xx, and 10xxx Switch Series

- member: Always 1. VSF is not supported on this switch.
- slot: Always 1. This is not a modular switch, so there are no slots.
- port: Physical number of a port on the switch.

For example, the logical interface **1/1/4** in software is associated with physical port 4 on the switch.



NOTE

If using breakout cables, the port designation changes to x:y, where x is the physical port and y is the lane when split. For example, the logical interface 1/1/4:2 in software is associated with lane 2 on physical port 4 in slot 1 on member 1.

Control Plane Policing (CoPP) Overview

CoPP provides a way for administrators to protect the management processor on the switch from high packet loads (generated by malicious or nonmalicious sources) that might interfere with its ability to keep data plane traffic flowing. For example, a denial of service attack can result in excessive traffic that would slow down the management processor and negatively affect switch throughput.

A CoPP policy is composed of one or more classes. Each class defines one or more target protocols and how their traffic is managed. Every policy also has a default class to regulate packets that do not match any other class. The following actions can be applied for all packets matching a class:

- Drop the packets. (Excluding the default class.)
- Set the processing priority in the range 0 to 7 (0 - highest priority and 7 - lowest priority).
- Set the maximum data rate in packets per second (pps) at which each line module can send packets to the management processor.

- Set the maximum burst size in packets at which each line module can send packets to the management processor.

Up to 32 CoPP policies can be defined, but only one can be active on the switch at a time. A CoPP policy must always be active on the switch. By default, the switch has a CoPP policy named **default** which is automatically applied at first boot.

When the switch reboots, the CoPP policy that was actively applied to the switch before the reboot occurred is applied if it was saved to the startup configuration with the `copy running-config startup-config` command.

For GRE tunneled traffic, CoPP policies match on the payload. CoPP policies do not regulate traffic received from the Out-of-Band-Management (OOBM) Ethernet port.

Configuring CoPP

Procedure

1. Configure the default CoPP policy, edit an existing policy, or create a policy with the command `copp-policy`.
2. Add, edit, or remove classes in the policy with the command `class`.
3. If the policy is not the active policy on the switch, apply it with the command `apply copp-policy`. (Changes made to an active policy take effect immediately and do not need to be applied.)
4. Review the CoPP policy configuration settings with the command `show copp-policy`.

Example

This example creates the following configuration:

- Defines a new policy named **My_CoppPolicy**.
- Adds two classes to the policy.
- Activates the policy.
- Displays policy configuration settings.

```
switch(config)# copp-policy My_CoppPolicy
switch(config-copp)# class igmp priority 6 rate 5000 burst 60
switch(config-copp)# class lacp priority 2 rate 2000 burst 1000
switch(config-copp)# exit
switch(config)# apply copp-policy My_CoppPolicy
switch(config)# exit
switch# show copp-policy My_CoppPolicy
```

class	drop	priority	rate pps	burst pkts	hardware rate pps
igmp	6		5000	60	5000
lacp	2		2000	1000	2000
default	1		6000	70	6000

CoPP commands

Select a command from the list in the left navigation menu.

Subtopics

[Classes of traffic](#)

[apply copp-policy](#)

[class](#)

[clear copp-policy statistics](#)

[copp-policy](#)

[default-class](#)

[reset copp-policy](#)

[show copp-policy](#)

[show copp-policy factory-default](#)

[show copp-policy statistics](#)

[show tech copp](#)

Classes of traffic

The different classes of traffic that can be individually configured are:

Applies to the HPE Aruba Networking 8320, 8325, 9300/9300S, 10000 Switch Series:

- **acl-logging:** Access Control List logging packets.
- **arp-broadcast:** Address Resolution Protocol packets with a broadcast destination MAC address.
- **arp-unicast:** Address Resolution Protocol packets with a switch system destination MAC address.
- **bfd:** Bidirectional Forwarding Detection (BFD) packets with a destination IP address owned by the switch.
- **bgp-ipv4:** Border Gateway Protocol packets with a destination IPv4 address owned by the switch.
- **bgp-ipv6:** Border Gateway Protocol packets with a destination IPv6 address owned by the switch.
- **dhcp-ipv4:** Dynamic Host Configuration Protocol packets with a destination IPv4 address.

- **dhcp-ipv6:** Dynamic Host Configuration Protocol packets with a destination IPv6 address.
- **dss: 10000**
- **erps:** Ethernet Ring Protection Switching control packets with the destination MAC address 01:19:a7:00:00:XX, where XX can be any value.
- **flow-telemetry:** Packets received for flow telemetry such as IP Flow Information Export (IPFIX).



NOTE

The **flow-telemetry** class is not supported for HPE Aruba Networking 8320, 8325, 9300, 9300S, 10040 Switch series.

- **hypertext:** Hypertext Transfer Protocol (HTTP) or Hypertext Transfer Protocol Secure (HTTPS) packets.
- **icmp-broadcast-ipv4:** Internet Control Message Protocol packets with a broadcast or multicast destination IPv4 address.
- **icmp-multicast-ipv6:** Internet Control Message Protocol packets with a well-known multicast destination IPv6 address.
- **icmp-unicast-ipv4:** Internet Control Message Protocol packets with a destination IPv4 address owned by the switch.
- **icmp-unicast-ipv6:** Internet Control Message Protocol packets with a destination IPv6 address owned by the switch.
- **ieee-8021x:** IEEE 802.1X protocol packets with EtherType 0x0888E.



NOTE

The **flow-telemetry** class is not supported for HPE Aruba Networking 8320 9300, 9300, 10040 Switch series.

- **igmp:** Internet Group Management Protocol packets.
- **ip-exceptions:** Routable packets that would exceed the MTU for the egress interface, packets that trigger ICMP redirects, and packets with TTL/hop_limit=1 that are discarded when routing through the switch.

- **ipfix:** Packets received for IPFIX (IP Flow Information Export).



NOTE

The **ipfix** class is not supported for HPE Aruba Networking 8320, 9300, 9300S, 10000, 10040 Switch series.

- **ipsec:** Internet Protocol Security IPv4 or IPv6, unicast or configured multicast. All IPsec traffic received by the CPU will be regulated by the **ipsec** class regardless of the encapsulated protocol.
- **ipv4-options:** Unicast IPv4 packets including option headers.
- **ipv6-options:** Unicast IPv6 packets including option headers.
- **lACP:** Link Aggregation Control Protocol packets with the destination MAC address 01:80:c2:00:00:02.
- **lldp:** Link Layer Discovery Protocol packets with the destination MAC address 01:80:c2:00:00:0e.
- **loop-protect:** Loop Protection packets with the destination MAC address 09:00:09:09:13:a6.
- **mdns:** Multicast Domain Name System packets.



NOTE

The **mdns** class is not supported for HPE Aruba Networking 8320 Switch series.

- **mirror-to-cpu:** Packets from mirroring session configured to deliver to the console.
- **mld:** Multicast Listener Discovery packets of type V1 or V2 with an IPv6 address of FF00::/8, FF02::16 or FF02::2.
- **mvrp:** Multiple VLAN Registration Protocol packets with the destination MAC address 01:80:c2:00:00:20 or 01:80:c2:00:00:21.
- **ntp:** Network Time Protocol packets with a destination IP address owned by the switch.
- **ospf-multicast-ipv4:** Open Shortest Path First packets with the multicast destination IPv4 address 224.0.0.5 or 224.0.0.6. The HPE Aruba Networking 8325 Switch series has VxLAN packets with VNI 0.
- **ospf-multicast-ipv6:** Open Shortest Path First packets with the multicast destination IPv6 address FF02::5 or FF02::6.
- **ospf-unicast-ipv4:** Open Shortest Path First packets with a destination IPv4 address owned by the switch.
- **ospf-unicast-ipv6:** Open Shortest Path First packets with a destination IPv6 address owned by the switch.

- **pim:** Protocol Independent Multicast packets with the destination IPv4 address 224.0.0.13 or IPv6 address FF02::D, or Multicast Source Discovery Protocol (MSDP) packets, or with a destination IP address owned by the switch. Also includes PIM packets received from a 6in6 tunnel.
- **secure-learn: 10000**



NOTE

The **secure-learn** class is not supported for HPE Aruba Networking 8320, 8325, and 9300, 9300S, 10040 Switch series.

- **sflow:** Packet headers sampled by the switch that will be sent to the sFlow collector.
- **ssh:** Secure Shell (SSH) or Secure File Transfer Protocol (SFTP) packets. Dropping ssh packets will result in the connection to the CLI being lost.
- **stp:** Spanning Tree Protocol (STP) packets with the destination MAC address 01:80:c2:00:00:00 or Per-VLAN Spanning Tree (PVST) packets with the destination MAC address 01:00:0c:cc:cc:cd.
- **telnet:** Secure Telnet packets.
- **ulld:** Unidirectional Link Detection packets with the destination MAC address 01:00:0c:cc:cc:cc or 00:e0:52:00:00:00, or Cisco Discovery Protocol packets with the destination MAC address 01:00:0c:cc:cc:cc.
- **unknown-multicast:** Packets with an unknown multicast destination IP address.
- **unresolved-ip-unicast:** Packets to be software forwarded by the management processor.
- **vrrp-ipv4:** Virtual Router Redundancy Protocol packets with the destination IPv4 address 224.0.0.18 or VSR-Keepalive.
- **vrrp-ipv6:** Virtual Router Redundancy Protocol packets with the destination IPv6 address FF02::12.

Applies to the HPE Aruba Networking 8100 and 8360 Switch Series:

- **acl-logging:** Access Control List logging packets.
- **arp-broadcast:** Address Resolution Protocol packets with a broadcast destination MAC address.
- **arp-protect:** Address Resolution Protocol packets intercepted and inspected for ARP protection.
- **arp-unicast:** Address Resolution Protocol packets with a switch system destination MAC address.
- **bfd-control:** Bidirectional Forwarding Detection (BFD) control or Ethernet Operations, Administration, and Maintenance (EOAM).
- **bgp:** Border Gateway Protocol packets with a destination IPv4 or IPv6 address owned by the switch.

- **dhcp:** Dynamic Host Configuration Protocol packets. Also includes snooped DHCP packets if DHCP snooping is enabled.
- **erps:** Ethernet Ring Protection Switching control packets with the destination MAC address 01:19:a7:00:00:XX, where XX can be any value.
- **fib-optimization:** Packets for Forwarding Information Base (FIB) Optimization.
- **icmp-broadcast-ipv4:** Internet Control Message Protocol packets with a broadcast or multicast destination IPv4 address.
- **icmp-multicast-ipv6:** Internet Control Message Protocol packets with a well-known multicast destination IPv6 address.
- **icmp-security-ipv6:** IPv6 Internet Control Message Protocol packets intercepted and inspected.
- **icmp-unicast-ipv4:** Internet Control Message Protocol packets with a destination IPv4 address owned by the switch.
- **icmp-unicast-ipv6:** Internet Control Message Protocol packets with a destination IPv6 address owned by the switch.
- **ieee-8021x:** IEEE 802.1X protocol packets with EtherType 0x0888E.
- **igmp:** Internet Group Management Protocol packets.
- **ip-exceptions:** Routable packets that would exceed the MTU for the egress interface, packets that trigger ICMP redirects, and packets with TTL/hop_limit=1 that are discarded when routing through the switch.
- **ip-lockdown:** Packets denied and logged due to violation of allowed "IP address/VLAN/port/MAC address" association.
- **ipfix:** Packets received for IPFIX (IP Flow Information Export).
- **ipsec:** Internet Protocol Security IPv4 or IPv6, unicast or configured multicast. All IPsec traffic received by the CPU will be regulated by the `ipsec` class regardless of the encapsulated protocol.
- **ipv4-options:** Unicast IPv4 packets including option headers.
- **lacp:** Link Aggregation Control Protocol packets with the destination MAC address 01:80:c2:00:00:02.
- **lldp:** Link Layer Discovery Protocol packets with the destination MAC address 01:80:c2:00:00:0e.
- **loop-protect:** Loop Protection packets with the destination MAC address 09:00:09:09:13:a6.
- **manageability:** Unicast IP packets addressed to the switch for specific protocols that do not have a dedicated CoPP class like HTTP, SSH, Telnet, and RADIUS.
- **mirror-to-cpu:** Packets from mirroring session configured to deliver to the console.

- **mld:** Multicast Listener Discovery packets of type V1 or V2 with an IPv6 address of FF00::/8, FF02::16 or FF02::2.
- **mvrp:** Multiple VLAN Registration Protocol packets with the destination MAC address 01:80:c2:00:00:20 or 01:80:c2:00:00:21.
- **nae-packet-monitor:** Network Analytics Engine (NAE) monitored packets.
- **ntp:** Network Time Protocol packets with a destination IP address owned by the switch.
- **ospf-multicast:** Open Shortest Path First packets with the multicast destination IPv4 address 224.0.0.5 or 224.0.0.6, or IPv6 address FF02::5 or FF02::6, or Routing Information Protocol packets with the multicast destination IPv4 address 224.0.0.9 or IPv6 address FF02::9, or MPLS Label Distribution Protocol packets with the multicast destination IPv4 address 224.0.0.2 and destination UDP port 646. Also includes OSPF multicast packets received from a 6in6 tunnel.
- **ospf-unicast:** Open Shortest Path First packets or Routing Information Protocol packets with a local destination IPv4 address or IPv6 address. Also includes OSPF unicast packets received from a 6in6 tunnel.
- **pim:** Protocol Independent Multicast packets with the destination IPv4 address 224.0.0.13 or IPv6 address FF02::D, or Multicast Source Discovery Protocol (MSDP) packets, or with a destination IP address owned by the switch. Also includes PIM packets received from a 6in6 tunnel.
- **ptp:** Precision Time Protocol (PTP) packets to synchronize clocks between networks.
- **secure-learn:** Packets intercepted and inspected to see if source MAC address is allowed on the port.
- **sflow:** Packet headers sampled by the switch that will be sent to the sFlow collector.
- **stp:** Spanning Tree Protocol (STP) packets with the destination MAC address 01:80:c2:00:00:00 or Per-VLAN Spanning Tree (PVST) packets with the destination MAC address 01:00:0c:cc:cc:cd.
- **stp:** Spanning Tree Protocol (STP) packets with the destination MAC address 01:80:c2:00:00:00 or Per-VLAN Spanning Tree (PVST) packets with the destination MAC address 01:00:0c:cc:cc:cd.
- **udld:** Unidirectional Link Detection packets with the destination MAC address 01:00:0c:cc:cc:cc or 00:e0:52:00:00:00, or Cisco Discovery Protocol packets with the destination MAC address 01:00:0c:cc:cc:cc.
- **unknown-multicast:** Packets with an unknown multicast destination IP address.
- **unresolved-ip-unicast:** Packets to be software forwarded by the management processor.
- **vrrp-ipv4:** Virtual Router Redundancy Protocol packets with the destination IPv4 address 224.0.0.18 or IPv6 address FF02::12, or VSX-Keepalive packets.

To regulate any other traffic destined for the CPU, every CoPP policy has a class named `default` that can also be configured to regulate other traffic to the CPU or prevent other traffic from being delivered.



NOTE

All IPsec traffic received by the CPU will be regulated by the `ipsec` class regardless of the encapsulated protocol.

`apply copp-policy`

Syntax

```
apply copp-policy { <NAME> | default }
no apply copp-policy <NAME>
```

Description

Applies a CoPP policy to the switch, replacing the policy that is in effect. There may be a brief interruption in traffic flow to the management processor while the switch implements the change.

Enter the **no apply copp-policy <NAME>** command with the name of a CoPP policy to unapply a CoPP policy and apply the default CoPP policy. This will only take effect if the specified policy is actively applied. Since there must always be a CoPP policy applied, this command effectively attempts to replace the applied CoPP policy with the default CoPP policy. The default CoPP policy cannot be unapplied using this command.

Parameter	Description
<code><NAME></code>	Specifies the name of the policy to apply. Length: 1 to 64 characters.
<code>default</code>	Applies the default policy.

Usage

If the new policy cannot be applied (for example, due to a lack of hardware resources), the previous policy remains in effect. Use the `show copp-policy` command to determine which policy is in effect.

Examples

Applying a policy named My_CoppPolicy:

```
switch(config) # apply copp-policy My_CoppPolicy
```

Applying the default policy:

```
switch(config)# apply copp-policy default
```

Unapplying a policy named My_CoppPolicy:

```
switch(config)# no apply copp-policy My_CoppPolicy
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

class

Syntax

```
class <CLASS> {drop | priority <PRIORITY> rate <RATE> [burst <BURST>]}  
no class <CLASS> {drop | priority <PRIORITY> rate <RATE> [burst <BURST>]}
```

Description

Adds a class to a CoPP policy. If the class exists, the existing class is modified. Changes made to an active (applied) policy take effect immediately.

When adding or modifying a class in an active policy, CoPP immediately activates the change on the switch. In cases where insufficient hardware resources exist to support a class or its action, CoPP fails to activate the changed class on the switch. When this failure occurs, the active configuration on the switch will be out of sync with its definition. To diagnose and remedy this situation:

- Use the [show copp-policy](#) command to determine which classes are out of sync between the active policy and its definition.

- Use the `reset copp-policy` command to synchronize the active policy with its definition. This synchronization changes the classes in the definition to match the classes in the active policy.

The **no** form of this command removes a class from a CoPP policy. Traffic for the removed class that is destined for the processor will be included in the default class. To stop a class of traffic from reaching the processor, set the class action to drop.

Parameter	Description
<code><CLASS></code>	Specifies the class to add or edit.
<code>drop</code>	Drop packets matching the selected class.
<code>priority <PRIORITY></code>	Specifies the priority for packets matching the selected class. Range: 0 to 7.
<code>rate <RATE></code>	Specifies the maximum rate, in packets per second (pps), for packets matching the selected class. Range: 1 to 99999.
<code>burst <BURST></code>	Specifies the maximum burst size, in packets, for packets matching the selected class. Range: 1 to 9999.

Examples

Adding a class to handle LACP traffic with priority of 2 and rate of 2000:

```
switch(config-copp) # class lacp priority 2 rate 2000
```

Modifying the class to drop LLDP packets:

```
switch(config-copp) # class lldp drop
```

Removing the class that handles LLDP packets. LLDP traffic destined to the processor will be included in the default class.

```
switch(config-copp) # no class lldp
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-copp	Administrators or local user group members with execution rights for this command.

clear copp-policy statistics

Syntax

```
clear copp-policy statistics
```

Description

Resets statistics for all CoPP classes to zero.

Examples

Displaying and then resetting statistics for all classes in the active policy:

```
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
Totals:
    bytes passed      : 64000          bytes dropped      : 96000
    packets passed    : 1000           packets dropped    : 1500
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: default
    bytes passed      : 25600          bytes dropped      : 38400
    packets passed    : 400            packets dropped    : 600
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: acl-logging
    bytes passed      : 6400           bytes dropped      : 6400
    packets passed    : 100            packets dropped    : 100
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: arp-broadcast
    bytes passed      : 32000          bytes dropped      : 51200
    packets passed    : 500            packets dropped    : 800
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
    <--OUTPUT OMITTED FOR BREVITY-->
switch# clear copp-policy statistics
switch# show copp-policy statistics
```

```

Statistics for CoPP policy 'default':
Totals:
    bytes passed      : 0
    packets passed    : 0
    avg_packet_size_passed: 0
    bytes dropped     : 0
    packets dropped    : 0
    avg_packet_size_dropped: 0
Class: default
    bytes passed      : 0
    packets passed    : 0
    avg_packet_size_passed: 0
    bytes dropped     : 0
    packets dropped    : 0
    avg_packet_size_dropped: 0
Class: acl-logging
    bytes passed      : 0
    packets passed    : 0
    avg_packet_size_passed: 0
    bytes dropped     : 0
    packets dropped    : 0
    avg_packet_size_dropped: 0
Class: arp-broadcast
    bytes passed      : 0
    packets passed    : 0
    avg_packet_size_passed: 0
    bytes dropped     : 0
    packets dropped    : 0
    avg_packet_size_dropped: 0
    <--OUTPUT OMITTED FOR BREVITY-->
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
Totals:
    packets passed    : 1000
    packets dropped    : 1500
Class: default
    packets passed    : 400
    packets dropped    : 600
Class: acl-logging
    packets passed    : 100
    packets dropped    : 100
Class: arp-broadcast
    packets passed    : 500
    packets dropped    : 800
    <--OUTPUT OMITTED FOR BREVITY-->
switch# clear copp-policy statistics
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
Totals:
    packets passed    : 0
    packets dropped    : 0
Class: default
    packets passed    : 0
    packets dropped    : 0
Class: acl-logging
    packets passed    : 0
    packets dropped    : 0
Class: arp-broadcast
    packets passed    : 0
    packets dropped    : 0

```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

copp-policy

Syntax

```
copp-policy {<NAME> | default [revert]}  
no copp-policy <NAME>
```

Description

Creates a CoPP policy and switches to the **config-copp** context for the policy. Or, if the specified policy exists, switches to the **config-copp** context for the policy. A predefined policy, named **default**, contains factory default classes and is applied to the switch at first startup. This policy cannot be deleted, but its configuration can be changed.

The **no** form of this command removes a CoPP policy. If a policy is active (applied), it cannot be removed. It must be replaced with another policy before it can be removed.

Parameter	Description
<NAME>	Specifies the name of the policy to add or edit. Length: 1 to 64 characters. The name must not be a substring of any of the following reserved words: default, factory - default, commands, configuration, or statistics.
default	Specifies the default CoPP policy. Use this default policy to configure the default policy.
revert	Sets the default CoPP policy to its factory settings.

Examples

Creating a policy named My_CoppPolicy:

```
switch(config) # copp-policy My_CoppPolicy
switch(config-copp) #
```

Removing a policy named My_CoppPolicy:

```
switch(config) # no copp-policy My_CoppPolicy
```

Setting the default policy to its factory settings:

```
switch(config) # copp-policy default revert
```

Unapplying the policy named My_CoppPolicy:

```
switch(config) # no apply copp-policy My_CoppPolicy
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

default-class

Syntax

```
default-class priority <PRIORITY> rate <RATE> [burst <BURST>]
```

Description

Configures the default class that is automatically defined for all CoPP policies. The default class cannot be removed, but its configuration can be changed. The default class is applied to traffic that does not match any other class defined for a policy.

Parameter	Description
priority <PRIORITY>	Specifies the priority for packets matching the selected class. Range: 0 to 7.
rate <RATE>	Specifies the maximum rate, in packets per second (pps), for packets matching the selected class. Range: 1 to 99999.
burst <BURST>	Specifies the maximum burst size, in packets, for packets matching the selected class. Range: 1 to 9999.

Example

Setting the default class to a priority of **2** and rate of **2000**:

```
switch(config-copp) # default-class priority 2 rate 2000
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config-copp	Administrators or local user group members with execution rights for this command.

reset copp-policy

Syntax

```
reset copp-policy { <NAME> | default }
```

Description

Resets an active CoPP policy to match the settings that are currently in effect for the active policy on the switch. Changes made to the active policy that could not be activated are removed from the active policy.

When the switch fails to add or modify a class in an active CoPP policy, it is possible the active policy settings on the switch may be out of sync with those defined in the policy.

Parameter	Description
<code><NAME></code>	Specifies the name of the policy to reset. Length: 1 to 64 characters.
<code>default</code>	Resets the default policy to match its active settings.

Examples

Resetting a policy named My_CoppPolicy:

```
switch# show copp-policy My_CoppPolicy
class                drop priority rate kbps burst kB min-max pps
hardware rate kbps
-----
igmp                  6          5000      60      411-9765
5156
lacp                  2          2000      64      164-3906
2343
default               1          6000      70      494-11718
6093
switch# config terminal
switch(config)# copp-policy My_CoppPolicy
switch(config-copp)# class stp priority 4 rate 4000 burst 60
switch(config-copp)# do show copp-policy My_CoppPolicy
class                drop priority rate kbps burst kB min-max pps
hardware rate kbps
-----
igmp                  6          5000      60      411-9765
5156
lacp                  2          2000      64      164-3906
2343
default               1          6000      70      494-11718
6093
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# do show copp-policy My_CoppPolicy configuration
class                drop priority rate kbps burst kB min-max pps
```

```

applied
-----
-----
igmp                6          5000      60      411-9765      yes
lcp                 2          2000      64      164-3906      yes
stp                 4          4000      60      329-7812      no
default             1          6000      70      494-11718     yes
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
  active configuration.
switch(config-copp)# exit
switch(config)# reset copp-policy My_CoppPolicy
switch(config)# do show copp-policy My_CoppPolicy
class                drop priority rate kbps burst kB min-max pps
hardware rate kbps
-----
-----
igmp                6          5000      60      411-9765
5156
lcp                 2          2000      64      164-3906
2343
default             1          6000      70      494-11718
6093
switch# show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps
-----
-----
igmp                6          5000      60      5000
lcp                 2          2000      1000    2000
default             1          6000      70      6000
switch# config terminal
switch(config)# copp-policy My_CoppPolicy
switch(config-copp)# class stp priority 4 rate 4000 burst 60
switch(config-copp)# do show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps
-----
-----
igmp                6          5000      60      5000
lcp                 2          2000      1000    2000
default             1          6000      70      6000
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
  active configuration.
switch(config-copp)# do show copp-policy My_CoppPolicy configuration
class                drop priority rate pps burst pkts applied
-----
-----
igmp                6          5000      60      yes

```

```

lacp                2          2000      1000      yes
stp                 4          4000       60       no
default             1          6000       70       yes
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# exit
switch(config)# reset copp-policy My_CoppPolicy
switch(config)# do show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps
-----
igmp                  6          5000       60       5000
lacp                  2          2000      1000      2000
default              1          6000       70       6000
switch# show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps
-----
igmp                  6          5000       60       5000
lacp                  2          2000      2050      2000
default              1          6000       70       6000
switch# config terminal
switch(config)# copp-policy My_CoppPolicy
switch(config-copp)# class stp priority 4 rate 4000 burst 60
switch(config-copp)# do show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps
-----
igmp                  6          5000       60       5000
lacp                  2          2000      2050      2000
default              1          6000       70       6000
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# do show copp-policy My_CoppPolicy configuration
class                drop priority rate pps burst pkts applied
-----
igmp                  6          5000       60       yes
lacp                  2          2000      2050      yes
stp                   4          4000       60       no
default              1          6000       70       yes
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# exit
switch(config)# reset copp-policy My_CoppPolicy
switch(config)# do show copp-policy My_CoppPolicy
class                drop priority rate pps burst pkts hardware rate pps

```

```

-----
igmp                6          5000      60          5000
lcp                 2          2000     2050          2000
default             1          6000      70          6000
switch# show copp-policy My_CoppPolicy
class                drop priority rate pps hardware rate pps
-----
igmp                6          5000      5000
lcp                 2          2000      2000
default             1          6000      6000
switch# config terminal
switch(config)# copp-policy My_CoppPolicy
switch(config-copp)# class stp priority 4 rate 4000
switch(config-copp)# do show copp-policy My_CoppPolicy
class                drop priority rate pps hardware rate pps
-----
igmp                6          5000      5000
lcp                 2          2000      2000
default             1          6000      6000
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# do show copp-policy My_CoppPolicy configuration
class                drop priority rate pps applied
-----
igmp                6          5000      yes
lcp                 2          2000      yes
stp                 4          4000      no
default             1          6000      yes
% Warning: user-specified classes in CoPP policy My_CoppPolicy do not match
active configuration.
switch(config-copp)# exit
switch(config)# reset copp-policy My_CoppPolicy
switch(config)# do show copp-policy My_CoppPolicy
class                drop priority rate pps hardware rate pps
-----
igmp                6          5000      5000
lcp                 2          2000      2000
default             1          6000      6000

```

Resetting the default policy:

```
switch(config)# reset copp-policy default
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	config	Administrators or local user group members with execution rights for this command.

show copp-policy

Syntax

```
show copp-policy [<NAME> | default] [commands] [configuration] [vsx-peer]
```

Description

Shows CoPP policy settings for a specific CoPP policy. When entered without specifying either a name or the `default` parameter, shows all the CoPP policy settings that are active on the switch and have successfully been programmed into the hardware.

A warning is displayed if:

- The active and user-specified applications of a policy do not match.
- The active and user-specified configurations of a policy do not match.

Parameter	Description
<code><NAME></code>	Specifies the name of the policy for which to display settings. Length: 1 to 64 characters.
<code>default</code>	Displays CoPP settings for the default policy.
<code>commands</code>	Displays output as CLI commands.

Parameter	Description
configuration	Displays user - specified CoPP settings and not the active settings.
vsx-peer	Shows the output from the VSX peer switch. If the switches do not have the VSX configuration or the ISL is down, the output from the VSX peer switch is not displayed. This parameter is available on switches that support VSX.

Example

Displaying the CoPP policies defined in the configuration and the active application:

switch#

```

    show copp-policy
applied copp_policy_name
-----
        My_CoppPolicy
applied default
switch#

```

Displaying the active configuration of all CoPP policies as CLI commands:

```

switch# show copp-policy commands
copp-policy My_CoppPolicy
    class igmp priority 6 rate 5000 burst 60
    class lacp priority 2 rate 2000 burst 64
    default-class priority 1 rate 6000 burst 70
copp-policy default
    class acl-logging priority 0 rate 468 burst 4
    class arp-broadcast priority 4 rate 1406 burst 4
    class arp-protect priority 4 rate 2343 burst 4
    class arp-unicast priority 5 rate 937 burst 4
    class bfd-control priority 9 rate 937 burst 16
    <--OUTPUT OMITTED FOR BREVITY-->
    default-class priority 1 rate 17343 burst 16
apply copp-policy default
switch#
switch# show copp-policy commands
copp-policy My_CoppPolicy
    class igmp priority 6 rate 5000 burst 60
    class lacp priority 2 rate 2000 burst 1000
    default-class priority 1 rate 6000 burst 70
copp-policy default

```

```

class acl-logging priority 0 rate 50 burst 50
class arp-broadcast priority 3 rate 7000 burst 7000
class arp-unicast priority 4 rate 2500 burst 2500
class bfd priority 7 rate 1000 burst 1000
    <--OUTPUT OMITTED FOR BREVITY-->
default-class priority 1 rate 1000 burst 500
apply copp-policy default
switch#
switch# show copp-policy commands
copp-policy My_CoppPolicy
    class igmp priority 6 rate 5000 burst 60
    class lacp priority 2 rate 2000 burst 2050
    default-class priority 1 rate 6000 burst 70
copp-policy default
    class acl-logging priority 0 rate 25 burst 3
    class arp-broadcast priority 2 rate 1250 burst 1250
    class arp-protect priority 2 rate 2075 burst 2075
    class arp-unicast priority 3 rate 825 burst 825
    class bfd-control priority 5 rate 850 burst 850
    <--OUTPUT OMITTED FOR BREVITY-->
    default-class priority 2 rate 4225 burst 528
apply copp-policy default
switch#

```

Displaying the default policy:

```

switch# show copp-policy default
class                drop priority rate kbps burst kB min-max pps
hardware rate kbps
-----
acl-logging          0          468      4      38-906          468
arp-broadcast        4          1406     4      115-2734
1406
arp-protect          4          2343     4      192-4562
2343
arp-unicast          5          937      4      77-1828          937
bfd-control          9          937     16      77-1828          937
    <--OUTPUT OMITTED FOR BREVITY-->
default              1          17343    16      1427-33859
17343
switch# show copp-policy default
class                drop priority rate pps burst pkts hardware rate pps
-----
acl-logging          0          50      50      50

```

```

arp-broadcast      3      7000      7000      7000
arp-unicast        4      2500      2500      2500
bfd                7      1000      1000      1000
    <--OUTPUT OMITTED FOR BREVITY-->
default            1      1000      500      1000
switch# show copp-policy default
class              drop priority rate pps burst pkts hardware rate pps
-----
acl-logging        0        25      3        25
arp-broadcast      2        1250     1250     1250
arp-protect        2        2075     2075     2075
arp-unicast        3        825      825      825
bfd-control        5        850      850      850
    <--OUTPUT OMITTED FOR BREVITY-->
default            2        4225     528      4225
switch# show copp-policy default
class              drop priority rate pps hardware rate pps
-----
arp-broadcast      2        1250     1250
arp-unicast        3        825      825
    <--OUTPUT OMITTED FOR BREVITY-->
default            2        4225     4225

```

Command History

Release	Modification
---------	--------------

10.07 or earlier	- -
------------------	-----

Command Information

Platforms	Command context	Authority
All platforms	Operator (>) or Manage r (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this c ommand from the operator context (>) only.

show copp-policy factory-default

Syntax

```
show copp-policy factory-default [commands] [vsx-peer]
```

Description

Display the configuration for the factory-default CoPP policy.

Parameter	Description
commands	Displays output as CLI commands.
vsx-peer	Shows the output from the VSX peer switch. If the switches do not have the VSX configuration or the ISL is down, the output from the VSX peer switch is not displayed. This parameter is available on switches that support VSX.

Example

Displaying the factory-default policy:

```
switch# show copp-policy factory-default
class                drop priority rate kbps burst kB min-max pps
-----
acl-logging          0           468      4      38-906
arp-broadcast         4          1406     4      115-2734
arp-protect           4          2343     4      192-4562
arp-unicast           5           937     4       77-1828
bfd-control           9           937    16      77-1828
    <--OUTPUT OMITTED FOR BREVITY-->
default              1          17343    16     1427-33859
switch# show copp-policy factory-default
class                drop priority rate pps burst pkts
-----
acl-logging          0           50      50
arp-broadcast         3          7000    7000
arp-unicast           4          2500    2500
bfd                   7          1000    1000
    <--OUTPUT OMITTED FOR BREVITY-->
default              1          1000    500
switch# show copp-policy factory-default
class                drop priority rate pps burst pkts
-----
acl-logging          0           25       3
arp-broadcast         2          1250    1250
```

```

arp-protect          2          2075      2075
arp-unicast          3          825       825
bfd-control           5          850       850

```

<--OUTPUT OMITTED FOR BREVITY-->

```

default              2          4225      528

```

```

switch# show copp-policy factory-default

```

```

class                drop priority rate pps
-----

```

```

arp-broadcast         2          1250
arp-unicast           3          825

```

<--OUTPUT OMITTED FOR BREVITY-->

```

default              2          4225

```

Displaying the active configuration of **My_CoppPolicy** (**My_CoppPolicy** is applied):

```

switch# config terminal

```

```

switch(config)# apply copp-policy My_CoppPolicy

```

```

switch(config)# do show copp-policy My_CoppPolicy

```

```

class                drop priority rate kbps burst kB min-max pps

```

```

hardware rate kbps
-----

```

```

igmp                  6          5000      60      411-9765
5156

```

```

lacp                  2          2000      64      164-3906
2343

```

```

default              1          6000      70      494-11718
6093

```

```

switch# config terminal

```

```

switch(config)# apply copp-policy My_CoppPolicy

```

```

switch(config)# do show copp-policy My_CoppPolicy

```

```

class                drop priority rate pps burst pkts hardware rate pps
-----

```

```

igmp                  6          5000      60      5000

```

```

lacp                  2          2000     1000     2000

```

```

default              1          6000      70      6000

```

```

switch# config terminal

```

```

switch(config)# apply copp-policy My_CoppPolicy

```

```

switch(config)# do show copp-policy My_CoppPolicy

```

```

class                drop priority rate pps burst pkts hardware rate pps
-----

```

```

igmp                  6          5000      60      5000

```

```

lacp                  2          2000     2050     2000

```

```

default              1          6000      70      6000

```

```

switch# config terminal

```

```

switch(config)# apply copp-policy My_CoppPolicy
switch(config)# do show copp-policy My_CoppPolicy
class                drop priority rate pps hardware rate pps
-----
igmp                  6          5000    5000
larp                  2          2000    2000
default               1          6000    6000

```

Displaying the active configuration of **My_CoppPolicy** as CLI commands:

```

switch# show copp-policy My_CoppPolicy commands
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 64
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 1000
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 2050
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000
  class larp priority 2 rate 2000
  default-class priority 1 rate 6000
apply copp-policy My_CoppPolicy

```

Displaying the user-specified configuration of **My_CoppPolicy**:

```

switch# show copp-policy My_CoppPolicy configuration
class                drop priority rate kbps burst kB min-max pps
applied
-----
igmp                  6          5000    60      411-9765    yes
larp                  2          2000    64      164-3906    yes
default               1          6000    70      494-11718   yes
switch# show copp-policy My_CoppPolicy configuration
class                drop priority rate pps burst pkts applied

```

```

-----
igmp                6          5000      60          yes
larp                2          2000      1000         yes
default             1          6000      70           yes
switch# show copp-policy My_CoppPolicy configuration
class               drop priority rate pps burst pkts applied
-----
igmp                6          5000      60          yes
larp                2          2000      2050         yes
default             1          6000      70           yes
switch# show copp-policy My_CoppPolicy configuration
class               drop priority rate pps applied
-----
igmp                6          5000      yes
larp                2          2000      yes
default             1          6000      yes

```

Displaying the user-specified configuration of **My_CoppPolicy** as CLI commands:

```

switch# show copp-policy My_CoppPolicy commands configuration
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 64
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands configuration
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 1000
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands configuration
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000 burst 60
  class larp priority 2 rate 2000 burst 2050
  default-class priority 1 rate 6000 burst 70
apply copp-policy My_CoppPolicy
switch# show copp-policy My_CoppPolicy commands configuration
copp-policy My_CoppPolicy
  class igmp priority 6 rate 5000
  class larp priority 2 rate 2000
  default-class priority 1 rate 6000
apply copp-policy My_CoppPolicy

```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show copp-policy statistics

Syntax

```
show copp-policy statistics [class <CLASS> | default-class | non-zero] [vsx-peer]
```

Description

Displays statistics for all classes, a single class, or all classes with non-zero statistics in the active CoPP policy.

Parameter	Description
<CLASS>	Specifies the <u>class</u> for which to display statistics.
default-class	Displays statistics for the default class.
non-zero	Displays statistics for all classes with non - zero statistics.
vsx-peer	Shows the output from the VSX peer switch. If the switches do not have the VSX configuration or the ISL is down, the output f

Parameter

Description

rom the VSX peer switch is not displayed. This parameter is available on switches that support VSX.

Usage

If a single class is specified, the priority, rate, and burst size that has been programmed in hardware for that class will be shown. This command will fail with an alert if the user specifies a class that is not configured for the actively applied CoPP policy.

Examples

Applying the **default** CoPP policy and displaying statistics for all classes in the actively applied policy:



NOTE

The rate displayed is the actual rate in hardware.

```
switch# config terminal
switch(config)# apply copp-policy default
switch(config)# exit
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
Totals:
    bytes passed      : 64000          bytes dropped      : 96000
    packets passed    : 1000           packets dropped    : 1500
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: default
    bytes passed      : 25600          bytes dropped      : 38400
    packets passed    : 400            packets dropped    : 600
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: acl-logging
    bytes passed      : 6400           bytes dropped      : 6400
    packets passed    : 100            packets dropped    : 100
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
Class: arp-broadcast
    bytes passed      : 32000          bytes dropped      : 51200
    packets passed    : 500            packets dropped    : 800
    avg_packet_size_passed: 64         avg_packet_size_dropped: 64
    <--OUTPUT OMITTED FOR BREVITY-->
switch# config terminal
switch(config)# apply copp-policy default
switch(config)# exit
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
```

```
Totals:
    packets passed      : 1000                packets dropped      : 1500
Class: default
    packets passed      : 400                  packets dropped      : 600
Class: acl-logging
    packets passed      : 100                  packets dropped      : 100
Class: arp-broadcast
    packets passed      : 500                  packets dropped      : 800
    <--OUTPUT OMITTED FOR BREVITY-->
```

```
switch# config terminal
switch(config)# apply copp-policy default
switch(config)# exit
switch# show copp-policy statistics
Statistics for CoPP policy 'default':
```

```
Totals:
    packets passed      : 1000                packets dropped      : 1500
Class: default
    packets passed      : 400                  packets dropped      : 600
Class: arp-broadcast
    packets passed      : 500                  packets dropped      : 800
    <--OUTPUT OMITTED FOR BREVITY-->
```

Displaying statistics for the default class in the active policy:

```
switch(config)# show copp-policy statistics default-class
Statistics for CoPP policy 'default':
Class: default
Description: Default
    priority              : 1
    rate (kbps)           : 17343
    burst size (bytes)    : 16
    bytes passed          : 25600                bytes dropped        : 38400
    packets passed        : 400                  packets dropped        : 600
    avg_packet_size_passed: 64                  avg_packet_size_dropped: 64
switch(config)# show copp-policy statistics default-class
Statistics for CoPP policy 'default':
Class: default
Description: Default
    priority              : 1
    rate (pps)            : 1000
    burst size (pkts)     : 500
    bytes passed          : 25600                bytes dropped        : 38400
    packets passed        : 400                  packets dropped        : 600
    avg_packet_size_passed: 64                  avg_packet_size_dropped: 64
switch(config)# show copp-policy statistics default-class
```

```

Statistics for CoPP policy 'default':
Class: default
Description: Default
    priority           : 2
    rate (pps)         : 4225
    burst size (pkts)   : 528
    packets passed      : 400
                                packets dropped : 600
switch(config)# show copp-policy statistics default-class
Statistics for CoPP policy 'default':
Class: default
Description: Default
    priority           : 2
    rate (pps)         : 4225
    packets passed      : 400
                                packets dropped : 600

```

Displaying statistics for the class **arp-broadcast** in the actively applied policy:

```

switch# show copp-policy statistics class arp-broadcast
Statistics for CoPP policy 'default':
Class: arp-broadcast
Description: Address Resolution Protocol broadcast
    priority           : 4
    rate (kbps)        : 1406
    burst size (bytes)  : 4
    bytes passed        : 32000
                                bytes dropped   : 51200
    packets passed      : 500
                                packets dropped  : 800
    avg_packet_size_passed: 64
                                avg_packet_size_dropped: 64
switch# show copp-policy statistics class arp-broadcast
Statistics for CoPP policy 'default':
Class: arp-broadcast
Description: Address Resolution Protocol broadcast
    priority           : 3
    rate (pps)         : 7000
    burst size (pkts)   : 7000
    bytes passed        : 32000
                                bytes dropped   : 51200
    packets passed      : 500
                                packets dropped  : 800
    avg_packet_size_passed: 64
                                avg_packet_size_dropped: 64
switch# show copp-policy statistics class arp-broadcast
Statistics for CoPP policy 'default':
Class: arp-broadcast
Description: Address Resolution Protocol broadcast
    priority           : 2
    rate (pps)         : 1250
    burst size (pkts)   : 1250
    packets passed      : 500
                                packets dropped  : 800

```

```
switch# show copp-policy statistics class arp-broadcast
Statistics for CoPP policy 'default':
Class: arp-broadcast
Description: Address Resolution Protocol broadcast
  priority           : 2
  rate (pps)         : 1250
  packets passed     : 500                      packets dropped : 800
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Operator (>) or Manager (#)	Operators or Administrators or local user group members with execution rights for this command. Operators can execute this command from the operator context (>) only.

show tech copp

Syntax

```
show tech copp
```

Description

Displays the output of all show commands supported by CoPP.

Examples

Capturing the command output into a local file:

```
switch# show tech copp local-file
Show Tech output stored in local-file. Please use 'copy show-tech local-
file' to copy-out this file.
switch# copy show-tech local-file ?
  REMOTE_URL    URL of syntax
                {tftp://|sftp://USER@}{IP|HOST}[:PORT][;blocksize=VAL]/FILE
```

```
STORAGE_URL URL of syntax usb:/file
switch# copy show-tech local-file
```

Command History

Release	Modification
10.07 or earlier	- -

Command Information

Platforms	Command context	Authority
All platforms	Manager (#)	Administrators or local user group members with execution rights for this command.

Support and Other Resources

Access HPE Aruba Networking support and updates, and view warranty and regulatory information

Subtopics

[Accessing HPE Aruba Networking Support](#)

[Accessing Updates](#)

[Warranty Information](#)

[Regulatory Information](#)

[Documentation Feedback](#)

Accessing HPE Aruba Networking Support

HPE Aruba Networking Support Services

<https://www.hpe.com/us/en/networking/hpe-aruba-networking-support-services.html>

AOS - CX Switch Software Documentation Portal	https://arubanetworking.hpe.com/techdocs/ArubaDocPortal/content/new-portal/aoscx.html
HPE Aruba Networking Support Portal	https://networkingsupport.hpe.com/home
North America telephone	1 - 800 - 943 - 4526 (US & Canada Toll - Free Number) +1 - 650 - 750 - 0350 (Backup—Toll Number)
International telephone	https://www.hpe.com/psnow/doc/a50011948enw

Be sure to collect the following information before contacting Support:

- Technical support registration number (if applicable)
- Product name, model or version, and serial number
- Operating system name and version
- Firmware version
- Error messages
- Product-specific reports and logs
- Add-on products or components
- Third-party products or components

Other useful sites

Other websites that can be used to find information:

HPE Aruba Networking Developer Hub	https://developer.arubanetworks.com/hpe - aruba - networking - aoscx/docs/about
Airheads social forums and Knowledge Base	https://community.arubanetworks.com/
AOS - CX Software Technical Update channel on YouTube.	Videos on new features introduced in this release : https://www.youtube.com/playlist?list=PLsYGHuNuBZcbWPEjjHuVMqP - Q_UL3CskS
HPE Aruba Networking Hardware Documentation and Translations Portal	

HPE Aruba Networking software	<u>https://networkingsupport.hpe.com/downloads</u> <u>https://networkingsupport.hpe.com/downloads</u>
Software licensing and Feature Packs	<u>https://licensemanagement.hpe.com/</u>
End - of - Life information	<u>https://networkingsupport.hpe.com/end - of - life</u>

Accessing Updates

You can access updates from the HPE Aruba Networking Support Portal at <https://networkingsupport.hpe.com>.

Some software products provide a mechanism for accessing software updates through the product interface. Review your product documentation to identify the recommended software update method.

To subscribe to eNewsletters and alerts:

<https://networkingsupport.hpe.com/notifications/subscriptions> (requires an active HPE Aruba Networking Support Portal account to manage subscriptions). Security notices are viewable without an HPE Aruba Networking Support Portal account.

Warranty Information

To view warranty information for your product, go to <https://www.arubanetworks.com/support-services/product-warranties/>.

Regulatory Information

To view the regulatory information for your product, view the Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products, available at <https://www.hpe.com/support/Safety-Compliance-EnterpriseProducts>

Additional regulatory information

HPE Aruba Networking is committed to providing our customers with information about the chemical substances in our products as needed to comply with legal requirements, environmental data (company programs, product recycling, energy efficiency), and safety information and compliance data, (RoHS and

WEEE). For more information, see <https://www.arubanetworks.com/company/about-us/environmental-citizenship/>.

Documentation Feedback

HPE Aruba Networking is committed to providing documentation that meets your needs. To help us improve the documentation, send any errors, suggestions, or comments to Documentation Feedback (docsfeedback-switching@hpe.com). When submitting your feedback, include the document title, part number, edition, and publication date located on the front cover of the document. For online help content, include the product name, product version, help edition, and publication date located on the legal notices page.