



AIRCRAFT ID:

CC-BGE

Page: 1 / 7

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

WORK PACKAGE INFORMATION:

HM-WP CC-BGE FEB2022 [1C+2C] [EO]

Aircraft Type:	Serial N°:	Effective Code:
B787 - CC-BGE	38478	105
Work Location:	Organization:	Start Date:
AUH/ADAT HGR	CMA DGAC N° 593	2/16/22 8:00 AM
Work Order N°	Flight Hours:	Flight Cycles:
WO - 138815172		

	TASK LIST:					
Line N°	Barcode:	Status:	Task Name:	OBS	Signature	
1	T00DGT2H	ACTV	AD-B787-29-A8524 PART 1 (GROUP 3)(JIC) (HYDRAULIC POWER - WHEEL AND TIRE THREAT HYDRAULIC SYSTEMS - HYDRAULIC TUBE CHANGE)	INSP		
2	T00JSLK7	ACTV	CABIN-B787-9-CHECK-A1384 (JIC) (WASTE TROLLEY - BRAKE INSPECTION)			
3	T00D1GNE	ACTV	DA-B787-08-A4300-01 (JIC) (WEIGHING OF BOEING 787-9 AIRPLANES)	INSP		
4	T00JF0AS	ACTV	IH-B787-20-A4713 (JIC) (COMPOSITE SURFACE - CHEMICAL CLEANING)			
5	T00JSSMB	ACTV	IH-B787-21-B2844 PART 1 (JIC) (AIR CONDITIONING - Aft And Bulk Cargo Compartment Heating System - Bulk Cargo Compartment Heating System Air Distribution Nozzle Replacement)	INSP		
6	T00M0ANB	ACTV	IH-B787-21-B5321 PART 3 (JIC) (AIR CONDITIONING - Integrated Cooling System - Integrated Cooling System Liquid Cooling Pump Replacement)			
7	T00LRSWU	ACTV	IH-B787-23-B6224 (JIC) (FLIGHT INTERPHONE SYSTEM AUDIO GATEWAY UNIT AND AUDIO CONTROL PANEL SOFTWARE CHANGE)			



CC-BGE

Page: 2 / 7

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

T00FGDKQ T00HZZDC	ACTV	IH-B787-24-B1323 PART 2 (JIC) (ELECTRICAL POWER - Power Distribution System - Electrical Power Panel Door Marker Change)	
T00HZZDC	A C.T.\ /		
	ACTV	IH-B787-24-B2886 PART 3 (JIC) (ELECTRICAL POWER - Batteries - Auxiliary Power Unit Battery Wire Installation For Battery Cell Balancing)	
T00JERV7	ACTV	IH-B787-24-B3082 PART 1 (JIC) (LH WING DAMAGED BREAKAWAY TERMINAL LUGS INSPECTION)	
T00JERUW	ACTV	IH-B787-24-B3082 PART 2 (JIC) (RH WING DAMAGED BREAKAWAY TERMINAL LUGS INSPECTION)	
T00HRDA3	ACTV	IH-B787-25-A3004(REQ) (PROCEDURE FOR INSTALL FOLDER "APU IN FLIGHT START - AUTOLAND MONTHLY CONTROL SHEET WIDE BODY FLEET FORM. 0P-080")	
T00JSH89	ACTV	IH-B787-25-B3055 PART 2 (JIC) (EQUIPMENT AND FURNISHINGS - Insulation - Cabin Moisture Ingress Insulation Tape Installation)	
T00LC0PR	ACTV	IH-B787-27-B5840 (JIC) (FLIGHT CONTROLS - Trailing Edge Flap System - Aft Trailing Edge Power Drive Unit Tie Rod Assembly Change)	INSP
T00JSSMG	ACTV	IH-B787-32-B2989 PART 2 (JIC) (MAIN LANDING GEAR - ELECTRIC BRAKE ACTUATOR - BRAKE HARNESS AND BRACKET CHANGE)	
T00JSSHW	ACTV	IH-B787-32-B3084 PART 3 (JIC) (MAIN GEAR AND DOORS - P56 AND P57 MAIN LANDING GEAR WHEEL WELL SERVICE PANEL WIRE HARNESS - INSPECT REPAIR AND/OR REPLACE)	INSP
T00JF00N	ACTV	IH-B787-38-A1305(JIC) (TOILETS TREATMENT DESINFECTION)	
T00G29HA	ACTV	IH-B787-38-B1979 PART 1 (LH)(JIC) (Removal, Cleaning and Installation of Waste Tank Point Level Sensor)	
T00G29K9	ACTV	IH-B787-38-B1979 PART 2 (RH)(JIC) (Removal, Cleaning and Installation of Waste Tank Point Level Sensor)	
	T00JERUW T00HRDA3 T00JSH89 T00JSSMG T00JSSHW T00JF00N T00G29HA	T00JERUW ACTV T00HRDA3 ACTV T00JSH89 ACTV T00JSSMG ACTV T00JSSHW ACTV T00JF00N ACTV T00G29HA ACTV	TOOJERUW ACTV IH-B787-24-B3082 PART 2 (JIC) (RH WING DAMAGED BREAKAWAY TERMINAL LUGS INSPECTION) TOOHRDA3 ACTV IH-B787-25-A3004(REQ) (PROCEDURE FOR INSTALL FOLDER "APU IN FLIGHT START - AUTOLAND MONTHLY CONTROL SHEET WIDE BODY FLEET FORM. 0P-080") TOOJSH89 ACTV IH-B787-25-B3055 PART 2 (JIC) (EQUIPMENT AND FURNISHINGS - Insulation - Cabin Moisture Ingress Insulation Tape Installation) TOOLCOPR ACTV IH-B787-27-B5840 (JIC) (FLIGHT CONTROLS - Trailing Edge Flap System - Aft Trailing Edge Power Drive Unit Tie Rod Assembly Change) TOOJSSMG ACTV IH-B787-32-B3084 PART 2 (JIC) (MAIN LANDING GEAR - ELECTRIC BRAKE ACTUATOR - BRAKE HARNESS AND BRACKET CHANGE) TOOJSSHW ACTV IH-B787-32-B3084 PART 3 (JIC) (MAIN GEAR AND DOORS - P56 AND P57 MAIN LANDING GEAR WHEEL WELL SERVICE PANEL WIRE HARNESS - INSPECT REPAIR AND/OR REPLACE) TOOJFOON ACTV IH-B787-38-B1979 PART 1 (LH)(JIC) (Removal, Cleaning and Installation of Waste Tank Point Level Sensor)



CC-BGE

Page: 3 / 7

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

20	T00G29G0	ACTV	IH-B787-38-B1980 PART 1 (LH)(JIC) (Removal, Cleaning and Installation of Waste Tank Continuous Level Sensor)	
21	T00G29GH	ACTV	IH-B787-38-B1980 PART 2 (RH)(JIC) (Removal, Cleaning and Installation of Waste Tank Continuous Level Sensor)	
22	T00GBH7L	ACTV	IH-B787-38-B2128 (JIC) (WATER/WASTE - Storage And Distribution - Electrical Connector Inspection and Change)	INSP
23	T00E125G	ACTV	IH-B787-52-A9775 PART 3 (JIC) (Service and Miscellaneous Doors - Replacement of Hinges on Potable Water Service Access Door)	INSP
24	T00FH4KX	ACTV	IH-B787-52-B0949 (GROUP 2)(JIC) (DOORS - FLIGHT DECK SECURITY DOOR SYSTEM - FLIGHT DECK DOOR AND BULKHEAD ASSEMBLY CHANGE)	
25	Т00ННАЕ9	ACTV	IH-B787-53-B2931 PART 3 (GROUP 3) (JIC) (FUSELAGE - Tail Strike Protection System - Tail Strike Module Moisture Ingress Protection Installation)	INSP
26	T00L7KL2	ACTV	IH-B787-57-B3687 PART 1 (JIC) (LH WING - WINGS - Fixed Trailing Edge - Lower Support Struts 31-38 Inspection and Change)	
27	T00L7KKW	ACTV	IH-B787-57-B3687 PART 2 (JIC) (RH WING - WINGS - Fixed Trailing Edge - Lower Support Struts 31-38 Inspection and Change)	
28	T00EWX50	ACTV	IH-B787-70-A8927-CHECK-C(JIC) (RUN UP CHECKLIST B787)	INSP
29	T00JSLZ3	ACTV	IH-B787-78-B0269 PART 1 (JIC) (THRUST REVERSER SYSTEM - THRUST REVERSER BLOCKER DOOR - HINGE CHANGE)	
30	T00JSLZM	ACTV	IH-B787-78-B0269 PART 2 (JIC) (THRUST REVERSER SYSTEM - THRUST REVERSER BLOCKER DOOR - HINGE CHANGE)	
31	T00FCHJE	ACTV	IH-B787-78-B1053 PART 1 (JIC) (HRUST REVERSER - NON-STANDARD BLOCKER DOOR CRES DRAG LINK INTRODUCTION)	



CC-BGE
Page: 4/7

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

T00FCHL9 T00FCHL6	ACTV	IH-B787-78-B1053 PART 1 (JIC) (THRUST REVERSER - NON-STANDARD BLOCKER DOOR CRES DRAG LINK INTRODUCTION)	
T00FCHL6	ACTV	III D707 70 D4060 DADT 0 / IIO) / IIDUOT DEL/EDOED - NON OTANDADD	
		IH-B787-78-B1053 PART 2 (JIC) (HRUST REVERSER - NON-STANDARD BLOCKER DOOR CRES DRAG LINK INTRODUCTION)	
T00FCHLG	ACTV	IH-B787-78-B1053 PART 2 (JIC) (THRUST REVERSER - NON-STANDARD BLOCKER DOOR CRES DRAG LINK INTRODUCTION)	
T00JP7Q1	ACTV	IH-B787-78-B2450 PART 1 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change)	INSP
T00JP7AE	ACTV	IH-B787-78-B2450 PART 2 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change)	INSP
T00JP7FG	ACTV	IH-B787-78-B2450 PART 3 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change)	INSP
T00JP76Q	ACTV	IH-B787-78-B2450 PART 4 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change)	INSP
T00FTY1W	ACTV	CABIN-B787-9-CHECK-A0937 (JIC) (BC Seats and Ottoman Structure Paint)	
T00FTYEX	ACTV	CABIN-B787-9-CHECK-A0938(JIC) (Upper Capping on Front Row Ottoman Extensive Inspection)	
T00FTYHD	ACTV	CABIN-B787-9-CHECK-A0939(JIC) (Foot Rest Red Leather on Ottoman (Front and Standard) Replace)	
T00FTYKC	ACTV	CABIN-B787-9-CHECK-A0940(JIC) (Table Strap on BC Seats Replace)	
T00FTYUG	ACTV	CABIN-B787-9-CHECK-A0941(JIC) (Capping Side on Standard Ottoman Adjustment)	
	T00JP7Q1 T00JP7FG T00JP76Q T00FTY1W T00FTYHD T00FTYKC	T00JP7Q1 ACTV T00JP7G ACTV T00JP7GQ ACTV T00FTY1W ACTV T00FTYHD ACTV T00FTYKC ACTV	BLOCKER DOOR CRES DRAG LINK INTRODUCTION) TOOJP7Q1 ACTV IH-B787-78-B2450 PART 1 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change) TOOJP7AE ACTV IH-B787-78-B2450 PART 2 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change) TOOJP7FG ACTV IH-B787-78-B2450 PART 3 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change) TOOJP76Q ACTV IH-B787-78-B2450 PART 4 (JIC) (EXHAUST - Thrust Reverser System - Thrust Reverser Unlatch Sequence Marking Change) TOOJP76Q ACTV CABIN-B787-9-CHECK-A0937 (JIC) (BC Seats and Ottoman Structure Paint) TOOFTYEX ACTV CABIN-B787-9-CHECK-A0938(JIC) (Upper Capping on Front Row Ottoman Extensive Inspection) TOOFTYHD ACTV CABIN-B787-9-CHECK-A0939(JIC) (Foot Rest Red Leather on Ottoman (Front and Standard) Replace) TOOFTYKC ACTV CABIN-B787-9-CHECK-A0940(JIC) (Table Strap on BC Seats Replace)



CC-BGE

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

44	T00FTYUE	ACTV	CABIN-B787-9-CHECK-A0942 (JIC) (B787-9 C-Check / Seat Belt on BC Seats Replace)	
45	T00FTYUP	ACTV	CABIN-B787-9-CHECK-A0943(JIC) (Inlay cocktail table on BC Seats)	
46	T00FTYUJ	ACTV	CABIN-B787-9-CHECK-A0944(JIC) (Sourround cocktail table on BC Seats)	
47	T00FTYUX	ACTV	CABIN-B787-9-CHECK-A0945 (JIC) (B787-8 C-Check / Armcap Side arm on BC Seats Replace)	
48	T00FTYUL	ACTV	CABIN-B787-9-CHECK-A0946(JIC) (B787-9 C-Check / Dress cover on BC Seats Replace)	
49	T00FTYV5	ACTV	CABIN-B787-9-CHECK-A0950(JIC) (Replace NTF in Lavatory)	
50	T00FTYUR	ACTV	CABIN-B787-9-CHECK-A0960 (JIC) (Replace Dress cover on Attendant Seats)	
51	T00FTYUV	ACTV	CABIN-B787-9-CHECK-A0962(JIC) (B787-9 C-CHECK / REPLACE DRESS COVERS ECONOMY CLASS)	
52	T00FTYVC	ACTV	CABIN-B787-9-CHECK-A0963(JIC) (B787-9 C-Check / Check the Literature Pocket springs on EC Seats)	
53	T00FTXC3	ACTV	CABIN-B787-9-CHECK-A0964 (JIC) (Kickstrip on EC Cabin Inspection)	
54	T00FTYVH	ACTV	CABIN-B787-9-CHECK-A0965(JIC) (B787-9 C-Check / Replace the Literature Pocket on EC Cabin)	
55	T00FTXBD	ACTV	CABIN-B787-9-CHECK-A0966 (JIC) (B787-9 C-Check / Check the Latch Table on EC Seats)	



CC-BGE

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

56	T00FTYAA	ACTV	CABIN-B787-9-CHECK-A0967 (JIC) (EC Seats Cup holder Installation)	
57	T00FTY44	ACTV	CABIN-B787-9-CHECK-A0968 (JIC) (Lavatory Door Seal Replacement)	
58	T00FTXBT	ACTV	CABIN-B787-9-CHECK-A0947(REQ) (Overhead stowage bins interior Clean)	
59	T00FTXB4	ACTV	CABIN-B787-9-CHECK-A0948(REQ) (Overhead stowage bins doors laminated)	
60	T00FTYUY	ACTV	CABIN-B787-9-CHECK-A0951(REQ) (REPLACE NTF IN GALLEY FWD)	
61	T00FTYU9	ACTV	CABIN-B787-9-CHECK-A0952(REQ) (REPLACE NTF IN ENTRY MID)	
62	T00FTYUZ	ACTV	CABIN-B787-9-CHECK-A0953(REQ) (REPLACE NTF IN GALLEY AFT)	
63	T00FTYV2	ACTV	CABIN-B787-9-CHECK-A0961 (REQ) (B787-9 C-Check / CURTAIN IN GALLEY AFT AND FWD)	
64	T00M2G54	ACTV	MD-B787-11-B6327 (JIC) (INSTALLATION OF DECAL FOR CAUTION ON HANDLING)	INSP
65	T00ECDLB	ACTV	RP-B787-11-A7955(REQ) (PERFORM INSPECCION OF DENT AND REPAIR CHART UP DATE 787 FLEET)	INSP
66	T00JU5U4	ACTV	SI-B787-53-B4092(REQ) (REPETITIVE INSPECTION OF TEMPORARY REPAIR - AFT CARGO COMPARTMENT FWD ENDWALL PANELS 152AZ WITH DAMAGE)	
67	T00J9GM9	ACTV	SI-B787-57-B3593(REQ) (VISUAL INSPECTION - TIE ROD THREADED END)	
·		·		·



CC-BGE

USE THE REGION BELOW FOR HARDCOPY CERTIFICATION (NOT e-SIGN)

68	T00M2QEB	ACTV	OPEN-B787 ZONA100 (Master Panel Card B787 ZONA 100)		
69	T00M2QEC	ACTV	CLOSE-B787 ZONA100 (Master Panel Card B787 ZONA 100)		
70	T00M2QED	ACTV	OPEN-B787 ZONA400 (Master Panel Card B787 ZONA 400)		
70	TOOMZQLD	AOTV	Of EN-Brof Zona-Go (Master Failer Gard Brof Zona 400)		
71	T00M2QEE	ACTV	CLOSE-B787 ZONA400 (Master Panel Card B787 ZONA 400)		

Release Remarks		

SIGNATURE					
The signer below certifies that the Work Package has been completed.					
Skill Signed by Signature					

Ne - Task that cannot be electronic signed

Me - Task that requires recording measurements, tolerence or values

NA - Task that has a step N/A added by

INSP - Task considered RII