

Apex Talos VirtualLoop Quick Start Guide

1

Power with 12-24VDC or PoE

Open the displayed IP address in a browser window and login

Username •	user
Password •	V1rtualL00p!

2

Setup BIUs and Detectors, plugin the SDLC port

The controller BIUs serviced by this device:

☒ BIU 1 (#9) ☐ BIU 2 (#10) ☐ BIU 3 (#11) ☐ BIU 4 (#12)

3

Generate and deploy camera scripting

Scripts are pasted into the camera Alarm Task Editor

```
//// Alarm task script for camera [nw corner]
HttpCommand rule2deton := { Command("api/set/detector?
token=cfb93586fdd74433&detector=2&active=true")IP("192.168.1
h(false)Method(GET) };
```

Have questions or need help?

Scan the QR code to access the User's Guide PDF or email support@apextalos.tech

Apex Talos LLC • VirtualLoop Quick Start Guide v2

