

2.17 RC522

RC522 RFID

Overview

In this lesson, you will learn how to apply the RC522 RFID Reader Module on ESP32. This module uses the Serial Peripheral Interface (SPI) bus to communicate with controllers such as Arduino, Raspberry Pi, beagle board, etc.

Component Required:

- (1) x Elegoo ESP32
- (1) x RC522 RFID module
- (2) x 400 Tie Points Breadboard
- (7) x M-M wires (Male to Male DuPont wires)!

Component Introduction

RC522

The MFRC522 is a highly integrated reader/writer for contactless communication at 13.56 MHz. The MFRC522 reader supports ISO 14443A / MIFARE® mode.


The MFRC522's internal transmitter part is able to drive a reader/writer antenna designed to communicate with ISO/IEC 14443A/MIFARE® cards and transponders without additional active circuitry. The receiver part provides a robust and efficient implementation of a demodulation and decoding circuitry for signals from ISO/IEC 14443A/MIFARE® compatible cards and transponders. The digital part handles the complete ISO/IEC 14443A framing and error detection (Parity & CRC). The MFRC522 supports MIFARE® Classic (e.g. MIFARE® Standard) products. The MFRC522 supports contactless communication using MIFARE® higher transfer speeds up to 848 kbit/s in both directions.

Various host interfaces are implemented:


- SPI interface
- Serial UART (similar to RS232 with voltage levels according pad voltage supply)
- I2C interface.

The figure below shows a typical circuit diagram, using a complementary antenna connection to the MFRC522.

Connection Schematic



Wiring diagram



Code

You can click the blue text link to download the program file to your local device, and double-click the file to open it after the download is complete. Please note: Before opening the file, ensure that you have installed the Arduino IDE development environment and completed the installation of relevant components such as the board support package and driver corresponding to the ESP32 development board. If you have any questions about this operation process, you can refer to the "part 1" chapter of the document for detailed guidance

[DOWNLOAD mf-rc522_rfid.zip](#)

Before you can run this, make sure that you have installed the < rfid > library or re-install it, if necessary. Otherwise, your code won't work.

* Typical pin layout used:

	MFRC522	Arduino	ESP32	Arduino	Arduino	Arduino
	Reader/PCD	Uno		Nano v3	Leonardo/Micro	Pro Micro
* Signal	Pin	Pin	Pin	Pin	Pin	Pin
* RST/Reset	RST	9	5	D9	RESET/ICSP-5	RST
* SPI SS	SDA(SS)	10	21	D10	10	10
* SPI MOSI	MOSI	11 / ICSP-4	23	D11	ICSP-4	16
* SPI MISO	MISO	12 / ICSP-1	19	D12	ICSP-1	14
* SPI SCK	SCK	13 / ICSP-3	18	D13	ICSP-3	15
*/						

The locations of SPI pins vary with different chips, and you have to make a minor modification of the function.

[Back to Elegoo](#)

```
#include <SPI.h>
#include <MFRC522.h>

#define RST_PIN 5 // Configurable, see typical pin layout above
#define SS_PIN 21 // Configurable, see typical pin layout above

MFRC522 mfrc522(SS_PIN, RST_PIN); // Create MFRC522 instance

/* Set your new UID here! */
#define NEW_UID

MFRC522::MIFARE_Key key;
```

Library and Hardware Configuration:

- `#include <SPI.h>` : Includes the SPI (Serial Peripheral Interface) library for communication
- `#include <MFRC522.h>` : Includes the MFRC522 library for RFID reader operations
- `#define RST_PIN 5` : Defines the reset pin (GPIO 5) for the MFRC522 module
- `#define SS_PIN 21` : Defines the SPI slave select pin (GPIO 21) for the MFRC522 module
- `MFRC522 mfrc522(SS_PIN, RST_PIN)` : Creates an instance of the MFRC522 class with specified pins
- `#define NEW_UID {0xDE, 0xAD, 0xBE, 0xEF}` : Defines the new UID to be written to the card (4 bytes)
- `MFRC522::MIFARE_Key key` : Declares a MIFARE key object for authentication

RFID Technology Overview:

- **MIFARE Classic**: A type of RFID card that uses ISO/IEC 14443 A standard
- **UID**: Unique Identifier, a 4–7 byte number that uniquely identifies an RFID card
- **MFRC522**: A low-cost RFID reader/writer module that supports SPI communication

SPI Communication:

The MFRC522 module uses SPI (Serial Peripheral Interface) communication protocol, which requires four wires:

- **SCK** (Serial Clock): Generated by the master device (ESP32)
- **MOSI** (Master Out Slave In): Data sent from ESP32 to MFRC522
- **MISO** (Master In Slave Out): Data sent from MFRC522 to ESP32
- **SS** (Slave Select): Used to select the MFRC522 module for communication

```
void setup() {
  Serial.begin(9600); // Initialize serial communications with the PC
  while (!Serial); // Do nothing if no serial port is opened (added for Arduinos based on ATMEGA32U4)
  SPI.begin(); // Init SPI bus
  mfrc522.PCD_Init(); // Init MFRC522 card
  Serial.println(F("Warning: this example overwrites the UID of your UID changeable card, use with care!"));

  // Prepare key - all keys are set to FFFFFFFFh at chip delivery from the factory.
  for (byte i = 0; i < 6; i++) {
    key.keyByte[i] = 0xFF;
  }
}
```

setup() Function: Initializes the system and configures the MFRC522 reader.

- `Serial.begin(9600)` : Initializes serial communication at 9600 baud rate for data output
- `while (!Serial)` : Waits for the serial port to be opened (useful for boards with native USB)
- `SPI.begin()` : Initializes the SPI bus for communication with the MFRC522 module
- `mfrc522.PCD_Init()` : Initializes the MFRC522 reader module
- `Serial.println(F(...))` : Prints a warning message about UID modification
- **Key Preparation**: Sets up the default factory key (0xFFFFFFFF) for MIFARE Classic cards

MIFARE Classic Keys:

- MIFARE Classic cards use 6–byte keys for authentication
- Factory default key is 0xFFFFFFFF for all sectors

- Keys are used to access and modify card data

[Back to Elegoo](#)

loop() Function Overview: The main loop that continuously checks for RFID cards, displays their UID, and writes a new UID if possible.

1. Card Detection Module:

```
// Look for new cards, and select one if present
if (! mfrc522.PICC_IsNewCardPresent() || ! mfrc522.PICC_ReadCardSerial()){
  delay(50);
  return;
}
```

- **Card Detection:** Uses `PICC_IsNewCardPresent()` to detect if a new card is in range
- **Card Selection:** Uses `PICC_ReadCardSerial()` to select the card and read its UID
- **Delay:** If no card is detected, waits 50ms before checking again

2. UID Display Module:

```
// Dump UID
Serial.print(F("Card UID:"));
for (byte i = 0; i < mfrc522.uid.size; i++){
  Serial.print(mfrc522.uid.uidByte[i] < 0x10 ? " 0" : " ");
  Serial.print(mfrc522.uid.uidByte[i], HEX);
}
Serial.println();
```

- **UID Printing:** Displays the current UID of the detected card
- **Formatting:** Ensures single-digit hex values are prefixed with a 0 for consistent formatting
- **HEX Output:** Prints UID bytes in hexadecimal format

3. UID Modification Module:

```
// Set new UID
byte newUid[] = NEW_UID;
if ( mfrc522.MIFARE_SetUid(newUid, (byte)4, true)){
  Serial.println(F("Wrote new UID to card."));
}
```

- **New UID Assignment:** Creates a byte array with the new UID from the `NEW_UID` definition
- **UID Writing:** Uses `MIFARE_SetUid()` to write the new UID to the card
 - Parameters: new UID array, UID size (4 bytes), force write flag
- **Success Check:** Verifies if the UID write operation was successful

4. Card Re-selection Module:

```
// Halt PICC and re-select it so DumpToSerial doesn't get confused
mfrc522.PICC_HaltA();
if ( ! mfrc522.PICC_IsNewCardPresent() || ! mfrc522.PICC_ReadCardSerial()){
  return;
}
```

- **Card Halt:** Uses `PICC_HaltA()` to halt the current card communication
- **Re-selection:** Re-detects and re-selects the card to ensure proper communication
- **Error Handling:** Returns early if card re-selection fails

5. New UID Verification Module:

```
// Dump the new memory contents
Serial.println(F("New UID and contents:"));
mfrc522.PICC_DumpToSerial(&(mfrc522.uid));

delay(2000);
```

- **Memory Dump:** Uses `PICC_DumpToSerial()` to display the updated card information
- **Verification:** Shows the new UID and other card data to confirm the change
- **Delay:** Waits 2000ms before the next iteration to prevent rapid card reading

[Back to Elegoo](#)

Serial Monitor Output:

- Initial message: "Warning: this example overwrites the UID of your UID changeable card, use with care!"
- When card is detected: "Card UID: XXXXXXXX"
- After UID change: "Wrote new UID to card."
- New card information: "New UID and contents:" followed by the updated UID and card data

```
Card UID: 31 1A CE 05
Card did not respond to 0x40 after HALT command. Are you sure it is a UID changeable one?
Error name: Timeout in communication.
Activating the UID backdoor failed.
New UID and contents:
Card UID: 31 1A CE 05
Card SAK: 08
PICC type: MIFARE 1KB
Sector Block  0  1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 AccessBits
15      63  00 00 00 00 00 00 FF 07 80 69 FF FF FF FF FF FF [ 0 0 1 ]
      62  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      61  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      60  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
14      59  00 00 00 00 00 00 FF 07 80 69 FF FF FF FF FF FF [ 0 0 1 ]
      58  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      57  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      56  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
13      55  00 00 00 00 00 00 FF 07 80 69 FF FF FF FF FF FF [ 0 0 1 ]
      54  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      53  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      52  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
12      51  00 00 00 00 00 00 FF 07 80 69 FF FF FF FF FF FF [ 0 0 1 ]
      50  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      49  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 [ 0 0 0 ]
      48  MIFARE_Read() failed: Timeout in communication.
11      47  PCD_Authenticate() failed: Timeout in communication.
```

UID Changeable Cards:

- Not all MIFARE cards can have their UID changed
- Special "UID changeable" or "magic" cards are required
- These cards have a writable UID sector that allows modification

Limitations:

- Works only with MIFARE Classic cards (Mini, 1K, 4K)
- Requires UID changeable cards
- The MFRC522 library has limited support for other RFID card types

Applications:

- Access control systems
- Inventory management
- Asset tracking
- Payment systems
- Identification and authentication