

TABLET + ARCADE STICK STATION

Youth-Center Setup Guide for Free-Play Web Terminals

Power • Kiosk Boot • BSP-Y02 Wake • Daily Routine

Prepared for Coin Op 4 Charity / Arcade Angels

Simple station setup so staff can open the room and kids can play—without obscure button combos

1. Why This Matters

Excellence in STEM does not start in a vacuum. It grows when young people meet real tools, real problems, and real chances to try something interesting with their hands and minds. A working arcade station in a youth center is not only recreation. It is a small, visible system: power, a screen, a controller, a network page, and rules that make the whole thing reliable for the next person in line.

When the setup is simple enough for staff and engaging enough for kids, the room teaches more than high scores. It shows that technology can be shared, maintained, and improved in community space—not only consumed alone on a phone. This guide is written so a volunteer can stand the station up, power it on each day, and keep the focus on play and curiosity rather than troubleshooting.

2. What You Are Building

A free-play station made of three parts:

- A tablet (for example a Samsung Galaxy Tab) that opens the Coin Op 4 Charity terminal in kiosk mode.
- A BSP-Y02 or similar HID arcade stick for real joystick play.
- Wall power for the tablet (and ideally a second USB charger for the stick).

Kiosk page used on the live site: <https://coinop4charity.org/?kiosk=1> — games first, less admin chrome.

3. Safety & Placement

- Use wall outlets and proper USB chargers only. Do not open the stick or tablet to “hard-wire” power.
- Keep drinks away from the stick and tablet. Wipe the controls regularly for hygiene.
- Secure the tablet so it cannot walk away (stand, cable lock, or fixed shelf). The stick clamp is too narrow for many tablets—mount the tablet separately.
- Manage cables so they are not a trip hazard. A single power strip for the station keeps morning startup simple.

4. Arcade Stick Power (No Obscure Combos)

The BSP-Y02 is battery-powered. Daily use should not require holding special mode combinations. Those combos are mainly for **first-time pairing** (Android HID mode). After the stick is paired once, staff only need to wake or charge it.

Recommended youth-center pattern

- Keep the stick on a USB-C wall charger overnight or during the day when possible (full charge often lasts about 10–15 hours of use).
- If the stick sleeps after several minutes of no input, press **HOME** once to wake it and reconnect.
- Optional: run the stick in wired USB mode to a powered hub or OTG-capable tablet for fewer Bluetooth surprises.
- Do not modify the internal battery for permanent “always on.” That is a safety risk and not appropriate for public youth spaces.

First-time only: pair the stick to the tablet in standard Android / HID mode per the unit's manual, then reload the browser page. After that, daily operation is charge + HOME wake.

5. Tablet Boots Straight Into Kiosk

Goal: when the tablet powers on (or recovers from a power blip), it opens the free-play terminal without staff hunting through apps.

Best option — kiosk browser (Fully Kiosk or similar)

- Install Fully Kiosk Browser (or FreeKiosk on newer Android if preferred).
- Set the start URL to: <https://coinop4charity.org/?kiosk=1>
- Turn on Launch on boot / Autostart.
- Enable kiosk / lockdown mode with a staff PIN to exit.
- Keep the screen on while charging; set orientation to landscape if the stand is fixed.
- When prompted, set the kiosk app as the Home app.
- Plug the tablet into continuous wall power and test a full reboot.

Lighter option — older tablets / minimal install

- Open the kiosk URL in Chrome → Add to Home screen.
- Use only that icon for play.
- Optional: Android screen pinning so kids cannot leave the browser easily.
- Display sleep: long timeout or never while plugged in.

Screen pinning is weaker than a real kiosk app after reboot, but it works for supervised rooms.

6. Daily Staff Routine

Morning (or start of program):

- Power strip ON (tablet charger + stick charger).
- Wait for the tablet to boot into the kiosk page.
- Press HOME once on the arcade stick.
- Confirm a game can start with the stick (A / Start).

Closing:

- Leave both devices on charge if the room is secure, or power the strip off after a full stick charge.
- Note any problems on a simple log (no connect, dim screen, sticky button) for the next volunteer.

7. Staff Card (Copy for the Table)

- Play is free.
- Tablet should show the Coin Op 4 Charity games page.
- Stick: press HOME once if it does not respond.
- A or Start = play • Select = back • Hold Start = exit a game.
- If the page is wrong, ask staff (PIN / kiosk exit is for adults only).

8. Setup Checklist Before First Public Use

- Tablet charges from the wall and stays on when plugged in.
- Kiosk URL opens on boot (or pinned home icon is the only play path).
- Stick paired once in Android HID mode; page reloaded after pairing.
- HOME wakes the stick; A starts a game; Select or hold Start exits.
- B does not quit games by accident.
- Tablet is secured; cables are tidy; room staff have the exit PIN if using a kiosk app.
- One-page staff card is on the table.

9. Notes for Host Sites

This station is a low-cost free-play complement to full arcade cabinets. It is meant to be interesting, shareable, and maintainable—not a locked tournament machine. When power and wake steps stay this short, staff can protect program time for young people instead of fighting devices.

Contact Coin Op 4 Charity / Arcade Angels for placement support, spare sticks, or updates to the terminal software. Related detail: [BSP-Y02_Web_Arcade_Controller_Guide.pdf](#) in the same docs set.

10. Document Control

Guide type: DIY youth-center station • Hardware: tablet + BSP-Y02-class HID stick • Software: coinop4charity.org/?kiosk=1 • Audience: site staff and volunteers • Companion to restoration and controller guides under [docs/restoration/](#).