

## COIN OP 4 CHARITY / ARCADE ANGELS

## CATCHER VOICE★c-ute 2

## Japanese Small-Prize Claw Catcher

## Staff Restoration, Free-Play Operation &amp; Error Reset Guide

Fleet No. 021 • Placement: Boys &amp; Girls Clubs of Southern NV — James Club • Status: Free play • Rev. 1.0 • 31 August 2026

*Prepared for host-site staff and restoration volunteers. Keep a printed copy with the machine keys.***1 Overview & Purpose**

This cabinet is a Yuai (Yuuai Hanbai) CATCHER VOICE★c-ute 2 — a compact Japanese two-button claw / prize catcher used for small prizes, capsules, and 3D-printed STEM pieces. Coin Op 4 Charity placed it as fleet unit 021 for free play at a Nevada youth site. Kids play at no charge. The Japanese 100-yen coin mechanism is still installed but is not collecting money.

This sheet is the on-site staff guide: how to power the machine, load credits, free a stuck claw, clear error codes (especially Error 21), handle keys, and who to call if the site ever wants U.S. coin operation.

**2 Machine Identity (what you are looking at)**

Cabinet as received — prize chute open for service.

|                        |                                                       |
|------------------------|-------------------------------------------------------|
| <b>Marquee:</b>        | CATCHER VOICE★c-ute 2                                 |
| <b>Maker / line:</b>   | Yuai (Yuuai Hanbai) compact prize catcher             |
| <b>Fleet ID:</b>       | 021 — Claw Machine (Voice 2Cute)                      |
| <b>Controls:</b>       | Two player buttons: blue (left) and white (right)     |
| <b>Prize door:</b>     | Lower-left chute marked toridashiguchi (prize outlet) |
| <b>Service access:</b> | Front lower lock beside the coin mechanism            |
| <b>Power cutoff:</b>   | Rocker / toggle switch behind that lower lock         |
| <b>Credit mode:</b>    | FREE PLAY — operator can load up to 99 credits        |
| <b>Coin mech:</b>      | Original Japanese (yen) mechanism still in cabinet    |
| <b>Intended use:</b>   | Youth-center free play / STEM prize activity          |

**3 Safety**

- Unplug the cabinet or use the internal power switch before reaching into the claw well, prize chute, or coin door.
- The claw carriage can move without warning when credits are loaded. Keep hands clear of the travel path.
- Do not yank the claw sideways or twist the cables. If it hangs, use the light downward pull described in Section 6.
- The front glass and prize door are not a step or a seat. Keep the cabinet level and the casters locked if equipped.
- This unit is set for free play. Do not accept money in the Japanese coin slot. It will not vend change in U.S. currency.

## 4 Keys — photograph them and keep a backup on site

Every host site must treat the keys as part of the machine. If keys walk off, staff are forced to kill power at the wall outlet, which is harder on the board and leaves the cabinet unlocked-looking.

- Photograph both sides of every key on day one. Include the stamped key number in the frame (the number is usually on the bow of the key).
- Print one set of photos and tape it inside a staff binder or the site's machine folder. Keep a second digital copy (shared staff drive or printed packet).
- Keep one working key ring on site, labeled "Voice Cute 2 / Fleet 021," stored with other Coin Op 4 Charity cabinet keys — not on a personal keychain.
- Do not leave keys in the lock during public hours. Unlock, do the work, relock.
- If a key is lost, contact Coin Op 4 Charity before drilling or swapping locks. We can cut a duplicate from the photographed number in most cases.

## 5 How to power on and load credits (up to 99)

Daily start-up does not require pulling the wall plug. Use the keyed front and the operator panel.

- 1 Confirm the cabinet is plugged into a grounded outlet and the prize chute door is fully closed and latched. An open chute is a common reason the machine throws a sensor error.
- 2 Unlock the front using the site key. The service door is the lower front panel next to the coin mechanism.
- 3 If the cabinet was powered down at the internal switch, turn that switch ON (the rocker / toggle directly behind the lower lock, by the coin mech).
- 4 On the operator / service panel just inside the front, press the top two service buttons to add credits. Each press adds play credits. You can load up to 99 credits for a free-play session or event.
- 5 Close and lock the front door. Confirm the attract lights / sound come up and the claw homes to the rest position.
- 6 If the site is closing, burn off remaining credits with a test grab or power the cabinet down at the internal switch — do not yank the cord.

### About the two upper service buttons

Yuai operator panels typically put Service (saabisu) and Test / Set (tesuto / settei) as the two upper buttons inside the front door. On this cabinet those two upper buttons are what staff use to add credits for free play. Button silkscreen on imported boards can be worn or in Japanese only — if the labels are unreadable, the two buttons at the top of the inner service cluster are the ones that load credits. Do not hold them through a full menu dive unless you intend to change settings. A short press is enough to add credits. Maximum load is 99.

## 6 If the claw gets stuck

Japanese compact catchers will hang if a prize wedges in the ring, if the carriage loses a limit, or if a player lets go mid-travel. Do this before calling for service:

- Open the upper playfield door only if you have the key and the cabinet is not mid-cycle. If it is mid-cycle, wait for the claw to finish or kill power at the internal switch first.
- Take the claw body in one hand and pull it straight downward — lightly. Do not yank, twist, or swing it toward the glass. A light downward pull usually frees a wrapped prize or a carriage that stopped short of home.
- Clear any prize, bag, or tag that is binding the ring or the drop chute. Keep the floor of the well reasonably clear so the home / prize sensors can see.
- Close every door. Power-cycle using the internal switch (Section 7) if the display shows an error or the claw does not return home.
- If the claw still will not home after one gentle pull and one 30-second reset, stop. Do not force the rails. Contact Coin Op 4 Charity.

## 7 Error codes — the 30-second internal reset

The single most useful staff skill on this cabinet: do not unplug it from the wall first. Use the keyed lower front and the switch behind it.

- Unlock the lower front lock beside the coin mechanism.
- Find the power switch directly behind that lock (same pocket as the coin mech).
- Turn the switch OFF. Leave it off for a full 30 seconds. This lets the board, sensors, and claw home logic drop and clear.
- Confirm the prize chute door is shut and there is at least a visible prize / object path that will not look like an empty well to the drop sensor, if the well is supposed to have product.
- Turn the switch ON. Wait for the claw to home. Reload credits with the top two service buttons if needed.
- Relock the front. Watch one full test grab before walking away.

### ERROR CODE 21 — usually a sensor, not a dead board

Error 21 on this cabinet is almost always a sensor condition, not a failed motor. The two most common causes on unit 021 are: (1) the prize well is empty — no toys / prizes for the drop or presence sensor to see, or (2) a door is left open (prize chute, playfield glass, or lower service door). Close every door, put at least a few prizes back in the well if it is meant to be stocked, then run the 30-second internal power reset above. Do not keep cycling the wall outlet. If Error 21 returns after a closed-door reset with prizes in the well, call Coin Op 4 Charity — the drop / home sensor may need cleaning or alignment.

## 8 Free play now — U.S. coin mech later

This machine is currently a free-play cabinet. Credits are added by staff from the service panel. The original Japanese yen coin mechanism is still in the door so the cabinet looks complete, but it is not set up to take U.S. coins or bills.

- Youth-center and charity placements stay on free play. That is the intended mode for fleet 021.
- If a host later wants commercial or paid play (U.S. quarters, bills, or a card reader), do not jury-rig the yen mech. Call Coin Op 4 Charity. We will swap the coin mechanism for a U.S.-currency unit and set pricing.
- Until that swap is done, put a small staff note on the coin door: “FREE PLAY — do not insert money.”
- Do not change DIP switches or operator pricing menus unless a restorer has walked you through it. Wrong settings are how Error 21 and “no credit” calls start.

## 9 Daily / weekly staff checklist

| Check              | What good looks like                                                           |
|--------------------|--------------------------------------------------------------------------------|
| Doors closed       | Prize chute, glass, and lower service door fully latched before public hours.  |
| Prizes in the well | Do not leave the catch area empty; empty well is a common Error 21.            |
| Claw at home       | Carriage resting in the ready position, cables not wrapped.                    |
| Credits loaded     | Top two inner service buttons; cap is 99 credits.                              |
| Test grab          | One staff grab after power-up, especially after any error reset.               |
| Keys accounted     | Photographed numbers on file; working ring locked away, not in the door.       |
| Glass & buttons    | Wipe fingerprints off the glass and the blue / white player buttons.           |
| No cash in slot    | Yen mech is not a U.S. coin acceptor. Return any inserted coins to the player. |

## 10 Who to call

Coin Op 4 Charity / Arcade Angels — coinop4charity.org • GitHub: github.com/arcadeangel/coinop4charity. Use the site contact form or open a GitHub issue and name fleet 021 / Voice Cute 2.

Call before any coin-mech swap, lock change, or if Error 21 survives a closed-door 30-second reset with prizes in the well.

Document version 1.0 • 31 August 2026 • Fleet 021 • Educational & nonprofit use.