

using your Treo™

Includes setup information and instructions for most tasks

Copyright

Copyright © 2004 palmOne, Inc. All rights reserved. palmOne, Treo, the palmOne and Treo logos, and Blazer are among the trademarks or registered trademarks owned by or exclusively licensed to palmOne, Inc. or its subsidiaries. Palm, Palm OS, HotSync, and the Palm Powered logo are trademarks or registered trademarks licensed to palmOne, Inc.. This product contains ACCESS Co., Ltd.'s NetFront 3.0 Internet browser software. © 1996-2004 ACCESS Co., Ltd. and ACCESS Systems America, Inc. NetFront is the trademark or registered trademark of ACCESS Co., Ltd. in Japan and in other countries except the United States of America. NetFront is a registered trademark of NetFront Communications, Inc. in the United States of America and is used under a license. All other brand and product names are or may be trademarks of, and are used to identify products or services of, their respective owners.

Disclaimer and limitation of liability

palmOne, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this guide. palmOne, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. palmOne, Inc. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of all important data on other media to protect against data loss.

Software download available

Palm™ Desktop software is supplied on a CD-ROM disc. If you do not have access to a CD-ROM drive for your computer, you can download this software from www.palmOne.com.

406-10042-00

Contents

3 Contents
5 Welcome
6 If you read nothing else...

7 **read this now: getting started**
8 What you'll need
9 Treo overview
12 Charging the battery
13 Inserting the SIM card
14 Turning Treo on and off
15 Making your first call

17 **first day: learning the basics**
18 Moving around the Treo screen
22 Using the keyboard
25 Launching applications
27 Setting up your computer
30 Synchronizing contacts and other personal data
31 Battery life
32 Where to learn more

33 **first week: using phone, web, and messaging**
34 Phone overview
36 Dialing calls
39 Receiving calls
40 Using voicemail
42 Managing active calls
43 More ways to manage calls
47 Managing contacts
49 Defining Favorites buttons
52 Using a phone headset
53 Browsing the web
60 Taking pictures with the camera
64 SMS
69 MMS
73 Sending and receiving messages with Mail

81 **first two weeks: using organizer features**
82 Calendar
87 To Do List
90 Memo Pad
91 CityTime
93 Calculator
95 Looking up contacts and other information
97 Beaming information

99 **first month: managing applications**
100 Installing applications
103 Removing applications
104 Using Application Info
105 Using expansion cards

109 when you're ready: customizing your Treo
110 Phone settings
113 System Sound settings
114 Display and appearance
116 Applications Launcher settings
117 Button settings
118 Date and time settings
120 General Preferences
121 Locking your phone and data

127 if something happens: help
128 Upgrading from another Palm Powered device
130 Trouble installing Palm Desktop?
131 Resetting your Treo
133 Screen
134 Network connection
137 Synchronization (HotSync)
140 Mail
143 Web
144 Camera
145 Third-party applications
146 Errors
147 Making room on your Treo
148 Voice quality

150 glossary
152 FCC
153 Index
160 Specifications

Welcome





LOOK HERE: Don't miss the helpful tips and cross-references given in this column.

Congratulations on the purchase of your Treo™ phone. You now have

- an advanced mobile phone*
- a Palm Powered™ organizer with portable expansion capability (SD media)
- a digital camera
- email*
- web browsing*
- SMS*
- MMS**

all in one compact and indispensable device.

* Requires service contract with your mobile service provider
**MMS requires MMS services running on GPRS

This guide will help you set up your Treo and quickly learn to use it.

If you read nothing else...

This guide is designed to get you using your Treo quickly, starting with just the basics. As you become more comfortable with your Treo and want to learn more, come back and read the other sections.

Read this Now: Getting Started

Follow the instructions on pages 7-16 to set up your Treo and make your first call.

First Day: Learning the Basics

Read through pages 17-32 to learn how to enter text, move around the screen and set up synchronization.

First Week: Using Phone, Web and Messaging

Learn how to use all the great wireless features of your Treo on pages 33-80, including phone, email, web browsing, and messaging.

First Two Weeks: Using Organizer Features

Your Treo is not just a phone. It also includes a full-featured Palm Powered organizer that gives you instant access to your Calendar, To Do List, Memo Pad, CityTime, Calculator, and more. See pages 81-98.

First Month: Managing Applications

Explore pages 99-108 to learn how to add or delete extra applications and use an expansion card with your Treo.

When You're Ready: Customizing your Treo

Once you've learned the basics, you'll want to explore additional features on your Treo and customize its settings. See pages 109-126 for information about these features.

If Something Happens: Help

If something goes wrong or you can't figure out how to use a Treo feature, we can help. See pages 127-148 for the answers to frequently asked questions.

read this now: getting started

What you'll need

As you work through the instructions in this guide, you'll need all the items that came in the Treo box (see page 9) as well as the following:

- a SIM card for which you have an activated mobile account with data services*
- a location with wireless coverage for your phone
- an electrical outlet
- the computer with which you will synchronize your personal data
- the CD included in the box

* We recommend choosing the GPRS data service option. You cannot use email, web browsing, or picture messaging without data services of some type.

Treo overview

You should have received all of the following components in the Treo box:

Hardware


- Treo handset
- AC charger
- USB HotSync® cable
- headset
- electrical socket adapter(s) (if required in region)

Documentation and software

- Using Your Treo (this book)
- Synchronization software CD

Treo handset features

The following illustrations show the locations and names of the physical features of the Treo. Refer back to these illustrations while following the instructions in this guide.




A. Antenna
B. Wireless Mode button
C. Infrared (IR) port
D. Ringer switch
E. Stylus
F. Expansion card slot
G. SIM slot


You can purchase a separate serial HotSync cable and other accessories. For more information, visit www.palmOne.com.

Warranty does not cover damage by Secure Digital (SD) cards which do not meet SD Memory Card Specifications. SD cards which do not meet SD Memory Card Specifications may damage Treo 600.


Be careful not to scratch or crush your Treo's touchscreen. Do not store it in a place where other items might damage it.



A. Phone receiver
B. LED (Wireless Mode and charge indicator)
C. Volume buttons
D. Phone
E. Calendar
F. Headset jack
G. HotSync and power supply connector
H. Microphone
I. Messaging
J. Screen on/off button
K. 5-way navigation control



A. SIM slot
B. Camera lens
C. Speaker
D. Reset button
E. Reset tool (within stylus)




IMPORTANT: Treo's speaker includes a large magnet, so be sure not to store your Treo near credit cards or other items that could be demagnetized.

Charging the battery

Battery consumption varies based on your personal usage. Consumption factors include signal strength, backlight and speakerphone usage, and whether calls are data or voice calls.

Before using your Treo, you need to charge the battery. It may not turn on at all when you first remove it from the box. We recommend three hours for a full charge, or until the LED is solid green.

1. Plug the AC charger into a wall outlet. If necessary, connect an adapter.
2. Connect the charger cable to the bottom of the Treo with the word UP facing the same way as your Treo screen.



A. LED


3. To confirm your Treo is charging, check the LED.
   - When the LED is solid red, your Treo is charging.
   - When the LED turns solid green, your Treo is fully charged.
   - If the LED does not turn on when you connect your Treo to the charger, double-check the cable connection and the electrical outlet to which it is connected.

After you turn on your Treo, the onscreen battery gauge displays power status:

- Full battery icon : Battery is charged
- Partial battery icon : Battery has some power and is not charging
- Empty battery icon : Battery needs charging immediately
- Red lightning bolt : Charging
- Green lightning bolt with full battery : Fully charged

Inserting the SIM card

Your Subscriber Identity Module (SIM) card contains account information such as your phone number and voicemail access number. To use the phone, email, or web features of your Treo, you need to insert the SIM card. If a SIM card did not come with your Treo, your mobile service provider will give you one when you subscribe. If you have an older, 5-volt SIM card, you should request a newer, 3-volt SIM. This Treo is not compatible with older 5-volt SIM cards.



A. SIM tray
B. SIM card
C. Notches
D. SIM slot

1. Slide the SIM tray out of the Treo.
2. Insert the SIM card into the SIM tray by aligning the notches until you feel it lock into place.
3. Slide the SIM tray back into the Treo.
4. If your SIM card is not already activated, follow the activation steps provided by your mobile service provider or contact them directly for assistance. If you want to use email, web browsing, and MMS, be sure to confirm that your SIM card is activated for data services.

Your mobile service provider may already have inserted the SIM card into your Treo. In that case, skip to page 14.

To remove the SIM card, pull the SIM tray out of the slot and remove the card from the tray.

Turning Treo on and off

Treo includes a keyboard backlight for nighttime use. The keyboard backlight activates automatically when the screen turns on, but shuts off if the keyboard is not in use. When the screen is on, press Option then the P key to manually activate the keyboard backlight.

You can use the Palm OS features of your Treo independently of the wireless features and applications. Therefore, the screen and Wireless Mode are designed to be turned off and on separately.

Turning the screen on and off

1. Press the Screen button to turn on the screen.
2. Briefly press the Screen button to turn off the screen.

Turning Wireless Mode on and off

Wireless Mode allows your Treo to connect to a mobile network so that you can make and receive phone calls and use other wireless services.

1. Press and hold the Wireless Mode button to turn on Wireless Mode. You will hear a series of ascending tones. When Wireless Mode is on, your Treo connects to a mobile network, and you can use the phone and Internet features (if supported by the local network).
2. Press and hold the Wireless Mode button again to turn off Wireless Mode. You will hear a series of descending tones. When Wireless Mode is off, your Treo does not have a connection to any mobile network. You can still use the organizer and other Palm OS features. This is ideal for airplane flights and for maximizing battery life.

Making your first call

We recommend that you charge your Treo for a full three hours (or until the LED is solid green) before using it for the first time.

1. Press and hold the Wireless Mode button . You will hear a series of ascending tones.
2. If a Welcome screen appears, follow the onscreen instructions to set up your Treo.
3. Allow the Treo to complete a network search. The search may take several seconds. When it is complete, the network status icon appears in the upper right.
4. If prompted for a PIN, enter it on the PIN screen. The default PIN is often 1234. Otherwise, your mobile service provider may have given you some documentation with this information. Contact your mobile service provider for help.
5. Press Phone .
6. Using the number pad on the Treo keyboard, type the desired phone number.
7. Press Center to dial.
8. When your call is complete, use the 5-way navigation control to choose Hang Up.




If No Service appears in the upper left, you are out of a wireless coverage area. If you believe you are in a wireless coverage area and this problem persists, contact your mobile service provider for assistance.

If the Welcome screen does not appear, recalibrate the touchscreen. This ensures that the screen responds accurately to taps (see page 133).

Learn how to quickly redial your most recent calls on page 38.

Adjusting call volume

While a call is in progress, press the volume buttons on the side of your Treo to adjust call volume.



A. Volume buttons

What's my number?

1. Make sure Wireless Mode is on (see page 14).
2. Press Phone .
3. Press Menu (menu).
4. From the Options menu, choose Phone Info (/I). If your phone number is not displayed, exit Phone Info, and make sure your SIM card is properly inserted in the SIM slot. If your phone number still does not appear in Phone Info, consult your mobile service provider.



A. Look here for your phone number


first day: learning the basics

Moving around the Treo screen

To move around the Treo screen, you can use the 5-way navigation control, or tap items on the screen with the stylus. With use, you will find your own favorite way to scroll, highlight, and select menu commands.

The 5-way navigation control includes Right, Left, Up, Down, and Center buttons.






A. Up
B. Down
C. Left
D. Right
E. Center

Scrolling through screens

As on a computer, you scroll on the Treo to move from field to field, or page to page, or in some cases to highlight an item or option in a list. There are several methods of scrolling:

- Press the 5-way navigation control on the front of the Treo. Pressing Right ▶, Left ◀, Up ▲, and Down ▼ moves to the next field, button, or action in that direction.
- Tap an onscreen scroll arrow:



- Press Option and Up ▲ or Down ▼ to scroll to the next page of information within the current record.
- When inside a text field, press Up ▲ and Down ▼ to scroll through the text.
- Drag the slider of an onscreen scroll bar.

Highlighting items

The 5-way navigation control lets you highlight items before launching or selecting them.

- When an onscreen button (OK, Cancel, etc.) or pick list is highlighted, the button acquires a blue glow around its border.



- When a phone number, email address or web link is highlighted on a web page or in a message, the text appears in reverse type (light text on a dark background).
- When an entire text entry field is highlighted, you can press Center to edit the text. After you edit the text, press Center again to highlight the entire field.

Some third-party applications may not work with 5-way navigation, and you must use the stylus instead.

In this guide, we use arrow icons to indicate directions on your Treo's 5-way navigation control. These are different from any onscreen arrows that you tap with your stylus or select with the 5-way control to display pick lists.

5-way buttons: ◀ ▶ ▲ ▼

On screen arrows:



Once you've launched an application (see page 25), you can experiment with using the navigation control to highlight different screen elements.

You can also use the stylus to highlight text on the screen. When text is highlighted it appears in reverse type.

- Drag the stylus across the text you want to highlight.
- Double-tap a word to highlight it.
- Triple-tap a line of text to highlight it.

Accessing command buttons

Command buttons, such as New, OK, and Details appear at the bottom of the screen. In many cases you can jump directly to these buttons instead of scrolling to them.

- From a list screen, such as the Contacts list or Mail inbox, press Right to jump to the first button.
- From a screen where you create or edit entries, such as Edit Contacts or Day View in Calendar, press Center to jump to the first button.
- From a dialog box, such as the Edit Categories, press Right to scroll to the first button, or press Option then Return for OK, or Option then Backspace for Cancel.

Choosing or activating items

After highlighting an item with the 5-way navigation control, you can choose or activate it by pressing Center. You can also choose an item by tapping it with the stylus.

Selecting menu items

Many applications have menus to provide access to additional features. These menus are usually hidden from view, but they appear when you press Menu (menu). To get the most out of your Treo, it's a good idea to familiarize yourself with the additional features available through the various application menus.


1. Press Menu (menu) to display an application's menus.
2. Press Right ▶ and Left ◀ to switch between menus.
3. Press Up ▲ and Down ▼ to highlight a menu item.
4. Press Center to choose the menu item, or press Menu (menu) to close the menu and cancel your selection.



Choosing options in a pick list

A range of options is often presented in a type of menu called a *pick list*, which can be identified by a downward-pointing arrow. Pick lists are different from the application menus described above.


- Use the 5-way navigation control to highlight the pick list, then press Center to display the items in the list. Press Up ▲ and Down ▼ to highlight the item you want, then press Center to accept your selection.
- To exit the pick list and cancel your selection, press Left ◀ or Right ▶.
- Use your stylus to tap the pick list, then tap the item you want from the list.



Most menu commands have keyboard shortcuts listed in the menu. To use a shortcut, press Menu plus the shortcut letter. You don't have to see the menu item to use the shortcut.

Using the keyboard

When using the keyboard, most people find it easiest to hold the Treo with two hands and use the tips of both thumbs to press the keys, as shown above.



A. Option
B. Shift/Find
C. Alt
D. Space
E. Applications Launcher
F. Menu
G. Return
H. Backspace

Using the keyboard backlight

- To turn on the backlight, press Option then P. The backlight may not be visible in bright sunlight.
- The backlight will turn off if the keyboard is not in use.

Entering lowercase and uppercase letters

- To type lowercase letters, press the desired keys.
- To type an uppercase letter, press Shift, then type a letter. You don't need to hold down Shift while typing a letter.
- To turn Caps Lock on, press Shift twice. To turn it off, press Shift again. When Caps Lock is on, this symbol appears in the lower right:

Entering numbers, punctuation, and symbols that appear above the letters on the keys

- Press Option, then press the key with the desired character shown above the letter. You don't need to hold down Option while pressing the second key.
- To turn Option Lock on, press Option twice. To turn it off, press Option again. When Option Lock is on, this symbol appears in the lower right:

Entering other symbols and accented characters

1. Type the character that corresponds to the symbol or accented character you want. See the table on the next page.
2. Press Alt.
3. Press Up or Down to highlight the desired character.
4. Press Center to insert the character, or just continue typing the next character.

In many applications you can view a list of all the alternate characters. From the Edit menu, choose Keyboard Help (/G).

Some application views automatically default to Option Lock, such as the Dial Pad of the Phone application, or the Calculator. In this case, you do not have to hold down Option to enter numbers.


The alternate characters are grouped according to their similarity to the corresponding key. For example, the alternate characters available for the e key are é, è, ë, ê and €.

Symbols and accented characters

Type...	then press Alt to choose...	Type...	then press Alt to choose...	Type...	then press Alt to choose...
a	á à ä â ã å æ	o	ó ò ö ô œ õ ø	0	% ‰ °
A	Á À Ä Â Ã Å Æ	O	Ó Ò Ö Ô Œ Õ Ø	1	¹ ¼ ½
b or B	ß	p or P	% ¶	2	²
c	ç ¢ © ^ ˆ	r or R	®	3	³ ¾
C	Ç ¢ © ^ ˆ	s	ß š § ℵ	.	? ! …
d	† ‡	S	ß Š § ℵ	,	„
D	† ‡ Ð	t or T	~ ™ † ‡	!	¡
e	é è ë ê €	u	ú ù ü û	?	¿
E	É È Ë Ê €	U	Ú Ù Ü Û	:	; :-) :-(;-) :-D
f or F	*f*	x or X	x ¤	'	‘ ’ < > ~ `
i	í ì ï î	y	ý ÿ ¥	"	“ ” « »
I	Í Ì Ï Î	Y	Ý Ÿ ¥	$	€ £ ¥ ¢
l or L	£			+	&
m or M	µ			-	_ ~ • = – —
n	ñ			/	% \ ÷ | ⁄
N	Ñ			#	=
				(	< [{ ‹
				)	>] } ›

Launching applications

Each of the three application buttons on the front of the Treo can be used to launch two applications. To access a button's primary application, simply press the button. To access a button's secondary application, press Option , then press the application button. The fourth button turns the screen on and off, and controls the keyguard.



A. Phone
B. Calendar
C. Messaging
D. Screen

You can also customize the buttons yourself; see page 117 for details.

Your mobile service provider may have customized the applications associated with each button.

Button	Primary application	Secondary application
	Phone	+ Blazer® Web Browser
	Calendar	+ Calculator
	SMS	+ Mail
	Screen (on/off)	+ Keyguard

In Palm OS, you access all available applications through a screen called the Applications Launcher:

1. Press Applications Launcher.
2. Use the 5-way navigation control to highlight the application you want to use.
3. Press Center to launch the selected application.



Press Applications Launcher repeatedly to cycle through different categories of applications.

In the Applications Launcher, you can type the first few letters of the application's name to highlight it. For example, if you type c it highlights Calendar, then if you type i it highlights CityTime. If you pause and then type i, it highlights the first application that starts with i.

Setting up your computer

Synchronization lets you enter information on your computer (using Palm Desktop or Microsoft Outlook for Windows) and then efficiently transfer that information to your Treo. At the same time, changes you make on the Treo are transferred to Palm Desktop or Microsoft Outlook. Even if you manage all your contacts on your Treo, synchronization is a great way to back up your data.

Before you can synchronize, you need to install the Palm Desktop synchronization software on your computer. Even if you already own a Palm Powered device and have installed a previous version, you must install the software that comes on the CD with your Treo.

Windows 98SE, Me, 2000, or XP*

- 32 MB of memory
- 30 MB of free hard disk space
- CD-ROM drive
- available USB port
- USB HotSync cable (included with your Treo)

Windows NT 4

- 32 MB of memory
- 30 MB of free hard disk space
- CD-ROM drive
- available serial port
- serial HotSync cable (sold separately)

Macintosh OS 10.1-10.3.x*

- 32 MB of memory
- 25 MB of free hard disk space
- CD-ROM drive
- USB port
- USB HotSync cable (included with your Treo)

*later versions may also be supported


IMPORTANT: If you're upgrading from another Palm Powered device, follow the upgrade steps on page 128 before you set up your computer for your new Treo.

If you are synchronizing with a computer that is running Windows NT 4, you must use a serial HotSync cable, available for separate purchase at www.palmOne.com.

Connecting your Treo to your computer

1. Plug the AC charger into a wall outlet. If necessary connect an adapter.
2. Connect the charger to the short end of the HotSync cable. Be sure to match the sides of the connectors labeled UP.
3. Plug the USB HotSync cable into an available USB port on your computer.
4. Connect the long end of the HotSync cable to the bottom of your Treo with the button facing up.

For best performance, plug your USB synchronization cable directly into a USB port on your computer. If you use a USB hub, make sure it is a powered hub.



A. USB cable
B. HotSync button

Installing the Palm Desktop synchronization software on your computer

Your computer needs to have all its resources available to install the software. Follow these guidelines for a successful installation:

1. Exit any applications that are currently running on your computer, including those running in the background.
2. Insert the CD that came with your Treo into the CD-ROM drive on your computer. If you are installing on a Macintosh, double-click the CD icon on the desktop, then double-click the Installer icon.
3. Follow the onscreen instructions of the installation program. Click Install Now to install the Palm Desktop software. Please note these important points about the installation process:
   - If a language selection screen appears, click the same language you use on your Treo.
   - During the installation process, you will be prompted to synchronize for the first time.


If you are installing on a computer at work, make sure your company allows you to install new software. Contact your company's IT department for help.

Synchronizing contacts and other personal data

We strongly recommend that you install the Palm Desktop synchronization software soon after you start using your Treo, and that you synchronize your Treo and computer frequently to keep your information up-to-date (and backed up) in both locations.

Before you can synchronize your contacts and other personal data, you must install the Palm Desktop software from the CD that came with your Treo. See page 29 for instructions.

1. Connect your Treo to your computer as described on page 26.
2. Press the HotSync button on the cable.



A. HotSync button

3. Wait for your Treo to display a message indicating that the process is complete.
   - If nothing happens, make sure that you installed the Palm Desktop software and that the HotSync Manager application is running on your computer ( ).
   - If you want to synchronize data with applications other than Palm Desktop or Microsoft Outlook, you need to purchase additional third-party conduit software.
   - If you have any problems performing a HotSync operation, see pages 137-139 for troubleshooting suggestions.

Battery life

Battery life depends on individual usage. When used as a phone, your Treo battery provides approximately 6 hours of talk time or 10 days of standby time. When used as an organizer only (no phone), the battery provides about 10 days of normal use.

Maximizing battery life

You can increase the life of your Treo battery by following a few easy guidelines. Remember that battery life depends on how you use your Treo.

- Charge your Treo whenever you're at your desk. The Li-Ion battery in your Treo has a much longer useful life when it is *topped off* frequently, versus charging it after it is fully drained.
- The wireless features (phone, email, messaging, and web) of your Treo generally consume more power than its organizer features. However, if you spend a lot of time using the camera, games, media players, eBooks, or other Palm OS applications, keep an eye on the battery level and charge when necessary.
- If you don't plan to use the wireless features on your Treo for a while, you may want to turn off Wireless Mode (see page 14). You can forward calls to a different number or let all calls be picked up by voicemail (see page 45).
- As with any mobile phone, if you are in an area with no wireless coverage, your Treo searches for a signal, which consumes power. If you cannot move to an area of better coverage, you may wish to temporarily turn off Wireless Mode.
- Use the keyboard backlight (see page 22) only when you need it.
- Turn down the screen brightness (see page 114).
- Decrease the Auto-off setting in General Preferences (see page 120). This turns off your screen automatically after a shorter period of inactivity.

IMPORTANT: You must charge your Treo fully before using it the first time. Wait until the LED turns solid green which may take up to three hours.

If the battery drains to the point where your Treo doesn't turn on, the Treo stores your data safely for about three days. We recommend that you charge and synchronize your Treo every day, especially if you use your phone often.

If the battery is fully drained, it may take a few moments for the LED to turn on while charging.

Where to learn more

To launch the built-in tutorial:

1. Press Applications Launcher.
2. Choose the pick list in the upper-right, select All.
3. Choose the Tutorial icon.
4. Follow the onscreen instructions in the Tutorial.

A quick introduction to your new Treo

- Tutorial: The Tutorial teaches you how to use many features of your Treo. It is already installed on your Treo and you can launch it any time.

While using your Treo

- Tips: Many of the built-in applications include helpful tips for getting the most out of your Treo. To view these tips, launch an application, press Menu (menu), then from the Options menu, choose Tips.
- Information: Many screens have an Information icon in the upper-right corner. Tap the Information icon with your stylus to learn about the tasks you can perform in that dialog.
- Online support from palmOne: For up-to-date downloads, troubleshooting and support information, check out www.palmOne.com/support/treo600.

If you need more information

- Books: Many books on Palm Powered devices are available in local or online book retailers (look in the computers section).
- Online forums: Consult online Treo user discussion groups to swap information and learn about areas you may find nowhere else.
- Customer service from your mobile service provider: For questions about your mobile account or features available on the network, contact your mobile service provider for the latest information and help.

first week:


using phone, web, and messaging

Phone overview

The Phone application lets you make and receive calls, store information about your contacts, and store Favorites for contacting people and launching applications. Be sure you know how to turn on Wireless Mode before reading this section (see page 14).

Accessing the Phone application

- Press Phone .



You can monitor the status of several items, using icons at the top of the Phone screen:

Network name	Displays the name of a mobile service provider when Wireless Mode is on and you are in a coverage area. If you are outside a coverage area, No service or SOS Only appears instead.
	Appears when call forwarding is active.
	Appears when you have voicemail. Some networks use a full-screen alert instead. Call your mobile service provider for more information.
1 2	Appears when ALS, Alternate Line Service, is active. This feature may not be available on all accounts or regional networks. Contact your mobile service provider for more information.
	Appears when Wireless Mode is on. The bars display the signal strength. The stronger the signal, the more bars appear. If you are outside a coverage area, no bars appear.
	The triangle appears when Wireless Mode is on and a GPRS network is within range. Some service providers do not show the triangle.
	Appears when you are connected to a GPRS network and a data session is active (for example, when you are browsing the web). You can still receive calls.
	Displays the battery charge status. As the battery drains, the icon changes from blue to clear, and then to red when it's time to recharge.
	Appears when your Treo battery is charging.
	Appears when your Treo battery is fully charged.

To display details about your battery power, tap the battery icons at the top of the screen.

If ALS is active and available, you can press and hold # to switch lines.

Dialing calls

To see more information for a person in your Contacts list, highlight the name and press Center to view their address, company and other details.

You can begin a Name Lookup immediately from the Main view in the Phone application. From the Options menu, select Display Preferences, and choose Typing Starts Contacts Search.

Your Treo offers several options for making phone calls. As you get familiar with your Treo, you'll discover which method you prefer.

Dialing with the keyboard

1. Press Phone .
2. Using the numbered keys on the keyboard, start typing a phone number. You do not need to press Option to access the numbers on the keyboard.
3. Press Center to dial.

Dialing by contact name

Before you can dial a call by contact name, you must create some contacts (see page 47), or import them with a HotSync operation (see page 30) or from your SIM card (see tip on page 48). The first time you display the Contacts list, Treo asks if you would like to import any numbers from your SIM card into your Contacts list.

1. Press Phone .
2. Use the 5-way navigation control to access the Contacts list.
3. Using the keyboard, begin typing one of the following for the contact you want to call:
   - First initial and last name
   - First name
   - Last name
4. Choose the number you want to dial.
5. Press Center to dial.

To start another search, press Backspace to delete letters you've entered. Or, just press Phone to start all over.

Dialing with a Favorites button

Before you can use Favorites buttons, you must create some Favorites entries. See page 49.


1. Press Phone .
2. Use the 5-way navigation control to access your Favorites buttons.
3. Highlight the desired button.
4. Press Center to dial the selected button.

Dialing using the onscreen Dial Pad

1. Press Phone .
2. Tap the onscreen Dial Pad to enter the number.
3. Press Center to dial.







You can paste numbers directly into the Dial Pad view. Copy a number from another application, then switch to Dial Pad view. Press Menu, then from the Edit menu, choose Paste. Press Center to dial.

If you can't highlight and dial a phone number on a web page or in a text message, using the 5-way navigation control or stylus, it means that Treo does not recognize it as a phone number.





Dialing from a web page or text message


Treo recognizes most phone numbers that appear in web pages or text messages.


1. Use the 5-way navigation control to highlight the phone number you want to dial in the web page or text message.
2. Press Center to dial.

Redialing the last number you called

Do either of the following to redial the last number you called:

- Press Phone, then press Center to display a list of your most recently dialed numbers.
- Press Phone, then use the 5-way navigation control to launch Dial Pad. Choose Dial to display the last number you dialed.
- Press Phone, then press Menu (menu). From the Views menu, choose Call Log (/Y). This view shows all your recent calls in chronological order.





Receiving calls

To receive calls, Wireless Mode must be on. This is different from having just the screen turned on (see page 14).

To answer a call, do one of the following:

- Using the 5-way navigation control, choose the onscreen Answer button.
- If the headset is attached, press the headset button.

To ignore a call and send it to voicemail, do one of the following:

- Press Backspace.
- Using the 5-way navigation control, choose the onscreen Ignore button.

To silence the ringer while your phone is ringing:

- Press the volume buttons or any key on your Treo except the 5-way navigation control, Space, Return, or Backspace.
- To immediately silence all system sounds including the ringer, slide the ringer switch to Sound Mode Off.

When you silence the ringer, you can either answer the call or let it ring through to voicemail.

If audio (MP3 music, for example) is playing, and a call arrives, you can still hear the phone ringing softly. To answer the call, do one of the following:

- Using the 5-way navigation control, choose the onscreen Answer button.
- Press the headset button (if headset is attached).

The audio continues playing but you won't hear it during your call.

To prevent calls from accidentally being answered while the phone is in a pocket or briefcase, you can disable the touchscreen when an incoming call arrives (see page 121).

See a photo of the person calling you! Learn how to assign a caller ID picture on page 112.

Using voicemail

Setting up voicemail

1. Turn on Wireless Mode, as described on page 14.
2. Press Phone.
3. Use the 5-way navigation control to access Favorites.
4. Choose the voicemail Favorites button.



Your Treo connects to your mobile service provider's automated voicemail system. If your Treo is unable to connect to the automated system, please contact your mobile service provider for assistance.

Voicemail notification

When you have a new voicemail message, you are notified with an alert. A voicemail icon may also appear near the top of your screen (this feature is not supported by all mobile networks).



Retrieving voicemail messages

1. Press Phone.
2. From the Phone application Main view, Dial Pad, or Favorites, press and hold 1 on the keyboard. Treo dials your mobile service provider's voicemail system.
3. Enter your voicemail password using the Treo keyboard, or choose Extra Digits if you defined this option (see page 51 for information on editing Favorites buttons). Remember, you do not need to press Option to type numbers, *, or # while on an active call.

If a voicemail icon appears in the title bar at the top of the screen, you can tap this icon to retrieve your voicemail.

Managing active calls

Press Phone repeatedly to toggle between the Active call screen and the Main view of the Phone application.


The personal speakerphone lets you use other features, such as checking your calendar, during a call.

The Extra Digits button appears only during outbound calls to numbers that include pre-defined extra digits (see page 50).

To avoid accidentally pressing onscreen buttons while you're holding the phone up to your ear to speak, you can disable the touchscreen during active calls (see page 122).

When you make or receive a call, the Active Call view appears. Use the 5-way navigation control to access the onscreen buttons in this view:

- Hang Up (or pressing Backspace ⌫): Ends the call immediately. You can also press the headset button (if the headset is attached).
- Spkr-phone (or pressing Space ␣): Switches to the personal speakerphone.
- Hold (or pressing Period .): Places the current call on hold.
- Dial Pad: Opens the Dial Pad so you can manually dial additional numbers.
- Mute: Mutes the Treo microphone so you cannot be heard.
- Add Call: Lets you place another call while keeping the first call active. First choose Hold, then choose Add Call.
- Extra Digits: Dials any extra digits (such as a password or extension) that you assigned to a Favorites button. See page 50 for information on creating a speed dial Favorites button.



A. Caller's name and number
B. Current duration of call
C. Hang up immediately
D. Switch to speakerphone
E. Place current call on hold
F. Mute the microphone
G. Open Dial Pad view

More ways to manage calls

Treo offers many advanced telephone features, including call waiting, conference calling, and call forwarding.

Making a second call

You can make a second call while your first call is still active.

1. After dialing the first number, use the 5-way navigation control to choose Hold.
2. Use the navigation control to choose Add Call.
3. Dial the second number using Favorites, Contacts, Dial Pad, Call Log, or Redial list (see pages 36-38).

The Active Call view now includes two status lines, each representing one of the calls. To switch between the two calls, choose Swap.



You can use nearly any other application on Treo while holding a phone conversation, including the organizer features and SMS. You cannot send and receive email while on an active call. To return to an active call from another application, press Phone.

Answering a second call (call waiting)

When you are on an active call, you can receive a second call. When the second call comes in, the Call Waiting dialog appears, giving you the following options for handling the second call:

- To place the current call on hold and answer the new call, use the 5-way navigation control to choose Answer.
- To send the new call to voicemail, use the navigation control to choose Ignore.

Making a conference call

You can join a total of five other calls in a conference session, provided that your network and service plan include 6-way conferencing. Please contact your mobile service provider for more information. Minutes in your mobile account may be deducted for each active call you place.


1. While the first call is active, place or answer a second call.
2. Use the 5-way navigation control to choose Conf. This joins the two active calls in a conference session.
3. Repeat this process to add other calls to the conference call.
4. To end the conference, use the navigation control to choose Hang Up and end all the calls.



Forwarding all calls

You can forward all of your calls to another telephone number. You can also selectively forward certain calls (see page 46). Keep in mind that your mobile service provider might charge you for forwarded calls.

1. Press Phone .
2. Press Menu (menu) .
3. From the Options menu, choose Call Preferences (/A).



4. Choose the Forward all calls pick list.
   - If the forwarding number appears in the pick list, select the number.
   - If the forwarding number does not appear in the pick list, select Edit Numbers, then choose New. Enter a forwarding number, including the area code or country code if it is different from your mobile phone number. Choose OK to finish.
5. Choose OK.

Forwarding calls under certain conditions

You can forward calls to another number when the line is busy, a call is unanswered, Wireless Mode is off, or you are outside a coverage area.

1. Press Menu (menu).
2. From the Options menu, choose Call Preferences (/A).
3. Choose the Forward all calls pick list, then select Don't forward calls.
4. Choose any of the following pick lists:
   - When busy: Forwards calls if the phone is busy.
   - Not answered: Forwards calls instead of sending to voicemail.
   - Off/No service: Forwards calls when your Treo is not connected to a mobile network.

   If the forwarding number appears in the pick list, select the number. If the forwarding number does not appear in the pick list, select Edit Numbers then choose New, enter a forwarding number, and choose OK to finish.
5. Choose OK.

Call Barring

Call Barring lets you prevent unauthorized calls on your Treo. This feature may not be available on all mobile networks. Contact your mobile service provider for more information.

You must enter your Call Barring password every time you change your Call Barring preferences. Contact your mobile service provider if you do not know this password.

1. Press Menu (menu).
2. From the Options menu, choose Call Barring.
3. Choose the onscreen pick lists, then select your Call Barring preferences.
4. Choose OK.

Managing contacts

Contacts is a view in Phone. If you are familiar with Palm Powered devices, you may recognize this application as similar to the Address Book on previous devices.

Adding a contact

1. Press Phone.
2. Use the 5-way navigation control to access the Contacts list.
3. Choose New Contact.



4. Use the 5-way navigation control to move between fields as you enter information.
5. To place the entry in a category or mark it private, choose Details.
6. To add a note to an entry, choose Note.
7. After you enter all the information, choose Done.

If you have several contacts to enter, it's more efficient to use the Palm Desktop software or Microsoft Outlook on your computer and then synchronize data between the Treo and your computer. For more information, see page 30.

In the Contacts View, Up and Down move to the previous or next Contacts record.

Be sure to label your contacts' mobile numbers correctly. The SMS application (see page 64) will only look up numbers labeled as Mobile.

Import contacts from your SIM quickly and easily. Press Phone, then use the 5-way navigation control to open Contacts view. Press Menu, then from the Record menu, choose Import from SIM.

Viewing or changing contact information

1. In the Contacts list, begin typing one of the following for the contact you want to view or edit:
   - First initial and last name
   - First name
   - Last name
2. Choose the name of the entry you want to open.
3. Choose Edit.
4. Make changes to the entry as necessary.
5. Choose Done.

Deleting a contact

1. Open the contact you want to delete.
2. Press Menu (menu).
3. From the Record menu, choose Delete Contact (/D).
4. Choose OK.

Defining your business card

1. Create a new contact with your business card.
2. While still in Contact Edit view, press Menu (menu).
3. From the Record menu, choose Select Business Card.

Now you can beam your business card to other Palm OS devices. In any Phone view, press Menu (menu). From the Record menu, choose Beam Business Card (/M).

Defining Favorites buttons

To see the next page of Favorites, press Right repeatedly. To see the previous page, press Left repeatedly.

Treo provides 50 programmable Favorites buttons for quick access to the following common tasks:

- Dialing a phone number (speed dial)
- Launching an application
- Accessing a web page
- Addressing a text message
- Accessing voicemail (preset on Treo)

Your mobile service provider may include special Favorites buttons on your Treo that are customized for their services.



When you are in the Main, Favorites, or Dial Pad view, you can press and hold a Quick Key to launch the Favorite associated with that key. Quick Keys are optional, must be letters, and are not case sensitive.

Creating a speed dial Favorites button

1. Press Phone.
2. Use the 5-way navigation control to access your Favorites buttons.
3. Choose a blank button.
4. Choose the Types pick list, then select Speed Dial.
5. Enter a label for the favorite:
   - If the entry is for an existing contact, choose Lookup. Start typing the last name of the contact, then select the contact when it appears in the Lookup list.
   - If the entry is for a new contact, type the Label, press Down ▼ and type the Number.
6. (Optional) Enter a Quick Key. When you are in the Phone application, you can press and hold the Quick Key to instantly launch the favorite.
7. (Optional) Choose More, and select advanced options:
   - Extra Digits: Lets you define additional digits to dial, such as a password or extension.
   - Dial Extra Digits Automatically: Dials pre-defined Extra Digits immediately after dialing the phone number, when checked.
   - Ringtone: Assigns a special ringtone for incoming calls from that contact.
   - Image: Assigns a Caller ID picture that displays when that person calls.
8. Choose OK.



To see all the contact numbers for the selected person or business, highlight the Favorite button and press Space.

To add a photo caller-ID image, a special ringtone, and extra digits, choose More.

Creating an application, message or web link Favorites button

1. Press Phone.
2. Use the 5-way navigation control to access your Favorites buttons.
3. Choose a blank button.
4. Choose the Types pick list, then select Application, Message or Web Link.
5. Enter a label for the favorite, and enter any other necessary information on the screen.
6. (Optional) Enter a Quick Key that launches the favorite when pressed and held.
7. Choose OK.

Editing or deleting an existing Favorites button

1. Press Phone.
2. Use the 5-way navigation control to access your Favorites buttons.
3. Highlight the Favorites button you want to edit or delete.
4. Press Menu.
5. From the Edit menu, choose Edit Favorites Button (/E).
6. Make the desired changes. For example, you can add a Quick Key shortcut to any favorite. When you press and hold the assigned letter from within the Phone application, the favorite launches.
7. To delete the entry, choose Delete.
8. Choose OK.

You can also organize your Favorite buttons on different pages. From the Edit menu, choose Edit Favorites Pages.

You can edit but not delete the voicemail entry.


Using a phone headset

In addition to the headset that came with your Treo, you can use other third-party headsets.

To hear stereo through the jack (such as music), you should use a stereo adapter or other accessory. Visit www.palmOne.com for more information.

The headset designed for previous models of Treo is not compatible with the Treo 600.

You can connect a phone headset for hands-free operation. If you need to use your phone while driving and this is permitted in your area, we recommend using a phone headset.



A. Speaker
B. Microphone
C. Headset button

You can press the headset button to perform any of the following tasks:

- answer an incoming call
- answer a call-waiting call
- switch between two active calls
- hang up a single call

Headset specifications

Your Treo uses a 2.5mm, 3-pin headset connector. Your Treo works with headsets that are designed for this type of connector. When in doubt, ask the third-party headset manufacturer if their product is compatible with Treo phones. If you hear a headset buzz or poor microphone performance, your headset may be incompatible with Treo.

Browsing the web

Blazer Web Browser on your Treo provides quick and easy access to web pages. You can view the regular sites you use today, including those with security and advanced features like JavaScript and frames. To browse the web, you must activate data services from your mobile service provider.

Viewing a web page

1. Make sure Wireless Mode is turned on, as described on page 14.
2. Press Applications Launcher, then choose Blazer.
3. Navigate to the web page you want:
   - To view a portal of mobile content designed specifically for your Treo, choose .
   - To go to any web page on the Internet, choose .
   - If you browse to a secure web page, a Lock icon appears.
   - To view the previous or next page, choose or .
   - To refresh the page with the latest content available from the Internet, choose .

Navigating in Optimized Mode

Blazer uses a patent-pending technology to optimize web pages for your Treo. By default, the browser reformats web pages into one column on your screen. This way, you can see most content without needing to scroll left or right.

- Press Up or Down to move through a web page.
- Press Left or Right to move between links on the page. To follow a link to another web page, highlight the link and then press Center. You can also tap the link on the screen with your stylus.

Navigating in Wide Page Mode

Some web pages, such as maps, are easier to view without the optimization done in Optimized Mode. You may want to view these pages in Wide Page Mode. This mode presents the web page as you would expect to see it on your computer's screen.

1. Go to the page you want to view.
2. Press Menu (menu).
3. From the Page menu, choose Wide Page Mode (/W).
   - Press Up ▲, Down ▼, Left ◀, or Right ▶ to scroll through the wide page.
   - To follow a link to another web page, tap the link with your stylus.

Want to get to the icons faster? Press Option and Center to jump down to the icons, or press Menu to access the same commands through the menus.

Always using bookmarks? Make Bookmark View the default view when you launch the browser. From the Options menu, choose Preferences, then select the Bookmarks icon as your Initial View.

Creating a bookmark

Bookmarks let you instantly access a web page, without needing to type the address every time. Blazer can store up to 100 bookmarks or saved pages, allowing you to open your favorite web pages quickly. Remember, a Blazer bookmark is different from a Favorite (see page 50).

1. Go to the page you want to bookmark.
2. Press Menu (menu).
3. From the Page menu, choose Add Bookmark (/A).



4. If desired, change the Name and Description.
5. Choose OK
6. Use the stylus to drag and drop the new bookmark into a slot on the current page. To move the bookmark to a different page, drag and drop it on the page icon ■.
7. Choose OK.

Saving a page

Blazer lets you save a page for offline viewing, so you don't need an Internet connection to view it later.

1. Go to the page you want to save.
2. Press Menu (menu).
3. From the View menu, choose Save Page.
4. Choose OK.
5. Use the stylus to drag and drop the new bookmark into a slot on the current page. To move the bookmark to a different page, drag and drop it on the page icon ■.
6. Choose OK.

Viewing bookmarks or saved pages

Bookmarks and saved pages both appear in Bookmark view. Saved pages are indicated by a small triangle in the upper-right corner of the bookmark.

1. Choose the Bookmarks view icon ▦.
2. Choose the bookmark or saved page you want to view.



Tap and hold the back or forward buttons to pop up a list of sites you've visited.

Editing or deleting a bookmark or saved page

1. From the Bookmarks view, press Menu (menu).
2. From the Bookmarks menu, choose Edit Bookmarks.
3. Choose the bookmark you want to edit or delete.
4. Enter the desired changes.
5. Choose OK.

Arranging bookmarks and saved pages

Blazer includes 10 pages so that you can arrange bookmarks and saved pages in a logical fashion. For example, you can store travel links on one page, stock links on another, and business links on third page.

1. From the Bookmarks view, press Menu (menu).
2. From the Bookmarks menu, choose Edit Bookmarks.



3. Type a new title for this page.
4. Use the stylus to drag and drop bookmarks into different slots on the current page. To move a bookmark to a different page, drag and drop it on the page icon ■.
5. Choose OK.

Downloading files from a web page

Blazer lets you download files that are useable on your Treo, such as new applications or MIDI ringtones. When you download a file, it is automatically sent to the application that can use the file. Note: Only certain images tagged specifically for download can be downloaded by Blazer.

1. Go to the page that contains the link to the file you want to download.
2. Press Left ◀ or Right ▶ to highlight the link to the file, then press Center to initiate the download process.

Navigating web sites with split pages (Frames)

Some web sites split their pages into separate areas, each with their own scroll bars. You can navigate these sites more easily by "zooming in" on one of the separate areas. To do this:

1. Tap inside the area of the split page you want to make larger. Make sure you tap on an area that is not a link, otherwise, you will navigate to that link.
2. Tap the magnifying glass icon in the navigation bar. This will make the area you tapped on the entire page. Note: This icon will only appear if you are on a page that is split into separate areas.

Copying text from a web page

You can copy text from a web page and paste it in other applications.

1. Use the stylus to highlight the text you want to copy.
2. Press Menu (menu).
3. From the Edit menu, choose Copy (/C).
4. Go to the application in which you want to paste, then position the cursor where you want to paste the text.
5. Press Menu (menu).
6. From the Edit menu, choose Paste (/P).

Lots of pretty graphics slowing you down? Browse the web faster by turning off images. From the Options menu, choose Preferences, and then check the Don't Show Images box.

If Blazer does not recognize a phone number as dialable, you can copy the phone number (as text) and paste it into the Phone Dial Pad (see tip on page 37).

Using the History list

The History list stores the addresses of the last 100 pages you visited. Items in the History list are sorted chronologically.

1. From the Page view, press Menu (menu).
2. From the Page menu, choose History.
3. Press Down ▼ to navigate through the list.
4. Choose the web page you want to load.

Finding text on a web page


1. From the Page view, press Menu (menu).
2. From the Page menu, choose Find Text on Page.
3. Type the text you want to find.
4. Check or uncheck the Wrap Search box to indicate whether you want the search to wrap from the end of the page to the beginning when the end is reached.
5. Choose Find to start the search.

Customizing your Blazer Web Browser settings

1. Press Menu (menu).
2. From the Options menu, choose Preferences.
3. Set any of the following preferences:
   - Initial view: Determines which view displays every time you launch Blazer.
   - Don't show images: Selects whether you want images to appear when you load a web page. If you don't view images, web pages will load faster. If you choose not to view images, you can still see any image by choosing the placeholder box on the web page.

Visit secure web sites. The 128-bit SSL, strong encryption lets you browse secure sites, such as online shopping, banking, and email. Remember: some secure sites also require specific browsers, and may not work with Blazer.





4. Choose Advanced and set any of the following preferences:
   - Set limit on memory for storing recently viewed pages (cache): Sets the amount of memory used for your cache. Pages are cached so they load faster the next time you view them.
   - Memory Management: Enables you to free up memory on your phone by clearing the memory for recent pages, history, and cookies.
   - Set Proxy: Sets up a proxy server to access the Internet. If your connection requires a proxy server, please contact your Internet service provider or IT administrator for this information.
   - Accept cookies: Allows some web sites to store personalized information on your Treo. Some sites do not work properly unless you select this option.
5. Choose OK.

Blazer supports JavaScript, SSL, and cookies, but does not support plug-ins (Flash, Shockwave, etc.) or Java applets.

Email from a web page. Email addresses appear as links on web pages. After you configure an email application on your Treo, you can select an email address link to create a message to the selected address.

Taking pictures with the camera

Your Treo includes a camera that lets you take pictures, send them to other people as attachments or picture messages, and use them to personalize your device (such as wallpaper or picture caller ID; see page 112 for details).

You can move pictures to a Windows computer by performing a HotSync operation. Pictures are 12-bit color at a maximum of 640x480 resolution (0.3 megapixels).

Taking a picture

1. Press Phone.
2. Press Right ▶ to launch Camera.
3. Point the lens on the back of your Treo at the subject you want to photograph.
4. Press Center to capture the picture.
5. If desired, edit the picture name and category at the top of the screen.
6. Choose Save to keep the picture, choose Don't Save to discard it, or choose Send to send the picture.



To send a picture to someone at the same time you save it, choose Send instead of Save.

You can reduce the size of an image before sending it. From the Picture menu, choose Downsize. Indicate whether you want to resize the original or save a reduced copy.

To view other full-size pictures, choose Prev or Next.


Viewing a picture

1. Choose the Pictures view icon.
2. Choose the picture you want to view.
3. Choose Done.

Sending a picture

You can send a picture to other picture-enabled mobile phones or to an email address.

1. From the Pictures view, choose the picture you want to send.
2. Choose Send.
3. If a dialog appears, choose the application you want to use to send the picture.
4. When the sending application launches, address and send the message.



You cannot send pictures that appear with a lock icon in the Pictures view.

When using the camera in low light, you may see blue dots on the screen, especially in the darker areas. Once you capture the picture, image quality improves.

You can rename a picture. From the Picture menu, choose Edit Name.

Move or copy a picture to your SD card. Select a picture, then press Menu. From the Picture menu, choose Move, then choose your SD card from the pick list. See page 105 for more information on using expansion cards.

Moving pictures

1. From the Pictures view, choose the picture you want to move.
2. Press Menu (menu).
3. From the Picture menu, choose Move (/M).
4. Choose the category or expansion card where you want to move the picture.
5. Choose Move to finish.




Deleting a picture

1. From the Pictures view, choose the picture you want to delete.
2. Choose Delete.
3. If prompted, choose OK to confirm deletion.

Customizing your Camera settings

1. From any Camera view, press Menu (menu).
2. From the Options menu, choose Preferences.
3. Set any of the following preferences:
   - Default name: Names a series of pictures to be captured, such as Seattle001, Seattle002, etc.
   - Category: The default category for newly captured pictures.
   - Picture size: The default size for newly captured pictures. Large is 640 x 480 pixels, small is 120 x 160 pixels.
   - Play capture sound: Plays a sound to confirm picture capture.
   - Confirm before deleting: If checked, Camera asks if you're sure you want to delete a picture before erasing it.
   - Confirm before saving: If checked, Camera asks if you're sure you want to save a picture before storing it on your Treo.
   - Backup settings: When activated, backs up the Treo image database on your desktop computer.
4. Choose OK.



Viewing pictures on your computer (Windows only)

When you perform a HotSync operation, your Treo images are copied to your desktop computer. You can view these pictures in JPEG format, or email them to friends using your desktop email application.

1. Locate your Pictures folder. This is most likely at C:\Program Files\palmOne\Treo Pictures\(user name) or if you upgraded from another Palm Powered device, at C:\Program Files\Palm\Treo Pictures\(user name).
2. Double-click any file to launch it with the default picture viewing software on your Windows computer.

SMS

When entering a message, you can insert emotive symbols by choosing Emoticons or predefined QuickText phrases. To add a new phrase, select Edit QuickText from the list.


Not all symbols available on your device may be used in text messages. The SMS application automatically replaces invalid characters before it sends your message.

You can address text messages to multiple recipients by separating the addresses with a space or a comma. If you address a single message to three people, you will be billed for three messages.

SMS messages are brief notes that you exchange with other mobile phones that have SMS capability (also known as short messaging). Long messages with more than 160 characters are split into several messages. Refer to your service plan for per-message pricing and availability.

Creating and sending a message

1. Make sure Wireless Mode is turned on, as described on page 14.
2. Press SMS.
3. Choose New.



4. If the intended recipient is in your Contacts list, start typing the first initial and last name (no spaces). Otherwise, type the full phone number or email address. Destination email addresses are included in the 160 character count.
5. Press Down . If you typed just a few letters of the recipient's name, choose the recipient's phone number or email address from the list that appears.
6. Type your message.
7. Choose Send.

Receiving messages

When your phone is on and in an area of wireless coverage, you will automatically receive SMS messages sent to you. You can configure your Treo to automatically notify you when new text messages arrive, using a ringtone and vibration or simply an onscreen alert.

From the New Message alert:

- To view your message(s), choose Go To.
- To dismiss the alert, choose OK. The message will go straight to the Inbox.
- To be reminded of the new message again in 5 minutes, choose Snooze.





Using links in messages

When you receive an SMS message that contains a telephone number, email address, or URL, you can dial the number, send an email message, or go to the web page immediately.

1. Choose a message from the list.
2. Choose the phone number, email address, or URL (appears as underlined blue text).
3. Your Treo automatically launches the appropriate application from the link.

If you are out of a coverage area or if Wireless Mode is off, outgoing messages go into the outbox. When you return to a coverage area, messages are sent automatically.

Choose Save to save a draft of the message without sending it. To access the draft, choose the pick list in the upper-right corner, then select Drafts.

Managing your messages

The status icons that appear next to each message in the Inbox, Outbox, and Sent folders indicate the following:

- An incoming message. Unread messages appear in bold; messages you've read appear in plain text.
- An item that is locked and cannot be deleted or purged until you unlock it.
- An outbound message that is waiting to be sent.
- A chat session. Chats containing unread incoming messages appear in bold text.
- A voicemail or numeric page. An unread voicemail or numeric page appears in bold.

In list view you can rearrange the messages in any folder using the Sort command.

1. From list view, press Menu (menu).
2. From the View menu, choose Sort by Name or Sort by Date.

In list view you can delete several messages at once from any folder using the Purge command.

1. From list view, press Menu (menu).
2. From the Message menu, choose Purge.
3. Choose the Purge pick list, then select an option.
4. Choose OK.



Chatting with SMS

When you exchange more than one SMS message with a single contact, your messages are grouped into a chat session. The upper part of the Chat view displays all messages you've exchanged with this contact, and the lower part provides a text entry area. You can carry on multiple chats at the same time and easily switch between them, using the pick list at the top of the screen.



1. From the Inbox, choose a chat.
2. Type your message.
3. Choose Send.

Customizing your SMS settings

1. Press Menu (menu).
2. From the Options menu, choose Preferences.
3. Set any of the following preferences:

- Messages: Your preferences for individual text messages.
  - Confirm message deletions: Indicate whether you want deletion confirmation messages to appear.
  - Return to list view after deletion: Indicate whether you want to return to the list view or the next item in the folder after deleting a message.

SMS messages can be sent and received even while you are on a phone call. This is easiest when using the hands-free headset or speakerphone.

To find the conversations you had with someone, open your SMS Inbox and select a chat session.

Warning: Changing your SIM preferences may cause the SMS application to stop functioning.

- Chat: Your preferences for chat sessions.
  - Show timestamps in chats: Indicate whether you want to see the date and time stamps of each message in the Chat screen.
  - Display my name in chat window as: Enter the name you want displayed as the label for your messages in the Chat screen.
  - Label Color: Select the color in which you want messages to appear.
  - Use color for: Indicate whether you want to view both the message label and message in a different color, or only the name.







- SIM: your preferences for the SIM card in your Treo.
  - SMS Message center number: Enter, verify, or update your mobile service provider's SMS Message Center phone number.
  - Email gateway: Enter, verify, or update your mobile service provider's email gateway number. This is required to send SMS messages to an email address.

4. Choose OK.


MMS

MMS (multimedia messaging) is used for messages consisting of pictures, text, and sounds presented as one or more pages. You can include any of the following items:

- Ringtones
  - MIDI: Up to 16-voice polyphony (Standard or SP-MIDI format), 64 KB per sound file
  - iMelody: Up to 64 KB per sound file
- Sound clips
  - AMR: Up to 30 seconds playback time, 64 KB per sound file
- Pictures
  - JPEG: Up to 640 x 480 pixels, 64 KB per image file
  - GIF: Up to 640 x 480 pixels, 64 KB per image file

Creating and sending a multimedia message

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the MMS icon.
4. From the MMS list view, choose New.



Before you use your Treo to send or receive multimedia messages, consult your mobile service provider for pricing and availability of multimedia messaging services.

Save a message as a template for other messages. From the Compose menu, choose Save as Template. To create a message based on the template, go to the Template folder and then choose the template you want to use.

A multimedia message may contain multiple pages. To navigate between pages or add a new one, choose the Page Selector arrows at the top of the screen.

To stop playback of a message, choose Play/Stop.

To save a picture from an incoming message, select it then press Center. To select the text of an incoming message, position the cursor in the text area then press Center.

5. If the recipient is in your Contacts list, start typing the first few letters of the recipient's name. Otherwise, type the number of a phone that supports multimedia messaging, or an email address.
6. Press Down ▼. If you typed a few letters of the recipient's name, choose the recipient's phone number or email address from the list that appears.
7. Add ringtones, sound clips, pictures, or text to the message:
   - Choose Add Picture to insert a picture. Once a picture is inserted, choose the picture to edit or remove it.
   - Choose Sound to insert a ringtone.
   - Add more pages to your message using the Next Page arrow in the title bar.
   - Select the text entry area and type any text you want to include with the message.
8. Choose Preview to view the message as the recipient will see it.
9. Choose Send to finish.

Receiving multimedia messages

You can automatically download new messages or have Treo notify you that a message is ready to download. In either case, an alert appears when you have a new message.

From the alert:

- To view your message(s), choose Go To.
- To dismiss the alert and view the message(s) later, choose OK.
- To be reminded again in 5 minutes, choose Snooze.



Viewing/playing a multimedia message

1. From the Inbox, choose the message you want to view.
2. If there are sounds or multiple pages, playback will begin immediately.
3. Use the onscreen controls to scroll to other pages and messages.
4. If a Sound icon appears, choose it to play or save the sound.
5. Choose OK.



A. Previous message
B. Play/Stop
C. Next message
D. Sound icon
E. Playback icon

Responding to a multimedia message

1. From the MMS list view, choose the message you want to view.
2. Choose Respond.
3. Choose the appropriate action to reply, forward, or call.

Managing multimedia messages

You can rearrange messages in any folder using the Sort command.

1. From list view, press Menu (menu).
2. From the View menu, choose Sort by Name or Sort by Date.

In list view you can delete several messages at once from any folder using the Purge command.

1. From the MMS list view, press Menu (menu).
2. From the Message menu, choose Purge.
3. Choose the Purge pick list, then select a purge option.
4. Choose OK.

To delete an item from a message you're creating, highlight it and then press Backspace.

You can expand and collapse header information by choosing one of the "full header" icons in the title bar of a message.

If you reply to a multimedia message with a text message, you'll automatically be sent to the SMS application to compose your reply.

Customizing your MMS settings

1. Press Menu (menu) .
2. From the Options menu, choose Preferences.
3. Set any of the following preferences:
   - Automatically deliver messages: Indicate whether you want to automatically download incoming multimedia messages.
   - Even when roaming: Indicate whether you want to automatically download incoming multimedia messages while roaming.
   - Confirm message deletion: Indicate whether you want deletion confirmation alerts to appear.
   - Display alerts in Privacy Mode: Indicate whether you want the subject and sender's name to appear in the notification alert.
   - Save copies of sent messages: Indicate whether you want to save copies of messages you send.
   - Connection Settings: Indicate whether you want to use the Automatic or Custom connection settings. If you choose Custom, choose Edit and enter your settings.
4. Choose OK.



Sending and receiving messages with Mail

If you have activated data services (such as GPRS), you're ready to set up your Treo for email. These steps differ depending on who provides your email service.

- Mail: The built-in email application on Treo that provides wireless access to an existing POP3 email account. See the sections that follow for details.
- Other mobile email services: Your mobile service provider may offer a wireless email service to which you can subscribe with your service plan. Contact your mobile service provider for details.
- Third-party email applications: A number of third-party developers offer Palm OS email applications. Consult the email application's documentation to learn how to set it up.

Setting up Mail

The first time you use Mail, you need to set it up on your Treo. If you have multiple email accounts, you can set up Mail to access more than one account. To use Mail, you must have:

- Mobile account with data services activated.
- Email account with an email service provider that supports the POP3 protocol. Examples include Earthlink, SBC and AT&T Worldnet. Contact your email provider to determine if your account is POP3 compatible. If not, contact your mobile service provider to learn about their corporate email solutions, or use a third-party solution.

The Mail application is compatible with regular POP3 email accounts. Other accounts, such as corporate or web-only email, require special applications, if available.

For quick access to the Mail application, link it to one of the buttons on the front panel of your phone, such as the Messaging button. For details, see page 117.

1. Press Applications Launcher .
2. Choose the Mail icon.
3. Choose the pick list, then select your email service provider. If your email service provider is not listed, select Other.





4 Choose Next.
5. Type your Full Name (as you want it to appear when you send messages), your full email address, and your Password for this account. If you selected Other from the pick list earlier, choose the tabs for Server and Advanced, and enter the necessary information. If you do not have this information, contact your email service provider to obtain it. For SMTP, enter the regional SMTP server provided by your mobile service provider.
6. Choose OK to continue.
7. Choose Done.

Creating and sending messages

1. From the Inbox, choose New.
2. Begin typing the addressee's email address, first name, or last name. Mail remembers your most recent addressees and suggests choices. To accept a suggestion, press Down ▼. To send to a different address, keep typing the email address or name.
3. Enter the subject and message text. To move between fields, press Up ▲ or Down ▼.
4. Choose Send to connect and send all messages immediately. Or, choose Send Later to put this message into your Outbox.





Attaching ringtones and images to your messages

1. Create the message to which you want to attach the item.
2. From the New Message screen, press Menu .
3. From the Options menu, choose Insert Attachment.
4. Choose the type of item you want to attach.
5. Choose the specific item you want to attach.

Attaching applications to your messages

You can create a new email with a Palm OS application attached (subject to copyright restrictions).

1. Press Applications Launcher .
2. Press Menu .
3. From the App menu, choose Send.
4. Choose the application you want to send. If the application has a lock icon next to it, it is protected and can't be attached.
5. Complete the message and send.

To address a message to several people, separate each address with a comma or space. When you're finished adding addresses press Center to finish.

If you receive an error when sending a message, you may need to specify an SMTP server for your email account, or add other security preferences before you can send emails. For more information, see the troubleshooting tips on pages 140-142.

To send a copy or blind copy, choose Cc or Bcc, select those lines and enter the address(es) in those fields. See page 80 for details on displaying the Bcc field.

To save a message without sending, choose Cancel (instead of Save), then choose Yes in the Save Draft screen.

You can attach other types of third-party files to an email if the third-party software supports the "Send" command. Launch the third-party application, open the item in question, press Menu, and choose "Send" if available.

Receiving and viewing messages

By default, your Treo will automatically send and receive messages (see page 79 for more details). You can manually send and receive messages on-demand as described below.

1. Make sure Wireless Mode is turned on (see page 14).
2. From any mailbox, choose Send and Receive.
3. From the Inbox, choose the message you want to view.
4. When viewing the message text, press Option and Left or Right to view the previous or next message.
5. Choose Done to return to the Inbox.





Replying to or forwarding messages

When you respond to messages, you can choose whether to include the original text (see page 80).

1. From the Inbox, Filed, or Deleted folder, open the message to which you want to respond.
2. From the Message view, choose Respond to reply. To reply to all or forward, choose the appropriate button.
3. Enter your reply.
4. Choose Send to finish.

You can also reply to all addressees. Choose the Respond button, then choose Reply All.

If you want your Treo to check your email automatically, change the Delivery preference.

Viewing attachments

There are a number of attachment types you can open with the built-in software on your Treo (e.g. ringtones, pictures). You can open other types of attachments by installing third-party applications. In Message view, attachments appear with the paperclip icon if they are unsupported on Treo. If attachments are supported on Treo, they appear with the icon for the associated program (e.g. the camera icon for pictures).

1. From any folder, open the message with the attachment you want to view.
2. Choose the attachment icon.
3. Follow the prompts from the viewing application.

Managing your messages

The status icons that appear next to each message in your Inbox indicate the following:

- You have not read the message
- You have read the message
- The message includes an attachment

You can rearrange the Mail list to make it easier to find and view messages.

- From the Mail list view, press Menu (menu), then from the Options menu, choose one of the following: Sort by Date (/Z), Sort by Name (/Y), Sort by Subject (/J).
- To quickly switch between folders in list view, choose the folder pick list in the upper-right corner, then select the desired folder.

If a large incoming message is truncated, go to the Message menu, then choose Get Entire Message.

If you have problems receiving email, see the troubleshooting tips starting on page 140.

To hear sound file attachments, press Menu. From the Attachments menu, choose Open.

You can also use the system Find dialog to quickly scan your mailbox. Press Option and Shift/Find.

Deleting selected messages from the Inbox

When you delete a message from the Inbox, it moves to the Deleted folder which stores the 200 most recently deleted messages. If you delete more than 200 messages, the oldest messages are automatically removed from the phone.

1. Highlight the message you want to delete. To highlight a group of messages, press Shift and Up ▲ or Down ▼.
2. Press Backspace.
3. If a confirmation dialog appears, choose OK to confirm deletion.

To empty (or purge) the Deleted folder, go to the Message menu, then choose Empty Deleted Items (/E).

Deleting messages by the date

You can quickly delete a group of messages by selecting a range of dates.

1. Press Menu.
2. From the Message menu, choose Purge (/K).
3. Choose a date range for the messages you want to delete.
4. Choose OK.
5. If a confirmation dialog appears, choose OK to confirm deletion.





Switching accounts

To switch between different email accounts, press Menu, then from the View menu, choose an account.

Customizing your Mail settings

If you have multiple email accounts, you can customize the Mail settings for each individual account on your Treo. Remember, the preferences you set will only apply to the email account you are currently viewing.

1. Press Menu.
2. From the Options menu, choose Preferences.
3. Set any of the following Delivery preferences:
   - Get mail: Sets the interval for mail delivery. If you select an automatic delivery option, you can also select the hours during which you want automatic delivery.
   - For each message get: Sets the maximum size for incoming messages. 1K of information is about 4 screens of text on your Treo.
   - Only get mail from last ## days: Specifies the timeframe for retrieving earlier messages.
   - Auto-deliver even when roaming: Specifies whether you can continue automatically retrieving your email when you are not in your mobile plan's home area (which may incur additional charges on your account). This option applies only if you selected an automatic delivery option.




Remember, your Mail preferences (including automatic delivery) are set for the individual account currently displayed. If you have multiple accounts, configure each account separately.

If you want to access more than one email account with your Treo, choose Add Account.

If you assign Mail to an application button, you can press and hold that button to send and receive mail. This is very useful for discreet mail checking.





4. Choose the Delete tab and set any of the following preferences:
   - Confirm message deletion: Asks if you're sure you want to delete a message before erasing it.
   - Return to list view after deleting a message: Shows the Mail list view after you delete a message, if checked, or shows the next message in the list, if unchecked.
5. Choose the Message tab and set any of the following preferences:
   - Include original text when replying: Appends the full text of the original message when you reply to a message.
   - Include attachments when forwarding: Sends attachments as well as the original message when forwarding, even if you cannot open an attachment on Treo.
   - Always show Bcc: Displays the Bcc field when creating messages and allows you to pre-fill this field with a default address (useful for creating a backup copy of email that is sent to your email server).
   - Signature: Controls what messages have your signature automatically appended to them and lets you define a custom signature.
6. Choose OK.

first two weeks:

using organizer features

Calendar

If you have several appointments to enter, it's more efficient to use the Palm Desktop software or Microsoft Outlook on your computer and then synchronize data between the Treo and your computer. For more information, see page 30.

Displaying your calendar

- Press Calendar repeatedly to cycle through the various active views.



- Use the 5-way navigation control to move to another day, week, or month (depending on the current view).
- Choose Go or press Menu (menu). From the Options menu, choose Go to Day (/O), then choose a date from the calendar.

Creating an event

1. Press Calendar until you are in Day view.
2. Press Left and Right to select the desired day.
3. Using the keyboard, type a starting time for the event. For example, type 53 for 5:30 (Remember to press Option before typing numbers).
4. Press Down and type the ending time for the event.
5. Choose OK.
6. Type a description for the event.




A. Selected date
B. Starting and ending times
C. Selected day

Adding an alarm reminder to an event

1. In Calendar, highlight the event.
2. Choose Details.
3. Check the Alarm box and choose the number of minutes, hours, or days before the event you would like to receive the alarm.
4. Choose OK.





A. Type of time units
B. Number of time units
C. A diamond indicates an untimed event.

Creating an untimed event

An untimed event, such as a birthday or anniversary, does not occur at a particular time.

1. Press Calendar until you are in Day view.
2. Press Left and Right to go to the date of the event.
3. Make sure nothing is highlighted.
4. Type a description for the event.

Editing or deleting an event

1. Highlight the event you want to reschedule.
2. Choose Details.
3. Change the date and time as needed, or choose Delete.
4. Choose OK.

The silent alarm for untimed events is defined by minutes, days, or hours before midnight of the date of the event.

When an alert occurs, the Reminder screen displays all your Treo's pending alerts. Tap an item's description to jump to that item, or check the box to clear that item.

To enter a birthday or anniversary, create an untimed event. Then, from the Details screen, choose Year as the repeat interval.

Scheduling a repeating event

1. Create an event, then highlight it.
2. Choose Details.
3. Choose the Repeat box, then choose a repeat interval.
4. For weekly events, choose the day(s) the event repeats; for monthly events, choose Day or Date to indicate the repeating method.
5. If the event has an ending date, choose the End on pick list, then select Choose Date, and select the ending date.
6. Choose OK.






A. This icon indicates a repeating event.

Customizing general preferences for your calendar

1. Press Menu (menu).
2. From the Options menu, choose Preferences (/R).
3. Set any of the following preferences:
   - Start Time and End Time: The beginning and end of the day shown on Calendar screens.
   - Event Duration: The default duration of a new event.
   - Week Start: The day on which the calendar week starts.
   - Initial View: The view that appears when you launch Calendar.
   - Button Views: The views that appear when you press Calendar repeatedly. By default, you see Day and Month Views, but you can also see other views.






   - Display Options: Your choices for different Calendar view options:
     - Show Time Bars: shows the duration of an event and illustrates conflicts.
     - Compress Day View: When off, all time slots display. When on, start and end times display for each event, but blank time slots disappear to minimize scrolling.
     - Show PM Label: Displays a *p* after PM times.
     - Show End Times: Displays all time bars and time slots for end times of an event.
     - Auto-scroll Time: Displays events based on the time of day when there is more than one screen of information. The arrows at the bottom-right corner indicate more information.
     - Float Advance at Midnight: Advances floating events to the next day at midnight of the current day.
     - Show Completed Floating Events: Displays completed floating events.
4. Choose OK to close the Display options dialog.
5. Choose OK.

Customizing To Do List preferences for your calendar

You can display To Do List items in your calendar to keep on top of your tasks.

1. Press Calendar until you are in Day view.
2. Press Menu (menu).
3. From the Options menu, choose To Do Preferences.
4. Set any of the following preferences:



- **Show Categories:** Determines which To Do List categories appear.
- **Priorities Displayed:** Limits the To Do List to certain priorities.
- **Show Priority:** Displays the priority assigned to an item.
- **Show Completed Items:** Displays checked off items.
- **Show Undated Items:** Displays items that do not have a Due Date assigned.
- **Show Dated Items:** Displays To Do List items that have a Due Date assigned.

5. Choose OK.

To Do List

You can use To Do List as a reminder of tasks you need to complete and to keep a record of complete tasks.

Adding a To Do item

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the To Do List icon.
4. Choose New to create a new To Do item
5. Type the text of the To Do item. The text can be longer than one line.
6. Press Down to deselect the To Do item.





Setting item priority, due date, and other details

The Details dialog enables you to assign a priority level, due date, category, privacy flag, and note to each item.

1. Highlight the item to which you want to assign details.
2. Choose Details.

To save memory, you can purge all completed To Do List items. From the Record menu, choose Purge. Choose OK to finish.

You can set To Do List to record the date that you completed the To Do item, and you can choose to show or hide completed items. Completed items remain in the memory of your phone until you purge them.

You can display To Do List items in your calendar. See page 86 for information on customizing To Do List preferences for your calendar.

To uncheck the selected item, hold Option and press Return.

3. Set any of the following:
   - Priority: Choose the Priority number for this item (1 is most important). Later you can arrange your To Do List based on the importance of each item.
   - Category: Assign the item to a specific category.
   - Due Date: Choose the Due Date pick list, then select a due date for the item.
   - Private: Check this box to mark this item private.
   - Note: Enter additional text you want to associate with the item.
4. Choose OK.





Checking off a To Do item

1. Choose the item you want to check off.
2. Hold Option and press Return.

Deleting a To Do item

1. Highlight the item you want to delete.
2. Press Menu (menu).
3. From the Record menu, choose Delete Item (/D).
4. Choose OK.

Customizing To Do List

The To Do Preferences screen enables you to control the appearance of the To Do list screen.

1. In the To Do list screen, choose Show.
2. Set any of the following preferences:



- Sort by: Indicates the order in which your To Do items appear in the list.
- Show Completed Items: Displays items you've checked off.
- Show Only Due Items: Hides items that are not yet due.
- Record Complete Date: Replaces due date with the completion date when you complete (check) the item.
- Show Due Dates: Displays item due dates, and inserts an exclamation mark next to overdue items.
- Show Priorities: Displays the priority setting for each item.
- Show Categories: Displays the category for each item.

3. Choose OK.

Press Menu to access other features such as importing phone numbers into the To Do list.

If you turn on the Show Due Dates option in the To Do Preferences screen, you can tap directly on the due date in the To Do List to choose a new date.

Memo Pad


Each Memo Pad item can include 4,096 characters of text.

You can assign categories to Memo Pad items. Open the item you want to change, choose the pick list in the upper-right corner, then select a category.

Memos are a great way to store notes on your Treo.

Creating a memo

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Memo Pad icon.
4. Enter the text you want to appear in the memo.
5. Choose Done.



Deleting a memo

1. Choose the memo you want to delete.
2. Press Menu .
3. From the Record menu, choose Delete Item (/D).
4. Choose OK.


CityTime

The CityTime world clock displays the day and time in your home city and in four other cities around the globe. Whether you're travelling or at home, it's easy to keep track of the best time to reach your business associates, friends, and family in far away places.

Setting your Home City

The Home City serves as a point of reference for your other city selections. The Home City time reflects the current system time (unless you have changed locations, see page 92). The information displayed for all the other cities is based on the day and time in your Home City.

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the CityTime icon.
4. Press Menu .
5. From the Options menu, choose Select Home City (/H).
6. Choose the Home City pick list, then select the city closest to your location (in the same time zone).
7. Choose OK.



A. Home City

Selecting remote cities

In addition to your Home City, you can display the day and time for four other cities anywhere around the globe. These other cities are called remote cities.

1. Use the stylus to tap a pick list in the lower part of the CityTime screen, then select the city closest to the city you want to display.
2. Choose the remaining pick lists, then select the other three cities you want to display.

Adding cities

If the city you want to display is not in the predefined list, you can add it.

1. Press Menu (menu) .
2. From the Options menu, choose Edit Cities (/E).
3. Choose New.
4. Enter the city name and other information.
5. Choose OK.

Changing locations

If you travel, you can easily coordinate the system time on your Treo with the local time.

1. Press Menu (menu) .
2. From the Utilities menu, choose Change Location (/L).
3. Choose the To pick list, then select your new location.
4. Choose OK.

CityTime does not automatically update the system time for Daylight Savings Time.

Run your stylus over the map to see the time in other cities.


The shadow over the map represents nighttime moving across the globe.


Calculator

Calculator includes a basic calculator, plus an advanced calculator with scientific, financial and conversion functions.

Switching between Basic and Advanced Calculator modes

1. Press Menu (menu) .
2. From the Options menu, choose Toggle Mode (/M).





Selecting functions in Advanced Calculator mode

1. Switch to Advanced Calculator mode (see above).
2. Choose the pick list near the upper-left part of the screen, then select the Advanced Calculator function you would like to use:
   - Math: Advanced mathematical functions such as exponents, roots and logarithms.
   - Trig: Trigonometric functions such as sine, cosine, tangent and variants.
   - Finance: Financial calculator functions such as APR and amortization.
   - Logic: Hexadecimal characters in keypad, plus logic functions such as and, not, or and xor. In place of Float/Degrees (see below), this view includes options for class (bin, oct, SDec, UDec, hex) and bits (8, 16, 32).

You can tap the screen or use the keyboard to input numbers.

Choose Sto to store a number in one of ten memory slots. Choose Rcl to recall a stored number.

Choose Con to access a list of mathematical constants such as Avogadro's number or the speed of light.

- **Statistics:** Statistical functions such as sum, factorial and random number generator.
- **Weight/Temp:** Weight and temperature conversions for metric and English values.
- **Length:** Length conversions for metric and English values.
- **Area:** Area conversions for metric, traditional and English values.
- **Volume:** Volume conversions for metric and English values.



3. Choose the pick list near the upper-middle of the screen, then select how to display decimal values:
   - **Float (Floating point):** Position of decimal point varies according to calculation results.
   - **Fixed(x) (Fixed point):** Enter an integer for the number of decimal places to display, then select Fixed(x) to round calculations to that decimal place.
   - **Sci(x) (Scientific notation):** Enter an integer for the number of decimal places to display, then select Sci(x) to round calculations to that decimal place using scientific notation.
   - **Eng(x) (Engineering notation):** Enter an integer for the number of decimal places to display, then select Eng(x) to round calculations to that decimal place using engineering notation.
4. Choose the pick list near the upper-right of the screen, then select whether you want to display numbers in degrees, radians or grads.

Looking up contacts and other information

To access Name Lookup in other applications, choose the Lookup button if it appears.

With the built-in search features on your Treo, you can find information quickly:

- **Name Lookup:** Enables you to dial your Contacts by name. It locates people's phone numbers when you're in the Contacts list.
- **Find:** Searches through the text in all the applications on your Treo.

Name Lookup

You can access Name Lookup directly from the Contacts list. This feature helps you locate Contacts quickly by entering just a few letters of a Contact's name.

1. Press Phone.
2. Use the 5-way navigation control to access the Contacts list.
3. From the Contacts list, enter the first few letters of the Contact you want to find. You can enter:
   - First name (*JOH* for John) or
   - Last name (*SMI* for Smith) or
   - First name initial and last name (*JSM* for John Smith)



For example, entering SM displays Smilla Anderson, John Smith, and Sally Martin as shown above. Entering JSM finds only John Smith.

4. Do one of the following:
   - Highlight the contact name, then press Center to view the contents of the record.
   - Highlight any phone number, then press Center to dial.

Using Find

The Find feature locates any text in the built-in applications and databases, and in some third-party applications. The Find feature performs an exact search on a character string, including characters that are parts of words.

1. Press Option then Shift to open the Find dialog.
2. Enter the text you want to find.
3. Choose OK to start the search.
4. In the search results, choose the text you want to review, or choose Find More to search additional applications.



To search by company for a name you can't remember, open Find, and type the name of the company.

Find is not case-sensitive and it locates any word that begins with the text you enter. For example, entering plan finds planet, but not airplane.


Find searches through one screen's-worth of information at a time. At first, you may see search results from one application, or several. If you don't find what you need on the first screen, choose Find More to check other applications.

Beaming information

Your Treo is equipped with an IR (infrared) port that lets you beam information to another Palm Powered device with an IR port. The IR port is located on the top of your Treo, between the Wireless Mode button and the ringer switch, behind the small dark shield.

Beaming a record

1. Choose the record or category you want to beam.
2. Press Menu (menu).
3. From the Record menu, choose one of the following:
   - Beam (/B): Sends an individual record.
   - Beam Category (/Y): Sends all records in the current category.
4. When the Beam Status dialog appears, point the IR port on your Treo directly at the IR port of the receiving device.
5. Wait for the Beam Status dialog to indicate that the transfer is complete before you continue using your Treo.



You can store a beamed application on your phone, or send it to an expansion card inserted in the expansion slot.

Beam your business card in two key presses: in any Phone view, press Menu, then press M.



For best results, the path between the two devices must be clear of obstacles, and both devices kept stationary. If you have difficulty beaming, shorten the distance and avoid bright sunlight.

If you do not choose a category upon receiving a beamed item, the item is placed in the Unfiled category.

If you can't receive beamed information, try a soft reset (see page 131).

Beaming an application

Not all applications can be beamed. A lock icon appears on the Beam screen next to applications that cannot be beamed.

1. Press Applications Launcher.
2. Press Menu (menu).
3. From the App menu, choose Beam (/B).
4. Choose the Beam From pick list, then select whether the application you want to beam is located on your Treo or an expansion card.
5. Choose the application you want to transfer.
6. Choose Beam.
7. When the Beam Status dialog appears, point the IR port on your Treo directly at the IR port of the receiving device.
8. Wait for the Beam Status dialog to indicate that the transfer is complete before you continue using your Treo.

Receiving beamed information

1. Turn on your screen.
2. Point the IR port on your Treo directly at the IR port of the transmitting device to open the Beam Status dialog.
3. When the Beam dialog appears, choose a category for the entry.
4. Press Up ▲ to receive the beam or press Down ▼ to refuse it.

first month:

managing applications

Installing applications

On a Windows computer, you can also access the Install Tool dialog by selecting Install Tool under palmOne on the Start menu or from the Programs folder.

Your Treo comes with several applications built-in and ready to use. You can also install third-party Palm OS applications, such as business software, games, and more. To learn more, go to www.palmOne.com/software.

When you download an application to your computer, it is probably in a compressed format such as a .zip or .sit file. If the file is compressed, you need to use a decompression utility on your computer, before you install applications on your Treo.

These instructions tell you how to install basic .prc (Palm OS application) and .pdb (Palm OS database) files onto your Treo. Some Palm OS software uses an installer or wizard to guide you through the process. Consult the documentation that came with the software for details.


Installing applications from the Internet

You can install Palm OS applications directly from the Internet, using the Blazer web browser. When you download an application, it automatically installs on your Treo. Remember: Palm OS applications have .prc or .pdb at the end of their file names.


1. Launch the Blazer web browser (see page 53).
2. Go to the page that contains the link to the application you want to download.
3. Press Left ◀ or Right ▶ to highlight the link to the file, then press Center to initiate the download process.

Installing applications from a Windows computer

1. Double-click the .prc or .pdb file you want to install on your Treo.
2. A dialog may appear with a User drop-down list. Select your User Name from the list.
3. The Install Tool window appears. If you would like to install additional files, simply drag and drop them into the space in this window.
4. If you want to install an application to an expansion card, click Change Destination. Click the arrows to move the application to the expansion card pane, then click OK.
5. Click Done.
6. Perform a HotSync operation to install the application(s) on your Treo.



Before you can install an application on your Treo, you need to have the Palm Desktop synchronization software installed on your computer (see page 29).



Installing applications from a Macintosh computer

1. On your Macintosh, launch Palm Desktop.
2. From the HotSync menu, choose Install Handheld Files.
3. Select the User Name that corresponds to your Treo phone from the User drop-down menu.
4. Click Add To List.
5. Locate the .prc or .pdb file you want to install on your Treo. Highlight it and click Add File.
6. Perform a HotSync operation to install the application(s) on your Treo.

Getting help with third-party applications

If a you encounter a problem with a third-party application (such as an error message), contact the application's author or vendor. For general troubleshooting of third-party applications, see page 145.

Removing applications

If you decide that you no longer need an application, or want to free up memory on your Treo, you can remove applications from your Treo or an expansion card (for more on expansion cards, see pages 105-108). You can remove only applications, patches, and extensions that you install; you cannot remove the built-in applications that reside in the ROM portion of your Treo.

1. Press Applications Launcher.
2. Press Menu (menu).
3. From the Options menu, choose Delete (/D).
4. If you want to remove an application from an expansion card, insert the card into your Treo.
5. Choose the Delete From pick list, then select the location of the application you want to remove.
6. Choose the application that you want to remove.
7. Choose Delete to finish.
8. Perform a HotSync operation to remove the application from the Backup folder on your computer.



If the application re-appears on your device, you may need to manually delete it from your computer. Locate your Backup folder on your computer (Windows: C:\Program Files\palmOne\user name; Macintosh: Mac HD\Applications\palmOne\Users\user name). If you find a .prc or .pdb file for the application you just removed, delete the file from the Backup folder.

Some applications are factory-installed in your phone and cannot be deleted. These are listed with a lock icon next to them.


If you upgraded from a previous version of Palm Desktop software, your backup folder may be located in the Palm folder.

Applications deleted from your phone are kept on your computer, in the Archive folder of your user folder.

Using Application Info

The Info screens display basic statistics about the applications on your Treo.

1. Press Applications Launcher .
2. Press Menu (menu) .
3. From the App menu, choose Info.
4. At the bottom of the screen, choose the type of information you want to view:
   - Version: The version numbers of applications on your Treo.
   - Size: The size (in kilobytes) of applications and data on your Treo.
   - Records: The number of records in different applications on your Treo.
5. Choose Done.



Using expansion cards


The expansion slot on your Treo enables you to add Secure Digital (SD) cards and MultiMedia Cards (MMC) to extend the storage capacity of your Treo. For example, SD or MMC expansion cards can store:

- Pictures
- MP3 audio files
- Games
- eBooks
- Applications
- Databases
- ... and more

Although expansion cards are sold separately, your Treo includes a mock, non-functional card inside the expansion slot. When you do not have a functioning card inside the expansion slot, reinsert the mock card to protect the slot opening.

Inserting and removing expansion cards

1. Press down and release the mock card.
2. After you feel the expansion slot eject the mock card, remove the card from the expansion slot.



SD cards are faster than MMC cards for reading and writing data.


When not using the expansion card, reinsert the mock card to keep the expansion slot clean.

Warranty does not cover damage by Secure Digital (SD) cards which do not meet SD Memory Card Specifications. SD cards which do not meet SD Memory Card Specifications may damage Treo 600.

When you insert an expansion card, the card name appears as a category with a card icon next to the name. To switch between the applications on the expansion card and your phone, choose the category pick list in the upper-right corner, then select another category.

In order to run an application on an expansion card, you must have enough free space in the internal memory of your Treo to accommodate the program.

3. Hold your Treo with the screen facing you and the card with the notch in the lower-right corner next to the camera lens.
4. Insert the card into the expansion slot until you feel the card lock into place and hear the confirmation tone.



A. Notch
B. Camera lens

Launching applications on an expansion card

After you insert an expansion card in the expansion slot, you can launch any of the applications stored on the expansion card.

1. Insert the expansion card into the expansion slot. The Applications Launcher automatically appears.
2. Choose the icon for the application you want to launch.
3. Press Center to launch the application.



Copying applications to an expansion card

You can copy applications between your Treo and your expansion card.

1. Press Applications Launcher.
2. Press Menu (menu).
3. From the App menu, choose Copy (/C).
4. Choose the Copy To pick list, then select the destination: card name, or Phone.
5. Choose the From pick list, then select the location of the application you want to copy: card name, or Phone.
6. Highlight the application you want to copy.
7. Choose Copy to finish.





Viewing expansion card information

The Card Info application displays general information about the expansion card that is currently in the expansion slot

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Card Info icon.

Before you copy an application to an expansion card, make sure that it is compatible with Palm OS version 5.2 or higher. Some applications do not work with expansion cards and do not allow you to store data files in a location that is separate from the application.



Renaming an expansion card

If you change the contents of an expansion card, you may at some point want to rename the card to better match its contents.

1. Insert the expansion card into the expansion slot. The Applications Launcher automatically appears.
2. Choose the Card Info icon.
3. Press Menu (menu) .
4. From the Card menu, choose Rename Card (/R).
5. Type a new name for the card.
6. Choose OK.

Formatting an expansion card

Formatting an expansion card is similar to formatting a disk on a computer. When you format an expansion card, you erase all the data stored on the card.

1. Insert the expansion card into the expansion slot. The Applications Launcher automatically appears.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Card Info icon.
4. Press Menu (menu) .
5. From the Card menu, choose Format Card (/F).
6. Type a new name for the card.
7. Choose OK.

when you're ready: customizing your Treo

Phone settings


You can also adjust the ringer volume by pressing the volume buttons when a call is not in progress.

Want more ringtones? You can download them from the web to your phone (see page 57).

Selecting ringtones and messaging alert tones

You can set different tones and volumes for incoming phone calls, Calendar alarms, and Mail, MMS, and Messaging alerts.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Sound.
5. Choose the Application pick list, then select Phone, Mail, Calendar, MMS, or Messaging.
6. Choose the Volume box.
7. Choose each pick list, then select an alert volume.
8. Choose the Tones box.
9. Depending on the application, select alert tones from the pick lists that appear:
   - Phone
     - Known Caller Tone: An incoming call from someone in your Contacts or Favorites.
     - Unknown Caller Tone: An incoming call from someone identified by Caller ID who is not in your Contacts or Favorites.
     - Roaming Tone: A special tone for incoming calls when you're outside your home mobile network.
     - Voicemail Tone: A new voicemail.
     - Service Tone: A warning of a service change, such as moving into and out of a mobile network coverage area.



   - Mail
     - Message Tone: A message arrives with automatic delivery
   - Calendar
     - Alarm Sound: The tone played the first time your alarm goes off
     - Reminder Sound: The tone played if an alarm is not acknowledged and the alarm repeats itself
     - Play Sound: The number of times an alert tone will play during the alarm sequence
     - Repeat Alarm: The number of times the alarm repeats itself if not acknowledged
     - Every: The interval between alarm repeats if not acknowledged
     - Alarm Preset: A default for the number of minutes, hours, or days before the event that the alarm goes off
   - MMS
     - Message Tone: A new MMS message arrives
   - Messaging
     - Message Tone: A new text message arrives

Adjusting call volume

While a call is in progress, or while using the personal speakerphone, press the volume buttons on the side of your Treo to adjust call volume.


You can also preview, send, and delete sounds on your phone. From Sound Preferences, choose the Tones box. Choose Manage, then choose Play, Send, or Edit to perform the corresponding action.

If you prefer to use the onscreen Dial Pad, assign the Dial Pad as the default wallpaper.

If you remove the Dial Pad as the wallpaper, you can still access it quickly. Press Phone, then press center. Dial Pad is always the first selection in your redial list.

Assigning a caller ID picture and ringtone

1. Press Phone .
2. Press Up ▲ to access your Favorites buttons.
3. Highlight the Favorites button you want to give a picture caller ID.
4. Press Menu (menu) .
5. From the Edit menu, choose Edit Favorites Button (/E).
6. Choose More.



7. Choose Select Image.
8. Choose the picture you want to assign to the selected Favorites button.
9. Choose Select.
10. From the ringtone pick list, choose a caller ID ringtone.
11. Choose OK.

Choosing Wallpaper for the Phone screen

If you have images stored on your Treo, you can select different wallpaper for the Main view in the Phone application.


1. Press Phone .
2. Press Menu (menu) .
3. From the Options menu, choose Display Preferences.
4. Choose the pick list at the top of the screen, then select Show Wallpaper.
5. Choose a Wallpaper image for your Phone screen.
6. Choose OK.

System Sound settings

You can immediately silence all sounds on your Treo, including phone ringtones, Calendar alerts, and system sounds. This does not mute the speaker on your Treo during a phone call.

1. Slide the ringer switch to Sound Mode Off.
2. To hear all sounds again, slide the ringer switch to Sound Mode On.

When you slide the ringer switch back to the Sound Mode On position, it restores the previous sound settings. For example, if the Phone ring volume is set to 7 and you slide the ringer switch to Sound Mode Off, you will not hear the phone ring. When you move the ringer switch back to Sound Mode On, the Phone ring volume is still set to 7.



A. Sound Mode On
B. Sound Mode Off

If the ringer switch is set to no sound, the ringer setting overrides the sound settings and all sounds are turned off.

Your Treo includes a silent alarm that vibrates when the ringer switch is set to Sound Mode Off.

Display and appearance

Turning on the keyboard backlight

1. Press Option then . The backlight illuminates the keys, and the screen dims slightly.
2. The backlight will turn off if the keyboard is not in use.

Adjusting the contrast and brightness

Depending on the lighting conditions in which you're using your Treo, you may need to adjust the screen contrast and brightness.

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Display.
5. Choose the slider, and use Left and Right to adjust brightness.
6. Choose the slider, and use Left and Right to adjust contrast.

Changing the screen font

You can change the screen font in Calendar, Contacts, Memo Pad, Messaging, and To Do List.

1. Launch the application in which you want to change the font.
2. Press Menu .
3. From the Options menu, choose Font (/F).
4. Choose a font style:



A. Small font
B. Small bold font
C. Large font
D. Large bold font

5. Choose OK.

Aligning the touchscreen

Occasionally, your Treo touchscreen may need to be readjusted. If this occurs, you may see the wrong feature being activated when you tap the screen. To fix the problem, you can recalibrate the touchscreen any time.

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Touchscreen.
5. Follow the onscreen instructions.

Changing the system color scheme

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select General.
5. Choose the Colors pick list, then select a color scheme.

Applications Launcher settings

The Applications Launcher displays each application as an icon, or you can view them as a list.

1. Press Applications Launcher.
2. Press Menu.
3. From the Options menu, choose Preferences (/R).
4. Choose the View By pick list, then select List.
5. Choose OK.

To create a new category, choose the category pick list, then select Edit Categories. Choose New, then enter the category name. Choose OK to close the dialog, then choose OK.

Arranging applications by category

You can assign an application to a category and then display a specific category of applications in the Applications Launcher.

1. Press Applications Launcher.
2. Press Menu (menu).
3. From the App menu, choose Category (/Y).



4. Choose the pick list next to each application, then select a category.
5. Choose Done.

Displaying applications by category

Do one of the following:

- Press Applications Launcher repeatedly to cycle through the categories.
- Choose the pick list in the upper-right corner, then select a category.

Button settings


You can also pick an application to launch from the HotSync button on the cable.

To restore all of the buttons and key combinations to their factory settings, choose Default.

Buttons Preferences

Buttons Preferences let you choose which applications are associated with the buttons on your Treo.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Buttons.
5. Choose the pick list next to the button or key combination you want to re-assign, then select an application.





Setting default applications

Sometimes, one application looks for another application to handle data (for example, a mail application might launch a browser when you choose a link in an email message).

1. Press Applications Launcher.
2. Choose the pick list in the upper right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Default Apps.
5. Choose each pick list, then select the application you want to associate with that function.

Date and time settings

Setting the date and time

Date & Time Preferences enable you to set the time, date, time zone, and daylight savings setting for your Treo.


1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Date & Time.
5. Choose the Set Date box. Highlight the current year, month, and date, then press Center to set the date.
6. Choose the Set Time box. Using the stylus, tap the up and down arrows to select the current time, then choose OK to set the time.
7. Choose the Set Time Zone box. Choose the time zone for your location, then choose OK to set the time zone.
8. Choose the Daylight Saving pick list, then select On or Off.



Setting date and time formats

Formats Preferences enable you to choose number conventions based on geographic regions. For example, in the United Kingdom, time often is expressed using a 24-hour clock. In the United States, time is expressed using a 12-hour clock with an AM or PM suffix. All the built-in applications on your Treo use the Format Preferences settings.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Formats.
5. Set any of the following preferences:
   - Preset to: The standard number conventions for your country. When you select a country, the other Formats Preferences are automatically set to that country's conventions. You can also edit each option individually.
   - Time: The time format. Select HH:MM to display a 24-hour clock.
   - Date: The date format.
   - Week starts: The first day of the week (usually Sunday or Monday).
   - Numbers: The format for numbers with decimal points and commas.



The Week starts setting controls the Day, Week, Month, Year, and List views in Calendar and all other aspects of your phone that display a calendar.


General Preferences

The Auto-off setting conserves battery power by turning off your phone's screen. It does not turn off Wireless Mode so you can still receive calls, email, and text messages after the automatic shutoff period.

The system and game volume settings apply when the ringer switch is set to the on position.

General Preferences enable you to set the auto shutoff interval, the beam receive feature, sounds, and screen colors for your Treo.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select General.



5. Set any of the following preferences:
   - Auto-off After: The time that elapses before your screen turns off automatically.
   - System Sound: The volume for system beeps and alerts.
   - Game Sound: The volume for game sounds.
   - Beam Receive: The setting for whether you want your Treo to receive beamed information.
   - Colors: The set of predefined colors for the system display.

Locking your phone and data

When you receive or make a call, the touchscreen on the Active call screen may be automatically disabled to prevent accidental termination of a call. You must use the 5-way navigation control to access the buttons on the Active call screen. Check the Keyguard settings in Preferences.

Your Treo includes several features that help you protect your phone from inadvertent use and keep your data private. The built-in security software enables you to use your Treo for emergency calls even if the handset is locked.

- Keyguard: Manually disables all buttons and the touchscreen to prevent accidental presses in your briefcase or pocket.
- Auto-Keyguard and touchscreen lockout: Automatically enables Keyguard after a period of inactivity, and lets you disable the touchscreen during an active call or call alert.
- Phone Lock: Requires a password to make and receive calls with your SIM card.
- System password lock: Requires a password to see any data on your Treo.
- Private records: Masks or hides items marked as private, and requires a password to view them.

Keyguard

Your Treo includes a feature that locks the keyboard, so that you don't accidentally press buttons or activate screen items while the phone is in a pocket or bag.

1. With the Treo screen on, press Option and the Screen button to enable Keyguard.
2. To disable Keyguard, press Center.

Auto-Keyguard and touchscreen lockout

Auto-Keyguard lets you automatically lock the keyboard after a period of inactivity.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Keyguard.
5. Set any of the following preferences:
   - Auto-Keyguard: The period of inactivity that passes before the keyboard automatically locks.
   - Disable touchscreen when: The conditions under which the touchscreen disables.

To change your password, choose the Password box, enter your current password, then enter the new password. To delete your password, choose the Password box, then choose Unassign.

Important: If your SIM card is locked and you enter the wrong PIN more than three times, your SIM will be blocked, and you must call your mobile service provider for your unique PUK (Pin Unlock Code).

Phone Lock

You can lock your SIM card to prevent unauthorized use of your mobile account. When your SIM card is locked, you must enter the correct PIN code to unlock it, even if you move it to a different phone.

1. Press Phone.
2. Press Menu.
3. From the Options menu, choose Phone Lock (/L).
4. Check the Lock SIM box.
5. When prompted, enter the current PIN and choose OK. Unless you changed your PIN code, enter the default PIN code, provided with your mobile service provider's account materials.
6. If you want to change the PIN, choose Change PIN, enter a new PIN, then choose OK to accept it. Repeat this step to verify the new PIN.
7. Turn Wireless Mode off to activate the phone lock feature.
8. To turn Wireless Mode on again, press and hold the Wireless Mode button, enter your PIN, then choose OK to unlock your phone.

Your SIM card locks again when you turn off Wireless Mode and then turn it back on. To permanently unlock your SIM card:

1. Press Menu.
2. From the Options menu, choose Phone Lock (/L).
3. Uncheck the Lock SIM option.
4. When prompted, enter the current PIN and choose OK.

System password lock

To protect your personal information, you can lock the system so that you need to enter your password to access any of your data or use other features of your Treo.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Security icon.
4. Choose the Password box.
5. Assign a password and a password hint to your Treo.
6. Choose the Auto Lock Handheld box.
7. When prompted, enter your password.
8. Choose one of the following options:
   - Never: Prevents your Treo from locking automatically.
   - On power off: Locks your Treo when you turn off the screen, or when it shuts off with the auto-off feature.
   - At a preset time: Locks your Treo at a specific time of day.
   - After a preset delay: Locks your Treo after a period of inactivity.





Important: If you lock your system, you must enter the exact password to unlock it. If you forget the password, you need to perform a hard reset to resume using your phone. Performing a hard reset deletes all the records in your phone. However, you can restore all previously synchronized data at the next HotSync operation (see page 137).

To lock your system manually, choose Lock & Turn Off, and then choose Off & Lock.

Setting Owner Preferences

You can use Owner Preferences to record information that you want to associate with your Treo, such as your name, company name, and phone number. If you lock your keyboard, the Owner Preferences information appears on the screen that requests your password to unlock it, and you must also enter your password to change the Owner Preferences information.

1. Press Applications Launcher.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Owner.
5. If you assigned a password with the Security application, choose Unlock, enter your password, then choose OK to continue.
6. Type the text that you want to appear in the Owner Preferences screen.



Private records

In most applications you can mark individual entries as private. All private entries remain visible and accessible until you select the Security setting to hide or mask them. When you hide entries, they do not appear anywhere in the application. When you mask entries, a visual placeholder appears where the entry would normally appear. If you define a password, you must enter it to display private entries. If you do not define a password, you (or anyone else) can reveal private entries without a password.

1. Display the entry that you want to mark private.
2. Choose Details.
3. Check the Private box.
4. Choose OK.

Hiding or masking all private records

1. Make sure the records you want to mask are marked private.
2. Press Applications Launcher.
3. Choose the pick list in the upper-right corner, then select All.
4. Choose the Security icon.
5. Choose the Current Privacy pick list, then select either Hide Records or Mask Records.

Viewing all private records

1. Make sure the records you want to mask are marked private.
2. Press Applications Launcher.
3. Choose the pick list in the upper-right corner, then select All.
4. Choose the Security icon.
5. Choose the Current Privacy pick list, then select Show Records.
6. If the Show Private Records dialog appears, enter your password, then choose OK.

As a security measure, masked Contacts records are temporarily hidden when you perform a search. So you will not see a placeholder for masked entries when viewing the results of a Lookup or Find request.

Viewing private entries in a specific application

1. Launch the application that contains the private entries you want to display.
2. Press Menu (menu) .
3. From the Options menu, choose Security (/H).
4. Choose the Current Privacy pick list, then select Show Records.
5. Choose OK.

Security and Palm Desktop (Windows)

Palm Desktop for Windows observes the security password for your Treo. If you forget your Treo password, you cannot view your data in Palm Desktop. You can change your password, but all records marked as Private will be deleted. You can restore these records at the next HotSync operation.

1. Press Applications Launcher .
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Security icon.
4. Choose the Password box.
5. Choose the Lost Password box.
6. Choose Yes.

If you want additional security for Palm Desktop files, you may wish to purchase a third-party solution.

if something happens:
help

???



Always use the same language for your Treo and your desktop software. Otherwise, you may lose data.

Upgrading from another Palm Powered device

To transfer all compatible applications and data from your previous device to your new Treo:

1. Perform a HotSync operation with your old device and your old desktop software to back up your data one last time.
2. Install the Palm Desktop synchronization software from the CD that came with your Treo (see page 29). During the installation process, perform a HotSync operation with your new Treo. When prompted to choose a user name for your new Treo, be sure to select the existing user name for your *old* device.
3. Some third-party applications may be quarantined by the HotSync Manager because they are not compatible with the Palm OS 5.2 on your Treo. Do not manually install any quarantined files (see the documentation that came with the third-party applications for more information).
4. If you plan to continue using your old device, perform a hard reset (see page 132) to remove its associated user name. Each device you synchronize with your computer must have a unique name. The next time you synchronize with your *old* device, be sure to assign it a new user name.

After upgrading, there are a few things you need to know about your new Treo:

- Address Book: This application is now called Contacts. To launch Contacts, press Phone, then use the 5-way navigation control to choose Contacts.
- Date Book+: This application is now called Calendar. To access this application, press Calendar.

- Applications Launcher: Some previous Palm Powered devices called this the Home screen. To access this screen, press Applications Launcher.
- Find: Some previous Palm Powered devices launched this global search engine by tapping the magnifying glass icon in the Graffiti area. Now you can access it by pressing Option and Shift together.
- Menu commands: Users familiar with Graffiti's Menu launch command can now access system menus by pressing Menu (menu) (see page 22).
- Backlight: Treo includes a keyboard backlight that also dims the screen slightly for low light conditions. While your Treo screen is on, press Option then P to turn on the keyboard backlight.
- Center button: If you used a previous Treo phone, you might be accustomed to pressing Spacebar to activate commands or dial numbers. With this Treo phone, we recommend pressing Center instead.
- Screen button: The fourth button on the right is used to control the screen and is not an application button. However, you can remap this button to your favorite application if you wish (see page 117).
- Internet connection: This Treo was designed to work on GPRS wireless data networks. When you sign up for a GPRS wireless data account, these settings are automatically configured on your Treo. If you prefer to use an older, manual dial-up connection method, enter your Internet service provider's settings in Network Preferences.
- 5-way navigation compatibility: Some Palm OS 5 applications are optimized for 5-way navigation on devices other than Treo. Therefore you may notice inconsistencies with software that is not designed with Treo in mind.

???



To access a menu shortcut, press Menu, then the letter for the shortcut.

Some third-party utilities allow you to backup your old device's data onto an SD or MMC card, and then transfer the data to your Treo. We do not recommend this method because any incompatible applications are also transferred to your Treo.

???

Trouble installing Palm Desktop?

The CD included with your Treo installs the software and drivers that let you synchronize with Palm Desktop software or Microsoft Outlook for Windows. If you want to synchronize with a different Personal Information Manager (PIM), you must install a third-party solution. Contact the PIM's author or vendor to learn if software is available for your Treo.

1. Restart your computer.
2. Quit any active applications, including virus scanners and Internet security applications.
3. Make sure you're installing the version of Palm Desktop that came on the CD with your Treo. Other versions of Palm Desktop may not work with this Treo.
4. Make sure your computer profile includes administrator rights to install software. In large organizations, these are usually granted by the system administrator.

Resetting your Treo

???

Soft reset

A soft reset is similar to restarting a computer. If your Treo is not responding or you have trouble synchronizing with your computer, a soft reset may help. Unless your battery is extremely low, a soft reset should not affect your data.

1. Unscrew the stylus tip to access the reset tool.
2. Use the reset tool to gently press the reset button on the back of your Treo.



If you need to perform a system reset and disable conflicting applications, always end the process with a soft reset. This returns your Treo to normal operation.

System reset

A system reset, also called a *safe* or *warm* reset, tells your Treo to stop what it's doing and start over again without loading any system extras. If your Treo loops or freezes during a soft reset, a system reset may help. Performing a system reset allows you to get out of an endless loop in order to uninstall a third-party application causing the looping. Unless your battery is extremely low, a system reset should not affect your data.

1. Unscrew the stylus tip to access the reset tool.
2. While holding Up ▲, use the reset tool to gently press the reset button on the back of your Treo.
3. When the Palm Powered logo appears, release Up ▲.

Hard reset

A hard reset erases all data and third-party software on your Treo. Never perform a hard reset without first trying a soft and system reset. You can restore previously synchronized data with the next HotSync operation.

A hard reset can tell you whether a problem stems from your Treo or an application installed on it. If you do not experience the problem after you perform a hard reset, the problem may be related to software you installed. See page 145 for suggestions on diagnosing third-party software issues.

1. Unscrew the stylus tip to access the reset tool.
2. While holding the Wireless Mode button ⏻, use the reset tool to gently press the reset button on the back of your Treo.
3. When the Palm Powered logo appears, release the Wireless Mode button ⏻.
4. When the warning appears, press Up ▲ to confirm the hard reset.
5. If a language selection screen appears, select the same language you selected for your desktop software.

Screen

The screen appears blank

1. Look closely at the screen. If you can see a dim image, try adjusting the screen contrast and brightness (see page 114).
2. If that doesn't work, perform a soft reset (see page 131).
3. If that doesn't work, connect the Treo to the AC charger (see page 12) and perform a soft reset again.
4. If that doesn't work, perform a hard reset (see page 132).

The screen doesn't respond accurately to taps or activates wrong features

1. Press Applications Launcher ⌂.
2. Choose the pick list in the upper-right corner, then select All.
3. Choose the Prefs icon.
4. Choose the pick list in the upper-right corner, then select Display.
5. Choose Touchscreen.
6. Follow the onscreen instructions to recalibrate the touchscreen.

???

Network connection

Become familiar with low coverage areas where you live, commute, work, and play. Then, you will know when to expect signal strength issues.

Signal strength is weak

1. If standing, move about 10 feet in any direction.
2. In a building, move near a window. Open any metal blinds.
3. In a building, move outdoors or to a more open area.
4. Outdoors, move away from large buildings, trees, or electrical wires.
5. In a vehicle, move your Treo level with a window.

Treo won't connect to the mobile network

1. Try our suggestions above for weak signals.
2. Turn off Wireless Mode and turn it on again (see page 14).
3. Remove the SIM card and re-insert it (see page 13).
4. Perform a soft reset (see page 131).

Treo hangs up when I hold it to my ear

You may be accidentally pressing the onscreen Hang Up button with your cheek. Try holding the phone so your face doesn't press against the screen. If this is not convenient, you may want to disable the touchscreen during active calls (see page 122).

Treo makes or answers calls when it's in a briefcase or pocket

Items in your briefcase or pocket may be pressing the onscreen Answer button, or otherwise activating screen items. If this happens, you may want to disable the touchscreen during incoming calls (see page 121).

I can't tell if data services are available

The following icons indicate data services:

	Wireless Mode is on and a GPRS network is within range.
	Wireless Mode is on but you are not connected to any GPRS network.
	You are connected to a GPRS network and a data session is active (for example, when you are browsing the web). You can still receive calls.
	You are actively using a dial-up (CSD) connection.

Wireless Mode seems to turn off by itself

If a system error and reset occurs, Treo automatically turns on Wireless Mode if it was on before the reset. However, if the Treo can't determine whether Wireless Mode was on before the reset, it does not turn on automatically (see page 14).

Treo won't connect to the Internet

Your Treo supports GPRS. To connect to the Internet, you must subscribe to and activate GPRS data services with your mobile service provider.

- Press and hold the Wireless Mode button ⏻ to turn off Wireless Mode. Then, press and hold the same button to turn it back on again.
- Perform a soft reset (see page 131).
- For additional suggestions, see www.palmOne.com/support.

???

- Contact your mobile service provider to verify that your subscription plan includes high-speed data services and that these services have been correctly activated. Your mobile service provider should also be able to tell you if there are any outages in your location. Confirm your user name and password.
- Confirm that high-speed data services are correctly configured on your Treo:
  1. Press Applications Launcher.
  2. Choose the pick list in the upper-right corner, then select All.
  3. Choose the Prefs icon.
  4. Choose the pick list in the upper-right corner, then select Network.
  5. If the Service field says Untitled, choose the Service pick list, then select the appropriate data service. Call your mobile service provider for more information about their data services
  6. Choose Modify and enter the user name and password you received from your mobile service provider.
  7. Choose OK.

I can't send or receive text or multimedia messages

- Make sure the SIM card is inserted correctly (see page 13) and Wireless Mode is turned on (see page 14).
- Contact your mobile service provider to verify that your plan includes messaging services, that these services have been correctly activated, and that they are available at your location (your mobile service provider should be able to tell you if messaging services have been experiencing transmission delays).
- If possible, contact the recipient or sender of the message, and make sure the receiving device can handle the type of file that is being sent.
- If an SMS message arrives but does not display an alert, perform a soft reset (see page 131).

Synchronization (HotSync)

Synchronization lets you back up your Treo data onto your computer. If you ever need to perform a hard reset or otherwise erase all your data on your Treo, you can perform a HotSync operation to restore the data. To make sure you always have an up-to-date backup of your data, synchronize frequently.

Before you attempt a HotSync operation, make sure you have installed the Palm Desktop and HotSync Manager software from the CD that came with your Treo.

Desktop does not respond to HotSync attempt

As you complete the following steps, perform a HotSync operation after each. If the synchronization is successful, you do not need to complete the remaining steps.

1. Verify that the HotSync cable is securely connected at all points (see page 28).
2. Make sure that the HotSync Manager is running:
   - **Windows:** Click the HotSync Manager icon in the lower-right corner and make sure Local USB is checked. If you don't see the HotSync Manager icon, click Start, select Programs, select palmOne and then select HotSync Manager.



   - **Macintosh:** Find the Palm folder on your Mac hard drive. Double-click the HotSync Manager icon in the Palm folder. In the Connection Settings panel, set the Local Setup Port to palmOne USB.

Every device needs a unique name. Never synchronize more than one device to the same user name on your computer.

If you're using an optional serial HotSync cable, click the HotSync Manager icon on your computer and make sure Local Serial is checked.

3. Verify with your computer hardware vendor that your operating system supports your internal USB Controller.
4. Perform a soft reset (see page 131).
5. If problems persist and you're synchronizing through a USB hub, try connecting the HotSync cable to a different USB port, or directly to your computer's built-in USB port.
6. Uninstall Palm Desktop.
7. Reboot your computer.
8. Reinstall Palm Desktop.

HotSync operation starts but stops without finishing

As you complete the following steps, perform a HotSync operation after each step. If the synchronization is successful, you do not need to complete the remaining steps.

1. If you upgraded from a previous Palm Powered device, there may be conflicts with files from your previous device. Locate your Backup folder (Windows: C:\Program Files\palmOne\user name; Macintosh: Mac HD\Applications\palmOne\Users\user name). Move the Backup folder to another location. Perform a HotSync operation, and then manually reinstall any third-party applications you want on your new phone, from the items in the old Backup folder you moved.
2. (Windows only) If the Windows New Hardware Wizard appears, the HotSync process may be timing out before the wizard completes its job. Follow all instructions in the New Hardware Wizard, and attempt another HotSync operation.
3. Uninstall Palm Desktop.
4. Reboot your computer.
5. Reinstall Palm Desktop.

HotSync operation finishes but data does not appear where it should

1. Make sure you're synchronizing with the intended desktop Personal Information Manager (PIM). The CD that came with your Treo lets you synchronize with Palm Desktop or Microsoft Outlook for Windows. If you use a different PIM, you will need to install third-party software to synchronize. Consult the company that makes the PIM for more information.
2. If there are multiple Palm Powered devices synchronizing with your computer, make sure you are synchronizing with the correct user name. If data is not appearing in Palm Desktop, make sure the correct user name is selected in the toolbar of Palm Desktop.
3. Launch the HotSync Manager application on your computer, and make sure the necessary conduits are set to Synchronize the files.
4. Uninstall Palm Desktop.
5. Reboot your computer.
6. Reinstall Palm Desktop.
7. (Outlook only) With the included software, your Treo can synchronize with the root folders of Contacts, Calendar, Tasks, and Notes. If you want to synchronize with a global Exchange Address Book, you must copy the addresses to your local Contacts list in Outlook (right-click the addresses, and select Add to Personal Address Book).
8. (Outlook only) Outlook subfolders and public folders are not accessible with the included software. You may wish to use a third-party solution instead.
9. (Outlook only) If you're trying to synchronize offline, be sure to set your Outlook Calendar, Contacts, Notes, and Tasks to be available offline.



The software that lets you synchronize with Microsoft Outlook is called PocketMirror, from Chapura, Inc. When you install the Treo software from the CD, PocketMirror will be activated if you choose the option to synchronize with Outlook.

Mail

If you use web-based email (Hotmail, AOL) or corporate email (Microsoft Outlook, Lotus Notes), the Mail application that comes with Treo will not work. You must use a third-party solution.

Contact your email service provider if you are not sure whether your email account is POP3-compatible.

I can't receive email

First, make sure you have Internet access: launch the Blazer web browser to see if you can view a web page you've successfully viewed before. If necessary, ensure that you are viewing the page directly from the Internet: press Menu (menu), then from the Page menu, choose Refresh. The email account you use with the Mail application must be POP3-compatible, such as Earthlink.

1. In Mail, press Menu (menu).
2. From the View menu, choose Edit Accounts.
3. Highlight an account, then choose Edit.
4. Make sure your email address and password are correct.
5. Choose the Server tab.
6. Check the Incoming (POP3) Server and Outgoing (SMTP) Server settings for your email account. If you do not have this information, please contact your email service provider.
7. Choose OK to accept these settings.
8. Choose Done.

Other things to consider when trying to retrieve email:

- In Mail, press Menu (menu), then from the Options menu, choose Connection Log. This log contains details and error messages from the last several send and receive sessions.
- Mail does not automatically retrieve your email when:
  - Your radio is off.
  - You are outside the automatic delivery time window. See page 79 for more information on customizing your mail settings.

- Some email preferences may not work with your Treo or your mobile network's capabilities. To view these settings, press Menu (menu), then from the View menu, choose Edit Accounts. Choose an account and press Right ▶ to choose Edit. Each setting is explained in detail in the Tips for that tab. Contact your email service provider to determine the correct settings for your email account.
- Auto-retrieve settings apply to only the mail account you are currently viewing. If you have two accounts, Treo auto-retrieves emails for only the current account. To change the current account, press Menu (menu), then from the View menu, choose another account.

I can't open or save an attachment

- You can only open attachments that are supported by the built-in software on your Treo, or by third-party applications that can open the attachment type. If you can't open an attachment on your Treo, the attachment appears with the paperclip icon.
- Large attachments may be truncated, which prevents you from saving them. Scroll to the bottom of the email message to see if this is the case. To retrieve the rest of the attachment, press Menu (menu), then from the Message menu, choose Get Entire Message. This downloads the remainder of the attachment so that you can save it.

I can't send email

Your ability to send email depends on several factors. You may need to enter additional information into the Mail application. Also, some mobile service providers use Internet security requirements that may cause difficulties with your email service.

When retrieving messages, you may see a larger number of messages than you actually receive (e.g. you see Retrieving 1 of 10 messages and you only receive 3 messages). If this happens, check your Delivery Preferences. If the preferences are set to retrieve only recent emails, any older emails may appear in the total number, but are not delivered to your Treo.

First, obtain this information from your mobile service provider*:

- Does the Internet connection they provide support sending SMTP emails?
- Is there an alternate SMTP authenticated server used for email?
- Is SSL required for POP3 or SMTP email transactions?

* If you are using a circuit-switched data (CSD) connection, contact your Internet service provider for this information, instead of your mobile service provider.

Then, contact your email service provider for this information:

- Does this provider support the POP3 protocol? If they don't, you won't be able to use Mail for this email account.
- Does this provider allow email access from mobile phone networks?
- What is the User Name for your email account?
- What is the Outgoing (SMTP) server for your email account? Does it require authentication? Does it require SSL? Does it use the same User Name for POP3 and SMTP?

Then, follow these steps:

1. In Mail, press Menu (menu).
2. From the View menu, choose Edit Accounts.
3. Highlight the account you want to edit, then choose Edit.
4. Make sure your email address and password are correct.
5. Choose the Server tab. Tap the Information icon for a detailed explanation of Server settings.
6. Enter the correct Incoming (POP3) Server setting for your email account. Enter the SMTP server used by your mobile service provider for email.
7. Choose the Advanced tab. Tap the Information icon for a detailed explanation of Advanced settings.
8. Check or uncheck the boxes for SSL required for POP3 and SSL required for SMTP, according to the information you received.
9. If necessary, enter your User Name. Also enter your email password in the box.
10. Choose OK to accept these settings.
11. Choose Done.

Web

I can't access a page

First, make sure you have Internet access: launch Blazer and try to view a web page you've loaded before. Press Menu (menu), then from the Page menu, choose Refresh to get the latest version from the Internet. After confirming your Internet connection, try to view the page in question again, and press Menu (menu), then from the Page menu, choose Refresh.

If you're still having trouble, the page may contain elements that are not supported by Blazer. These include Flash, Shockwave, VBScript, WML script, and other plugins.

Some websites use a redirector to their true home page (for example, if you enter the address http://www.palmOne.com/support it may resolve to http://www.palmOne.com/us/support). If Blazer can't follow the redirect, try using a desktop browser to see the landing page of the redirector, and enter that address in Blazer.

An image or map displays too small on the Treo screen

Blazer has two modes: Optimized and Wide Page. Optimized Mode re-sizes all images and page elements to fit in a single column on the Treo screen. Switch to Wide Page mode to see the full-size image (see page 54).

A secure site refuses to permit a transaction

Some websites don't support certain browsers for transactions. Please contact the site's webmaster to make sure the site allows transactions using Blazer.

Treo can launch your email application when you choose an email address on a web page. If nothing happens when you choose the link, try setting up your email application first.

Camera

The Camera application takes pictures at Small picture size (160x120 pixels) and Large picture size (640x480 pixels, or .3 megapixel). Here are some tips for taking good pictures with the built-in camera:

- Clean the camera's lens with a soft, lint-free cloth.
- Take pictures in bright lighting conditions. Low-light images may be grainy, due to the sensitivity of the camera.
- Hold the camera as still as possible. You may want to support your picture-taking arm up against your body or a stationary object (such as a wall).
- Keep the subject of the pictures still. Exposure time is longer with lower light levels, so you may see a blur.
- For best results, verify that you have the brightest light source coming from behind you, lighting the subject's face. Don't take indoor pictures with the subject in front of a window or light.
- Make sure the subject is at least 18 inches away from the camera to ensure good focus.

Remember, when you synchronize, your Camera images are stored in the Treo Pictures folder on your hard drive (see page 62).

The Camera preview image looks strange

Some third-party applications overwrite the Treo's color settings with their own 8-bit color settings. This can affect the Camera preview mode. Delete third-party applications one by one until the preview image improves.

When using the camera in low light, you may see blue specks on the screen. Once you capture the image, the quality improves, and many of the blue specks disappear.

Third-party applications

Sometimes, third-party applications can cause conflicts on your Treo. Third-party applications that modify wireless features may require extra troubleshooting.

If you recently installed an application and your Treo seems to be *stuck*, try the following:

1. Perform a soft reset (see page 131).
2. If the problem persists, perform a system reset (see page 131).
3. Delete the most recently installed application from your Treo (see page 103).
4. If the problem persists, perform another system reset.
5. Delete other third-party applications one at a time until you eliminate the problem.
6. If none of the steps above are possible, you may wish to perform a hard reset (see page 132). Then, locate your Backup folder on your computer (Windows: C:\Program Files\palmOne\user name; Macintosh: Mac HD\Applications\palmOne\Users\user name). If you find a .prc or .pdb file for any applications you just removed, delete the file(s) from the Backup folder. Then, perform a HotSync operation to restore your data and applications.

Remember, not all third-party applications were written with the Treo keyboard and 5-way navigation in mind. You may encounter strange behavior or errors in these applications if you use the keyboard and navigation control.

Getting more help

Contact the author or vendor of any third-party software if you require further assistance.

Errors

Your Treo is designed to minimize interruptions, when a system error occurs. If Treo encounters a system error, it automatically resets itself and resumes functioning as normal. If possible, it even turns Wireless Mode back on if it was on before the error occurred.

Sometimes, you might want to know more about an error. Treo uses a special interface to show error messages in greater detail.

1. Press Phone.
2. Press Center, then choose Dial Pad.
3. Type # * 377, then press Center.
4. Review the screen with details about the conditions that lead up to the most recent automatic reset.
5. Choose OK.

Please note that third-party developers create their own error messages. If you do not understand an error message, please contact the developer of the application for help.

Making room on your Treo

If you store a large number of records, or install many third-party applications, the internal memory on your Treo may fill up. Here are some common ways to clear space on your Treo:

- Mail: Emails that have large attachments can quickly consume memory on your Treo. Delete emails with large attachments. If you have hundreds of messages with or without attachments, you may wish to delete older messages to make room (see page 78).
- Camera: Large size images take up a lot of memory. Move images to an expansion card or delete images from your Treo (see page 62).
- MMS: Multimedia content also can consume excessive memory. Move MMS content to an expansion card or delete large files from your Treo (see page 71).
- Internet: If you have set a large Blazer cache, you may wish to use Blazer's advanced Memory Management settings to clear all recent pages (see page 59).
- Third-party applications: You can delete infrequently used applications or move them to an expansion card (see page 103).

Also, remember that your Treo includes an expansion slot, and that you can store applications and data on expansion cards. However, you still need some free memory on the Treo itself to run applications from an expansion card.



Voice quality

Is the other person hearing an echo?

- Try decreasing the Treo's volume to avoid coupling or feedback on the other person's end. This applies to both speakerphone and the built-in handset speaker.
- Position the Treo handset closer to your ear to prevent sound leaking back to the microphone. Keep your hand away from the microphone hole, which is on the back of your Treo near the bottom of the device.
- If you're using Speakerphone mode with the device lying on a flat surface, try turning the Treo "face down" (screen facing the surface).

Are you hearing your own voice echo?

- Ask the other person to turn down their volume, or hold the phone closer to their ear.

Is your voice too quiet on the other end?

- Be sure to hold the bottom of the Treo, or the hands-free microphone, close to your mouth.

Glossary

ALS (Alternate Line Service): A service that enables two phone numbers to coexist on one phone/SIM. The Treo phone supports ALS, but be sure to contact your mobile service provider for regional availability of this service.

Alt (alternative) : A keyboard key. Type a letter on the keyboard, then press Alt to access variations such as international characters and symbols.

Applications Launcher : The view on your Treo from which you can launch all applications.

Auto-off interval: The time of inactivity that passes before the screen on your Treo turns off. Wireless Mode is unaffected by this setting.

Beam: The process of sending or receiving a data record or application using the infrared port on your Treo.

CSD (Circuit-Switched Data): A dial-up Internet connection. You pay for the connection time, not how much data you transfer. Contrast with GPRS.

GPRS (General Packet Radio Service): The next generation of mobile Internet connectivity that allows persistent data connections. You pay for the amount of data you transfer, not the connection time.

HotSync: The PalmSource technology that synchronizes your Treo and your computer with the simple press of a button.

HotSync Manager: The computer application that manages the synchronization with your Treo.

Infrared (IR): A way of transmitting data using light waves. The IR port on your Treo lets you transfer data between other IR devices within a short radius.

Install tool: The component of Palm Desktop software that enables you to install Palm OS applications and data on your Treo.

Lithium Ion (Li-Ion): The rechargeable battery technology used in Treo phones.

MMS (Multimedia Messaging System): An enhanced form of SMS messaging that lets you send pictures, animations, and ringtones almost instantly.

Option key : The keyboard button that lets you access the alternative feature that appears above the letter on each key.

Palm Desktop: A PIM application for computers that helps you manage your personal information and keep your personal data synchronized with your Treo.

Palm OS: The operating system of your Treo phone. A trademark of PalmSource, Palm OS is known for its simplicity of use and for the large number of applications that can be added to your Treo.

Phone : The application on your Treo that provides quick access to the most commonly used applications on your Treo.

PIM (Personal Information Management): A genre of software that includes applications such as Palm Desktop software, Microsoft Outlook, Lotus Notes, and ACT!. PIMs generally store contacts, schedules, to do items, and memos.

PIN (Personal Identification Number): The four-digit password assigned to your SIM card by your mobile service provider. Turning on the PIN lock secures your wireless account. See also PUK.

PocketMirror: Software included on the Treo CD that lets you synchronize with Microsoft Outlook (English language and Windows only). PocketMirror is made by a third-party company called Chapura, Inc.

PUK (Pin Unlock Code): A special extended password assigned to your SIM card. If you enter the wrong PIN more than three times, your SIM will be blocked, and you must call your mobile service provider for the PUK.

SIM (Subscriber Identity Module): The smartcard, inserted in your Treo, that contains your GSM mobile account information. SIM cards are portable between GSM phones – your mobile subscriber information moves to whatever phone houses the SIM.

SMS (Short Messaging Service): The service that exchanges short text messages almost instantly between mobile phones. These messages can usually include up to 160 characters. Treo phones can send and receive SMS messages while you are on a voice call.

User name: The name associated with your Treo that distinguishes it from other Palm Powered devices. When you first synchronize your Treo, you are asked to give it a user name.

Wireless Mode: The feature inside your Treo that controls the radio which enables you connect to the mobile network for wireless communications.

FCC Statement This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet or circuit different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help and for additional suggestions.

RF Safety Exposure To Radio Frequency Energy (SAR) Radio transmitting devices radiate Radio Frequency (RF) energy during its operation. RF energy can be absorbed into the human body and potentially can cause adverse health effects if excessive levels are absorbed. The unit of measurement for human exposure to RF energy is "Specific Absorption Rate" (SAR).

The Federal Communications Commission (FCC), Industrie Canada (IC), and other agencies around the world have established limits that incorporate a substantial safety margin designed to assure the safety of all persons using this equipment.

In order to certify this unit for sale in the US, Canada and Europe this unit has been tested for RF exposure compliance at a qualified test laboratory and found to comply with the regulations regarding exposure to RF Energy.

SAR was measured with the unit transmitting at its maximum certified RF power. Often, however, during normal operation the unit will transmit much less than maximum power. Transmit power is controlled automatically and, in general is reduced as you get closer to a cellular base station. This reduction in transmit power will result in a lower RF energy exposure and resulting SAR value.

FCC RF Safety Statement In order to comply with FCC RF exposure safety guidelines, users MUST use one of the following types of body-worn accessories.

1. A palmOne brand body-worn accessory that has been tested for SAR compliance and is intended for use with this product.
2. An accessory that contains NO metal (snaps, clips, etc) and provides AT LEAST 1 cm of separation between the users body and the unit.

Do NOT use the device in a manner such that it is in direct contact with the body (i.e. on the lap or in a breast pocket). Such use will likely exceed FCC RF safety exposure limits See www.fcc.gov/oet/rfsafety/ for more information on RF exposure safety.

Responsible party

(North America)
palmOne, Inc.
400 N. McCarthy Blvd.
Milpitas, CA 95035
USA
www.palmone.com

(Europe)
Vesey Chrichton
Buckhurst Court
London Road
Wokingham, Berkshire RG40 1PA,
UK

Antenna Care/Unauthorized Modifications Use only the supplied integral antenna. Unauthorized antenna modifications or attachments could damage the unit and may violate FCC regulations. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Potentially Unsafe Areas Potentially explosive atmospheres: Turn off your phone when you are in any areas with a potentially explosive atmosphere, such as fueling areas (gas or petrol stations) or storage facilities for fuel or chemicals.

Declaration of Conformity

Treo Model 600 palmOne declares that the above models of Treo smartphones are compliant with the regulations below. The declaration applies to the communicators and their associated accessories (power supply, headset, USB and serial cable) where applicable.

Maximum Measured SAR Values (W/kg)

Band:	850 MHz	900 MHz	1800 MHz	1900 MHz
Head SAR:	1.49	1.07	1.53	1.05
Body SAR:	.646	.703	.402	.336

EMC: EN 301 489
EN 310 420 (Dec 1999)
EN 50360 (July 2001)
FCC OET Bulletin 65 Supplement C
Radiated Emissions: EN 55022

GSM: EN 301 419-1(Apr 2000)
SAR: ANSI/IEEE C95.1 1992
EN 50361 (July 2001)
Safety: EN 60950: 2000 (Jan-2000)
Immunity: EN 55024

Using TTY

A TTY (also known as TDD or Text Telephone) is a telecommunications device that allows people who are deaf or hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your Treo 600 is compatible with select TTY devices. You can connect a TTY/TDD machine to your phone through the headset jack, but you cannot use your headset jack with a headset or handsfree kit, while this mode is enabled. Please check with the manufacturer of your TTY device for connectivity information and to ensure that the TTY device supports digital wireless transmission.

To use TTY, you may need to make additional arrangements with your mobile service provider. Please contact their customer service department for more information.

1. Press Phone.
2. Dial #*889, and choose Dial.
3. You will receive an onscreen alert that TTY is enabled.
4. To disable TTY, dial #*889 again, and choose Dial. A red "T" will appear at the top of the Phone screen whenever TTY is enabled.

index

5-way navigation control 10, 15, 18–21, 26, 36–40, 42–44, 47–48, 50–51, 82, 95, 121, 128, 129, 145
6-way calling. See Conference calls

A

AC charger 9, 12, 28
Accented characters 23–24
Active call 41, 42–44, 52, 121, 134
Add-on applications. See Third-party applications
Address Book. See Contacts
Adjusting volume 110–111, 113
Alarms and alerts
  MMS 70, 72
  preset 83
  setting 83
  SMS 65
  sound 110–111, 120
  vibrating 113
  voicemail 35, 41
Anniversaries. See Repeating events
Answering calls 39, 44, 46, 52, 134
Antenna 9, 150
Applications
  beaming 98, 148
  Blazer 26, 53–59, 100, 140, 143, 147
  buttons 10, 25–26, 49, 51, 73, 80, 117, 129
  Calculator 23, 26, 93–94
  Calendar 10, 25, 26, 42, 82–86, 87, 110–111, 113, 119, 120, 128, 139
  categories 26, 106, 116
  CityTime 91–92
  Desktop software 27, 29, 30, 47, 63, 82, 101–102, 103, 126, 128, 130, 132, 137–139, 148
  font style 115
  Info 104, 107, 117
  installing 27, 29, 77, 100–102, 128, 130, 131, 132, 139, 145, 147, 148
  Launcher 22, 26, 98, 100–104, 106–107, 116, 129, 148
  Mail 26, 73–80, 110–111, 140–142, 147
  Memo Pad 90
  MMS 5, 13, 69–72, 110–111, 147, 149opening 25–26, 49, 51, 65, 106
  Phone 10, 15, 16, 25, 26, 34–51, 95, 97, 110–112, 121–123, 149
  Preferences 36, 45–46, 54, 57, 58–59, 62, 67–68, 72, 76, 79–80, 84–86, 89, 110–126, 129, 141
  removing 103, 145
  security 53, 76, 121–126, 130, 141
  SMS 38, 49, 64–68, 111, 120, 149
  third-party 18, 73, 77, 96, 100–103, 126, 128, 129, 130, 131, 132, 138, 139, 140, 141, 145, 146, 147, 149
  To Do List 86–89, 120
Appointments. See Calendar
Archive files
  for deleted applications 103
  saving completed To Do items 87
Auto-off setting 31, 120, 123, 140

B

Backlight, keyboard 12, 14, 22, 31, 114, 129
Backup. See HotSync
Battery
  charging 12, 15, 31
  conserving power 12, 14, 31, 120
  gauge 12, 35
  low 31, 131
  type 148
  usage 35
Beaming
  applications 98, 120, 148
  business card 48, 97
  information 97–98, 120, 148
  location of IR port 9, 97
  problems with 120
  See also Infrared
Beep tone 14, 15, 106, 110–111, 113, 120
Birthdays. See Repeating events
Blazer
  bookmarks 54–56
  opening 26, 53
  overview 53
  installing applications from 100
  Preferences 58–59
  problems with 143, 147
  viewing web pages 53–54, 57–58
Boilerplates. See Templates
Bold font for text 115
Bookmarks 54–56
Brightness Control 31, 114, 133
Business card for beaming 48, 97
Buttons
  5-way navigation 10, 15, 18–21, 26, 36–40, 42–44, 47–48, 50–51, 82, 95, 121, 128, 129, 145
  application 10, 25–26, 49, 51, 73, 80, 117, 129
  Calendar 10, 25–26, 82–86, 117, 128
  HotSync 28, 30, 117
  Messaging 10, 25–26, 64–68, 73, 117
  Phone 10, 15, 16, 25–26, 34–51, 60, 95, 112, 122, 128, 146
  preferences 117
  ringer switch 9, 39, 97, 113, 120
  Screen 10, 14, 25–26, 121, 129
  volume 10, 16, 39, 110, 111, 113
  Wireless Mode 9, 14, 15, 122, 132, 135

C

Cable
  charger 12
  connecting to computer 28
  HotSync 9, 27–28, 30, 117, 137, 138
Calculator 23, 26, 93–94
Calendar
  adding events 82–84
  alarm 83, 110–111, 113, 120
  button 10, 25–26, 82–86, 117, 128
  changing events 83
  conflicting events 85
  deleting events 83
  display format 82, 84–86
  floating events 85
  fonts 115
  opening 25–26, 128
  Preferences 84–86
  repeating events 84
  scheduling events 82–84
  selecting date 82
  start of week 119
  switching views 82
  synchronizing 82, 139
  To Do List items 86
  untimed events 82, 83
  using during call 42
Calibration 15, 115, 133
Call
  5-way conference 44
  5-way navigation 42, 121
  active 42–44, 121
  answering 39, 44, 52
  barring 46
  conference 44
  data 35, 136
  dialing 15, 23, 36–38, 71
  emergency 121
  ending 15, 42, 52
  forwarding 31, 35, 45–46
  hanging up 15, 42, 52
  history log 38
  ignoring 39, 44
  incoming 14, 39, 44, 120, 135
  missed 35, 41
  muting 42

outgoing 14, 15, 36–38, 71
placing a second 42, 43
placing on hold 42
Preferences 45–46, 110
preventing 39, 46, 121, 134
receiving 14, 39, 44, 120, 135
redialing 38
ringer 39, 113
sending to voicemail 39, 44
status 35
switching 43, 52
using applications during 39, 42, 43, 67, 149
using speakerphone 42
using touchscreen during 121
voicemail 41
volume 16, 42, 111
waiting 44, 52
Caller ID 39, 50, 60, 110, 112
Capital letters 23
Card
Business 48, 97
expansion 62, 97, 98, 101, 103, 105–108, 147
MMC 105, 129
SD 62, 105, 129
SIM 8, 13, 16, 36, 68, 121, 122–123, 134, 136, 149
Categories
application 26, 116
assigning records to 47, 60, 62, 87–88, 90
beaming 97, 98
creating 116
default 62, 98
displaying 86, 89, 116
expansion card 106
Charger. See AC charger
Charging battery 12, 15, 31, 35
CityTime 26, 91–92
Color control 68, 115, 120
COM port. See Ports
Command buttons 15–16
Command equivalents (keyboard) 21, 51, 129
Communicator. See Phone
Conduits 30, 139
See also HotSync
Conference calls 44
Conflicting events 85
Connection
AC charger 12
computer 28, 138
headset 52
HotSync cable 28, 138
Internet 53–59, 129, 135–136, 142, 143, 148
log 140
MMS 72
mobile network 14, 35, 40, 46, 134–135, 149
Connection preferences 137
Contacts
adding 47
addressing messages to 47, 64, 70, 74
attaching to email 75
deleting
dialing 36
entering 47
fonts 115
importing from SIM 36, 48
looking up 95–96
notes 47
opening 128
private 125
receiving calls from 110
synchronizing 27, 30, 139
viewing 36, 47, 48
Continuous events. See Repeating events
Copying
addresses to Microsoft Outlook 139
applications 107
blind 75, 80
carbon 75
phone number 37, 57
pictures 60, 62
text 57
Country default setting 91, 119
See also Language selection
Coverage area 8, 15, 31, 35, 46, 65, 66, 110, 134–136
Cradle. See Cable
Creating
bookmarks 54–55
categories 116
Contacts entries 47
currency symbols 23–24, 64, 148
events 82–84
Favorites 49–51
memos 90
messages 64, 69–70, 74–75
notes for records 47, 87–88
To Do List items 87
wallpaper 112
Current date and time 118
Customer service 32
Customizing
Applications Launcher 116
browser settings 56, 57, 58–59
buttons 25, 117
Calendar settings 84–86
camera settings 62–63
colors 68, 115, 120
date and time formats 119
default applications 117
Mail settings 79–80, 140–141
MMS settings 72
Phone settings 36, 45–46, 110–112
security settings 121–126
SMS settings 67–68
sounds 110–111, 120
To Do List settings 86, 89
Wallpaper 112
See also Preferences
Cycling through views 26, 82, 116

D

Data
entry. See Entering data
transfer. See HotSync
Dates
deleting messages by 66, 71, 78
selecting in Calendar 82, 84
setting current 118
setting for email delivery 79
setting format 119
setting in To Do List 87–88, 89
sorting by 66, 71, 77
viewing in text messages 68
Decimal point 23, 94, 119
Default
applications 63, 117
browser mode 53, 54
button settings 117
Calendar settings 84–86, 111
camera settings 62
categories 62
Mail settings 76, 79–80
Option Lock on keyboard 23
PIN code 122
wallpaper 112
See also Preferences
Deleting
applications 103, 131, 145, 147
bookmarks 56
contacts 48
data 123, 126, 128
Desktop software 138, 139
events 83
Favorites entries 51
memos 90
messages 66, 67, 70, 71, 72, 78, 80, 147
passwords 122, 126
pictures 62, 63, 147
search entry 36
sounds 111
To Do items 87, 88
See also Purging
Desktop software
backup settings 63, 103
entering data in 47, 82
installing 29, 130
installing applications from 101–102, 148
language selection 132
password 126
removing 138, 139
security settings 126
synchronizing with 30, 47, 82, 137–139
system requirements 27
upgrading 103, 128
viewing data 63
Dial Pad 23, 37, 41, 42, 43, 49, 57, 112, 146
Dialing
emergency numbers 121
Extra Digits 42, 50
from Call Log 38
from Contacts list 36, 95–96
from text message 38, 65
from web page 38, 57
last number 38
passwords 42
previous numbers 38
second call 43
voicemail 41
with Dial Pad 37, 112
with Favorites 37, 49
with keyboard 15, 36, 129
Digitizer. See Touchscreen
Display
aligning 115, 133
colors 115, 120
contrast (brightness) control 114
turning on/off 14
wallpaper 112
Docking station. See Cable
Double-booked events 85
Dragging
files in desktop software 101
using the stylus 19, 20, 55, 56

E

Editing
bookmarks 56
call forwarding number 45–46
categories 116
cities 92
contacts 48
date formats 119
events 83
Favorites 51, 112
Mail accounts 140–142
number formats 119
picture name 60, 62
QuickText 64
text 19
text messages 66
Email messages. see Mail
Emergency numbers 121
Entering data
importing from SIM 36
using phone keyboard 22–24
using the computer keyboard 47, 82
Entries. See Entering data
Events. See Calendar
Exchanging data. See HotSync
Exclamation marks 23, 24, 89
Expansion cards 62, 97, 98, 101, 103, 105–108, 147

F

Favorites
caller ID picture 50, 112
caller tone 50, 110
defining 49–51
deleting 51
dialing with 37, 43
editing 51
Extra Digits 42, 50
organizing 51
voicemail 40–41
Files
attachments 75, 77, 80, 136, 141, 147
deleting from backup folder 103, 145
downloading from web 57
installing 100–102, 128
pictures 63, 69, 147
quarantined 128
ringtones 69
sounds 69, 77, 105
storing on expansion cards 105, 107
synchronizing 30, 47, 82, 137–139
Finding
applications 103
archived applications 103, 145
contacts 36, 50, 95–96, 125
messages 67, 77
private entries 125
text on web page 58
using the Find feature 22, 77, 96, 129
Floating events 85
Fonts 115
Formats preferences 119
Forwarding
calls 31, 35, 45–46
messages 71, 75, 76, 80
Frozen phone 131, 145

G

Games 31, 100, 105, 120
General preferences 31, 84, 120
Glossary 148–149
GSM 149, 150

H

Hard reset 123, 128, 132, 133, 137
Headset 9, 10, 39, 42, 52, 67, 150
Help 5, 23, 29, 32, 102, 127–147, 150
Hiding records 87, 89, 121, 125
Hold button 42, 44
HotSync
button 28, 30, 117
cable 9, 27, 28, 30, 137, 138
conduits for synchronizing 30, 139
connector 10, 28
defined 27, 148
installing applications 101–102, 145
Manager 30, 137, 139, 149
operations 30, 31, 36, 47, 60, 82, 101, 123, 126, 128, 132, 139, 144
problems with 131, 137–139
removing applications 103
setting options 139
synchronizing data 30, 31, 36, 47, 60, 82, 101, 123, 126, 128, 132, 139, 144

I

Icons
ALS 35
application 116
attachment 77, 141
battery 12, 35
Bookmarks view 54, 55
call forwarding 35
card 106
Card Info 107, 108
CityTime 91
data services 35, 135
Emoticons 64
Find 57, 129
GPRS 35
HotSync Manager 137
Information 32, 142
Lock 53, 61, 75, 98, 103
Macintosh desktop software 29
magnifying glass 57, 129
Mail 74, 77
Memo Pad 90
MMS 69, 71
network status 15, 35
page 55, 56
Page view 53
Pictures view 61
Prefs 110, 114, 115, 117, 118, 119, 120, 122, 124, 133, 136
repeating event 84
Security 53, 123, 125, 126
signal strength 35
SMS 64, 66
Sound 71
To Do List 87
Tutorial 32
voicemail 35, 41
Ignoring calls 39,44
Importing data 36, 47, 82
Incoming calls 14, 39, 44, 120, 135
Indicators
charge 10, 12, 15, 31
LED 10, 12, 15, 31
Wireless Mode 10
See also Icons
Infrared 9, 97–98, 148
Installing
applications 77, 100–102, 128, 131, 132, 145, 148
conduit to install applications 30, 139
Desktop software 27, 29, 130, 139

International characters 23–24, 64, 148
IR. See Infrared
Items. See To Do List

K

Keyboard
  accented characters 23–24, 148
  backlight 14, 22, 31, 114, 129
  beaming business card with 97
  capital letters 23
  compatibility with third-party applications 145
  computer 47, 82
  dialing with 15, 36
  layout 22
  locking 25, 26, 121–122, 124
  lowercase letters 23
  menu commands 21, 129
  numbers 93
  online Help 23
  Quick Keys 41, 49, 50, 51
  shortcuts 21, 41, 49, 50, 51, 129
  silencing ringer with 39
  symbols 23–24, 148

L

Large font for text 115
Launching
  applications 25–26, 49, 51, 106, 117, 129, 143, 148
  Blazer 26, 53
  Calculator 26
  Calendar 25–26, 82, 128
  Camera 60
  Contacts 47, 128
  CityTime 91
  Dial Pad 42
  Favorites 49–51
  links 65
  Mail 26, 74
  Memo Pad 90
  MMS 69
  Phone 25–26, 34
  SMS 25–26, 64
  To Do List 87
  Tutorial 32
  see also Opening
LED 10, 12, 15, 31
Letters
  font 115
  keyboard 22–23
Light. see LED
List
  accessing command buttons from 20
  Applications Launcher 116
  Calendar view 82, 119
  Call Log 38, 43
  Contacts 36, 139, 47–48, 64, 70, 74, 77, 80, 95, 139
  History 58
  message 65, 66, 67, 69, 71
  pick 18, 19, 21
  Redial 38, 43
  scrolling in 18
  To Do 86–89
Locking
  keyboard 25, 26, 121–122, 124
  phone with a password 121–124
  records. See Security
Looking up. See Finding
Lost phone, contact for 124

M

Macintosh 27, 29, 102, 103, 137, 138, 145
Mail
  accounts 73–74, 78, 79
  attaching applications 75
  attaching items 75, 80
  Bcc (blind copies) 75, 80
  Cc (carbon copies) 75
  creating messages 74–75
  deleting 78, 80, 147
  forwarding 76, 80
  launching 26, 73, 74
  messages 19, 43, 59, 61, 63, 65, 74–78, 117, 120, 140–142, 147
  preferences 79–80, 110–111
  receiving 76, 79
  responding to 76, 80
  requirements 73
  saving draft messages 75
  setting up 73–74
  signature 80
  sorting 77
  troubleshooting 140–142
  viewing 76, 77, 78
Maintenance information 147
Meetings. See Calendar
Memo Pad 90, 115
Memory
  browser 59
  Calculator 94
  for expansion cards 106
  regaining 87, 103, 147
  required for computer 27
Memos. See Memo Pad
Menus
  choosing 20–21, 54
  command equivalents (keyboard) 21, 129
Messages
  accessing with Favorites 41, 51
  addressing 64, 67, 72–73, 75–75
  alert tones 110–111
  attachments 72–73, 75, 77, 141
  checking 41, 70, 76
  creating 59, 64, 72–73, 74–75, 136
  dialing from 38
  email 73–80, 140–142
  forwarding 76
  photo 61, 69–72, 136, 149
  preferences for 67–68, 72, 74, 79–80
  purging 65, 71, 78, 147
  receiving 65, 70, 76, 77, 110–111, 120, 136, 140–141
  replying 67, 71, 76
  selecting items in 19, 38, 65, 77, 141
  sorting 66, 71, 77
  text 64–68, 136, 149
  voicemail 41
Microphone 10, 42, 52
Microsoft
  Outlook, connecting to 27, 30, 47, 82, 130, 139, 140, 149
  Windows 27, 60, 63, 100, 101, 103, 126, 137, 138, 145, 149
Missed calls 35,41
MMS
  creating messages 69–70
  deleting 71, 147
  overview 69, 149
  preferences 72, 110–111
  purging 71
  receiving 70
  requirements 5, 13, 69
  responding to 71
  saving from 70, 71
  sorting 71
  templates 69
  viewing 70, 71
MMS Messages. See MMS.
Modes
  browser 53–54, 143
  Calculator 93–94
  Privacy 72
  Sound 39, 113
  Wireless 14, 15, 16, 31, 35, 39, 40, 46, 53, 64, 66, 76, 120, 122, 123, 134–135, 146, 148, 149
Moving
  Calendar events 83
  cursor 18–21, 47, 53, 75, 82
  files 60, 101, 138, 147
  items on screen 55, 56, 78
  messages 78
  pictures 60, 62, 147
  ringer switch 113
  SIM card 122, 149
Multi-day events. See Repeating events
Multimedia Messages. See MMS

N

Network
  voicemail number 13, 41
  connection 14, 15, 134–136, 149
  email support 141–142
  GPRS settings 129
  password 41, 136
  preferences 129, 136
  roaming 110
  service 32
  signal strength 35, 134
  status 15, 35, 110, 134–136
  user name 136
  voicemail number 13, 41
Notes
  attaching to entries 47, 87–88
  Lotus 140, 149
  Microsoft Outlook 139
  See also Memo Pad
Numbers
  ALS 16, 148
  Application Info 104
  calculating 93–94
  call forwarding 31, 45–46
  entering 23, 41, 82, 93
  Extra Digits 42, 50
  Formats 119
  dialing 15, 36–38, 43, 57, 65, 129
  phone 13, 16, 19, 36–38, 47, 50, 57, 64, 65, 70, 89, 95–96, 124, 148
  priority 88
  speed dial 50
  PIN 15, 122–123, 149
  PUK 122, 149
  SIM 13, 16, 68, 148, 149
  Treo 16, 124, 148
  version 104

O

Opening
  attachments 77, 141
  entries 20, 48, 51, 63, 125–126
  Find dialog 96, 129
  links 65
  menus 20, 129
  web pages 49, 51, 53, 54, 65, 140, 143
  See also Launching
Options. See Preferences
Organizer 14, 31, 43, 81–98
  See also Desktop software
Outgoing calls 14, 15, 36–38, 71
Outlook, connecting to 27, 30, 47, 82, 130, 139, 140, 149
Overlapping events 85
Owner preferences 124

P

Palm Desktop software. See Desktop software
Passwords
  voicemail 41
  Call Barring 46
  changing 122
  creating 123
  deleting 122
  email 74, 140, 142
  entering 42, 50, 124, 125
  forgotten 123, 126
  mobile service provider's 46, 136
  PIN 15, 122–123, 149
  PUK 122, 149
  SIM 121, 122–123
  system 121, 123
  voicemail 41
Pasting 37, 57
Personal information manager. See Organizer
Phone
  answering 39, 44, 52
  application 34–51, 149
  battery. See Battery
  button 10, 15, 16, 25–26, 34–51, 60, 95, 112, 122, 128, 146
  Call Log 38
  components 9–11
  Contacts. See Contacts
  contrast control 114, see also Display
  Dial Pad 23, 37, 41, 42, 43, 49, 57, 112, 146
  dialing 15, 23, 36–38, 71, see also Dialing
  Favorites. See Favorites
  hanging up 15, 42, 52
  holding 134
  numbers 13, 16, 19, 36–38, 47, 50, 57, 64, 65, 70, 89, 95–96, 124, 148
  opening application 25–26, 34
  overview 34–35
  screen 10, 14, 25–26, 121, 129 see also Touchscreen
  settings 110–112
  signal strength 35, 134
  speed dial. See Favorites
  status 15, 35, 110, 134–136
  turning on/off 14
Pick lists 21
PIM (personal information manager). See Organizer
PIN 15, 122–123, 149
Ports
  IR (infrared) 9, 97–98, 148
  Serial 27
  USB 27, 28, 137, 138
Power button. See Wireless Mode
PRC (application file extension) 100–103, 145
Preferences
  Applications Launcher 116
  Blazer 54, 57, 58–59
  Buttons 117
  Calendar 84–86
  Call 45, 46
  Call Barring 46
  Camera 62
  Date & Time 118
  Display 36, 112
  Formats 119
  General 31, 120
  HotSync button 117
  icon 110, 114, 115, 117, 118, 119, 120, 122, 124, 133, 136
  Keyguard 121, 122
  Mail 79–80, 141
  MMS 72
  Network 129
  Owner 124
  security 76
  SMS 67–68
  Sound 110-111
  To Do List 86, 89
Private entries 47, 88, 121, 125–126
Proxy server 59
PUK 122, 149
Punctuation marks 23–24
Purging 66, 71, 78, 87,

Q

Quick Keys 41, 49, 50, 51
QuickText 64

R

Receiving
  data. See Beaming
  email messages. See Mail
  photo messages. See MMS
  text messages. See SMS
Records. See Entering data
Redialing 38, 43
Reminder. See Alarms and alerts
Removing
  applications 103, 145
  Desktop software 138, 139
  expansion cards 105
  pictures from messages 70
  SIM card 13, 134
  See also Deleting
Renaming
  expansion cards 108
  pictures 62
Repeating events 84
Rescheduling events 83
Reset
  automatic 135, 146
  button 11, 131–132
  hard 123, 128, 132, 133, 137, 145
  soft 131, 133, 134, 138, 145, 146
  system 131, 132, 145
  tool 11, 131, 132
  warm 131, 132, 145
Ringer 9, 39, 110, 113, 120

S

Safety 31, 150
Saving
  attachments 70, 71, 141
  messages 66, 69, 72, 75
  pictures 60, 63, 70
  sounds 71
  web page 55
Scheduling events 82–84
Screen
  auto-off interval 31, 120, 123, 148
  blank 133
  brightness 31, 114, 129
  browser mode 53–54, 143
  button 10, 14, 25, 26, 121, 129
  calibrating 15, 115, 133
  caring for 10
  colors 115, 120
  contrast 114
  fonts 115
  moving around 18–21
  touching 15, 18–21, 39, 42, 93, 115, 121, 122, 133, 134
  wallpaper 112
Scrolling 18–19, 20, 53, 54, 57, 71, 85
  See also 5-way navigation control
Searching. See Finding
Security
  Desktop software 126, 130
  displaying owner's name 124
  email 76, 141
  forgotten password 123,126
  Internet 53, 130, 141
  passwords 121–126
  PIN 15, 122–123, 149
  private records 121, 125–126
  PUK 122, 149
  SIM card 121, 122–123
Sending
  data 75
  messages 43, 64, 67, 69–70, 74–75, 76, 80, 136, 141, 149
  pictures 60, 61, 69–70, 149
  sounds 69–70, 111, 149
  See also Beaming
Serial port 9, 27–28, 137
Service
  ALS 35, 41, 148
  customer 32
  data 8, 13, 53, 73, 135–136
  email 8, 73–74, 140–141, 142
  GPRS 5, 8, 35, 73, 135, 148
  Internet 59, 129, 135, 142
  mobile service provider 15, 32
  multimedia messaging 5, 8, 69, 136
  SMS 64, 136
  voicemail 40–41
  warranty 2
  wireless 5, 14, 15, 35, 44, 110
Settings. See Preferences
ShortCuts
  Favorites 37, 49–51
  menu commands 21, 129
  MMS, templates 69
  SMS, QuickText 64
Signal strength 35, 134
Signature 80
SIM card
  ALS 148
  defined 13, 149
  Email center number 68
  importing contacts from 36, 48
  inserting and removing 13, 16, 134, 136
  locking and unlocking 121, 122–123, 149
  Message Center number 68
  PIN 149
  preferences 68
  PUK 149
  slot 9, 11, 13
  tray 13
Slider 19, 114
Small font for text 115
SMS
  alerts 111
  chat threads 67
  creating messages 51, 64
  defined 149
  deleting messages 66, 67
  dialing from 38
  editing draft messages 66
  Inbox 66
  opening 25–26, 64
  Preferences 67–68
  purging messages 66
  QuickText 64
  receiving messages 65, 120
  saving draft messages 66
  sorting messages 66
SMS Messages. See SMS
Soft reset 131, 133, 134, 138, 145, 146
Sorting
  applications 116
  browser bookmarks 56
  browser history 58
  by date 58, 66, 71, 77, 89
  Favorites 51
  messages 66, 71, 77
  pictures 62
  To Do items 88, 89
Sounds 14, 15, 39, 50, 63, 65, 69, 70, 71, 77, 106, 110–111, 113, 120
Speaker 11, 52, 113
Speakerphone 12, 42, 67, 111
Speed Dial. See Favorites
Standing Meetings. See Repeating events
Starting applications. See Launching
Stylus
  accessing reset tool 11, 131, 132
  dragging with 19, 20, 55, 56
  locating 9
  tapping with 18–21
Switching calls 43, 52
Symbols 23–24, 148
Synchronizing data. See HotSync
System requirements for Desktop software 27

T

Technical Support 32
Templates
  MMS 69
  QuickText 64
Text
  copying 57
  entering. See Entering data
  finding 22, 36, 50, 58, 77, 95–96, 125, 129
  fonts for 115
  pasting 37, 57
  selecting 19–20
Third-party applications 18, 73, 77, 96, 100–103, 126, 128, 129, 130, 131, 132, 138, 139, 140, 141, 145, 146, 147, 149
Time
  alarm setting 83
  Auto Lock 123
  automatic email delivery 79, 140
  bars in Calendar 85
  battery life 31
  Daylight Savings 118
  format 119
  Home City 91
  remote cities 92
  setting current 118
  setting event 82, 83
  stamps 68
  start and end for Calendar Day view 84
Tips
  Information icon 32, 142
  printed 5
  online 32, 141
To Do List 86–89, 115, 120
Today. See Current date and time
Touchscreen
  calibrating15, 115, 133
  caring for 10,
  disabling during calls 39, 42, 121, 122, 134
  see also Display
Transferring data. See HotSync
Transmitting data. See Beaming
Turning on and off
  automatically 121, 122, 135
  displaying owner's name 124
  keyboard backlight 22, 129
  phone 14, 135
  problems with 12, 31
  screen 14
  Wireless Mode 14, 15, 135
Typing. See Entering data

U

Uninstalling Desktop software 138, 139
Unlock code 122–123
Unresponsive phone 131, 145
Untimed events 82, 83
Updating data. See HotSync
Upgrading 63, 103, 128, –129, 138
USB cable 9, 27–28, 138
User name
  data services 136
  desktop software 101, 102, 128, 137, 139, 149
  email 142
  HotSync 101, 102, 128, 137, 139, 149
  phone 101, 102, 128, 137, 139, 149

V

Vibrate 39, 65, 113
Voice quality 148
  echo 148
Voicemail 40–41, 51
Volume 10, 16, 39, 94, 110–111, 113, 120

W

Warm reset 131, 132, 145
Web pages. See Blazer
Windows. See Microsoft
Wireless mode 19
  indicator 10
  turning on and off 14, 15, 135
  troubleshooting 134–136
  See also Network

Specifications

Radio	• GSM 850/900/1800/1900 quad band world phone • GPRS class 10, class B; also supports CSD
Phone features	• Personal speakerphone • Hands-free headset jack (2.5 mm, 3-barrel connector) • Microphone mute option • TTY compatible • 6-way calling
Processor technology	• Texas Instruments OMAP 1510 (ARM) processor
Expansion	• SD/MMC slot (SD I/O compatible)
Battery	• Rechargeable Lithium Ion • 3 hours full charge time • 6 hours talk time, 10 days standby
Palm OS version	• Palm OS 5.2.x
Camera	• VGA resolution (640x480), 0.3 megapixel • Automatic light balance
Size	• 4.41 in x 2.36 in x .87 in (11.2 cm x 6.0 cm x 2.2 cm) with antenna
Weight	• 5.92 ounces (167.6 grams)
IR	• Yes
Display	• LCD Touchscreen (includes stylus) • 3375 colors (11.5-bit color, compatible with 16-bit applications) • User-adjustable brightness and contrast
Keyboard	• Built-in QWERTY keyboard plus 5-way navigation control • Backlight for low lighting conditions
Included software	• Phone (including Palm OS Contacts, Favorites, Dial Pad) • Camera • MMS • Blazer Web Browser (Internet) • Memo Pad • PocketMirror Standard (for synchronizing with Microsoft Outlook for Windows) • Calendar (Palm OS Date Book+) • SMS • Mail • To Do List • Calculator (basic and advanced) • Palm Desktop and HotSync Manager • CityTime world clock
System requirements	• Windows 98SE, Me, 2000 or XP with USB port. Windows NT4 requires serial cable, sold separately • Mac OS 10.1-10.3.x with USB port • Later versions may also be supported
Operating and storage temperature range	• 0C-40C • 5% to 90% RH