


Revision 11.01.18



Controls

- Loudness Sets the overall output volume
- **Filter** Adjusts the range of band-pass filtered tone
- **Sustain** Controls the amount of fuzz
- **Scoop** Sweeps between mid-scoop / flat-mids
- **Crunch** Adjusts the intensity of compression
- **Voice (internal trim)** Controls the Scoop control intensity
- Clip (internal trim) Adjusts between smooth / open fuzz

All trademarks and registered trademarks are the property of their respective owners. The company, product, and service names used in this web site are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.



Gerkin Fuzz

Parts List

RESISTORS					
R1	33K				
R2	100K				
R3	100R				
R4	470K				
R5	10K				
R6	4K7				
R7	1K				
R8	10K				
R9	100K				
R10	100R				
R11	470K				
R12	10K				
R13	4K7				
R14	10K				
R15	100K				
R16	100R				
R17	470K				
R18	1K5				
R19	33K				
R20	100K				
R21	1K5				
R22	470K				
R23	10K				
R24	10K				
R25	4K7				


150R

R26

R100 4K7

CAPACITORS				
C1	100n			
C2	470p			
C3	1u			
C4	1u			
C5	1u			
C6	470p			
C7	47n			
C8	100n			
C9	1u			
C10	1u			
C11	470p			
C12	100n			
C13	1u			
C14	33n			
C15	3n3			
C16	100n			
C17	1u			
C18	1u			
C19	4711			


CAPACITORS INTEGR			RATED CIRCUITS		
C1	100n	Q1	MPQ3904		
C2	470p				
C3	1u	DIODE	OIODES		
C4	1u	D1	3mm Red LED		
C5	1u	D2	3mm Red LED		
C6	470p	D3	1N4148		
C7	47n	D4	1N4148		
C8	100n	D5	1N4148		
C9	1u	D6	1N4148		
C10	1u	D100	1N5817		
C11	470p				
C12	100n	POTEN	OTENTIOMETERS		
C13	1u	LOUDNESS B1001		B100K	
C14	33n	FILTER		B100K	
C15	3n3	SUSTAIN		B100K	
C16	100n	CRUNCH		A470K	
C17	1u	SCOOP		B50K	
C18	1u				
C19	47u	TRIM POTS (3362P)			
C100	100u	VOICE 500K		500K	
		CLIP		500K	





Gerkin Fuzz

Wiring Diagram





Gerkin Fuzz

Drill Template 125B enclosure with top mounted jacks

