JOYSTICK
CONNECTIONS

UP

↑

LEFT ←

RIGHT →

DOWN

↓

DOWN

ARDUINO PINS

UP — 5
DOWN — 4
RIGHT — 3
LEFT — 2
GND

GND

6

PUSH