ZCL Clusters (TSR)

Domain	Cluster Name	Cluster ID	Server Mandatory	Server Optional	Client Mandatory	Client Optional
General	Basic	0x0000	All			Remote Control
General	Power Configuration	0x0001		All		
General	Device Temperature Configuration	0x0002				
General	Identity	0x0003	AII		Door Lock Controller Simple Sensor On/Off Switch On/Off Light Switch Dimmer Switch Colour Dimmer Switch Light Sensor Occupancy Sensor Smart Plug	Level Control Switch Scene Selector Remote Control
General	Groups	0x0004	On/Off Output Door Lock Simple Sensor On/Off Light Dimmable Light Colour Dimmable Light	Thermostat	 Scene Selector Door Lock Controller 	On/Off Switch Level Control Switch Remote Control On/Off Light Switch Dimmer Switch Colour Dimmer Switch
General	Scenes	0x0005	 On/Off Output Door Lock Simple Sensor On/Off Light Dimmable Light Colour Dimmable Light 	Thermostat	Scene Selector Door Lock Controller	On/Off Switch Level Control Switch Remote Control On/Off Light Switch Dimmer Switch Colour Dimmer Switch
General	On/Off	0x0006	 On/Off Output On/Off Light Dimmable Light Colour Dimmable Light Smart Plug 		On/Off Switch Level Control Switch On/Off Light Switch Dimmer Switch Colour Dimmer Switch	Remote Control
General	On/Off Switch Configuration	0x0007		On/Off Switch Level Control Switch On/Off Light Switch Dimmer Switch Colour Dimmer Switch		Remote Control
General	Level Control	0x0008	Dimmable Light Colour Dimmable Light		Level Control SwitchDimmer SwitchColour Dimmer Switch	Remote Control
General	Alarms	0x0009				
General	Time	0x000A				All
General	Binary Input (Basic)	0x000F	Simple Sensor			
General	Partition	0x0016				
General	Power Profile	0x001A				
General	Poll Control	0x0020				

Lighting	Color Control	0x0300	 Colour Dimmable Light 		 Colour Dimmer Switch 	Remote Control
Measurement & Sensing	Illuminance Measurement	0x0400	Light Sensor			Remote Control
Measurement & Sensing	Illuminance Level Sensing	0x0410				Remote Control
Measurement & Sensing	Temperature Measurement	0x0402				Remote Control
Measurement & Sensing	Relative Humidity Measurement	0x0404				
Measurement & Sensing	Occupancy Sensing	0x0406	Occupancy Sensor	Thermostat		On/Off Light Dimmable Light Colour Dimmable Light Thermostat