

Main relay driver, GFCI test, voltage measurement trigger

## Max output current setting

Arduino programming header


BLK -> GND on FTDI

RXI -> TX on FTDI


TXO -> RX on FTDI

GRN -> GRN on FTDI


GND



Pilot signal generation & sensing



Power supply connectors



Arduino Pro Mini (5V  $\times$  16Mhz, ATMega328P) is not shown on schematics All Arduino pins are broken out on the UNO-style shield header

Electric Motor Werks, Inc

EMW JuiceBox - Base edition

Valery Miftakhov Rev 8.6
10/13/2013 Page 1 of 1