You are here: Synthesis Man Pages > Synthesis Variables and Attributes > I > link_library

link_library

NAME TYPE DEFAULT GROUP DESCRIPTION SEE ALSO

NAME

link_library

Specifies the list of design files and libraries used during linking.

TYPE

list

DEFAULT

* your_library.db

GROUP

system_variables

DESCRIPTION

This variable specifies the list of design files and libraries used during linking. The **link** command looks at the files and tries to resolve references in the order of the specified files. A "*" entry in the value of this variable indicates that the **link** command is to search all the designs loaded in dc_shell while trying to resolve references. If file names do not include directory names, files are searched for in the directories in **search_path**. The default is {"*" your_library.db}. Change *your_library.db* to reflect your library name.

To determine the current value of this variable, use the **printvar link_library** command. For a list of all system variables and their current values, use the **print_variable_group system** command.

SEE ALSO

link(2)

1 of 1 8/28/2017, 4:02 PM