IBASE OBSERVER CONNECT


System Design Specification

1 Home

The main screen briefly explains the purpose of the system. The menu at the top allows you to choose to login or password reset.




Login After entering your account and password, you can log in to the system.




Password reset
 If you forget your password, you can reset it through your authentication

mailbox.

1.2.1 Enter the authentication email and click Password Reset.



1.2.2 After receiving the letter in the authentication mailbox, click Reset Password. This password reset link will expire in 60 minutes.




1.2.3 Enter the new password and new password confirmation to reset your password. If you suddenly remember your old password, you can log in again before confirming it.



2 Dashboard

The system page after successful login, the upper part displays the permissions/subscription identity and logout function, the left side is the system function menu, and the right side is the current function page.

Click 【View On IBASE】 to link to the official website of IBASE.



2.1. Administrator


The highest authority, and the new user is Power. Administrator is added by the system administrator.

	Create	Edit	Delete	View
User	0	0	0	0
Company	0	0	0	0
Action	0	0	0	0
Subscription	0	0	0	0

	Create	Edit	Delete	View	Download
Group Element	0	0	0	0	0

	View	Sensor	Mail Slot
Hardware Information	0	0	0

	View Command For		Command For
		Groups	Systems
Mail Slot	0	0	0




2.2. Power Secondary permissions can be added, deleted and modified, and the new user is User.

	Create	Edit	Delete	View
User	0	0	0	0
Company	Х	Х	Х	Х
Action	Х	Х	Х	Х
Subscription	Х	Х	Х	Х

	Create	Edit	Delete	View	Download
Group Element	0	0	0	0	0

	View	Sensor	Mail Slot
Hardware Information	0	0	0

	View	Command For	Command For
		Groups	Systems
Mail Slot	0	0	0



2.3. User

General permissions can only view and edit your own password.

	Create	Edit	Delete	View
User	Χ	Χ	Х	0
Company	Х	Х	Х	0
Action	Х	Х	Х	0
Subscription	Х	Х	Х	0

	Create	Edit	Delete	View	Download
Group Element	Х	Х	Х	0	Х


	View	Sensor	Mail Slot
Hardware Information	0	0	Х

	View Command For		Command For
		Groups	Systems
Mail Slot	0	Х	Х




3.1. User

The main functions have been Create, Reset, Delete, View and are controlled according to permissions.




User permissions can only view their own Profile and Reset their own Password.



3.1.1. Create


Select Company, enter E-mail and Password to add a new User.

Administrator adds a User with Power permissions, and Power adds a User with User permissions.




3.1.2. Reset

Reset Password, Administrator can modify the User Password of all Companies, Power can modify the User Password of its own Company, and User can only modify its own User Password.




3.1.3. Delete

Administrator can delete all Users other than the own Company, and Power can delete Users other than the own Company.




3.2. Group Element

The main functions have been Create, Reset, Delete, View, Download and are controlled according to permissions.




3.2.1. Create


Enter the Group Name and Description to add a new one.



3.2.2. Edit Group Name and Description can be modified.




3.2.3. Delete Delete Group Element.



3.2.4. Download

Download Vendor Key File.




3.3. Hardware Information

Can view Hardware Information and use Sensor and Mail Slot functions.




3.3.1. Sensor

You can view the statistical chart of Hardware's Temperature CPU Chart, Temperature System Chart, CPU Fan Speed Chart, System Fan Speed Chart, and CPU Usage Chart within 8 hours. This statistical chart is updated every minute and can be zoomed in, zoomed out, and panned.



3.3.2. Mail Slot

The Command For Hardware function can be used.




3.4. Mail Slot

Can view Mail Slot, Administrator and Power permissions can use Command for Groups, Command for Systems.




3.4.1. Command For Groups

You can select all or specified Group Element commands.




3.4.2. Command For Systems

You can select all or specified Hardware-Group Element commands.




3.5. Company

You can Create, Edit, Delete and View Company information. This function is limited to Administrator.




3.5.1. Create

Enter the Company Name to add it.




3.5.2. Edit

Company Name can be modified.




3.5.3. Delete Delete Company.




3.6. Action

You can Create, Edit, Delete and View Action information. This function is limited to Administrator. The default cannot be Edit or Delete.




3.6.1. Create

After entering the Action Name, you can add Action data.




3.6.2. Edit

Action Name can be modified.




3.6.3. Delete




3.7. Subscription

You can Create and Edit the Subscription of the specified User.



3.7.1. Create

You can select unsubscribed Users to perform the subscription function. The subscription function is divided into Month and Year.



3.7.2. Edit

Subscribed User can be modified to Month or Year.

