

LOXFORD

X200 Wireless Router — User Manual

Model: Loxford X200
Document No.: LOX-MAN-X200-R3
Revision date: March 2026
Firmware version covered: 2.4.x and later

1. Overview

The Loxford X200 is a dual-band wireless router designed for small offices and home networks. It supports Wi-Fi 6 (802.11ax), gigabit wired ports, and Loxford's Companion App for remote management. This manual covers unboxing, setup, everyday use, troubleshooting, and warranty information.

1.1 Package Contents

- 1 × Loxford X200 router
- 1 × Power adapter (12V / 2A)
- 1 × Ethernet cable (1.5 m)
- 1 × Quick start card

1.2 Key Specifications

Specification	Detail
Wi-Fi standard	Wi-Fi 6 (802.11ax), dual-band 2.4 GHz + 5 GHz
Max throughput	Up to 1.8 Gbps combined
Wired ports	4 × Gigabit LAN, 1 × Gigabit WAN
Coverage	Up to 1,800 sq ft (typical home/office layout)
Power input	12V DC, 2A
Dimensions	180 mm × 120 mm × 32 mm
Operating temperature	0°C to 40°C (32°F to 104°F)

2. Setup & Installation

2.1 Physical Setup

1. Place the X200 in a central, well-ventilated location, away from walls and large metal objects.
2. Connect the WAN port to your modem or ISP wall socket using an Ethernet cable.
3. Connect the included power adapter and plug it into a wall outlet.
4. Wait about 60 seconds for the Power LED to turn solid green before proceeding.

2.2 Initial Configuration

5. Download the Loxford Companion App from your device's app store.
6. Open the app and select “Set Up a New Router.”

7. Connect your phone or laptop to the Wi-Fi network printed on the router's bottom label.
8. Follow the in-app steps to create your admin password and name your Wi-Fi network (SSID).
9. Once setup completes, the Status LED will turn solid blue, indicating the router is online.

3. LED Indicator Guide

LED	State	Meaning
Power	Solid green	Router is powered on and functioning normally
Power	Blinking red	Startup error — restart the device
Status	Solid blue	Connected to the internet
Status	Blinking blue	Starting up or updating firmware
Status	Off	No internet connection detected
Wi-Fi	Solid white	Wireless radios are active
Wi-Fi	Blinking amber	Factory reset in progress

4. Everyday Use

4.1 Managing Your Network

Use the Loxford Companion App to view connected devices, set up a guest network, run a speed test, and apply parental controls. Changes made in the app take effect immediately and do not require a reboot.

4.2 Guest Network

To create a guest network, open the app, go to Wi-Fi Settings > Guest Network, and toggle it on. Guest devices are isolated from your main network and from each other by default.

4.3 Firmware Updates

The X200 checks for firmware updates automatically once per week. To update manually, go to Settings > Firmware > Check for Updates in the Companion App. Do not unplug the router during an update — this can take up to five minutes and is indicated by a blinking blue Status LED.

5. Factory Reset

A factory reset erases all settings, including your Wi-Fi name, password, and any custom configuration, and restores the router to its out-of-box state.

10. Locate the small Reset button on the back panel, next to the WAN port.
11. Using a paperclip or SIM tool, press and hold the button for 10 seconds.
12. Release once the Wi-Fi LED begins blinking amber.
13. The router will restart automatically; this takes about 90 seconds.
14. Reconfigure the router using the Companion App as described in Section 2.2.

6. Troubleshooting

Symptom	Suggested Fix
No lights on the router	Check the power adapter and outlet; try a different outlet.
Status LED stays off	Confirm the WAN cable is connected to a working modem.
Wi-Fi name not visible	Move closer to the router; confirm the network isn't hidden in app settings.
Slow wireless speeds	Switch to the 5 GHz band and check for interference from other devices.
Companion App can't find router	Confirm your phone is on the same Wi-Fi network as the router.
Forgot admin password	Perform a factory reset (Section 5) and set up the router again.

7. Warranty & Support

The Loxford X200 is covered by a two (2) year limited warranty from the date of purchase, covering manufacturing defects under normal use. The warranty does not cover water damage, physical damage, or unauthorized modification of the hardware or firmware.

For support, visit support.loxford.example, email support@loxford.example, or use the in-app “Contact Support” option. Have your model number and serial number (found on the bottom label) ready when contacting support.