INTRODUCTION

Installation documents, drawings and specifications for gas turbine-generator units are separated into the following categories:

- Gas Turbine Installation and Maintenance (I&M) Drawings
- Generator Installation and Assembly Documents - Drawing List Numbers (DLN)
- Material Shipped Direct (MSD) - Vendor Documentation (VENDOC)
- Balance of Plant (BOP) - Architectural Engineering (A/E) Construction Documents

Tables 1 through 9 of this document are lists and checklists of installation drawings, specifications, parts lists and other essential documentation for a typical MS6001B gas turbine unit installation.

Following is a brief description of each table.

- **Table 1** – the general structure of information of a gas turbine Model List (ML).
- **Table 2** – required GE I&M drawings and Print Lists (PL) for a typical MS6001B gas turbine “Split Base” unit.
- **Table 3** – a checklist of Customer Drawings. These drawings are sent to the Customer or A/E approximately 6 to 12 weeks after an order is placed, and should also be included the I&M prints used by the GE Technical Advisor (TA). See EM 5017, Use of Gas Turbine-Generator Customer Drawings, for more detail.
- **Table 4** – a checklist of the electrical installation drawings and start-up documents typically required.
- **Table 5** – a checklist of generator drawings, sorted by the generator Drawing List Number (DLN), that are typically required. Generator installation and assembly drawings are not included in the Gas Turbine Model List.
- **Table 6** – a consolidated checklist of gas turbine unit assemblies and materials shipped directly to the installation site as MSD equipment. These are vendor drawings managed through a system called VENDOC.
- **Table 7** – a consolidated checklist of generator assemblies and materials shipped directly to the installation site as MSD equipment. These are also VENDOC drawings.

- **Table 8** – a “maximum case" list of gas turbine documents sorted by systems and work areas.
- **Table 9** – a checklist of the BOP A/E drawings and specifications typically required for an installation. BOP construction prints define the site-to-unit interfaces (e.g., foundations, piping and electrical connections/terminal points), as well as the piping, conduit and wiring interconnections between the unit and the major skids and modules supplied with the unit.

TABLE 1

General Structure of Information of Gas Turbine Model Lists

A000	Requisition Items
E000	Heavy Fuels
G000	Gas Fuels
200	Test, Inspection and Equipment
300	Outlines and Notes
400	Diagrams and Data
500	Control Arrangements and Assemblies
600	Control Components
700	Turbine Stator and Combustion
800	Compressor Stator
1000	Piping Components
1100	Electrical Arrangements and Assemblies
1200	Electrical Components
1300	Rotors, Blades, Couplings
1600	Unit Assembly and Enclosures

TABLE 2

MS6001B Installation and Maintenance (I&M) Typical Drawing List

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
A010	Later	Spec. Control - Cont Sys Settings	*	*
A012	329A7836P001	Load Gear	*	
A013	Later	Load Package	*	
A024	334A7404P001	Bus Duct, Non-Segregated	*	
A033	295A9606G010	Tool Kit, Major Disassembly	*	*
A035	336A2414P001	Water Inj. Unit, Nox RDCN Sys.	*	
A036	336A2067P001	Generator Auxiliaries Compt.	*	
A040	334A7795P001	Inlet Compartment Arr. Air	*	
A041	336A2415P001	Duct Arr. Inlet-Air	*	
A042	159D7422G005	Exhaust System Arr.	*	*
A044	339A6426G001	Piping, Oil Tank & Load, Gen Vent	*	*
A045	334A7790P001	Fuel Handling Equipment	*	
A053	339A6319G007	Piping Arr. Intcon-Field	*	*
A062	169D3044G001	Cable Arr. Unit Intercompt-MSD	*	*
A068	336A2438P001	Fire Protection Sys	*	
A076	336A2455P001	Water Cooling Unit	*	
A098	237B2595G004	Vent System Component, Lube Oil	*	*
A107	334A7796P001	Inlet Compartment Arr. Gen-Air	*	
A122	973E0547G005	Sensor Arr. Humidity	*	*
A125	103E8204G001	Piping Arr. Lube Oil Flush - Fld.	*	*
A130	979E0403G013	Air Processing Unit, CPRSR Disc	*	*
G002	336A2432P001	Inlet Gas Scrubber	*	
0104	279A2608G001	Tool List	*	*
0105	Later	Instruction, Tool Use	*	
0106	302A4997G026	Installation & Start-Up Extras	*	*

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
0108	317A9381P006	Instruction, Cleaning & Painting	*	
0110	302A4998G026	Install & Startup Extras, Sta.	*	*
0211	969E0546	Instrumentation Arr - Unit	*	
0218	178C8546G001	Thermocouple Arr. Tb. Whl. Stg.-1	*	*
0228	227B6021	Instm. Test-Case Inlet & Brg. 1	*	
0229	156D2900G003	Instm. Turbine Lube System	*	*
0235	142D4842G003	Instrumentation Arr. Brg.	*	*
0301	169D3882	Outline, GT Package Conn. - Elec.	*	
0302	328A9988	Outline, Purch. Mounted Devices	*	
0306	101E2956	Outline, Mech - GT & Load	*	
0313	169D3924	Outline, GT Package Conn - Piping	*	
0314	336A2555	Notes, GT Pkg. Conn Outline - PP	*	
0315	Later	Outline, Base Insulation - Sugg.	*	
0323	328A9985	PL. Foundation Interface Otln.	*	
0326	336A2541	Otln, Fdn Intfc, Off-Base, Mech.	*	
0330	336A2545	Outline, GT Package Conn - Elec	*	
0401	Later	Diagram, Connection - Turbine	*	
0404	985E0572	Diagram, Clearance - Unit Assy	*	
0406	103E8213	Gas Turbine Arrangement	*	
0407	103E8214	Weight, C.G.G.T. Unit	*	
0408	101E2979	Wt. & CG, Gas Turbine Package	*	
0410	334A7767	Instruction, Factory Alignment	*	
0411	336A2410	Instruction, Align-Field, Basic	*	
0412	251B1493	Data, Temp & Heat Radiation	*	
0414	334A7395	Device Summary	*	
0415	251B1094	Diagram, Cont Devices - Turbine	*	
0416	251B1652	Diagram, Schem PP - Lube Oil	*	
0417	251B1069	Diagram, Schem PP - CLG & SLG Air	*	

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
0418	251B1151	Diagram, Schem PP - Trip Oil	*	
0419	238B7410	Diagram, Schem PP - Control Air	*	
0420	251B1050	Diagram, Schem PP - Cooling Water	*	
0421	251B1066	Diagram, Schem PP - Starting Means	*	
0422	251B1369	Diagram, Schem PP - Fuel Gas	*	
0424	251B1062	Diagram, Schem PP - Liq. Fuel	*	
0425	251B1370	Diagram, Schem PP - Atomizing Air	*	
0426	251B1378	Diagram, Schem PP - Fire Protect	*	
0427	251B1366	Diagram, Schem PP - Liq. Fuel Fwd	*	
0434	251B1053	Diagram, Schem PP - Hydr Supply	*	
0435	302A4024	Cable Instl Data, Speedtronic	*	
0436	251B1377	Diagram, Flow - Heating & Vent	*	
0438	302A7878	Drawings, Standard Customer	*	
0440	251B1364	Diagram, Schematic, Load Equip	*	
0444	169D3517	Diagram, One Line	*	
0445	Later	Diagram, Interconnection	*	
0462	251B1380	Diag, Schem PP - Water Inj. Sys.	*	
0463	167D3544	Diagram, Block, Cable	*	
0465	235A9751P001	Instr. Lube Oil Selection	*	
0466	339A6367G001	Wire List, Turbine Compt.	*	*
0467	339A6355G001	Wire List, Accessory Compt	*	*
0469	251B1150	Diagram, Schem PP - IGV	*	
0471	251B1374	Diagram, Flow - Inlet & Exhaust	*	
0475	336A9491G002	Instruction, Conduit Sealing	*	*
0477	251B1376	Diagram, Schem PP - Fuel Purge	*	
0501	142D4959	Control Arr. Turbine	*	
0510	199C4381G001	Pump Arr. Fuel	*	*
0512	156D2632G010	Fuel Nozzle Assy, Dual Fuel	*	*

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
0516	154D7392G001	Valve Assy. Bypass - Fuel Oil	*	*
0533	314B7960G001	Servo Arrangement Bypass Valve	*	*
0540	232B8936G002	Servo Arrangement - IGV Actuator	*	*
0541	197C3428G001	Servo Arr. Stop R & Cont V - Gas	*	*
0544	197C3425G010	Valve, Stop, Ratio & Cont - Master	*	*
0548	142D4929G001	Actuator Arrangement, IGV	*	*
0557	103E8116G001	Transducer Arr.	*	*
0624	298A7830P001	Muffler, Diesel Engine	*	
0639	329A7298G012	Fuel Gas Flow Measurement Sys	*	*
0701	943E0253G008	Chamber Arr. Combustion	*	*
0903	103E0013G001	Piping Arr. Lube Oil Intcon	*	*
0904	103E8136G001	Piping Arr. Oil Tank - External	*	*
0905	103E8114G001	Piping Arr. Lube Feed & Drn Base	*	*
0906	103E8140G001	Piping Arr. Lo Feed & Drn - Load	*	*
0909	103E8189G001	Piping Arr. Cooling & Sealing Air	*	*
0910	103E8199G001	Piping Arr. Fuel Oil	*	*
0914	103E0023G001	Piping Arr. Cooling Water - LUBO	*	*
0916	156D2902G001	Piping Arr. Starting Means	*	*
0917	103E8141G002	Piping Arr. Fire Protection	*	*
0918	339A6435G001	Piping Arr. Fuel Purge System	*	*
0920	103E3294G001	Piping Arr. False Start Drain	*	*
0922	103E8429G001	Piping Arr. Atomizing Air	*	*
0924	201C7977G001	Piping Arr. Air Extraction	*	*
0926	103E8088G002	Cabinet Assy. Gauge	*	*
0929	185A1632P005	Strainer	*	
0931	235A7759P001	Air Cleaner	*	
0936	199C4398G001	Piping Arr. Turb Case Clg Air	*	*
0938	156D2904G001	Instl. Immersion Heaters - LUBO	*	*

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
0947	142D4923G001	Manifold Assy. Hydraulic	*	*
0961	103E8193G001	Piping Arr. Fuel Oil - Turbine	*	*
0962	103E8195G001	Piping Arr. Fuel Gas	*	*
0963	103E8006G001	Piping Arr. Clg Wtr Turbine	*	*
0964	103E8183G002	Piping Arr. Fire Protection	*	*
0965	103E8184G001	Piping Arr. Atomizing Air	*	*
0967	103E8054G001	Piping Arr. Diesel Exhaust	*	*
0968	103E8211G001	Piping Arr. Water Injection	*	*
0969	339A6178G001	Piping Arr. Base Intcon	*	*
0972	103E8106G001	Piping Arr. Exhaust Frame Clg.	*	*
0973	103E8101G001	Piping Arr. Cooling Water - Diesel	*	*
0974	142D4960G001	Tubing Arr. Gauge Cab to Base	*	*
0975	103E8090G001	Accessory Module Arr	*	*
0976	199C4398G001	Piping Arr. Exh Plenum Drain	*	*
0983	103E8207G005	Piping Arr. Atomizing Air	*	*
0985	339A6125G001	Module Assy. Hydraulic	*	*
0991	339A6234G001	Gas Fuel Module	*	*
0992	339A6194G001	Liquid Fuel Module	*	*
1101	336A2066P001	Control Compartment Assy.	*	
1103	339A9512G001	Conduit Arr. Turbine Compt	*	*
1104	339A6299G001	Conduit Arr. Accessory Compt	*	*
1105	103E8289G001	Conduit Arr. Field Wiring	*	*
1107	339A9513G001	Conduit Arr. Compt. Heating	*	*
1118	339A6472G001	Conduit Arr. Wheel Space TC	*	*
1121	199C4156G002	Detector, Flame	*	*
1127	339A6473G001	Conduit Arr. Flame Detectors	*	*
1137	339A6375G001	Conduit Arr. Access Compt Ltg.	*	*
1138	142D4954G005	Junction Box, No. 1 Assy.	*	*

I&M Drawing Requirements (GE drawings) – (* = Required Item)				
Item	**Identification**	**Nomenclature**	**Dwg.**	**PL**
1139	142D4950G001	Junction Box, No. 2 Assy.	*	*
1145	339A6376G001	Conduit Arr. Access Compt. Htg.	*	*
1153	339A6377G001	Conduit Arr. Accessory Compt. LL	*	*
1154	339A6452G001	Conduit Arr. Turbine Base	*	*
1155	336A9371G002	Support, Piping	*	*
1156	336A9372G002	Junction Box, No. 20 Assy.	*	*
1158	339A6378G001	Conduit Arr. Accessory Compt. HL	*	*
1159	339A9514G001	Conduit Arr. Turbine Compt. HL	*	*
1160	339A6474G001	Conduit Arr. Exhaust Area	*	*
1233	329A7801P007	Blower, Exhaust Frame-Cooling	*	
1309	279A2633G001	Hardware, Load Coupling	*	*
1310	315A2364P001	Coupling Load, Flexible, Output	*	
1311	156D2934G001	Guard, Coupling - Output	*	*
1313	315A9627G003	Coupling, Access Gear	*	*
1314	151D8752G002	Guard, Coupling - Accessory Gear	*	*
1602	101E2949G001	Walkway Arr, Unit	*	*
1603	101E2960G001	Foundation Bolting Arr.	*	*
1604	156D2921G001	Bolting & Doweling Arr.	*	*
1605	103E8228G001	Enclosure to Base Arr.	*	*
1617	103E8217G001	Enclosure Assy., Load Compt	*	*
1625	103E3211G002	Plenum Assy. Exhaust	*	*
1643	328A6772P012	Fan, Vent-Enclosure	*	

TABLE 3

Checklist of Customer Drawings

Model List Item (MLI) Number		Document Title
*Std. List	**Supl. List	
0301		Outline, Gas Turbine Package Connection - Electrical
0306		Outline, Mechanical - Gas Turbine and Load
0313		Outline, Gas Turbine Package Connection - Piping
0314		Notes, Gas Turbine Package Connection Outline - Piping
0323		Foundation Interface Outline
0326		Outline, Foundation Interface Off Base - Mechanical
0330		Outline, Foundation Interface Off Base - Electrical
0408		Weight and Center of Gravity, Gas Turbine Packages
0414		Device Summary
04XX		Diagram, Schematic Piping - Various
0438		List, Standard Customer Drawings
0444		Diagram, One Line
0463		Diagram, Block, Cable
1603		Foundation Bolting Arrangement
	A044	Piping Arrangement, Oil Tank Vent - Ext.
	A053	Piping Arrangement, Interconnection - Field
	A098	Vent System Component, Lube Oil
	A106	Integral Distribution Center
	A108	Data Analyzer and Processor System
	0302	Outline, Purchaser's Mounted Devices
	0412	Data, Temperature and Heat Radiation
	0445	Diagram, Interconnection
	0906	Piping Arrangement, Lube Oil Feed and Drain
	0914	Piping Arrangement, Cooling Water - Lube Oil
	0969	Piping Arrangement, Base Interconnection
	1105	Conduit Arrangement, Field Wiring
	1602	Walkway Arrangement, Unit

Table 3 Notes

* Standard Documents - issued by Gas Turbine Requisition Engineering typically 6 weeks after receipt of order. See MLI 0438 for an overview of the standard documents supplied.

** Supplementary Documents - often supplied by Gas Turbine Requisition Engineering depending on specific configuration of unit(s).

TABLE 4

Checklist of Electrical Installation and Start-Up Documents

Model List Item (MLI) Number			Description/Document Title
AO	Std. Options	Other Options	
A010			Control System Settings Specifications
A013*			Generator (Load Package)
		A014*	Off-base Turbine Control Panel
	A016*		Generator Control Panel/Elementary
	A019*		Motor Control Center
		A020*	Remote CRT Panel
	A023*		Metalclad Switchgear
A024*			Non-Segregated Bus Duct
	A025*		Auxiliary Transformer
A026*			Power Circuit Breaker
A036*			Generator Auxiliaries Compartment
	A039*		Limitamp, Motor Starter
A059*			PEECC***
A062*			Cable Arrangement - Intercompartment
		A083*	Batteries - Separate Compartment (See 1207)
	A087*		Starting Motor Transformer/Breaker
	A089*		Excitation Compartment
	A106*		Integral Distribution Center

Model List Item (MLI) Number			Description/Document Title
AO	Std. Options	Other Options	
		A108*	Remote CRT/Start Cables
		A111*	Generator Terminal Enclosure - GLAC
		A124*	Turbine & Load Equip. Control Panel (Combination of A014 & A016)
		A145*	Smart Remote
	106		Installation and Start-up Extras - Unit
	110		Installation and Start-up Extras - Station
0203			Control Test Instruction
0211			Instrumentation Arrangement - Unit
0301			Package Electrical Connections - Outline
0302			Outline - Purchaser's Mounted Devices
0330**			Package Electrical Connection Outline
0401			Turbine Connection Diagram
0414			Device Summary
0415			Turbine Control Device Diagram
04XX			System Schematics - Various
0435			Speedtronic Cable Installation Data
	0437		Speedtronic Control Schematic (Rarely Used)
0444			One Line Diagram
0445			Interconnection Diagram
0463			Cable Block Diagram
0466			Turbine Compartment Wire List
0467			Accessory Compartment Wire List
	0470		Field Device Wire List (See 1105)
	0639		Fuel Gas Flow Measurement
1101*			Control Compartment Assembly (Turbine, Generator and Auxiliary Panels Batteries and Charger)***
1105			Field Installed Conduit Arrangement
1207			Batteries - Shipped Loose (See A083)

Table 4 Notes

The abbreviation “AO” in Table 4 designates Gas Turbine “*Advance Order*” Base Model Design.

* Ordering Sheet, additional information needed. (Note: Item may be modified by Design Change Instructions (DCI) which are not included).

** Print List, additional drawings needed.

*** Turbine and Generator Elementary Diagrams, Interconnection Diagrams, and MCC drawings are shipped as part of the compartment (i.e., no separate designation or delivery for these documents).

TABLE 5
CHECKLIST
GENERATOR INSTALLATION/ASSEMBLY DOCUMENTS

DRAWING LIST NUMBER—DLN			
AIR COOLED	H_2 COOLED	MAINTENANCE/ INFREQUENT	DESCRIPTION/DOCUMENT TITLE
001	001		Stator Assembly
008	008		Stator Wiring/RTDs & Cables
009	009		Heater Wiring
		011	Terminal Box
013	013		Rotor Assembly
	014		CO_2 Piping
028	028		Loose Parts
029	029		Brush Rigging
		030	Blower/Filter Assembly
		031	Monitor Brush Rigging
033			Coupling Guard (7A6 MSD)
		036	Fire Protection Device
037	037		Collector Housing
		039	SCT Enclosure
		040	Exciter Housing
044	044		Accessories
047	047		Duct & Roof Assembly
048	048		Assembly Diagram
049	049		Installation Instruction
050	050		Cooler
050A	050A		Cooler Spec. Sheet
		055	Cab. Package Assembly
		056	Cooler Pkg. Assembly
057	057		Line–Up Data Sheet
058	058		Clearance Diagram
059	059		Installation Devices
060	060		Package Wiring
062	062		Cooler Connection Outline
064	064		Mechanical Outline
065	065		Electrical Conn. Outline
		066	Deviation Drawing
070	070		Ladder & Rail Assembly
		071	CO_2 Enclosure
		073	Air (Gas) Flow Diagram

NOTE: DLN DESIGNATION IS CURRENTLY BEING PHASED-OUT

TABLE 5 (Cont'd)
CHECKLIST
GENERATOR INSTALLATION/ASSEMBLY DOCUMENTS

DRAWING LIST NUMBER—DLN			
AIR COOLED	H2 COOLED	MAINTENANCE/ INFREQUENT	DESCRIPTION/DOCUMENT TITLE
		080	Component Wiring
		081	Generator Wiring Diagram
		099	Generator Assembly Diagram
		100	Top Drawing
	401		Piping Hydrogen
	409		Piping Seal Oil
		903	End Shield T.E.
		904	End Shield C.E.
909			Loose Parts Pedestal
910	910		Tools & Wrenches
		926	Lube Oil System
		927	Piping SA
		928	Piping PFS
		929	Piping FA
		930	Piping PFF
		932	Water Manifold
	933		Lagging Assembly TB
		934	Piping Water Cooler
	935		Hydrogen Seal Sys.
	939		Gas Analyzer
943	943		Gasket Installation
	945		Hydrogen Cont. Monitor
		955	Brushless Exc. Elem.
		956	Brushless Exciter
		959	RTE/RTD Lead Assembly
		960	Pedestal C.E.
		981	TC Assembly T.E.
		982	TC Assembly C.E.

NOTE: DLN DESIGNATION IS CURRENTLY BEING PHASED-OUT

TABLE 6
CONSOLIDATED CHECKLIST
GAS TURBINE MSD ITEMS

MODEL LIST ITEM NUMBER	DESCRIPTION/DOCUMENT TITLE
A012	Load Gear (Incl. C.E. Coupling Guard)
A024	Bus Duct Arrangement
A025	Auxiliary Power Lineup
A033	Major Disassembly Tools
A035	Water Injection Skid
A036	Generator Auxiliary Compt–GAC
A040	Turbine Inlet Air Filter
A041	Turbine Inlet Air Duct
A042	Exhaust Duct/Stack
A044	Lube Oil Tank Vent Piping
A045	Fuel Oil Forwarding
A053	Interconnecting Piping Arrangement
A059	Package Elec Cont Compt — PECC
A062	Inter Compt Cable Arrangement
A063	Load Center
A068	Fire Protection
A076	Cooling Water Module
A087	Starting Motor Lineup
A098	Lube Oil Demister
A105	Steam Injection Metering Tube and Valve
A107	Inlet Air Filter Generator
A122	Humidity Sensor
A125	Lube Oil Flush Materials
A130	Process "Pulse" Air Skid
A138	Remote Vibration, Monitor
A139	Monitor, Hazardous Gas, Alarm
0110	Installation & Start-Up Extras-Station
0559	Inlet & Exhaust Sensor Arrangement
0624	Diesel Engine Muffler
0639	Fuel Gas Flow Measurement System
0906	Lube Oil Feed & Drain Piping
0914	Cooling Water Piping
0922	Atomizing Air Piping
0969	Base Interconnection Piping
0991	Gas Fuel Module
1101	Control Compartment/ECC
1207	Batteries
1233	Exhaust Frame Blower
1309	Load Coupling Bolts — T.E.
1310	Load Coupling
1311	Load Coupling Guard
1313	Accessory Gear Coupling
1314	Accessory Gear Coupling Guard
1602	Walkways & Stairways
1605	Enclosure to Base
1627	Acoustic Barrier
1634	Off–Base Enclosure
1643	Fan Vent Enclosure

TABLE 7
CONSOLIDATED CHECKLIST
- AIR COOLED GENERATOR MSD ITEMS AND LOOSE PARTS

Generator MSDs		Inlet Silencer/Duct Outlet Silencer/Duct Rain Hood Elbow Silencer Duct Hood Load Gear Compartment (MS6/6A3 Only) Interface Connection, See NOTE 1 (MS6/6A3 Only) Load Gear Compartment Cooling Fan (MS6/6A3 Only) CO_2 Damper (MS7/7A6 Only) Coupling Guard (MS7/7A6 Only)
"Shipped Loose" Materials (Accumulated and Shipped From Schenectady)	028	Loose Parts: — Load Coupling Bolts — C.E. (MS6/6A3 Only) — Balance Weights — Bolts (Heavy) — Nuts (Heavy) — Set Screws — Collector Brushes — Brush Release Handle — Etc.
	059	Installation Devices: — Pulling Device — Cable — Lifting Hoists (MS6/6A3 Only) — Lifting Ring (MS7/7A6 Only) — Bearing Shoe (MS6/6A3 Only) — Steel Shim (MS6/6A3 Only) — Protective Shim (MS7/7A6 Only) — Air Gap Shim — Rotor Shoe — Coupling Shoe (MS7/7A6 Only) — Pedestal Shim (MS6/6A3 Only) — Pedestal Block (MS6/6A3 Only)
	094	— Load Gear Compt. Conduit, See NOTE 2 (MS6/6A3 Only)

NOTES

1. Three pieces of U shape lagging to cover the 2 inch gap between generator & load gear compartment.

2. Four pieces of 1 inch conduit, each about 12 feet long and loose fittings used to run wire from junction-box on left side of generator load gear compartment cooling fan.

TABLE 8
GAS TURBINE DOCUMENTS BY SYSTEMS & WORK AREAS

DOCUMENT TITLE	MODEL LIST ITEM NUMBER
Alignment	
Instructions, Alignment – Factory	0410
Instructions, Alignment – Field, Basic	0411
	VENDOC
Atomizing Air	
Diagram, Schematic Piping – Atomizing Air	0425
Piping Arrangement, Atomizing Air	0965
Atomizing Air System	A056
Conduit & Wire	
Cable Installation Data, Speedtronic	0435
Diagram, Interconnection	0445
Diagram – Cable Block	0463
Wire List Turbine	0466
Wire List Field Wiring	0470
Conduit Arrangement, Turbine Compartment	1103
Conduit Arrangement, Field Wiring	1105
Conduit Arrangement, Accessory & Turbine Heating	1107
Conduit Arrangement, Cab Lights	1113
Conduit Arrangement, Wheel Space Thermocouple	1118
Conduit Arrangement, Flame Detectors	1127
Junction Box 19 Assembly	1155
Junction Box 10 Assembly	1156
Conduit Arrangement, Turbine Compartment	1159
Conduit Arrangement, Exhaust Area	1160
Cable Arrangement, Unit Intercompartment	A062
Control/Protection Systems	
Device Summary	0414
Diagram, Cont. Devices – Turbine	0415
Diagram, Schematic Piping – Trip Oil	0418
Diagram, Schematic Piping – Control Air	0419
Cable Installation Data, Speedtronic	0435
Accessory System Control Arrangement	0502
Ignition System	1213
Neutral Grounding Resistor	1228
Control Specification	A010
Panel, Control – Turbine	A014
Outline, Panel Control Turbine	A014
Panel, Control – Generator	A016
Motor Control Center (source control part)	A019
Fuel Selection Unit	E031
Station Motor Control Center	F040

Cooling Water		
	Diagram, Schematic Piping – Cooling Water	0420
	Piping Arrangement, Lube Oil Cooling Water	0914
	Piping Arrangement, Cooling Water – Turbine	0915
	Piping Arrangement – Cooling Air	0972
	Lube Oil Cooling Water Temp. Actuating Valve	1035
	Cooling Water Module	A076
Cooling & Sealing Air		
	Diagram, Schematic Piping – CLG & SLG Air	0417
	Piping Arrangement, Cooling & Sealing Air	0909
	Piping Arrangement, Air Extraction	0924
	Piping Arrangement – Cooling Air	0972
	Compressor Extraction Control Valve	1022
	Compressor Bypass Solenoid Valve	1071
Electric Power Control/Protection		
	Neutral Grounding Resistor	1228
	Motor Control Center (source control part)	A019
	Auxiliary Power Lineup	A025
	Generator Auxiliary Compartment	A036
	Static Start System – LC/DC Reactor	A140
	Static Start/Excitation Substation	A141
	Station Motor Control Center	F040
Enclosures & Ventilation		
	Diagram, Schematic Piping – Heating & Ventilation	0436
	Wire List Turbine	0466
	Walkway Arrangement	1602
	Housing, Damper	1605
	Enclosure Assembly, Turbine Compartment	1614
	Enclosure Assembly, Load Compartment	1617
	Assembly, Barrier Walls	1627
	Enclosure assembly, Turbine Compartment	1634
	Enclosure Vent Fan	1643
	Walkway Arrangement	1645
	Fan Silencer	A043
Exhaust System		
		0010
	Insulation Arrangement, Suggested	0312
	Exhaust Thermocouple Radiation Shield Assembly	0531
	Exhaust Frame Assembly	0706
	Piping Arrangement, Exhaust Plenum Drain	0976
	Cooling & Sealing Air Duct Assembly	1635
	Exhaust System	A042
	Exhaust Diffuser & Cone Assembly	A151
Exhaust Frame Cooling		
	Enclosure Vent Fan	1643
	Cooling Fan Module	A132

Fire Protection System		
	Instructions, Test–Fire Protection	0113
	Diagram, Schematic Piping – Fire Protection	0426
	Piping arrangement Fire Protection Exhaust Area	0895
	Piping Arrangement, Fire Protection – Turb. Compt.	0964
	Piping Arrangement, Fire Protection – Water	0978
	Piping Arrangement, Fire Protection – Load Compt	0981
	Lube Oil Module	0990
	Fire Protection, Exhaust Area	0995
	CO2 – Fire Protection System	A068
Foundation Interface		
	Foundation Interface Outline	0323
	Outline, Foundation Interface, Off–Base Mech	0326
	Outline, Foundation Intfc, Off Base Electrical	0330
	Foundation Bolting Arrangement	1603
	Bolting & Doweling Arrangement	1604
	Gas Turbine–Generator Foundation Embedments	F070
	Auxiliary Foundation Embedments	F071
Fuel Gas System		
	Diagram, Schematic Piping – Fuel Gas	0422
	Fuel Gas Stop Valve Assembly	0507
	Vent Assembly, Gas Compartment	0520
	Piping Arrangement, Fuel Gas	0962
	Strainer Y–Type	0931
	Metering Tube and Flow Nozzle	0941
	Lube Oil Module	0990
	Interconnecting Module	0994
Fuel Oil System		
	Diagram, Schematic Piping – Liquid Fuel	0424
	Magnetic Pick–up	0508
	Pump & Motor Assembly, Fuel Oil	0510
	Stop Valve Assembly, Fuel Oil	0511
	Bypass Valve Assembly, Fuel Oil	0516
	Servo Arrangement, Bypass Valve	0533
	Flow Divider	0613
	Piping Arrangement, False Start Drain	0920
	Piping Arrangement, Fuel Oil – Turbine	0961
	Liquid Fuel Module	0992
	Interconnecting Module	0994
	Fuel Oil System Main Filter	1013
	Fuel Oil System Secondary Filter	1014
	Hydraulic Dump Solenoid Valve – 20HD	1019
	False Start Drain Valve	1026
	Main Fuel Oil Filter Cartridge	1075
	Secondary Fuel Oil Filter Cartridge	1076
	Fuel Forwarding Skid	A045

Fuel Purge Systems		
	Diagram, Schematic Piping –Fuel Purge	0477
	Piping Arrangement, Fuel Nozzle Purge	0918
General Outlines & Diagrams		
	Outline, Gas Turbine Pkg Conn–Electrical	0301
	Outline, Mech. Gas Turbine and Load	0306
	Outline, Gas Turbine Package Conn – Piping	0313
	Notes, Gas Turbine PKG Conn Outline – Piping	0314
	Foundation Interface Outline	0323
	Outline, Foundation Interface, Off–Base Mech	0326
	Outline, Foundation Intfc, Off Base Electrical	0330
	Weights & Center of Gravity, Package	0408
	Index, Customer Drawing	0438
	Diagram, Schematic – Load Equipment	0440
	One Line Diagram	0444
	Diagram, Interconnection	0445
	Diagram – Cable Block	0463
	Nameplate Arrangement, Corp. Signature	1637
	Alternate Fuels Nameplate	A005
	Name Plate Arrangement	A006
	Shipping Instruction	A032
Hydraulic Oil System		
	Diagram, Schematic Piping – Trip Oil	0418
	Diagram, Schematic Piping – Hydraulic Supply	0434
	Diagram, Schematic Piping –IGV	0469
	Servo Arrangement, Stop Ratio & Control Valve Gas	0541
	Piping Arrangement, Control Oil Int	0908
	Hydraulic Supply Filter	1051
Inlet System		
	Diagram, Schematic Piping – Control Air	0419
	Plenum Assembly, Inlet	1612
	Inlet Air Compartment	A040
	Duct Arrangement, Inlet Air	A041
Inlet Guide Vane		
	Servo Arrangement, Actuator – IGV	0540
	Actuator Arrangement, IGV	0548
	Variable Inlet Vane Arrangement	0811
	Compressor Stator Blade Arrangement	1301
Instrumentation		
	Instrumentation Arrangement – Unit	0211
	Instructions, Test – Vibration Sensors	0214
	Thermocouple Arrangement–Turbine Wheel 1st. Stage	0218
	Instrumentation Arrangement–Compressor Disch Case	0219
	Instrumentation, Turbine Lube System	0229
	Instrumentation Arrangement, Bearing	0235
	Outline, Purchased Installed Devices	0302
	Data, Temp & Heat Radiation	0412

	Diagram, Schematic Piping – Hazardous Gas Detection	0474
	Pick–up Arrangement, Magnetic – HP	0546
	Pressure Transducer Arrangement, Unit	0557
	Inlet & Exhaust Sensor Arrangement	0559
	Parts List, Thermocouple	0623
	Thermocouple Arrangement	0637
	Fuel Gas Measurement System	0639
	Metering Tube & Orifice	0939
	Metering Tube and Flow Nozzle	0941
	Tubing Arrangement, Performance Monitoring Sys	0987
	Conduit Arrangement, Turbine Compartment	1103
	Detector, Flame	1121
	Sensor Arrangement, Vibration – Turbine	1218
	Conduit Arrangement, Inlet Heating	A037
	Integral Distribution Center	A106
	Data Analyzer & Processing System	A108
	Sensor Arrangement, Humidity	A122
	Shaft Voltage Monitor	A138
Insulation		
	Turbine Insulation Specification	0311
	Insulation material (Field installed)	0327
Load Coupling		
	Hardware – Load Coupling	1309
	Guard, coupling – Load Assembly	1311
	Coupling Solid Output	1319
Lube Oil System		
	Lube Oil System Orifice Test	0224
	Vent Arrangement – Oil Tank, Sugg	0413
	Diagram, Schematic Piping – Lube Oil	0416
	Index, Customer Drawing	0438
	Instructions, Lube Oil Selection	0465
	Diagram, Schematic Piping – L.O. & CTL Intercon	0489
	Fuel Gas Control Valve Assembly	0509
	Hydraulic Pump	0627
	Auxiliary Hydraulic Pump	0628
	Piping Arrangement, Lube Oil Feed & Drain – #1 Brg	0905
	Piping Arrangement, Lube Feed & Drain	0906
	Piping Arrangement, Lube Oil Feed & Drain – #2 Brg	0907
	Strainer Y–Type	0929
	Base Interconnection Piping Arrgt.	0969
	Lube Oil Module	0990
	Lube Oil System Heat Exchanger	1001
	Lube Oil System Main Pump	1005
	Lube Oil System Auxiliary Pump	1006
	Lube Oil System Emergency Pump	1007
	Lube Oil System Main Filter	1010
	Manual Trip Valve	1021

	Lube Oil Pressure Regulator Valve – VPR	1023
	Lube Oil System Heat Exchanger Transfer Valve	1029
	Lube Oil System Filter Transfer Valve	1030
	Lube Oil Liquid Level Switch	1038
	Lube Oil Pressure Regulating Orifice	1043
	Lube Oil System Main Filter Cartridge	1053
	Emergency Seal Oil Pump – DC	1059
	Lube Oil Vapor Vent Piping	A044
	Field Interconnection Piping Arrangement	A053
	Lube Oil Vapor Vent & Demister	A098
	Piping, Lube Oil, Flush Field	A125
Processing/"Pulse" Air		
	Process/"Pulse" Air	A130
Paint		
	Instructions, Cleaning and Painting	0108
Starting Means		
	Diagram, Schematic Piping – Starting Means	0421
	One Line Diagram	0444
	Starting Unit (source controlled)	0997
Steam Injection		
	Diagram, Schematic Piping – Steam Injection	0431
Test Instructions		
	Instructions, Test–Generator	0201
	Instructions, Test–Accessories	0202
	Instructions, Test–Controls	0203
	Instructions, Test–Piping	0204
	Instructions, Test–Electrical	0205
	Instructions, Test–Vibration Sensors	0214
	Unit Test Instrumentation	0226
	Instructions, Test–field	0234
	Power Plant Equipment Parts List	A003
	Tool kit, Nozzle Removal – Stage 1	AA033
	Tool Kit, Rotor Jacking	AB033
Tools/Extras		
	Installation, Start–Up Extras	0106
	Tool Kit	0104
	Instruction, Tool Use	0105
	Tool kit, Major Disassembly	A033
Turbine Components & Assembly		
	Arrangement of Shipping Attach.	0103
	Turbine Connection Diagram	0401
	Diagram, Clearance–Unit Assembly	0404
	Diagram, Final Rotor System	0405
	Gas Turbine Arrangement	0406
	Weight & Center of Gravity, Gas Turbine	0407
	Alignment Diagram – Unit Assembly	0409
	Data, Temp & Heat Radiation	0412

	Diagram, Schematic Piping – Heating & Ventilation	0436
	Diagram, Flow – Inlet & Exhaust	0471
	Fuel Gas Stop Valve Assembly	0507
	Chamber Arrangement, Combustion	0701
	Combustion – Transition Piece Assembly	0702
	Combustion – Cap & Liner Assembly	0703
	Turbine Casing Assembly	0705
	Combustion – Outer	0713
	Combustion – Transition Piece Arrangement	0717
	Combustion – Outer Case Arrangement	0719
	Compressor – Inlet & #1 Bearing Assembly	0801
	Compressor – Forward Casing Assembly	0802
	Compressor – Aft Casing Assembly	0803
	Compressor – Discharger Casing Assembly	0805
	Inlet Casing Assembly	0812
	Unit Base – Fabrication & Machining	0901
	Tubing Arrangement, Performance Monitoring Sys	0987
	Spark Plug – Spring Positioning	1214
	Compressor Stator Blade Arrangement	1301
	Compressor Rotor & Turbine Assembly	1302
	Compressor Rotor Assembly	1303
	Turbine Rotor Assembly	1305
	First Stage Nozzle Arrgt.	1401
	Second Stage Nozzle Arrgt.	1402
	First Stage Nozzle Support Ring	1403
	Third Stage Nozzle Arrgt.	1409
	Bearing #1 Assembly	1501
	Bearing #2 Assembly	1502
	Thrust Bearing Assembly	1507
Turning Gear		
	Diagram, Schematic Piping – Starting Means	0421
	Turning Gear	A073
Water Injection System		
	Diagram, Schematic Piping – Water Injection	0462
	Fuel Nozzle assembly – Dual Fuel	0512
	Piping Arrangement, Water Injection	0968
	Water Injection Skid	A035
Water Wash System		
	Diagram, Schematic Piping – Turbine & Comp Washing	0442
	Diagram, Schematic Piping – Water Forwarding Unit	0461
	Piping, Compressor Washing	0953
	Water Wash Skid	E025

TABLE 9
CHECKLIST
TYPICAL BOP A/E PRINTS

IDENTITY/DISCIPLINE	DESCRIPTION/DOCUMENT TITLE
CIVIL/STRUCTURAL	
C001	General Notes — Civil
C100	Topographic Site Plan
C101	Grading and Drainage Plan
C103	Site Excavation Plan
C105	Site Work Roadways
C130	Pile Plan
C300	Foundation Arrangement: — Unit — Unit Sections — Off Base Equip. — Off Base Equip. Sections
C400	Equip. Foundations — Misc. (Skids)
C900	List of Installation Materials — Civil Incl. Embedded Steel Details
ELECTRICAL/CONTROL	
E001	General Notes & Symbols — Electrical
E150	One–line Diagram
E164	Phasing Diagram
E175	Grounding Conduit
E200	Grounding — Station
E208	Grounding — Units #4 & #6
E300	Embedded Conduit — Station
E308	Embedded Conduit — Unit
E508	Lighting and Conduit Arrangement Plan — Station
E901	List of Installation Materials — Electrical
MECHANICAL/FLUID	
M004	Plot Plan
M005	Station Arrangement
M027	Equipment Arrangement
M200	General Notes & Symbols — Mechanical
M215	P&I Diagram
M222	Flow Diagram
M301	Piping Arrangement Plan — Station Piping
M304	Piping Arrangement Plan — Station Drains
M900	Material Specifications — Mechanical
M901	List of Installation Materials — Mechanical