BDCOM OLT SHORT COMMEND

DDM SHOW

#config
#ddm enable

OLT AUTO NOTIFICATION OFF

#config
no terminal monitor

BDCOM OLT 10G PORT FIBER MOOD AUTO ON COMMEND

#config
interface tGigaEthernet 0/2
fiber-auto-config filter
ex
Speed 10000

BDCOM OLT GIG/TG 1G PORT NO FIBER CONFIG

#CONFIG
interface tgigaEthernet 0/4
no fiber-auto-config
ex
speed 1000

BDCOM OLT INTARFACE SHOW COMMEND

#config
#show interface brief

BDCON ACTIVE ONU SHOW COMMEND

—----------

#confige
show epon active-onu interface epoN 0/1

BDCOM OLT INACTIVE MAC DELETE

—----------

#config
#show epon inactive-onu interface epON 0/1
#interface epON 0/1
#no epon bind-onu mac

BDCOM OLT AII MAC DELTE COMMEND

—--—----------

#config
#show epon onu-information interface epON 0/1
#interface epON 0/1
#no epon bind-onu mac

UPLIK PORT OPTICAL POWER

#config
#show ddm

BD COM OTL PON ONU MAC SHOW RX ONU Received

#config
#show epon onu-ctc-optical-transceiver-diagnosis interface epon 0/1

BDCOM OLT ONU DB CHECK COMMEND TX OLT Received

#config
#show epon optical-transceiver-diagnosis interface epON 0/1

GPON ONU MAC SHOW

#config
#show mac address-table interface gpon 0/1

BDCOM OLT PON DB SHOW

#config
#show epon optical-transceiver-diagnosis

BDCOM OLT ONU BANDWIDTH 1G COMMAND

config#
interface epon 0/1:1
epon sla upstream pir 100000 cir 10000
epon sla downstream pir 100000 cir 10000
exit
write all

BDCOM OLT PON MAC SHOW

#config
#intarface epon 0/1
#show mac address-table

GPON ONU MAC SHOW

#config
#show mac address-table interface gpon 0/1

DBC OLT PON ALL MAC DELLETE COMMEND

#config
#default mac interface epon 0/1

OLT Port Hybrid

#Config
#interface GigaEthernet 0/1
no shutdown
switchport mode hybrid
switchport hybrid vlan-allowed add 100

Exi

OLT PORT Trunk

#config
#interface GigaEthernet 0/1
no shutdown
switchport mode trunk
switchport trunk vlan-allowed add 100
exi

OLT PORT ACCESS

#Config
#interface GigaEthernet 0/1
description Access Port
switchport mode access
switchport pvid 000
exi

port vlan Trunk

#config
interface gigabitethernet 0/6

switchport mode trunk
switchport trunk vlan allowed add 100
exi

port vlan Access

#config
interface gigabitethernet 0/0
switchport mode Access
switchport access vlan 00
exi

BDCOM OLT TAT UNTAG CONGIFURE

config#
interface epon 0/1
switchport mode trunk
switchport trunk vlan-allowed 2970,1871
switchport trunk vlan-untagged 2970
switchport pvid 2970

BDCOM OLT OFFLINE MAC AUTO DELETE

config#
mac address-table aging-time 300

PON ACCESS COMMEND

#config
interface epON 0/4
no shutdown
switchport mode access
switchport pvid 2241
exit

VALN TAG CONFIGURE

Config
interface epON 0/2:43
epon onu port 1 ctc vlan mode tag 3508
desc JAGORONITV
Exit
write all

VLAN ID delete করবেন।

enable
config
no vlan 100

INTERFACE VLAN IP address DELETE

config
interface vlan 3680
no ip address 10.112.200.18 255.255.255.252

Save configuration

—----------

#config
#write all

Reboot Device

—----------

#config
#reboot

Default/Factory Reset

—----------

#config
#erase startup-config

y দিন, তারপর: **REBOOT korte hobe**

monitor# reboot

IP ROUTE

#config
ip gateway

IP ROUTE

#Config
#ip default-gateway

IP ROUTE

#config
#ip route

VLAN REMOVE

#config
#no vlan

DESCRIPTION REMOVE

#CONFIG
#no description

BDCOM GPON OLT VLAN TAG

Switch_config#
gpon profile onu-vlan v2046
gpon-profile vlan mode tag
gpon-profile vlan pvid 2046

Switch_config#
int gpon 0/2:1
gpon onu uni 1 vlan-profile v2046

BDCOM OLT LOOPBACK OFF COMMAND

config#
epon onu config template Loopback

Config#
cmd-sequence 001 epon onu port 1 ctc loopback detect
cmd-sequence 002 epon onu port 1 ctc notify loopback

Config#
interface epoN 0/1
OLT_Config_epon0/1# epon pre-config-template Loopback
binded-onu-llid 1-64

cmd-sequence 001 epon onu port 1 ctc loopback detect
cmd-sequence 002 epon onu port 1 ctc notify loopback

BDCOM OLT VLAN TAG

interface epON 0/1:19
epon onu port 1 ctc vlan mode tag 1871
exit
epon reboot onu interface epON 0/1:1

BDCOM-ACTIVE/BACKUP-CONFIGURE

backup-link-group1
interface TGigaEthernet0/1
backup-link-group 1 active
exit
interface TGigaEthernet0/3
backup-link-group 1 backup
exit
backup-link-group 1 preemption-mode forced

VSOL OLT SHORT COMMEND

—----------

OLT AUTO NOTIFICATION ALARN OFF

#config

Alarm all print disable

VSOL OLT GIG PORT 1G TO 10G UPDATE

#config

debug mode

set giu mode sfp+

VSOL OLT Gig ports SFP Optical Power Comman

#congif
#configure terminal
#interface gigabitethernet 0/1
#show optical transceiver

VSOL OLT PON ports SFP Optical Transceiver Commands

#configure terminal
#interface epon 0/1
#show pon optical transceiver

VSOL OLT All ONU/ONT Optical Diagnosis Commands

—----------

#config
#show onu opm-diag all

V SOL OLT ONU RX TX POWER SHOW COMMEND

—----------

#config terminal
#intarface epon/Gpon 0/1
#show pon onu all Rx-power / show onu opm-diag

V SOl And DBC ONU BD CHECK

—----------

#config
#show onu opm-diag pon-1
#exit

PON ER ONU POWER SHOW COMMAND

#configure terminal
show onu opm-diag pon 3

PON ER POWER SHOW

#configure terminal
show pon baisc-info

PON ER MAC SHOW

#configure terminal
show onu basic-info al

V SOL OLT INTARFACE SHOW

—----------

#config terminal
#show interface brife

V SOL OLT MAC DELETE COMMEND

—----------

#config
#interface epon 0/1
#show onu auth-info
#no onu auth onuid 00

V SOL OLT PON ALL MAC DELETE COMMEND

—----------

#config
#intarface epon 0/1
#no onu auth all

V SOL OLT Auto onu DELETE command:

—----------

#config
#onu auto-undo-auth enable timeout

VSOL OLT MAC ADD COMMEND

—----------

#config
#interface epon 0/1
#show onu auth mode mac
#show onu auth-fine
#onu mac auth add

V-Sol loopback configure

#config
#loopback mode manual-recovery
#write

VSOL OLT ONU UPTIEM COMMEND

—----------

#congif
#show onu time-stamp

Web-Login Timeout

—----------

#config
web login timeout 30

Show Vlan Mac

—----------

#config
show vlan 1

VSOL OLT GIGabitethernet PORT SHOW

—----------

#config
#show running-config interface gigabitethernet 0/1

IP ROUTE

—----------

#config
#ip Route 0.0.0.0 10.151.22.17

IP ROUTE OID VERSON

—----------

#config
ip gateway

Save configuration

—----------

#config
write

Reboot Device

—----------

#config
#reboot

Default/Factory Reset

—----------

#config
#erase startup-config

V Sol OLT Verification Code Disable

#config
#web verification-code disable

OLT PORT Trunk

—----------

#interface GigaEthernet 0/1
#no shutdown
#switchport mode trunk
#switchport trunk vlan-allowed all
#exi

OLT PORT ACCESS

—----------

#Config
interface GigaEthernet 0/7
description router
switchport mode access
switchport vlan 1969
Exi

port vlan Trunk

—----------

#config
#interface gigabitethernet 0/0
switchport mode trunk
switchport trunk vlan allowed

port vlan Hybrid

#config
#interface gigabitethernet 0/2
description UTSHAB
#switchport mode hybrid
#switchport hybrid vlan 1879 tagged

PORT RANG VLAN HYBRID

#config
interface gigabitethernet 0/1
description
switchport mode hybrid
switchport hybrid vlan 326 - 330 tagged
ex

port vlan Access

—----------

#config
interface gigabitethernet 0/5
switchport mode Access
switchport access vlan 2260

PON ACCESS COMMEND

—----------

#config
#interface epON 0/1

#switchport mode access
#switchport vlan 100

V SOL OLT PON VLAN TAG MOOD COMMEND

VLAN UNTAG

#config
#interface epON 0/1
#switchport mode hybrid
#switchport hybrid vlan 1675

VLAN TAG

#config
#interface epON 0/1
#switchport mode hybrid
#switchport hybrid vlan 301 tagged

VLAN TAG UNTAGE

#config
interface epon 0/1
switchport mode hybrid
switchport hybrid vlan 1 untagged
switchport hybrid vlan 450 tagged
switchport hybrid pvid vlan 1

PON ISOLATE OFF

#config
interface-range-epon0/1-4
no switchport isolate
ex

GIGABITHERNT PORT ISOLATE OFF

#config
interface gigabitethernet 0/0
no switchport isolate
ex

V-SOL GPON OLT SHORT COMMEND

Host Name

#config
#hostname

Create VLAN

#config
vlan 3999

description —

#config
#vlan 10 - 1000

Delete VLAN

#config
#no vlan 3999

OR REANG VLAN

#config
#no vlan 10 - 1000

Show VLAN

#config
show vlan all

OR

#config
show vlan 10

V SOL GPON OLT PON ALL MAC DELETE COMMEND

#Config
#interface gpon 0/3
#no onu all

Gigabitethernet POT uplink Optical Leaser

#config
#show gigabitethernet optical transceiver all

ONU optical information

#config
#show pon optical transceiver all

PON ONU optical information

#config
#interface gpon 0/1
#show pon onu all rx-power

All ONU leaser

#config
#interface gpon 0/1
#show pon onu all rx-power

All ONU info

#config
#show onu info

Show Single ONU Optical laser:

#config
#interface gopn 0/1
#show onu 1 optical_info

Gigabitethernet Uplink Port Trunk

#config
interface gigabitethernet 0/1
switchport mode trunk
switchport trunk vlan 3999 tagged

Gigabitethernetport vlan Hybrid

#config
interface gigabitethernet 0/2
switchport mode hybrid
switchport hybrid vlan 1879 tagged

Gigabitethernet port vlan Access

#config
interface gigabitethernet 0/1
switchport mode Access
switchport access vlan 111

Uplink Port Speed

#config
#interface gigabitethernet 0/1
#speed auto
#speed 10
#speed 100
#speed 1000
#speed 10000

IP against VLAN

#config
#interface vlan 10
#ip address 192.168.12.111 255.255.255.0
#exit

IP Route

#config
#ip route 0.0.0.0 0.0.0.0 192.168.12.1

Show Vlan Mac

#config
#show vlan 1

MAC address table

#config
#show mac address-table

Uplink MAC Address Table

#config
#show mac address-table interface gigabitethernet 0/1

PON MAC Address table

#config
#show mac address-table interface gpon 0/1

Loop_Detect

#config
#loopback detect enable
#loopback mode auto-recovery loopback aging-time 300

TAG VLAN ALLOW

Config
profile srv id 11 name S@S
portvlan eth 1 mode tag vlan 3502 pri 0
portvlan eth 2 mode tag vlan 3502 pri 0
portvlan eth 3 mode tag vlan 3502 pri 0
portvlan eth 4 mode tag vlan 3502 pri 0
commit
exit

Config
profile line id 11 name S@S
tcont 11 dba max_bw
gemport 1 tcont 11
service 1 gemport 1 vlan 3502
service-port 1 gemport 1 uservlan 3502 vlan 3502
commit
exit

ONU detailed info & ONU Firmware version

#config
#interface gpon 0/1
#show onu detail-info

Gigabitethernet Port Isolation ON/OFF

#config
#interface gigabitethernet 0/1
#switchport isolate
#no switchport isolate

PON Port Isolation ON/OFF

#config
#interface gpon 0/1
#switchport isolate
#no switchport isolate

10G port enable

#config
#debug mode
#set giu mode sfp+

show onu online /offline number:

#config
#interface gpon 0/1
#show onu state

PON onu reboot:

#config
#interface gpon 0/1
#onu 1 reboot

All PON DELETE

#config
#interface gpon 0/1
#onu all reboot
(ONU all reboot in a interface)

GPON reboot ONU

#config
#interface gpon 0/1
#onu all reboot

ONU remove

#config
#interface gpon 0/1
#no onu 1

Version check

#config
#show version

Temperature

#config
#show fan

Default/Factory Reset

#config
#erase startup-config

OLT REBOOT

#config
#reboot

Web-Login Timeout

#config
#web login timeout 30

Save configuration

#config
write

HUAWEI OLT SHORT COMMEND

রানিং কনফিগ

display current-configuration

ONU CONFIGURE SHOW COMMAND

display current-configuration ont 0/1/5 22

অটো ফাইন্ড অনু - অল

display ont autofind all

অনু ম্যাক কনফিগার

interface gpon 0/0

ont add 6 69 sn-auth D4F9A11EA161 omci ont-lineprofile-id 507
ont port native-vlan 6 69 eth 1 vlan 507 priority 1

quit

সার্ভিস পোর্ট কনফিগার

service-port 122 vlan 507 gpon 0/0/6 ont 69 gemport 507
multi-service user-vlan 507 tag-transform translate

পনে কত গুলা অনু আছে তা দেখার জন্য:

interface gpon 0/0
display ont info 0 all

ওএলটি তে কত গুলা টোটাল অনু কনফিগার করা হয়েছে তা দেখার জন্য:

display service-port all

PON ER VLAN SHOW COMMAND

config#
display port vlan 0/1/0

ONT SUMMARY

Config#
interface gpon 0/0
display ont info summary 0

ONT LINEPORFILE SHOW COMMAND

config#
display ont-lineprofile epon all

ওএলটি তে কত গুলা টোটাল অনু কনফিগার করা হয়েছে তা দেখার জন্য:

Config
display service-port all

অনু যদি কনফিগার না নেয় তাহলে চেক করতে হবে অনটা এই ওএলটিতে কনফিগার করা আছে কিনা..

display current-configuration | include b8fb-b37d-e2bd

PON POWER SHOW COMMAND

interface gpon 0/0
display port state all
AND
display ont info summary 0

পন অল পাওয়ার শো

interface gpon 0/0
display ont optical-info 5 all

সিঙ্গেল অনু পাওয়ার শো

interface gpon 0/0
display ont optical-info 0 all

কোন অনু ডিলিট করতে হলে , আগে দেখে নিতে হবে অনুটা কোন **port** এ অনু কনফিগার করা আছে।
এর পর অনু ডিলিট করতে হবে।

ONU FIND
display current-configuration | include 8479-73FB-4A54

UNDO MAC
undo service-port port 0/0/3 ont 14
yes

interface gpon 0/1
ont delete 3 14
quit

ONU RESET

interface gpon 0/1
`ont reset 3 18`

অল ভিলেন শো

display vlan all

IP address assigns For MGT

interface vlanif400
ip address 192.168.12.6 255.255.255.252

IP ROUTE

ip route-static 0.0.0.0 0.0.0.0 192.168.12.5

কনফিগার অল সেভ

SAVE

EXET

QUIt

EPON OLT ONU DELETE

ONU FIND

display current-configuration | include 8479-73FB-4A54

config
undo service-port port 0/0/1 ont 0

Config
interface epon 0/0
ont delete 1 0

New Onu Add

interface epon 0/1
ont add 0 1 mac-auth 1C18-4A4F-74D0 oam ont-lineprofile-id 117 ont-srvprofile-id 117
ont port native-vlan 0 1 eth 1 vlan 477
quit

service-port 815 vlan 477 epon 0/1/0 ont 1 multi-service user-vlan 477 tag-transform translate

Ont Enther Port Add

config
interface epon 0/0
ont port native-vlan 0 1 eth 1 vlan 477

PON ALL POWER SHOW COMMAND

Config
interface epon 0/0
display ont optical-info 1 all

সিঙ্গেল অনু পাওয়ার শো

Config
interface epon 0/0
display ont optical-info 0 5

পনে কত গুলা অনু আছে তা দেখার জন্য:

Config
interface epon 0/0
display ont info 0 all

PON POWER SHOW COMMAND

interface epon 0/0
display port state all
OR
display ont info summary 0

C-DATA OLT SHORT ALL CONFIGURE

1.OLT Connect with PC:

****

PC IP: 192.168.1.11
OLT IP: 192.168.1.100 (telnet to OLT)

2.OLT Vlan Configuration:

****

epon# swmode vlan enable
vla 100
member add ge1,ge5 tag

3.Iligal DHCP Control:

****

epon(olt-1)# packet-filter dhcp enable
show olt 1 packet-filter

iligal DHCP Show Command

****

epon# dhcp-snooping admin enable
epon# dhcp-snooping port ge1 untrust

check/show broadcast /Abnormal Traffic

****

Epon# how swport ge1 statistics

4.Loop detect enable from ONU:

****

olt 1
onu 1
uni 1
ctc loop-detect enable
ctc looped enable

5.storm-ctrl:

****

epon#storm-ctrl
epon#storm-ctrl enable broadcast 10 (Limited packet)

Mac Binding Configuration:

****

epon#swport ge5 (pon 1)
epon(GE-5)#mac-address static (mac address)

Mac Address showing Configuration:

****

epon# olt 1 (pon port 1)
epon# mac-address-table learning enablee
epon# show mac-address-table

epon# show mac-address-table vlan id/all
epon# show mac-address-table all
epon# show mac-address-table port ge1

MGMT VLAN Configuration:

****

epon# show system ipconfig
epon# system ipconfig mgmt-vlan 15
epon# system ipconfig inband 172.31.31.2 255.255.255.252
epon# system ipconfig gateway 172.31.31.1

ONU Trunk Vla Configuration:

****

epon# olt 1
epon# onu 1
epon# uni 1
epon# description Test_ONU
epon# ctc vlan-mode 0x8100 0 1 vlan-list 20 (singl port ONU tag clint side)
epon# ctc vlan-mode tag 0x8100 0 101
epon# show olt 1 onu 1 uni 1 ctc vlan-mode
epon# show olt 1 online-onu (at a time show all onu with Distance)
epon# show olt 1 onu 6 uni 1 ctc vlan-mode
epon# show olt 1 online-onu
epon# or- show olt online-onu 1
epon# show olt 1 all-onu-info
epon# show olt 1 optical-online-onu (at a time show all onu with power)
epon# show olt optical-online-onu 1 (at a time show all onu with power)
epon# epon(olt-2/onu-3/uni-1)# storm-ctrl enable broadcast 2048
NOU Ethernet port Disable/Enable:
epon#olt 1 onu 1 uni 1 ctc admin disable/enable

Update ONU Firmware

****

epon# system update onu 192.168.101.11 FD304HC.mif ONU4FE1TVC

Backup ONU Configuration File:

****

system configurations backup onu <tftp-server>

Backup ONU configuration file into PC machine:

****

system configurations backup onu 192.168.2.130
Backup onu configurations file to host 192.168.2.130.
Remote filename: onu_cfg_backup_20000101060207.tar.gz.

Download ONU Configuration File:

****

system configurations download onu <tftp-server> <filename>

Download ONU configuration file:

****

system configurations download onu 192.168.2.130
onu_cfg_backup_20000101060207.tar.gz
Download onu configurations file from host 192.168.2.130

PON Port Manually Authentication:
8port_OLT# auth manual

Stroming Control:

****

epon# epon(olt-1/onu-1/uni-1)# qos
epon# storm-ctrl enable broadcast
epon# storm-ctrl enable broadcast 10

QinQ:

*****

qinq
qinq enable
qinq enable 100
qinq enable 100 raw-vlan-id-inbound
qinq enable 100 raw-vlan-id-inbound 10 ge1

Turn-on and Turn-off of Log Function:

****

system log admin all enable
show system log all

View the last 5 lines of all current logs:

****

show system log tail 5

View logs of ONU port loop warning:

****

show system log type onu-uni-loopback-alarm

Backup Log:

****

system log backup 192.168.2.130 (tftp/pc ip)

Clear Log:

****

system log flush

p2p :

****

epon# olt 1 p2p enable (same pon onu to onu command)
epon# show olt 1 p2p
epon# olt 1
epon(olt1)#onu 1
epon(olt-1/onu-4)# protect enable
p2p all pon port
epon# swmode pve switch (all pon onu p2p access command, its

means port isolation)

P2P port group create
epon# swmode pve
epon# swmode pve diy group add 1 ge1,ge2 (it means pon1 & pon2 p2p connection under group1)
epon# show swmode pve
system working node diy
----
epon# system save all

Backup OLT Configuration File:

****

system configurations backup olt <tftp-server>

Backup OLT configuration File into PC machine:

****

system configurations backup olt 192.168.2.133
Backup olt configurations file to host 192.168.2.133.
Remote filename: olt_cfg_backup_20000101055726.tar.gz.

Download OLT configuration file from PC machine:

****

configurations download olt 192.168.2.130
olt_cfg_backup_20000101063321.tar.gz

Automatic Backup of Configuration File:

****

system configurations auto-backup admin <admin>
system configurations auto-backup backup-type <type>
system configurations auto-backup interval <interval>
system configurations auto-backup server <ip>

Backup the configuration file into the tftp server with the IP address 192.168.5.122

****

system configurations auto-backup admin enable
system configurations auto-backup backup-type all
system configurations auto-backup interval 1
system configurations auto-backup server 192.168.5.122

Reset the entire device to factory default configuration:

****

system default all
Reboot the system now<y/n>?y

Save Current Configuration:

****

system save <all> or <olt>

Save all current configuration:

****

Save all current configuration

View all current configuration:

****

show running-config all

View Configuration File of Start-up File:

****

show startup-config all

Restart OLT:

****

system reboot

Update OLT Firmware:

****

system update firmware <firmware> tftp-server <ip>
system update firmware FD1104B_V2.3.01_161205_X000.img tftp-server 192.168.5.122

Update ONU Firmware:

****

system update onu <tftp-server> <file> <onu type>
system update onu 192.168.101.11 FD304HC.mif ONU4FE1TVC

ONU Remote remote management IP Configuration command:

****

epon(olt-1/onu-19)# ctc mng-ip 192.168.12.122 255.255.255.0 192.168.12.1

Configurate Snmp Community of Reading and Writing of OLT:

****

system snmp community read-only <community>
system snmp community read-write <community>
system snmp community read-only public
system snmp community read-write private

Configurate Warning Receive Address:

****

system snmp trap-ip <index> <ip-addr>
system snmp trap-ip 1 192.168.5.122

View SNMP Information:

****

show system snmp

Turn-on and Turn-off of Log Function:

****

system log admin <module> <admin>
system log admin all enable

Backup Log:

****

system log backup <server-ip>
system log backup 192.168.2.130

View Log:

****

show system log admin
show system log all
show system log tail <line>
show system log tail 5
show system log type onu-uni-loopback-alarm
system log flush
Clear all logs

Configurate and Manage VLAN:

****

system mgmt-vlan < vid>
system mgmt-vlan 100
show system ipconfig
show system ipconfig

Configurate the Status of Specific IP Remote Management:

****

system mgmt-ip access-control <admin>
system mgmt-ip access-control enable
system mgmt-ip access-ip-add <ip-addr> <mask>
system mgmt-ip access-ip-add 192.168.6.66 255.255.255.0
system mgmt-ip access-ip-del 192.168.6.66
show system mgmt-ip

Configurate system MTU:

****

system mtu <mtu>
system mtu 1518
show system mtu
show system mtu

Configurate Auto- Adaptive to Net Time Function:

****

system date ntp admin <admin>
system date ntp admin enable
system date ntp interval <interval>
system date ntp interval 300
system date ntp server <ip>
system date ntp server 192.168.5.254
system date ntp timezone <mask> <hours>
system date ntp timezone + 12
system date manual 2015.12.12-10:10:10

Show Command for 4 port OLT:

-

show system access-control - access control to management the olt
show system auto-backup-info - show system auto backup infor
show system aux-port-admin - show system aux port config
show system cpu - show system cpu usage
show system infor - show system infor
show system ipconfig - show ipconfig
show system log - show system log
show system loop-detect - loop detect on the pon port
show system memory - show sys memory
show system mgmt-vlan - show sys mgmt-vlan
show system mtu - show sys mtu
show system non-standard-mac - permit or deny the non standar mac address
show system ntp-info - show system ntp infor
show system onu-template-config - show onu-template configuration
show system snmp - snmp
show system uptime - Show system run time
show system user - show system user
show system user
show system snmp
show system all - show all logs
show system config - show log config
show system tail - show the tail of the log file
show system type - show logs of specific type
system log admin - enable or disable log for specific module
system log backup - backup log file to tftp server
system log flush - empty log file
system log level - configure system log level

PVID Configuration:

epon#vla 801
epon#member add ge1 tag
epon#member add ge5
epon# swport ge5
epon# pvid 801
epon# vlan add 801
epon# system save all

OLT to OLT connection with Redundancy

epon# trunk 1
epon(trunk-1)# member add ge3
epon(trunk-1)# member add ge4

show switch mode:

8port_OLT# show swmode pve

ALARM DISABLE:

epon(config)# alarm output all disable

VSOL SWITCH FULL CONFIGURE

192.168.8.100

LOGIN USER NAME PASSWORD

Username: admin
Password: admin

CONFIG MOOD

#configure

HOSTNAME

configure
Hostname BONOGRAM-LAN-SWITCH

VLAN ADD

configure
vlan 118-610,1000,1208

Management IP

configure
interface vlan1000
ip address 10.141.200.18 255.255.255.252

GIGA TE PORT TRUNK

configure
interface TE1
description UPLINK
switchport trunk allowed vlan add 1000,1208

GIGA TE PORT HYBRID

configure
interface TE2
description BADSHA-EPON-OLT-2
switchport hybrid allowed vlan add 1208

ROUTE

configure
ip route 0.0.0.0/0 10.141.200.17

ALL CONFIG SAVE

copy running-config startup-config

GIGA PORT DB SHOW COMMAND

configure
show fiber-transceiver interfaces TenGigabitEthernet 1-12

====BD COM====

192.168.0.1

Username-admin
Password-admin
Switch>ena

VLAN Creation:

#config
#vlan 351-359
#show vlan

UPLINK PORT VLAN CONFIGURE

Switch_config
interface gigaEthernet 0/1
Description UPLINK
no shutdown
switchport mode trunk
switchport trunk vlan-allowed 351-359
exit

Assign BDCOM OLT login ip

#config
interface vlAN 359
ip address 10.10.20.46 255.255.255.252

IP ROUTE

#config
#ip route 0.0.0.0 0.0.0.0 10.10.20.45

PON-1 ACCESS MOOD 101

1. PON PORT 1
Switch_config
interface epON 0/1
no shutdown
switchport mode access
switchport pvid 351
exit

PON-2 ACCESS MOOD 101 352

2 PON PORT 2
Switch_config
interface epON 0/1
no shutdown
switchport mode access
switchport pvid 352
exit

3. PON PORT 3

PON-3 ACCESS MOOD 101 353

Switch_config
interface epON 0/3
no shutdown
switchport mode access
switchport pvid 353
exit

4. PON PORT 4

PON-4 ACCESS MOOD 101 354

Switch_config
interface epON 0/4
no shutdown
switchport mode access
switchport pvid 354
exit

5. PON PORT 5

Access port then assign VLAN 355

Switch_config
#interface epON 0/5
#no shutdown
#switchport mode access
#switchport pvid 355
#exit

6. PON PORT 6

Access port then assign VLAN 356

Switch_config
#interface epON 0/6
#no shutdown
#switchport mode access
#switchport pvid 356
#exit

7. PON PORT 7

Access port then assign VLAN 357

Switch_config
#interface epON 0/7
#no shutdown
#switchport mode access
#switchport pvid 357
#exit

8. PON PORT 8

Access port then assign VLAN 358

Switch_config
#interface epON 0/8
#no shutdown
#switchport mode access
#switchport pvid 358
#exit

CONFIG SAVE

#write all

====DBC====

DBC EPON OLT default info:

The IP address: is 192.168.8.100
Username: admin
Password: Xpon@Olt9417#
Enable Password: Xpon@Olt9417#

Uplink with Vlan Configuration:

Here we have 4 Port vsol epon olt and we need to configure with different VLAN to each pon port. That means 4 pon ports and 4 different VLAN interfaces. So now we are creating the VLAN in our OLT. Our uplink port is G2 and let's start creating VLANs.

VLAN Creation:

Username:admin
Password: Xpon@Olt9417#
epon-OLT> ena
Password: Xpon@Olt9417#
#configure terminal
vlan 200 - 204
exit

Our VLANs (200 - 204) was successfully created and now we can use these VLANs for service. So we will be using VLAN 200 for olt MGT (remote management) and VLAN 201 to 204 for pon port.

Uplink Port Configure:

Now we are configuring our uplink as G2

#config)
interface gigabitethernet 0/2
switchport mode trunk
switchport trunk vlan 200 - 204
exit

Our uplink port G2 is successfully trunk configured with VLANs. Now we can check the mac address in the VLAN interface.

Mac Address Checking:
#config
show mac address-table interface gigabitethernet 0/2

IP address assigns For MGT:

We can access OLT from our LAN side. It needs to assign an IP address. through which the OLT will be accessed. So let's assign an IP to VLAN 400 for olt MGT (remote management) access using the below command.

IP address assigns

#config
#interface VLAN 200
ip address 10.200.200.6 255.255.255.252
exit

IP ROUTE:

#config
ip route 0.0.0.0/0 10.200.200.5

Pon Port Configure:

Now we need to configure the PON port. We have created 4 VLANs for 4 PON ports.
so let's start,

PON- 1:

#config
interface epon 0/1
switchport mode access
switchport access VLAN 201
exit

PON- 2:

#config
interface epon 0/2
switchport mode access
switchport access VLAN 202
exit

PON- 3:

#config
interface epon 0/3
switchport mode access
switchport access VLAN 203
exit

PON- 4:

#config
interface epon 0/4
switchport mode access
switchport access VLAN 204
exit

Configuration Save:

When the configuration is finished, the running configuration must be saved. If not saved, the configuration will be lost when the OLT reboots. So don't forget to save the configuration at the end. The command to save is given below.

saving Command:

#config
copy running-config startup-config

BDPON OLT FULL CONFIGURE

Connected to 192.168.100.100

Welcome to BDPON-EPON OLT CLI

OLT LOGIN USER NAME PASSWORD

Username:admin
Password:admin
RUBEL_BDPON_OLT>enable
RUBEL_BDPON_OLT#show running-config

#Configure Terminal

OLT NAME

#configure terminal
hostname BDPON
Exit

VLAN Creation:

#configure terminal
Vlan1.2532
Exit

IP address assigns For MGT:

#configure terminal
interface vlan1.2532
ip address 172.150.15.14/30
Exit

XGE Uplink Port Configure HYBRID

#configure terminal
interface xge1
switchport mode hybrid
switchport hybrid allowed vlan add 2532-2533 egress-tagged enable
Exit

GEG Uplink Port Configure HYBRID

#configure terminal
interface ge1
switchport mode hybrid
switchport hybrid allowed vlan add 2532-2533 egress-tagged enable
Exit

Uplink Port Configure ACCESS

#configure terminal
interface ge1
switchport access vlan 2532
Exit

Pon Port Configure:

PON–1:

#configure terminal
interface pon1
switchport access vlan 2532
Exit

PON–2:

#configure terminal
interface pon2
switchport access vlan 2532
Exit

PON–3:

#configure terminal
interface pon3
switchport access vlan 2532
Exit

PON–4:

#configure terminal
interface pon4
switchport access vlan 2532
Exit

IP ROUTE

#configure terminal
ip route 0.0.0.0/0 172.150.15.13
Exit

SAVE ALL CONFIGURETION

write

====VSOL====

Welcome to Vsol

Connecting to 192.168.8.100

Uplink with Vlan Configuration:

Username:admin
Password: Xpon@Olt9417#
epon-OLT> ena
Password: Xpon@Olt9417#

VLAN Creation:

#configure terminal
vlan 200 - 204
exit

Our VLANs (200 - 204) was successfully created and now we can use these VLANs for service. So we will be using VLAN 200 for olt MGT (remote management) and VLAN 201 to 204 for pon port.

Uplink Port Configure:

Now we are configuring our uplink as G2

#Config
interface gigabitethernet 0/1
switchport mode trunk
switchport trunk vlan 2155 - 2159
exit

Our uplink port G2 is successfully trunk configured with VLANs. No we can check the mac address in the VLAN interface.

Mac Address Checking:

You need to follow the command below to view the mac address.

#Config
show mac address-table interface gigabitethernet 0/2

IP address assigns For MGT:

We can access OLT from our LAN side. It needs to assign an IP address. through which the OLT will be accessed. So let's assign an IP to VLAN 400 for olt MGT (remote management) access using the below command.

#config)
interface VLAN 200
ip address 10.200.200.6 255.255.255.252
exit

IP ROUTE

#config)
ip route 0.0.0.0/0 10.200.200.5

Pon Port Configure:

Now we need to configure the PON port. We have created 4 VLANs for 4 PON ports. so let's start,

PON- 1:

#config
interface epon 0/1
switchport mode access
switchport access VLAN 201
exit

PON- 2:

#config
interface epon 0/1
switchport mode access
switchport access VLAN 2155
exit

PON- 3:

#config
interface epon 0/3
switchport mode access
switchport access VLAN 203
exit

PON- 4:

#config
interface epon 0/4
switchport mode access
switchport access VLAN 204
exit

SAVE ALL CONFIGURETION

#config
#write all

===GPON===

—----------

OLT NAME

#config
#hostname
#exit

ADD VLAN

#config
vlan 317 - 325

MGMT CONFIGURE IP ADDRESS

#config
interface vlan 317
ip address 192.168.99.2 255.255.255.252
ex

IP ROUTE

#config
ip route 0.0.0.0 0.0.0.0 192.168.99.1

Step2. Configure the OLT uplink port

interface gigabitethernet 0/5
Switchport mode hybrid
switchport hybrid vlan 317 - 325 tagged
ex

Step3. Create the DBA profile

#Config
profile dba id 1 name max_bw
type 4 maximum 1024000
commit
exit

Step4. Create ONT Line Profile.

#config
profile line id 1
tcont 1 dba max_bw
gem 1 tcont 1
service 1 gem 1 vlan 111
service-port 1 gemport 1 uservlan 111 vlan 111
commit
exit

#config
profile line id 2
tcont 2 dba max_bw
gem 1 tcont 2
service 1 gem 1 vlan 112
service-port 1 gemport 1 uservlan 112 vlan 112
commit
Exit

#config
profile line id 3
tcont 3 dba max_bw
gem 1 tcont 3
service 1 gem 1 vlan 113
service-port 1 gemport 1 uservlan 113 vlan 113
commit
exit

#config
profile line id 4
tcont 4 dba max_bw
gem 1 tcont 4
service 1 gem 1 vlan 114
service-port 1 gemport 1 uservlan 114 vlan 114
commit
exit

#config
profile line id 5
tcont 5 dba max_bw
gem 1 tcont 5
service 1 gem 1 vlan 322
service-port 1 gemport 1 uservlan 322 vlan 322
commit
exit

#config)
profile line id 6
tcont 6 dba max_bw
gem 1 tcont 6
service 1 gem 1 vlan 323
service-port 1 gemport 1 uservlan 323 vlan 323
commit
exit

#config
profile line id 7
tcont 7 dba max_bw
gem 1 tcont 7
service 1 gem 1 vlan 324
service-port 1 gemport 1 uservlan 324 vlan 324
commit
exit

#config
profile line id 8
tcont 8 dba max_bw
gem 1 tcont 8
service 1 gem 1 vlan 325
service-port 1 gemport 1 uservlan 325 vlan 325
commit
exit

Step5. Create ONT Srvprofile.

#config
profile srv id 1
portvlan eth 1 mode tag vlan 318 pri 0
portvlan eth 2 mode tag vlan 318 pri 0
portvlan eth 3 mode tag vlan 318 pri 0
portvlan eth 4 mode tag vlan 318 pri 0
Commit
Exit
#config
profile srv id 2
portvlan eth 1 mode tag vlan 319 pri 0
portvlan eth 2 mode tag vlan 319 pri 0
portvlan eth 3 mode tag vlan 319 pri 0
portvlan eth 4 mode tag vlan 319 pri 0
commit
exit

#config
profile srv id 3
portvlan eth 1 mode tag vlan 320 pri 0
portvlan eth 2 mode tag vlan 320 pri 0
portvlan eth 3 mode tag vlan 320 pri 0
portvlan eth 4 mode tag vlan 320 pri 0
commit
exit

#config
profile srv id 4
portvlan eth 1 mode tag vlan 321 pri 0
portvlan eth 2 mode tag vlan 321 pri 0
portvlan eth 3 mode tag vlan 321 pri 0
portvlan eth 4 mode tag vlan 321 pri 0
commit
exit

#config
profile srv id 5
portvlan eth 1 mode tag vlan 322 pri 0
portvlan eth 2 mode tag vlan 322 pri 0
portvlan eth 3 mode tag vlan 322 pri 0
portvlan eth 4 mode tag vlan 322 pri 0
commit
exit

#config
profile srv id 6
portvlan eth 1 mode tag vlan 323 pri 0
portvlan eth 2 mode tag vlan 323 pri 0
portvlan eth 3 mode tag vlan 323 pri 0
portvlan eth 4 mode tag vlan 323 pri 0
commit
exit

#Config
profile srv id 7
portvlan eth 1 mode tag vlan 324 pri 0
portvlan eth 2 mode tag vlan 324 pri 0
portvlan eth 3 mode tag vlan 324 pri 0
portvlan eth 4 mode tag vlan 324 pri 0
commit
Exit

#config
profile srv id 8
portvlan eth 1 mode tag vlan 325 pri 0
portvlan eth 2 mode tag vlan 325 pri 0
portvlan eth 3 mode tag vlan 325 pri 0
portvlan eth 4 mode tag vlan 325 pri 0
commit
exit

Step6. Add the ONT to OLT.

#config
interface gpon 0/1
onu auto-learn
onu auto-learn line-profile name line_profile_1
onu auto-learn srv-profile name srv_profile_1
exit

#config
interface gpon 0/2
onu auto-learn
onu auto-learn line-profile name line_profile_2
onu auto-learn srv-profile name srv_profile_2
exit

#config)
interface gpon 0/3
onu auto-learn
onu auto-learn line-profile name line_profile_3
onu auto-learn srv-profile name srv_profile_3
exit

#config
interface gpon 0/4
onu auto-learn
onu auto-learn line-profile name line_profile_4
onu auto-learn srv-profile name srv_profile_4
exit

#config
interface gpon 0/5
onu auto-learn
onu auto-learn line-profile name line_profile_5
onu auto-learn srv-profile name srv_profile_5
exit

#config
interface gpon 0/6
onu auto-learn
onu auto-learn line-profile name line_profile_6
onu auto-learn srv-profile name srv_profile_6
exit

#config
interface gpon 0/7
onu auto-learn
onu auto-learn line-profile name line_profile_7
onu auto-learn srv-profile name srv_profile_7
exit

#config
interface gpon 0/8

onu auto-learn
onu auto-learn line-profile name line_profile_8
onu auto-learn srv-profile name srv_profile_8
exit

#config
#debug mode
#set plug_and_play disable
#ex

IP DNS

#config
ip dns 8.8.8.8 8.8.4.4

Verification Code Disable

#Config
web verification-code disable

#config
fan temperature 20

web login timeout 30
#login-access-list login-password loopback
loopback detect enable

#config
no log
no login-access-list deny telnet 0.0.0.0 0.0.0.0
#no login-access-list deny snmp 0.0.0.0 0.0.0.0
snmp community brisk_sys ro
wr

ALL CONFIGURE SAVE

#Write

Gigabitethernet Port Access

—----------

#config
interface gigabitethernet 0/
#switchport mode access
#switchport access vlan 318
#ex

CORE LINK OLT FULL CONFIGURE

Welcome to EPON

Connecting to 192.168.0.88

ADMIN USER NAME

Username: admin
Password:admin

Epon> enable

OLT NAME

#config
sysname Johirul-OLT

SHOW OLT CONFIGURE

#config
show running-config

CREATE VLAN

#config
vlan 100-110,1830
exit

IP ADDRESS ASSIGNS

#config
interface vlan 1830
ip address 192.168.10.27 255.255.255.248 192.168.10.25
exit

UPLINK PORT CONFIGURE HYBRID

#config
interface gigabitethernet 1/1
description BRISK UPLINK
switchport mode hybrid
switchport native vlan 1830
switchport allowed vlan add 1830 tagged
exit

UPLINK PORT CONFIGURE TRUNK

#config
interface gigabitethernet 1/1
witchport mode trunk
description BDPON_OLT
switchport native vlan 1830
switchport allowed vlan add 1830 tagged
exit

UPLINK PORT CONFIGURE ACCESS

#config
interface gigabitethernet 1/1
description DBC_OLT
switchport mode access
switchport native vlan 1830
switchport allowed vlan add 1830 untagged
exit

PON ACCESS COFIGURE

PON- 1:
#config
interface epon 1/1
switchport mode access
switchport native vlan 145
switchport allowed vlan add 145 untagged
exit

PON- 2:

#config
interface epon 1/2
switchport mode access
switchport native vlan 1830
switchport allowed vlan add 1830 untagged
exit

PON- 3:

#config
interface epon 1/3
switchport mode access
switchport native vlan 1830
switchport allowed vlan add 1830 untagged
exit

PON- 4:

#config
interface epon 1/4
switchport mode access
switchport native vlan 1830
switchport allowed vlan add 1830 untagged
exit

IP ROUTE

#config
ip default-gateway 192.168.10.25
Exit

SAVE CONFIGURE ALL

write

C-DATA OLT NEW VERSON

CONNECT TO IP 192.168.1.100

EPON OLT Integrated Operating System

>>User name:root
>>User password:admin

ALARM DISABLE:

alarm output all disable

EPON OLT Integrated Operating System.

OLT> enable

OLT# show current-config

Current configuration:

ont optical-interval 300000

GEG UPLINK PORT CONFIGURE

interface ge 0/0
vlan mode 1 hybrid
vlan hybrid 1 tagged 2011

XGEG UPLINK PORT CONFIGURE

interface xge 0/0
vlan mode 1 trunk
vlan trunk 1 2011

PON CONFIGURE

PON:1

interface epon 0/0
vlan mode 1 access
vlan access 1 2011

PON:2

interface epon 0/0
vlan mode 2 access
vlan access 2 2011

PON:3

interface epon 0/0
vlan mode 3 access
vlan access 3 2011

PON:4

interface epon 0/0
vlan mode 4 access
vlan access 4 2011

IP address assigns For MGT:

interface vlanif 2011
ip address 10.152.20.155 29

IP ROUTE

ip route 0.0.0.0/0 192.168.155.33

DNS

dns server 8.8.8.8
dns server-bak 1.1.1.1

C-DATA OLT OLD VERSON

CONNECT TO IP 192.168.1.100

Command Line Interface for EPON System
Hardware Ver: V1.0
Software Ver: 2.4.06_000
Created Time: Nov 11 2020 17:44:53
—---------—----------

Username:admin
Password:admin

Show Configure

epon# show running-config all

VLAN Creation:

vla 20-25

Uplink Port Configure HYBRID

1-4 GEG PORT

swport ge1
vlan add 21-25 tag

PON PORT CONFIGURE

5-8 PON PORT

PON:1

swport ge5
pvid 21

PON:2

swport ge6
pvid 22

PON:3

swport ge7
pvid 23

PON:4

swport ge8
pvid 24

IP address assigns For MGT:

system ipconfig inband 10.10.20.18 255.255.255.252

ROUTE

system ipconfig gateway 10.10.20.17

C-DATA OLD VERSON OLT CONFIGURE

system hostname Mollarhat-Kodomtoli-CDATA-OLT
swmode vlan enable
swport ge5
pvid 216

vlan add 1
vlan add 216
swport ge6
pvid 217

vlan add 1
vlan add 217
swport ge7
pvid 218

vlan add 1
vlan add 218
swport ge8
pvid 219

vlan add 1
vlan add 219
swport ge1

vlan add 215 tag
vlan add 1 tag
vlan add 216-219 tag

swport ge2
vlan add 1
swport ge3
vlan add 1
swport ge4
vlan add 1

system ipconfig inband 10.68.200.6 255.255.255.252

system ipconfig gateway 10.68.200.5

system ipconfig mgmt-vlan 215

system snmp read-write maximsnmp

system save all

show system infor
vlan del 1260

E-COM OLT FULL CONFIGURE

Connecting to 192.168.1.100

****

EPON OLT Integrated Operating System

****

ADMIN USER NAME

User name:admin
Password: admin

Johirul-OLT> enable

OLT NAME

#config
sysname Johirul-OLT

Create VLAN

#config
vlan 1974

IP ADDRESS ASSIGNS

#config
interface vlanif 1974
ip address 10.152.20.98/30
exit

UPLINK CONFIGURE

interface xge 0/0
vlan mode 1 hybrid
vlan hybrid 1 tagged 1248
vlan mode 2 hybrid
vlan hybrid 2 tagged 1248
exit

GE PORT ACCESS

interface ge 0/0
vlan access 1 1248
vlan access 2 1248
exit

PON ACCESS COFIGURE

config
interface epon 0/1
vlan mode 1 access
vlan access 1 1248

vlan mode 2 access
vlan access 2 1248

vlan mode 3 access
vlan access 3 1248

vlan mode 4 access
vlan access 4 1248
exit

IP ROUTE

#config
ip route 0.0.0.0/0 10.152.20.97
Exit

SAVE ALL CONFIGURETION

#config
save

HSGQ-EPON OLT FULL CONFIGURETION

****

IP 192.168.100.1

OLT LOGIN

username:root
Password:admin

HOSTNAME

#config
hostneme

VLAN CREATION

#config
vlan standard 1,646-648,1839
Exit

GE UPLINK HYBRID

#config
interface ge 1
port desc uplink
vlan hybrid 1839 tagged
exit

XGE UPLINK HYBRID

#config
interface xge 2
port desc uplink
vlan hybrid 1839 tagged
Exit

GE UPLINK TRUNK

#config
interface ge 1
port desc uplink
vlan mode trunk
vlan trunk 646-648
exit

XGE UPLINK TRUNK

#config
interface xge 1
port desc uplink
vlan mode trunk
vlan trunk 646-648
Exit

GE UPLINK ACCESS

#config
interface ge 1
vlan mode access
vlan access 1839
exit

—----------

PON-1 CONFIGURE

#config
interface epon 1
vlan mode access
vlan access 1839
exit

PON-2 CONFIGURE

#config
interface epon 2
vlan mode access
vlan access 1839
exit

PON-3 CONFIGURE

#config
interface epon 3
vlan mode access
vlan access 1839
exit

PON-4 CONFIGURE

#config
interface epon 4
vlan mode access
vlan access 1839
exit

ASSING LOGIN IP

#config
interface vlanif 1839
ifconfig 192.168.10.42 netmask 255.255.255.252
Exit

IP ROUTER

#config
route default gw 192.168.10.41
Exit

ALL CONFIGURE SAVE

#config
save

CHANGE USER NAME PASSWORD

#config
user password test123
Exit

PORT SPEED

#config
interface ge 1
port speed 1000
Exit

PON DB SHOW COMMEND

#congif
interface epon 1
show optical-info
Exit

GE UPLINK PORT DB SHOW

#config
interface ge 4
show optical-state
Exit

ZIBBIX OLT FULL CONFIGURE

OLT CONNECT IP 192.168.168.1

[EPON]display current-config

VLAN

vlan 10,20,500,1739

IP address assigns For MGT:

interface vlan-interface 1739
ip address 192.168.9.50 255.255.255.252
quit

Uplink Port Configure HYBRID

interface ethernet 0/1/1
port hybrid tagged vlan 1739
quit

interface ethernet 0/1/2
port hybrid tagged vlan 1739
quit

Uplink Port Configure ACCESS

interface ethernet 0/0/1
port mode access
port default vlan 1739
quit

interface ethernet 0/0/2
port mode access
port default vlan 1739
Quit

interface ethernet 0/0/3
port mode access
port default vlan 1739
quit

interface ethernet 0/0/4
port mode access
port default vlan 1739
quit

PON CONGIGURE

PON:1
interface epon 0/2/1
port mode access
port default vlan 1739
quit

PON:2
interface epon 0/2/2
port mode access
port default vlan 1739
quit

PON:3
interface epon 0/2/3
port mode access
port default vlan 1739
quit

PON:4
interface epon 0/2/4
port mode access
port default vlan 1739
quit

STATIC_ROUTE
ip route 0.0.0.0 0.0.0.0 172.250.2.62

RICHER LINK OLT CONFIGURATION

Connecting to 192.168.20.1

welcome to Richerlink Olt

ADMIN USER NAME

Username:admin
Password:admin
EPON>enable
Password:admin

RUNNGIN CONFIGURE SHOW

#config
show running-config

CREATE VLAN

#config
vlan 520-524
Exit

IP ADDRESS ASSIGN

#config
interface vlan1.524
ip address 10.99.100.98/30
Exit

GEG UPLINK PORT CONFIGURE

#config
interface ge1
switchport mode hybrid
switchport hybrid allowed vlan add 520-524 egress-tagged enable
Exit

GEG PORT ACCESS

#config
interface ge1
switchport mode access
switchport access vlan 520
Exit

PON PORT ACCESS

PON-1

#config
interface epon1
switchport access vlan 520
Exit

PON-2

#config
interface epon2
switchport access vlan 521
Exit

PON-3

#config
interface epon3
switchport access vlan 522
Exit

PON-4

#config
interface epon4
switchport access vlan 523
Exit

IP ROUTE

#config
ip route 0.0.0.0/0 10.99.100.97
Exit

SAVE CONFIGURE

copy running-config startup-config
Exit

====AVEIS====

IP 192.168.100.1

Aveis EPON OLT Deafult IP:

IP Address: 192.168.100.1
Username: root
Password: admin

VLAN Creation:

#config)
#vlan standard 100-104
#exit

.

UPLINK CONFIGURE

#config)
interface ge 1
vlan mode trunk
vlan trunk 100-104
exit

MGT Configuration:

#config
interface vlanif 100
ifconfig 10.30.30.2/30
exit

IP ROUTE:

#config
ip route-static dest-ip 10.30.30.1

#route default gw 10.59.200.1

EPON Port Configuration:

PON-1:

#config)
interface epon 1
vlan mode access
vlan access 101
exit

PON-2:

#config
interface epon 2
vlan mode access
vlan access 102
exit

PON-3:

#config)
interface epon 3
vlan mode access
vlan access 103
exit

PON-4:

#config
interface epon 4
vlan mode access
vlan access 104
exit
exit

Save Configuration

#config
copy running-config startup-config

Configuration saved successfully

AOPT OLT

interface manage IP 192.168.100.1

Create VLAN

#config
vlan 110-115
exit

Uplink Port xge Configure

#config
interface xge 1
switchport mode trunk
switchport trunk allowed vlan add 110-114
exit

MGT PORT Configuration

#config
interface vlanif 110
ifconfig 192.168.20.10 netmask 255.255.255.252
exit

IP ROUTE

#config
ip route-static dest-ip 0.0.0.0 netmask 0.0.0.0 next-hop 192.168.20.9
Exit

PON 1 Port Configuration

#config
interface epon 1
switchport mode access
switchport access vlan 110
exit

PON 2 Port Configuration

#config
interface epon 2
switchport mode access
switchport access vlan 112
exit

PON 3 Port Configuration

#config
interface epon 3
switchport mode access
switchport access vlan 113
exit

PON 4 Port Configuration

#config
interface epon 4
switchport mode access
switchport access vlan 114
exit

CONFIGURE SAVE

#config
save

OLT(config)# show running-config

Current configuration:

interface manage
ifconfig 192.168.100.1 netmask 255.255.255.0

interface vlanif 1
ifconfig 192.168.99.1 netmask 255.255.255.0

interface vlanif 110
ifconfig 192.168.20.10 netmask 255.255.255.252
route default gw 192.168.20.9

POTON OLT FULL CONFIGURE

OLT-Connected to 192.168.100.100

Welcome to EPON OLT CLI

OLT LOGIN USER NAME PASSWORD

Username:admin
Password:admin
EPON-OLT>enable

RUNNING CONFIGURE SHOW COMMEND

EPON-OLT#show running-config

CONFIGURE MODE

#configure terminal

VLAN Creation:

#configure terminal
vlan 105-108

IP address assigns For MGT:

#configure terminal
interface vlan1.109
ip address 192.168.12.6/30

XGE Uplink Port Configure HYBRID

#configure terminal
interface xge1
switchport hybrid allowed vlan add 105-109 egress-tagged enable

GE Uplink Port Configure HYBRID

#configure terminal
interface ge1
switchport hybrid allowed vlan add 105-109 egress-tagged enable

GE Uplink Port Configure ACCESS

#configure terminal
interface ge1
switchport access vlan 105

PON PORT CONFIGURE:

PON-1:
#configure terminal
interface pon1
switchport access vlan 105

PON-2:
#configure terminal
interface pon2
switchport access vlan 106

PON-3:
#configure terminal
interface pon3
switchport access vlan 107

PON-4:
#configure terminal
interface pon4
switchport access vlan 108

IP ROUTE

#configure terminal
ip route 0.0.0.0/0 192.168.12.5

ALL CONFIGURE SAVE

write

TBS PHOTON GPON OLT

LOGIN IP

VLAN-1
192.168.20.2

USER NAME:admin
PASSWORD:admin

HOSTNAME

```
hostname CHILARCHOR-MADARIPUR-GPON-OLT

no spanning-tree
spanning-tree mst config

profile dba idx 0 name factory_dba_0
 type 4 max 1200000
 commit

profile line idx 1 name line_profile_1
 ont-type sfu
 tcont 1 dba-profile idx 0
 gemport 1 tcont 1
 mapping-rule 1 vlan 1185 gemport 1
 flow-rule 1 port eth 1 default vlan 1185
 flow-rule 2 port eth 2 default vlan 1185
 flow-rule 3 port eth 3 default vlan 1185
 flow-rule 4 port eth 4 default vlan 1185
 commit

profile line idx 3 name line_profile_1185
 ont-type sfu
 tcont 1 dba-profile idx 0
 gemport 1 tcont 1
```

mapping-rule 1 vlan 1185 gemport 1
flow-rule 1 port eth 1 default vlan 1185
flow-rule 2 port eth 2 default vlan 1185
flow-rule 3 port eth 3 default vlan 1185
flow-rule 4 port eth 4 default vlan 1185
commit

profile line idx 101 name line_profile_200
ont-type sfu
tcont 1 dba-profile idx 0
gemport 1 tcont 1
mapping-rule 1 vlan 1185gemport 1
flow-rule 1 port eth 1 default vlan 1185
flow-rule 2 port eth 2 default vlan 1185
flow-rule 3 port eth 3 default vlan 1185
flow-rule 4 port eth 4 default vlan 1185
commit

loop-detect enable

vlan database
vlan 1185 name UPLINK_UTSHAB

ip interface vlan 1185

IP address assigns For MGT

interface vlan1.1185
ip address 10.114.200.18/30

GIGA PORT HYBRID

interface ge1
description UPLINK
speed 1000-full

switchport hybrid allowed vlan add 1185 egress-tagged enable

GIGA PORT ACCESS

interface ge5
switchport mode access
switchport access vlan 1185

GIGA PORT SHUTDOWN

interface xge1
shutdown

PON ACCESS MOODE CONFIGUTRE

interface pon8
switchport hybrid vlan 1185
switchport hybrid allowed vlan add 1185 egress-tagged enable
switchport hybrid allowed vlan add 1 egress-tagged disable
loop-detect enable
loop-detect protect vlan 1185
exit

IP ROUTER

ip route 0.0.0.0/0 10.114.200.17

```
profile line idx 3 name line_profile_1185
 ont-type sfu
 tcont 1 dba-profile idx 0
 gemport 1 tcont 1
 mapping-rule 1 vlan 1185 gemport 1
 flow-rule 1 port eth 1 default vlan 1185
 flow-rule 2 port eth 2 default vlan 1185
 flow-rule 3 port eth 3 default vlan 1185
 flow-rule 4 port eth 4 default vlan 1185
 commit

interface pon1
 switchport hybrid vlan 1185
 switchport hybrid allowed vlan add 1185 egress-tagged enable
 switchport hybrid allowed vlan add 1 egress-tagged disable
 loop-detect enable
 loop-detect protect vlan 1185


ont auto-find interface gpon 0/1-0/8
ont auto-find list-age time 30 interface gpon 0/1-0/8
ont-logging buffer 0/1/1-0/8/128
ont auto-add enable
ont auto-add rule idx 1 all-ont line-profile idx 1
```

SOLITINE OLT FULL CONFIGURE

manage ip address 192.168.100.100

OLT LOGIN

login name:admin
password :admin

Welcome to EPON OLT SOLITINE

RUNNING CONGIFURE SHOW COMMEND
****

EPON-OLT#
show running-config

VLAN CREATE

#config
vlan 101-105
exit

IP ADDRESS ASSIGN

#config
interface vlan1.105
ip address 192.168.10.67/28
exit

XGIG UPLINK PORT CONFIGURE

#config
interface xge1
description
switchport mode trunk
switchport trunk allowed vlan add 101-105
exit

XGIG PORT ACCESS MODE CONDIGURE

#config
interface xge1
description
Switchport mode access
switchport access vlan 101
exit

PON CONFIGURE

PON-1:
#config
interface pon1
switchport access vlan 101
exit

PON-2:
#config
interface pon2
switchport access vlan 102
exit

PON-3:
#config
interface pon3
switchport access vlan 103
exit

PON-4:
#config
interface pon4

switchport access vlan 104
exit

IP ROUTE

#config
ip route 0.0.0.0/0 192.168.26.5
exit

SAVE CONFIGURE

EPON-OLT#
write

DN Optic OLT Full Configuration

Connect ip 192.168.1.100
enable

Configure Mood

configure terminal

Hostname

config#
hostname DN-OLT

Management IP

config#
interface vlan 1
ip address 192.168.100.2 255.255.255.0
exit

Default Gateway

config#
ip route 0.0.0.0 0.0.0.0 192.168.100.1

Create VLAN

config#
vlan 10
name INTERNET
Exit

Uplink Port trunk Configure

config#
interface xgei_1/1/1
switchport mode trunk
switchport trunk allowed vlan 10,20
Exit

Uplink Port Hybrid Configure

config#
interface xgei_1/1/3
switchport mode hybrid
switchport hybrid allowed vlan 10,20
Exit

Uplink Port ACCESS Configure

config#
interface xgei_1/1/3
switchport mode access
switchport access vlan 10
Exit

GE Port ACCESS Configure

interface gei_1/1/1
switchport mode access
switchport access vlan 10

GPON Port Enable

config#
interface gpon-olt_1/1/1
no shutdown
exit

Admin User

config#
username admin password Admin@123

SNMP

config#
snmp-server community public ro

Configure ONU Management

config#
interface gpon-onu_1/1/1:1

Save Configuration

write
Save

DN Optic OLT Short Commands

config#
show running-config
show vlan
show onu all
show onu online
show gpon onu state
show interface status
show mac address-table
show optical-info
show power
show cpu
show memory
show alarm

DN Optic OLT ONU Optical Power Check

config#
show pon power attenuation
show onu optical-info
ONU Reboot
interface gpon-onu_1/1/1:1
reboot

OPTILINK OLT FULL CONFIGURE

OLT DEFAULT IP

Connecting to ip 192.168.100.1

LOGIN

User name:root
User password:

OP_OLT> enable

CONFIGURE SHOW COMMAND

OP_OLT#
show current-config

Create VLAN

Config#
vlan 140-144,2831

IP ADDRESS ASSIGNS

Config#
interface vlanif 140
ip address 10.158.200.26 255.255.255.252

GE UPLINK TRUNK CONFIGURE

Config#
interface ge 0/0
vlan mode 1 trunk
vlan trunk 1 140-144
vlan mode 3 trunk
vlan trunk 3 2831

GE UPLINK CONFIGURE ACCESS

----
config#
interface ge 0/0
vlan access 1 141
vlan access 2 142

XGE UPLINK TRUNK CONFIGURE

Config#
interface xge 0/0
vlan mode 1 trunk
vlan trunk 1 140-144
vlan mode 2 trunk
vlan trunk 2 140-144

PON ACCESS COFIGURE

Config#
interface epon 0/0
vlan access 1 141
vlan access 2 142
vlan access 3 143
vlan access 4 144
exit

IP ROUTE

OP_OLT#
ip route 0.0.0.0/0 10.158.200.25

SAVE COMMAND

----
save

BDCOM SWITCH

Switch>enable
SW_config#config
SW_config(config#

Change Host Name/Switch Name/Identity Name

config#
hostname Core-SW

Set Login Username and Password

Core-SW_config#
Core-SW_config#username admin password admin

VLAN Create and Name Set

Core_SW_config#
vlan 100
Description name NOC_Router_IIG

Switch port Configure Trunk Mode allow VLAN, and port Description

Core_SW_config#
interface gigaEthernet 0/6
switchport trunk vl
switchport trunk vlan-allowed 101
description NOC_Router

Add More VLAN in the same Interface

Core_SW_config#
nterface gigaEthernet 0/6
switchport trunk vl
switchport trunk vlan-allowed add 101

Switch port Configure in Access Mode and allow VLAN

Core_SW_config#
interface gigaEthernet 0/7
no shutdown
switchport mode access
switchport pvid 101
description Access port

Manually Set MGT IP or Login IP

Core_SW_config#
interface vlAN 100
ip address 10.108.90.2 255.255.255.252

Set default gateway to login with Manually set IP

Core_SW_config#
ip route 0.0.0.0 0.0.0.0 10.108.90.1

Save All Configuration

config#
write
Saving current configuration…

TEST CHECK

interface GigaEthernet0/2

description Camera
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/3
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/4
description Rupnagar_Main-link
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/5
description core router
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/6
description Core-Router-FTP
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/7
description Purobi-Camera

switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/8
description Access2-ftp
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/9
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/10
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/11
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/12
description F@H
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/13
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/14
description Pollobi-Backup
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/15
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/16
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/17
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/18
switchport trunk vlan-allowed 184-194,317-326
switchport mode trunk

interface GigaEthernet0/19

description Rupnagar_Main-back
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 3
switchport mode trunk

interface GigaEthernet0/20
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/21
description Purobi_Backup_MC
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/22
description Mirpur-11-pop
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/23
description Mirpur11-Backup
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface GigaEthernet0/24

```
description Purobi_Main_Cisco
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk
duplex full

interface TGigaEthernet1/1
description Direct_noc
switchport trunk vlan-allowed 100-110,200-210
switchport mode trunk

interface TGigaEthernet1/2
 description Backup-link
 switchport trunk vlan-allowed 184-194,317-326
 switchport trunk vlan-untagged 1
 switchport mode trunk
  backup-link-group 1 backup

interface TGigaEthernet1/3
description Access-41
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk

interface TGigaEthernet1/4
description Circle-Link
switchport trunk vlan-allowed 184-194,317-326
switchport trunk vlan-untagged 1
switchport mode trunk
```

interface VLAN1
ip address 192.168.5.19 255.255.255.0
no ip directed-broadcast

HUAWEI SWITCH FULL CONFIGURETION

CONNECT SSH
IP
User Authentication
Enter password:

SHOW INTERFACE Description

<BELTOIL-LAN-SW>display interface description
PHY: Physical
*down: administratively down
^down: standby
(l): loopback
(s): spoofing
(b): BFD down
(e): ETHOAM down
(d): Dampening Suppressed
(p): port alarm down
(dl): DLDP down
(c): CFM down

Interface	PHY	Protocol	Description
10GE1/0/1	up	up	SAIFUL-VSOL-OLT
10GE1/0/2	up	up	OFFICE-OLT-1
10GE1/0/3	down	down	BABU-NARUA-OLT
10GE1/0/4	down	down	
10GE1/0/5	down	down	
10GE1/0/6	down	down	
10GE1/0/7	down	down	
10GE1/0/8	down	down	
10GE1/0/9	down	down	
10GE1/0/10	down	down	test
10GE1/0/11	down	down	
10GE1/0/12	down	down	
10GE1/0/13	down	down	
10GE1/0/14	down	down	
10GE1/0/15	down	down	
10GE1/0/16	down	down	FRC-UPLINK
10GE1/0/17	down	down	KADAI-VSOL-OLT
10GE1/0/18	up	up	RATANKANDI-SIRAJUL-OLT
10GE1/0/19	down	down	SOIYODPUR-VSOL-OLT
10GE1/0/20	up	up	OFFICE-OLT-2
10GE1/0/21	up	up	RATANKANDI-MONSUR-OLT

10GE1/0/22 down down RATANKANDI-KONNU-OLT
10GE1/0/23 up up GOPALPUR-SW
10GE1/0/24 up up RANIKHOLA-SW
10GE1/0/25 up up KHUKNI-OLT
10GE1/0/26 up up ATIK-OLT
10GE1/0/27 down down
10GE1/0/28 down down
10GE1/0/29 down down
10GE1/0/30 down down
10GE1/0/31 down down
10GE1/0/32 down down
10GE1/0/33 up up
10GE1/0/34 down down
10GE1/0/35 down down
10GE1/0/36 down down
10GE1/0/37 down down
10GE1/0/38 down down
10GE1/0/39 down down
10GE1/0/40 down down
10GE1/0/41 down down
10GE1/0/42 down down
10GE1/0/43 down down
10GE1/0/44 down down
10GE1/0/45 up up MAC-ACCESS-1-10G
10GE1/0/46 up up MAC-ACCESS-2
10GE1/0/47 up up BANDWIDTH-ACCESS-1
10GE1/0/48 up up BANDWIDTH-ACCESS-2
40GE1/0/1 up up MAC-ACCESS-1
40GE1/0/2 down down
40GE1/0/3 down down
40GE1/0/4 down down
40GE1/0/5 down down
40GE1/0/6 down down
MEth0/0/0 down down
NULL0 up up(s)
Vlanif998 up up

<BELTOIL-LAN-SW>display current-configuration

VLAN ADD

vlan batch 4 to 54
vlan 100

Management IP

```
interface Vlanif998
 ip address 10.53.200.66 255.255.255.252
#
interface MEth0/0/0
 ip address 192.168.88.150 255.255.255.0
```

10G GIGA PORT TRUNK COMMAND

```
interface 10GE1/0/1
 description SAIFUL-VSOL-OLT
 port link-type trunk
 port trunk allow-pass vlan 4 101 300 to 308 715
 device transceiver 10GBASE-FIBER

interface 10GE1/0/2
 description OFFICE-OLT-1
 port link-type trunk
 port trunk allow-pass vlan 4 to 5 32 to 36 101 207 to 215
 device transceiver 10GBASE-FIBER

interface 10GE1/0/3
 description BABU-NARUA-OLT
 port link-type trunk
 device transceiver 1000BASE-X

interface 10GE1/0/10
 description test
 port link-type trunk
 port trunk allow-pass vlan 998
 device transceiver 10GBASE-FIBER

interface 10GE1/0/15
 device transceiver 10GBASE-FIBER

interface 10GE1/0/16
 description FRC-UPLINK
 port link-type trunk
 port trunk allow-pass vlan 101
 device transceiver 10GBASE-FIBER

interface 10GE1/0/17
 description KADAI-VSOL-OLT
 port link-type trunk
 device transceiver 1000BASE-X
```

```
interface 10GE1/0/18
 description RATANKANDI-SIRAJUL-OLT
 port link-type trunk
 port trunk allow-pass vlan 101 710 to 714 1035 to 1039
 device transceiver 10GBASE-FIBER

interface 10GE1/0/19
 description SOIYODPUR-VSOL-OLT
 port link-type trunk
 device transceiver 1000BASE-X

interface 10GE1/0/20
 description OFFICE-OLT-2
 port link-type trunk
 port trunk allow-pass vlan 4 to 5 101 700 to 704 997 1006 to 1014 1046 to 1050 1075 to
1079
 device transceiver 10GBASE-FIBER

interface 10GE1/0/21
 description RATANKANDI-MONSUR-OLT
 port link-type trunk
 port trunk allow-pass vlan 5 101 1041 to 1045
 device transceiver 10GBASE-FIBER

interface 10GE1/0/22
 description RATANKANDI-KONNU-OLT
 port link-type trunk
 device transceiver 1000BASE-X

interface 10GE1/0/23
 description GOPALPUR-SW
 port link-type trunk
 port trunk allow-pass vlan 4 to 5 56 to 60 101 1080 to 1089 1095 to 1109 1126 to 1130 1164
 device transceiver 10GBASE-FIBER

interface 10GE1/0/24
 description RANIKHOLA-SW
 port link-type trunk
 port trunk allow-pass vlan 4 to 31 37 to 42 45 to 49 101 1040 1051 to 1059 1065 to 1069
1131 to 1135 1140 to 1148 1159 to 1163
 device transceiver 10GBASE-FIBER

interface 10GE1/0/25
 description KHUKNI-OLT
 port link-type trunk
 port trunk allow-pass vlan 101 1024 to 1028
 device transceiver 10GBASE-FIBER
```

```
interface 10GE1/0/26
 description ATIK-OLT
 port link-type trunk
 port trunk allow-pass vlan 5 101 900 to 904
 device transceiver 10GBASE-FIBER

interface 10GE1/0/45
 description MAC-ACCESS-1-10G
 port link-type trunk
 port trunk allow-pass vlan 710 to 715 1000 1024 to 1028 1035 to 1039 1041 to 1050 1095
to 1099 1105 to 1109 1115 1126 to 1130
 device transceiver 10GBASE-FIBER

interface 10GE1/0/46
 description MAC-ACCESS-2
 port link-type trunk
 port trunk allow-pass vlan 997 1040 1051 to 1059 1080 to 1084 1100 to 1104 1131 to 1135
1140 to 1148 1159 to 1164
 device transceiver 10GBASE-FIBER

interface 10GE1/0/47
 description BANDWIDTH-ACCESS-1
 port link-type trunk
 port trunk allow-pass vlan 4 to 5 19 to 22 37 to 42 56 to 60 207 to 215 300 to 308 1000 1115
 device transceiver 10GBASE-FIBER

interface 10GE1/0/48
 description BANDWIDTH-ACCESS-2
 port link-type trunk
 port trunk allow-pass vlan 6 to 18 23 to 36 45 to 49
 device transceiver 10GBASE-FIBER

interface 40GE1/0/1
 description MAC-ACCESS-1
 port link-type trunk
 port trunk allow-pass vlan 700 to 704 900 to 904 998 1005 to 1014 1065 to 1069 1075 to
1079 1085 to 1089
 device transceiver 40GBASE-FIBER
```

SHORT COMMAND

1. Basic status and troubleshooting

Software and hardware version

display version

Device and board status

display device

All interface status

display interface brief

Specific port details

display interface 10GE1/0/30

Running configuration

display current-configuration

Saved configuration

display saved-configuration

System logs

display logbuffer

Active alarms, if supported

display alarm active

2. VLAN and port commands

List VLANs

display vlan

Short VLAN summary

display vlan brief

Port VLAN assignments

display port vlan

MAC address table

display mac-address

MACs in VLAN 100

display mac-address vlan 100

Port descriptions, if supported

display interface description

3. Optics and fiber troubleshooting

Transceiver information, if supported

display transceiver

Detailed optical module diagnostics, if supported

display transceiver interface 10GE1/0/30 verbose

Link state, traffic and errors

display interface 10GE1/0/30

Interface error counters, if supported

display counters error

Check hardware and board state

display device

4. Routing and network checks

IP interface summary

display ip interface brief

Routing table

display ip routing-table

ARP table

display arp

OSPF routes, if configured

display ip routing-table protocol ospf

OSPF neighbors, if configured

display ospf peer

BGP neighbors, if configured

display bgp peer

Test IP reachability

ping 192.168.1.1

Trace network path

tracert 192.168.1.1

5. Configuration and saving

system-view
display current-configuration
display this
display interface brief
display vlan
save

CISCO NEXUS SHITCH FULL CONFIGUREH COMMAND

Step-by-Step Full Configuration:

1. Configure Hostname

```
configure terminal
hostname Nexus-SW1
```

2. Create VLANs

```
vlan 20
exit
```

3. Set Management IP (SVI or mgmt0)

```
interface vlan 1
ip address 192.168.1.2/24
no shutdown
exit
```

4. Default Gateway

```
ip default-gateway 192.168.1.1
```

5. Configure Access VLAN Ports

```
interface ethernet1/1
switchport mode access
switchport access vlan 10
no shutdown
```

6. Configure Trunk Port

interface ethernet1/48
switchport mode trunk
switchport trunk allowed vlan 10,20,30
no shutdown

7. Enable Interface Descriptions (Optional)

interface ethernet1/1
description PC-1

8. Enable SSH (Optional)

username admin password 0 admin@123

Cisco Nexus Switch SHORT CONFIGURE

ADD VLAN COMMAND

vlan
vlan 99

IP ADDRESS ADD COMMAND

interface Vlan99
no shutdown
ip address 192.168.26.150/30

IP ROUTE

ip route 0.0.0.0 0.0.0.0 192.168.1.1

PORT POERT SHOW COMMAND

show interface ethernet 1/1 transceiver details

show interface transceiver details

SAVE CONFIGURE COMMAND

copy running-config startup-config

ECOM SWITCH FULL CONFIGURE

Connecting to 192.168.1.100

enable
configure terminal

Hostname

#config
hostname CORE-10G-SW

Management IP

#config
interface vlan 1
ip address 192.168.10.2 255.255.255.0
Exit

Default Gateway

#config
ip default-gateway 192.168.10.1

Admin Password

#config
username admin password Admin@123

Enable SSH

#config
ip ssh enable

VLAN Create

#config
vlan 10
name OFFICE
exit

Access Ports

#config
interface tengigabitethernet 1/1
switchport mode access
switchport access vlan 10
exit

#config
interface tengigabitethernet 1/2
switchport mode access
switchport access vlan 20
exit

#config
interface tengigabitethernet 1/3
switchport mode access
switchport access vlan 30
Exit

Trunk / Uplink Port

#config
interface tengigabitethernet 1/12
switchport mode trunk
switchport trunk allowed vlan 10,20,30
Exit

LACP

```
#config
interface port-channel 1
switchport mode trunk
switchport trunk allowed vlan 10,20,30
exit

#config
interface tengigabitethernet 1/10
channel-group 1 mode active
exit

#config
interface tengigabitethernet 1/11
channel-group 1 mode active
exit
```

STP

```
#config
spanning-tree mode rstp
```

SNMP

```
#config
snmp-server community public ro
```

NTP

```
#config
ntp server pool.ntp.org
```

Static Route

```
#config
ip route 0.0.0.0 0.0.0.0 192.168.10.1
```

Save

```
#config
write memory
save
```

CONNECT

IP:172.27.28.150

CONFIDURE SHOW

[~BR-UP-SW]
display interface description

ADD VLAN

[~BR-UP-SW]
systems view
VLAN-1000

UPLINK PORT P+VLAN PASS

[~BR-UP-SW]
[~BR-UP-SW]interface Eth-Trunk 22
[~BR-UP-SW-Eth-Trunk22]port trunk allow-pass vlan 1930
[*BR-UP-SW-Eth-Trunk22]commit
[~BR-UP-SW-Eth-Trunk22]quit

PORT VLAN PASS COMMAND

[~BR-UP-SW]interface 10GE 1/0/6
[~BR-UP-SW-10GE1/0/6]port trunk allow-pass vlan 1930
[*BR-UP-SW-10GE1/0/6]commit
[~BR-UP-SW-10GE1/0/6]quit
<BR-UP-SW>save

Pubg Ip

150.109.27.214 - Singapore ip ping normal 47 ms
119.28.104.171
119.28.123.49
162.62.81.90
45.40.223.245
119.28.118.171
101.33.103.215
43.129.19.197
43.134.140.23

ip ping check

92.38.155.232
Singapore ip
150.109.27.19
150.109.27.18 - Singapore ip ping.normal 48-65ms take
150.109.27.214
122.11.128.172
EU game ping ip
5.101.166.7
5.101.166.118

Free Fire games ip

164.52.100.223 - Hong Kong SAR China (HK) ping 52 ms
148.153.197.21 - United States (US) ping 48 ms
148.153.196.119
148.153.196.96
148.153.196.48-49 ms
148.153.196.117-50 ms
164.52.73.48 - Hong Kong SAR China (HK) ping 46 ms
148.153.197.102 - United States (US) ping 48 ms
148.153.142.121 - United States (US) ping 54
148.153.197.108 - United States (US) ping 48 ms
148.153.197.18 - United States (US) ping 49
129.227.242.46 - India (IN) pimg -40 ms
164.52.121.54 - Hong Kong SAR China (HK) ping 60
164.52.120.72 - Hong Kong SAR China (HK) ping 79 ms
148.153.142.81- Capitalonline Data Service Co. Ltd ping 61
148.153.196.239 - us Capitalonline Data Service Co. Ltd 50 ms
148.153.197.43 - United States (US) ping 49
148.153.142.207 - United States (US) ping 42
148.153.154.105 - United States (US) ping 50 ms

148.153.142.75 - United States (US) ping 50 ms
164.52.100.213 - Hong Kong SAR China (HK)ping 61
164.52.118.49 - Hong Kong SAR China (HK) ping 48 ms
164.52.100.228 - Capitalonline Data Service Co. Ltdpin ping 49 mas
164.52.116.185 - Hong Kong SAR China (HK) ping 49 ms
129.227.204.226 - India (IN) ping 76
50.225.180.61 - usa ip ping 258 ms
156.59.70.234 - 17 ms singapore
156.59.71.86-17 singapore-ms
156.59.71.70-17 ms
156.59.70.218 - BD Zenlayer Inc -17 MS
192.169.117.134- India - 17 MS

=Valorant IP=

13.248.193.101- us ping 49 ms
66.22.220.4-singapore 52 ms
66.22.221.96 - singapore 51 ms
151.106.248.1-icmp off-us ping 54
162.159.128.233-50 ms
75.2.66.166

Fortain Games ip

162.159.128.233
162.159.130.234
54.88.207.92
52.217.128.25
54.88.161.73
15.184.34.97
15.185.34.37

14.1.103.203

Tiktok IP:

23.54.81.0/24
23.58.120.0/24
23.63.84.0/24
23.212.164.0/24
156.225.98.0/24***
129.227.71.0/24
122.10.254.0/24

Likee:

169.136.160.0/24
169.136.77.0/24
169.136.93.0/24

Fution bd video ip

194.163.155.219

IMO IP:

169.136.114.171
169.136.64.8
169.136.72.246
169.136.79.32

Fifa games ip:

66.22.221.63

Roblox Games:

128.116.54.3 46ms