SAMSUNG DIGITAL DOOR LOCK

SHS-H505 Essential Procedures

Initialization · Password Change · Replacing the Batteries

MODEL SHS-H505

Before you begin: keep the door open so you are not locked out if the procedure is unsuccessful

1 Initialization

RESET ALL REGISTERED DATA

1. Open the door and remove the **battery cover on the inner body**
2. Press and hold the inner **[Register] button for 5 seconds**
3. Go outside and wait for the number pad to light up
4. Enter the full initialization number: **4560852580**
5. Press the outside confirmation button *

Initialization complete → the main password is reset to 1234

Warning: Initialization deletes all registered data, including the existing password, cards and key tags. Afterwards, set a new password and register the required cards again.

2 Password Change

4–12 DIGITS

1. Keep the door open, remove the battery cover and **briefly press the [Register] button**
2. Go outside. When the number pad lights up, enter the **current password**, then press *
   After initialization, the current password is **1234**
3. Enter the **new password (4–12 digits)**, then press *

When you hear DING DONG DENG → the new password has been registered successfully

4. Before closing the door, enter the new password from outside and press * to confirm that the door unlocks normally

Note: Only one main password can be registered. The failure sound is **DING DONG DING DONG**. Do not disclose the password to unauthorised people.

3 Replacing the Batteries

8 × AA ALKALINE

1. If the **"Blues for Elise" melody** sounds when opening the door with a password or card, and the low-battery indicator lights up, the batteries need to be replaced
2. Replace the batteries **within 1 week** of the first low-battery alarm
3. Open the battery cover on the inner body
4. Replace **all 8 AA (LR6) 1.5V alkaline batteries** at the same time
5. Check the **+ / – polarity** against the battery compartment markings, then reinstall the battery cover

Test the lock → confirm that the number pad, password and cards work normally

Do not mix batteries

Do not mix new and used batteries or different brands or types. Incorrect polarity will prevent the lock from operating normally.

Check regularly

Battery leakage can damage the lock. Check the batteries every 6 months and deal with any leakage or corrosion promptly.

Replace promptly after the alarm

After the low-battery alarm, password or card registration, changes, deletion and initialization may be unavailable until the batteries are replaced.

Use alkaline batteries

Use AA (LR6) alkaline batteries. Do not wait until they are fully discharged, as the lock may suddenly stop operating.

Note: This guide contains only the three requested sections. Installation, removal and hardware repairs should be handled by authorised personnel.

Source: Samsung SHS-H505 User Manual