

Document Title	Specification of COM Based Transformer
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	662
Document Classification	Standard

Document Status	Final
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	4.3.0

Document Change History							
Date	Release	Changed by	Description				
2016-11-30	4.3.0	AUTOSAR Release Management	 Updated include file structure figure 5.1. Clarification on postBuild configuration in chapter 10. Added support for unqueued communication when no data is available in [SWS_ComXf_00035]. 				
2015-07-31	4.2.2	AUTOSAR Release Management	Exclude support for external trigger communica- tion [SWS_ComXf_00032]				
2014-10-31	4.2.1	AUTOSAR Release Management	Initial Release				



Disclaimer

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.



Table of Contents

1	Introduction and functional overview	5
2	Acronyms and Abbreviations	6
3	Related documentation	7
	3.1 Input documents	7 8 8
4	Constraints and assumptions	9
	4.1 Limitations	9
5	Dependencies to other modules	10
	5.1 File structure	10 10 10
6	Requirements Tracing	12
7	Functional specification	13
	7.1 Specification of the COM Based Transformer 7.2 Error classififcation 7.2.1 Development Errors 7.2.2 Runtime Errors 7.2.3 Transient Faults 7.2.4 Production Errors 7.2.5 Extended Production Errors	16 19 19 19 19 20
8	API specification	21
	8.2 Type definitions 8.3 Function definitions 8.3.1 ComXf_ <transformerid> 8.3.2 ComXf_Inv_<transformerid> 8.3.3 ComXf_Init 8.3.4 ComXf_DeInit 8.3.5 ComXf_GetVersionInfo 8.4 Callback notifications 8.5 Scheduled functions</transformerid></transformerid>	21 21 21 22 24 24 25 25 25 25
9	Sequence diagrams	26
10	Configuration specification	27





Α	Refe	erenced I	Meta Classes	28
В	Use	d ECU C	onfigurtion	40
С	Histo	ory of Co	nstraints and Specification Items	61
	C.1 C.2	Constr C.2.1 C.2.2 C.2.3	raint History of this Document according to AUTOSAR R4.2.1 raint History of this Document according to AUTOSAR R4.2.2 Added Traceables in 4.2.2	
	C.3	C.3.1 C.3.2 C.3.3	raint History of this Document according to AUTOSAR R4.3.0	_



1 Introduction and functional overview

The transformer feature provides functionality to chain arbitrary transformers when sending and receiving data in the RTE. The COM Based Transformer provides this functionality when the target bus system uses a fixed communication matrix with packed data representations.



2 Acronyms and Abbreviations

No specific terms have been introduced additionally to those already defined in [1].



3 Related documentation

3.1 Input documents

Bibliography

- [1] Glossary
 AUTOSAR TR Glossary
- [2] General Specification on Transformers AUTOSAR ASWS TransformerGeneral
- [3] Specification of RTE Software AUTOSAR_SWS_RTE
- [4] Specification of Communication AUTOSAR_SWS_COM
- [5] General Requirements on Basic Software Modules AUTOSAR_SRS_BSWGeneral
- [6] Requirements on AUTOSAR Features AUTOSAR_RS_Features
- [7] System Template
 AUTOSAR_TPS_SystemTemplate



3.2 Related standards and norms

Not applicable.

3.3 Related specification

AUTOSAR provides a General Specification on Transformers [2], which is also valid for COM Based Transformer.

Thus, the specification ASWS Transformer General shall be considered as additional and required specification for COM Based Transformer.



4 Constraints and assumptions

4.1 Limitations

For the COM Based Transformer all general transformer limitations (see [2]) apply.

Additionally the following restrictions apply for the COM Based Transformer:

[SWS_ComXf_00017] The COM Based Transformer does not support Client-Server communication. |(SRS Xfrm 00201)

[SWS_ComXf_00032] The COM Based Transformer does not support external trigger communication. |(SRS_Xfrm_00201)

[SWS_ComXf_00018] [The COM Based Transformer only supports composite data types (i.e. Signal Groups from COM). | (SRS_Xfrm_00201)

[SWS_ComXf_00019] The COM Based Transformer only supports fix sized data types. | (SRS_Xfrm_00201)

[SWS_ComXf_00022] [The COM Based Transformer only supports signal groups which are byte aligned. | (SRS_Xfrm_00201)

[SWS_ComXf_00023] [The COM Based Transformer only supports signal groups where all group signals are mapped consecutively to the IPdu. | (SRS_Xfrm_00201)

4.2 Applicability to car domains

The COM Based Transformer can be used for all domain applications when a fixed communication matrix is used.



5 Dependencies to other modules

The AUTOSAR RTE [3] has to exist to execute the COM Based Transformer.

The AUTOSAR COM configuration [4] of the data handled by the COM Based Transformer has to exists in order to allow the configuration of the COM Based Transformer.

5.1 File structure

5.1.1 Code file structure

The source code file structure is defined in the [2].

5.1.2 Header file structure

The header file structure of the COM Based Transformer is shown in Figure 5.1.




Figure 5.1: Header File Structure of COM Based Transformer



[SWS_ComXf_00001] \lceil The header file <code>ComXf[_<Ie>].h</code> shall be the main include file for the COM Based transformer and include <code>TransformerTypes.h</code> and its Module Interlink Header file <code>SchM_<bsnp>_[<vi>_<ai>].h</code> where

<!e> is the optional implementation specific file name extension according
[SWS_BSW_00103],

 $\mbox{\sc Name}$ is the BSW Scheduler Name Prefix according [SWS_Rte_07593] and [SWS_Rte_07594],

<vi> is the vendorId of the BSW module and

<ai> is the vendorApiInfix of the BSW module. | (SRS BSW 00346)

The file TransformerTypes.h contains the general transformer data types.



6 Requirements Tracing

The following table references the features specified in [5] and [6] and links to the fulfillments of these.

Feature	Description	Satisfied by
[SRS_BSW_00159]	All modules of the	[SWS_ComXf_00025]
	AUTOSAR Basic Software	
	shall support a tool based	
	configuration	
[SRS_BSW_00337]	Classification of	[SWS_ComXf_00028]
	development errors	
[SRS_BSW_00346]	All AUTOSAR Basic	[SWS_ComXf_00001]
	Software Modules shall	
	provide at least a basic set	
	of module files	
[SRS_BSW_00404]	BSW Modules shall support	[SWS_ComXf_00030]
	post-build configuration	
[SRS_BSW_00407]	Each BSW module shall	[SWS_ComXf_00024] [SWS_ComXf_00026]
	provide a function to read	[SWS_ComXf_00027]
	out the version information	
	of a dedicated module	
	implementation	
[SRS_BSW_00411]	All AUTOSAR Basic	[SWS_ComXf_00024] [SWS_ComXf_00026]
	Software Modules shall	[SWS_ComXf_00027]
	apply a naming rule for	
	enabling/disabling the	
[SRS BSW 00441]	existence of the API	[SWS_ComXf_00030]
[303_63W_00441]	Naming convention for type, macro and function	[3W3_C0IIIXI_00030]
[SRS_Xfrm_00009]	A fixed set of transformer	[SWS ComXf 00003]
[5115_X11111_00009]	classes shall exist	[3443_001174_00000]
[SRS_Xfrm_00011] A transformer shall belong		[SWS_ComXf_00003] [SWS_ComXf_00006]
	to a specific transformer	
	class	
[SRS_Xfrm_00201]	The COM Based	[SWS_ComXf_00004] [SWS_ComXf_00005]
	Transformer shall define the	[SWS_ComXf_00007] [SWS_ComXf_00008]
	serialization of atomic and	[SWS_ComXf_00009] [SWS_ComXf_00010]
	structured data elements	[SWS_ComXf_00011] [SWS_ComXf_00012]
	into linear arrays based on	[SWS_ComXf_00013] [SWS_ComXf_00014]
	a fixed data mapping	[SWS_ComXf_00015] [SWS_ComXf_00016]
		[SWS_ComXf_00017] [SWS_ComXf_00018]
		[SWS_ComXf_00019] [SWS_ComXf_00020]
		[SWS_ComXf_00021] [SWS_ComXf_00022]
		[SWS_ComXf_00023] [SWS_ComXf_00032]
ICDC Vives 000001	The COM Decad	[SWS_ComXf_00035]
[SRS_Xfrm_00202]	The COM Based Transformer shall take its	[SWS_ComXf_00005] [SWS_ComXf_00014]
		[SWS_ComXf_00020] [SWS_ComXf_00025]
	configuration from the COM	[SWS_ComXf_00031] [SWS_ComXf_00033]
	module	[SWS_ComXf_00034]



7 Functional specification

When a SWC initiates an inter-ECU communication which is configured to be transformed, the SWC hands the data over to the RTE. The RTE executes the configured transformer chain which contains - if the configuration demands this - the COM Based Transformer.




Figure 7.1: Overview of COM Based Transformer

The COM Based Transformer on the sender side serializes the data of the SWC and brings them into an uint8-array representation based on the communication matrix description. The uint8-array representation is forwarded to the COM module to be placed inside the respective IPdu. The COM module may analyze (depending on the configuration of the Transmission Mode Selection – TMS) the provided uint8-array and trigger the respective transmission mode. The IPdu is sent via the communication stack over the bus to the receiver(s).

The RTE of the receiver side executes the transformer chain in the reverse order. The COM Based transformer of the receiver deserializes the linear data back into the original data structure. These are handed over to the receiving SWC.

From the SWC's point of view it is totally transparent whether data are transformed or not.






Figure 7.2: IPdu and signal layout

The handling of the data inside COM's IPdu buffer and the transformer buffer is shown in figure 7.2.

The IsignalIPdu is handled by the COM module as ComIPdu and may contain several parts (signals and signal groups). A signal group in COM is represented by the ComSignalGroup container.

In the System Template [7] it is possible to define that a signal group shall be handled by the COM Based Transformer. The usage of the COM Based Transformer for a specific transformer chain is defined by the reference comBasedSignalGroupTransformation from the ISignalGroup to DataTransformation (see figure 7.3).






Figure 7.3: System Template Transformed communication

In the Ecu configuration of the COM module such ComSignalGroups have a ComSignalGroupArrayAccess=true parameter defined.

If the ComSignalGroupArrayAccess=true then it implicitly defines the length of the signal group ([SWS_Com_00845] [4]) and the start position inside the ComIPdu where the signal group starts ([SWS_Com_00844] [4]). Thus there can be several signals and signal groups defined inside an ISignalIPdu (e.g. 'Signal A' and 'Signal B' are part of the IPdu but are not considered by the COM Based Transformer for the 'Signal Group X').

The Com APIs Com_SendSignalGroupArray and Com_ReceiveSignalGroupArray handle the signal group as array representation based on length of the signal group and the start position inside the ComIPdu. This array representation contains all signals that belong to the signal group, regardless whether the application software has a data mapping defined or not.

As an example in figure 7.2 the 'Signal Group X' consists of the signals 'CRC', 'SC', 'D1', 'D2', 'D3', and 'D4'. Thus the RTE will interact with COM based on the whole array representation of this signal group with length of the signal group.

When the RTE interacts with the COM Based Transformer also all the other potential transformers need to be considered in order to determine which part of the array representation of the signal group actually is provided to each transformer since each transformer may add data during sending (or remove data during reception).

E.g. the part of the array representation which holds the 'CRC' and 'SC' signals are handled by the E2E transformer but will not be considered by the COM Based Transformer. The RTE will provide the data buffer from the 'Start of data with DataMapping defined' location to the COM Based Transformer.



7.1 Specification of the COM Based Transformer

Serialization describes the way data is represented in protocol data units (PDUs) transported over a network. For the COM Based Transformer the serialization is defined by the communication matrix using the System Template [7]. The communication matrix information is taken over to the Ecu configuration of the COM module.

[SWS_ComXf_00005] The serialization is based on the Ecu configuration of the COM module and

- the Software Components PortPrototype,
- the dataElement list defined by the respective SenderReceiverInterface,
- the SenderReceiverToSignalGroupMapping,
- and the ISignalToIPduMapping for the SystemSignalGroup.

(SRS Xfrm 00201, SRS Xfrm 00202)

[SWS_ComXf_00003] The COM Based transformer shall only be used as the top-most transformer (first) in a transformer chain.

| (SRS_Xfrm_00009, SRS_Xfrm_00011)|

The COM Based transformer serializes structured data into a linear form. Therefore it can only be used as the first transformer on the sending side and the last transformer on the receiving side.

[SWS_ComXf_00004] \[The COM Based transformer defined in this document shall be used as a transformer if

- the attribute protocol of the TransformationTechnology is set to COMBased
- and the attribute version of the TransformationTechnology is set to 1.0.0
- and the attribute transformerClass of the TransformationTechnology is set to serializer

(SRS Xfrm 00201)

[SWS_ComXf_00015] [The COM Based Transformer shall support all basic data types that are supported by the COM module in [SWS_Com_00675] except for UINT8_DYN. | (SRS_Xfrm_00201)

[SWS_ComXf_00016] [The COM Based Transformer shall handle each dataElement of the SenderReceiverInterface individually. | (SRS Xfrm 00201)

[SWS_ComXf_00021] [The COM Based Transformer shall handle each dataElement of the SenderReceiverInterface like defined for the COM module [4] when the COM API Com_SendSignal (rep. Com_ReceiveSignal) is called for a shadow signal.](SRS_Xfrm_00201)



This defines that the COM Based Transformer performs all actions equally to the COM module. This does include functionality like endianess conversion and sign extension.

The COM Configuration implicitly defines the length of the signal group ([SWS_Com_00845] [4]) and the start position inside the ComIPdu where the signal group starts ([SWS_Com_00844] [4]). In order to place the transformed data element into the data buffer provided by the RTE the COM Based Transformer needs to respect the offset introduced by the position of the ComGroupSignal inside the ComIPdu (defined by the start position inside the ComIPdu) and the additional offset introduced by header data which is handled by other transformers called after the COM Based Transformer.

[SWS_ComXf_00014] \[\text{ The COM Based Transformer shall calculate the 'COM Data Offset' by collecting all other transformer's headerLength information and add the start position inside the ComIPdu. | (SRS_Xfrm_00201, SRS_Xfrm_00202)

[SWS_ComXf_00020] The COM Based Transformer shall place the serialized data element into the data buffer at the position:

ComBitPosition - (8 * 'COM Data Offset')

where <code>ComBitPosition</code> is taken from the <code>ComGroupSignal</code> definition in COM and 'COM Data Offset' is defined by <code>[SWS_ComXf_00014]</code>. <code>](SRS_Xfrm_00201, SRS Xfrm_00202)</code>

[SWS_ComXf_00013] To allow migration, the deserialization shall be able to accept larger array representations and ignore dataElements appended at the end of a previously known parameter list. |(SRS_Xfrm_00201)

This means: data elements that were not defined in the interface specification used to generate or parameterize the deserialization code at the end of the serialized data will be ignored by the deserialization.

Class	TransformationTechnology				
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::Transformer	
Note	A Transformation	Technolo	gy is a t	transformer inside a transformer chain.	
	Tags: xml.nameP	lural=TF	RANSFO	DRMATION-TECHNOLOGIES	
Base	ARObject, Identifia	able, Mu	ultilangua	ageReferrable, Referrable	
Attribute	Туре	Type Mul. Kind Note			
bufferProp erties	BufferProperties	1	aggr	Aggregation of the mandatory BufferProperties.	
hasInternal State	Boolean	01	attr	This attribute defines whether the Transformer has an internal state or not.	
needsOrigi nalData	Boolean	01	attr	Specifies whether this transformer gets access to the SWC's original data.	
protocol	String	1	attr	Specifies the protocol that is implemented by this transformer.	



Attribute	Туре	Mul.	Kind	Note
transforma tionDescrip tion	Transformation Description	01	aggr	A transformer can be configured with transformer specific parameters which are represented by the TransformerDescription. Stereotypes: atpVariation Tags: vh.latestBindingTime=postBuild
transforme rClass	TransformerCla ssEnum	1	attr	Specifies to which transformer class this transformer belongs.
version	String	1	attr	Version of the implemented protocol.

Table 7.1: TransformationTechnology

Enumeration	TransformerClassEnum
Package	M2::AUTOSARTemplates::SystemTemplate::Transformer
Note	Specifies the transformer class of a transformer.
Literal	Description
custom	The transformer is a custom transformer.
	Tags: atp.EnumerationValue=0
safety	The transformer is a safety transformer.
	Tags: atp.EnumerationValue=1
security	The transformer is a security transformer.
	Tags: atp.EnumerationValue=2
serializer	The transformer is a serializing transformer.
	Tags: atp.EnumerationValue=3

Table 7.2: TransformerClassEnum

Class	BufferProperties	BufferProperties			
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::Transformer	
Note	Configuration of the	ne buffei	rpropert	ties the transformer needs to work.	
Base	ARObject				
Attribute	Туре	Mul.	Kind	Note	
bufferCom putation	CompuScale	01	aggr	If the transformer changes the size of the data, the CompuScale can be used to specify a rule to derive the size of the output data based on the size of the input data.	
headerLen gth	Integer	1	attr	Defines the length of the header (in bits) this transformer will add in front of the data.	
inPlace	Boolean	1	attr	If set, the transformer uses the input buffer as output buffer.	

Table 7.3: BufferProperties



Class	TransformationDescription (abstract)				
Package	M2::AUTOSARTe	M2::AUTOSARTemplates::SystemTemplate::Transformer			
Note		The TransformationDescription is the abstract class that can be used by specific transformers to add transformer specific properties.			
Base	ARObject, Describ	ARObject, Describable			
Attribute	Type Mul. Kind Note				
_					

Table 7.4: TransformationDescription

7.2 Error classififcation

7.2.1 Development Errors

[SWS_ComXf_00028] Development Errors The errors shown in table 7.5 are defined as development errors for the COM Based Transformer. | (SRS_BSW_00337)

Type of error	Related error code	Value
Error code if any other API service, except	<mip>_E_UNINIT</mip>	0x01
GetVersionInfo is called before the		
transformer module was initialized with Init		
or after a call to DeInit		
Error code if an invalid configuration set was	<mip>_E_INIT_FAILED</mip>	0x02
selected		
API service called with wrong parameter	<mip>_E_PARAM</mip>	0x03
API service called with invalid pointer	<mip>_E_PARAM_POINTER</mip>	0x04

Table 7.5: Development Errors

7.2.2 Runtime Errors

No runtime errors are specified for the COM Based Transformer.

7.2.3 Transient Faults

No transient faults are specified for the COM Based Transformer.

7.2.4 Production Errors

No production errors are specified for the COM Based Transformer.



7.2.5 Extended Production Errors

No extended production errors are specified for the COM Based Transformer.



8 API specification

8.1 Imported types

There are no imported types from other modules beyond those specified in [2].

In the Module Interlink Headers file which is imported by the COM Based Transformer, all ImplementationDataTypes known to the RTE are included. Using this mechanism, the COM Based Transformer knows all data types of data which shall be transformed.

8.2 Type definitions

[SWS_ComXf_00030] [

Name:	ComXf_ConfigType					
Type:	Structure					
Element:	implementation - specific					
Description:	This is the type of the data structure containing the initialization data for the transformer.					

Table 8.1: ComXf_ConfigType

(SRS BSW 00404, SRS BSW 00441)

8.3 Function definitions

The COM Based transformer provides the specific interfaces generally required by [2].

[SWS_ComXf_00006] [The COM Based Transformer shall only provide functions for transformers where the TransformationTechnology is referenced as the first reference in the list of ordered references transformerChain from a DataTransformation to a TransformationTechnology.] (SRS_Xfrm_00011)

That means, only the first transformer in a transformer chain can be a COM Based Transformer because serializer transformer are in general only allowed to be the first transformer in a chain.

8.3.1 ComXf_<transformerId>

[SWS ComXf 00007] [

Service name:	ComXf_ <transformerid></transformerid>



	Г					
Syntax:	uint8 ComXf_ <tra< th=""><th>nsformerId>(</th></tra<>	nsformerId>(
	uint8* buffer,					
	uint32* bufferLe	ngth,				
	const <type>* da</type>	taElement				
)					
Service ID[hex]:	0x03					
Sync/Async:	Synchronous					
Reentrancy:	Reentrant					
Parameters (in):	dataElement Data element which shall be transformed					
Parameters (inout):	None					
Parameters (out):	buffer Buffer allocated by the RTE, where the transformed					
		data has to be stored by the transformer				
	bufferLength Used length of the buffer					
Return value:	uint8	0x00 (E_OK): Serialization successful				
	0x81 (E SER GENERIC ERROR): A generic erro					
	occurred					
Description:	This function transforms a Sender/Receiver communication using the se-					
	rialization of COM Based Transformer. It takes the data element as input					
	and outputs an uint8 a	array containing the serialized data.				

Table 8.2: ComXf_<transformerId>

\(\(\sum_{\text{NRS}_Xfrm_00201}\)\)
where

- type is data type of the data element after all data conversion activities of the RTE
- transformerId is the name pattern for the transformer specified in [SWS Xfrm 00062] ([2]).

The function specified in [SWS_ComXf_00007] exists for each transformed Sender/Receiver communication which uses the COM Based Transformer.

[SWS_ComXf_00008] [The function specified in [SWS_ComXf_00007] shall exist for the first reference in the list of ordered references transformerChain from a DataTransformation to a TransformationTechnology if the DataTransformation is referenced by an ISignalGroup in the role comBasedSignalGroupTransformation where the ISignalGroup references a SystemSignalGroup which is referenced by SenderReceiverToSignalGroupMapping.] (SRS Xfrm 00201)

[SWS_ComXf_00009] The function specified in [SWS_ComXf_00007] shall serialize complex data elements of Sender/Receiver communication into a linear byte array representation using the COM Based Transformation. | (SRS_Xfrm_00201)

8.3.2 ComXf_Inv_<transformerId>

[SWS ComXf 00010] [



Service name:	ComXf_Inv_ <transform< th=""><th>merld></th></transform<>	merld>				
Syntax:	<pre>uint8 ComXf_Inv_<transformerid>(</transformerid></pre>					
	const uint8* buffer,					
	uint32 bufferLen	gth,				
	<type>* dataElem</type>	ent				
)					
Service ID[hex]:	0x04					
Sync/Async:	Synchronous					
Reentrancy:	Reentrant					
Parameters (in):	buffer	Buffer allocated by the RTE, where the still serial-				
		ized data are stored by the Rte				
	bufferLength Used length of the buffer					
Parameters (inout):	None					
Parameters (out):	dataElement	Data element which is the result of the transforma-				
		tion and contains the deserialized data element				
Return value:	uint8	0x00 (E_OK): Serialization successful				
		0x01 (E_NO_DATA): No data available which can be				
		deserialized				
	0x81 (E_SER_GENERIC_ERROR): A generic erro					
	occurred					
Description:	This function deserializes a Sender/Receiver communication using the					
	deserialization of COM Based Transformer. It takes the uint8 array con-					
		lata as input and outputs the original data element				
	which will be passed t	o the Rte.				

Table 8.3: ComXf Inv <transformerId>

](SRS_Xfrm_00201)
where

- type is data type of the data element before all data conversion activities of the RTF
- transformerId is the name pattern for the transformer specified in [SWS_Xfrm_00062] ([2]).

The function specified in [SWS_ComXf_00010] exists for each transformed Sender/Receiver communication which uses the COM Based Transformation.

[SWS_ComXf_00011] [The function specified in [SWS_ComXf_00010] shall exist for the first reference in the list of ordered references transformerChain from a DataTransformation to a TransformationTechnology if the DataTransformation is referenced by an ISignalGroup in the role comBasedSignalGroupTransformation where the ISignalGroup references a SystemSignalGroup which is referenced by SenderReceiverToSignalGroupMapping.] (SRS Xfrm 00201)



[SWS_ComXf_00012] The function specified in [SWS_ComXf_00010] shall deserialize a linear byte array to primitive or complex data elements of Sender/Receiver communication using the COM Based Transformation. | (SRS_Xfrm_00201)

8.3.3 ComXf Init

[SWS_ComXf_00026] [

Service name:	ComXf_Init			
Syntax:	<pre>void ComXf_Init(</pre>			
	const ComXf_Conf	igType* config		
)			
Service ID[hex]:	0x01			
Sync/Async:	Synchronous			
Reentrancy:	Reentrant			
Parameters (in):	config Pointer to the transformer's configuration data.			
Parameters (inout):	None			
Parameters (out):	None			
Return value:	None			
Description:	This service initializes	the transformer for the further processing.		

Table 8.4: ComXf_Init

(SRS_BSW_00407, SRS_BSW_00411)

8.3.4 ComXf_Delnit

[SWS_ComXf_00027] [

Service name:	ComXf_DeInit
Syntax:	<pre>void ComXf_DeInit(</pre>
	void
Service ID[hex]:	0x02
Sync/Async:	Synchronous
Reentrancy:	Reentrant
Parameters (in):	None
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	This service deinitializes the transformer.

Table 8.5: ComXf_Delnit

(SRS_BSW_00407, SRS_BSW_00411)



8.3.5 ComXf_GetVersionInfo

[SWS_ComXf_00024] [

Service name:	ComXf_GetVersionInfo			
Syntax:	<pre>void ComXf_GetVersionInfo(</pre>			
	Std_VersionInfoT	ype* VersionInfo		
)			
Service ID[hex]:	0x00			
Sync/Async:	Synchronous			
Reentrancy:	Reentrant			
Parameters (in):	None			
Parameters (inout):	None			
Parameters (out):	VersionInfo Pointer to where to store the version information of this module.			
Return value:	None			
Description:	This service returns the version information of the called transformer			
Description.	module.			

Table 8.6: ComXf_GetVersionInfo

(SRS_BSW_00407, SRS_BSW_00411)

8.4 Callback notifications

COM Based Transformer has no callback notifications.

8.5 Scheduled functions

COM Based Transformer has no scheduled functions.

8.6 Expected interfaces

COM Based Transformer has no expected interfaces.



9 Sequence diagrams

There are no sequence diagrams applicable to COM Based Transformer.



10 Configuration specification

[SWS_ComXf_00031] [The COM Based Transformer is configured based on the COM module configuration [4]. | (SRS Xfrm 00202)

Still, there is an EcuC necessary to map the implementation of the transformer. The EcuC defined in [2] shall be used.

[SWS_ComXf_00033] The vendor specific module definition of the COM Based Transformer - based on the Xfrm configuration [2] - may be extended by the vendor to support the close interaction with the Com module [4]. |(SRS_Xfrm_00202)

[SWS_ComXf_00034] [The COM Based Transformer shall be configured to be postBuild when the configuration of the Com module [4] is postBuild for the respective ComSignalGroups. |(SRS Xfrm 00202)

[SWS_ComXf_00025] [The apiServicePrefix of the COM Based Transformer's EcuC shall be set to ComXf. | (SRS_BSW_00159, SRS_Xfrm_00202)



A Referenced Meta Classes

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document but which are not contained directly in the scope of describing specific meta-model semantics.

Class	BswImplementat	ion					
Package	M2::AUTOSARTemplates::BswModuleTemplate::BswImplementation						
Note	Contains the implementation specific information in addition to the generic specification (BswModuleDescription and BswBehavior). It is possible to have several different BswImplementations referring to the same BswBehavior. Tags: atp.recommendedPackage=BswImplementations						
Base				eElement, Identifiable, Implementation, eableElement, Referrable			
Attribute	Туре	Mul.	Kind	Note			
arRelease Version	RevisionLabelSt ring	1	attr	Version of the AUTOSAR Release on which this implementation is based. The numbering contains three levels (major, minor, revision) which are defined by AUTOSAR.			
behavior	BswInternalBeh avior	1	ref	The behavior of this implementation. This relation is made as an association because • it follows the pattern of the SWCT • since ARElement cannot be splitted, but we want supply the implementation later, the BswImplementation is not aggregated in BswBehavior			
preconfigur edConfigur ation	EcucModuleCo nfigurationValue s	*	ref	Reference to the set of preconfigured (i.e. fixed) configuration values for this BswImplementation. If the BswImplementation represents a cluster of several modules, more than one EcucModuleConfigurationValues element can be referred (at most one per module), otherwise at most one such element can be referred. Tags: xml.roleWrapperElement=true			
recommen dedConfig uration	EcucModuleCo nfigurationValue s	*	ref	Reference to one or more sets of recommended configuration values for this module or module cluster.			



Attribute	Туре	Mul.	Kind	Note
vendorApil nfix	Identifier	01	attr	In driver modules which can be instantiated several times on a single ECU, SRS_BSW_00347 requires that the names of files, APIs, published parameters and memory allocation keywords are extended by the vendorld and a vendor specific name. This parameter is used to specify the vendor specific name. In total, the implementation specific API name is generated as follows: <modulename>_<vendorld>_ <vendorapilnfix>_<api from="" name="" sws="">. E.g. assuming that the vendorld of the implementer is 123 and the implementer chose a vendorApilnfix of "v11r456" an API name Can_Write defined in the SWS will translate to Can_123_v11r456_Write. This attribute is mandatory for all modules with upper multiplicity > 1. It shall not be used for modules with upper multiplicity =1. See also SWS_BSW_00102.</api></vendorapilnfix></vendorld></modulename>
vendorSpe cificModule Def	EcucModuleDef	*	ref	the vendor specific EcucModuleDef used in this BswImplementation if it represents a single module several EcucModuleDefs used in this BswImplementation if it represents a cluster of modules one or no EcucModuleDefs used in this BswImplementation if it represents a library Tags: xml.roleWrapperElement=true

Table A.1: BswImplementation

Class	DataTransformation			
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::Transformer
Note	A DataTransforma transformers.	tion rep	resents	a transformer chain. It is an ordered list of
Base	ARObject, Identifia	able, Mu	ıltilangu	ageReferrable, Referrable
Attribute	Type Mul. Kind Note			
dataTransf ormationKi nd	DataTransforma tionKindEnum	01	attr	This attribute controls the kind of DataTransformation to be applied.
executeDe spiteDataU navailabilit y	Boolean	1	attr	Specifies whether the transformer chain is executed even if no input data are available.



Attribute	Туре	Mul.	Kind	Note
transform erChain (ordered)	Transformation Technology	1*	ref	This attribute represents the definition of a chain of transformers that are supposed to be executed according to the order of being referenced from DataTransformation.

Table A.2: DataTransformation

Class	EcucModuleDef					
Package	M2::AUTOSARTemplates::ECUCParameterDefTemplate					
Note	Used as the top-level element for configuration definition for Software Modules, including BSW and RTE as well as ECU Infrastructure. Tags: atp.recommendedPackage=EcucModuleDefs					
Base	ARElement, ARO	bject, At finitionE	pBluepr	int, AtpBlueprintable, AtpDefinition, Collectable Identifiable, MultilanguageReferrable, Packageable		
Attribute	Туре	Mul.	Kind	Note		
apiService Prefix	Cldentifier	01	attr	For CDD modules this attribute holds the apiServicePrefix.		
				The shortName of the module definition of a Complex Driver is always "Cdd". Therefore for CDD modules the module apiServicePrefix is described with this attribute.		
container	EcucContainerD ef	1*	aggr	Aggregates the top-level container definitions of this specific module definition.		
				Stereotypes: atpSplitable Tags: atp.Splitkey=shortName xml.sequenceOffset=11		
postBuildV ariantSupp ort	Boolean	01	attr	Indicates if a module supports different post-build variants (previously known as post-build selectable configuration sets). TRUE means yes, FALSE means no.		
refinedMod uleDef	EcucModuleDef	01	ref	Optional reference from the Vendor Specific Module Definition to the Standardized Module Definition it refines. In case this EcucModuleDef has the category STANDARDIZED_MODULE_DEFINITION this reference shall not be provided. In case this EcucModuleDef has the category VENDOR_SPECIFIC_MODULE_DEFINITION this reference is mandatory.		
				Stereotypes: atpUriDef		
supported ConfigVari ant	EcucConfigurati onVariantEnum	*	attr	Specifies which ConfigurationVariants are supported by this software module. This attribute is optional if the EcucModuleDef has the category STANDARDIZED_MODULE_DEFINITION. If the category attribute of the EcucModuleDef is set to VENDOR_SPECIFIC_MODULE_DEFINITION then this attribute is mandatory.		



Attribute	Туре	Mul.	Kind	Note
-----------	------	------	------	------

Table A.3: EcucModuleDef

Class	ISignalGroup					
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::Fibex::FibexCore::CoreCommunication		
Note	SignalGroup of the Interaction Layer. The RTE supports a "signal fan-out" where the same System Signal Group is sent in different SignalIPdus to multiple receivers.					
	An ISignalGroup r ISignalGroup repr			ISignals that shall always be kept together. A Signal Group.		
	Therefore it is reconstitution ISignals (see atp.)			ut the ISignalGroup in the same Package as ackage)		
	Tags: atp.recomm	nendedF	ackage:	=ISignalGroup		
Base	ARObject, Collect PackageableElem			bexElement, Identifiable, MultilanguageReferrable,		
Attribute	Type Mul. Kind Note					
comBased SignalGrou pTransfor mation	DataTransforma tion	01	ref	Optional reference to a DataTransformation which represents the transformer chain that is used to transform the data that shall be placed inside this ISignalGroup based on the COMBasedTransformer approach. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=comBasedSignalGroup Transformation, variationPoint.shortLabel vh.latestBindingTime=codeGenerationTime		
iSignal	ISignal	*	ref	Reference to a set of ISignals that shall always be kept together.		
systemSig nalGroup	SystemSignalGr oup	1	ref	Reference to the SystemSignalGroup that is defined on VFB level and that is supposed to be transmitted in the ISignalGroup.		
transforma tionISignal Props	TransformationI SignalProps	*	aggr	A transformer chain consists of an ordered list of transformers. The ISignalGroup specific configuration properties for each transformer are defined in the TransformationISignalProps class. The transformer configuration properties that are common for all ISignalGroups are described in the TransformationTechnology class.		

Table A.4: ISignalGroup



Class	ISignallPdu					
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::FibexCore::CoreCommunication					
Note	Represents the IPdus handled by Com. The ISignalIPdu assembled and disassembled in AUTOSAR COM consists of one or more signals. In case no multiplexing is performed this IPdu is routed to/from the Interface Layer. A maximum of one dynamic length signal per IPdu is allowed.					
Base	Tags: atp.recomm			bexElement, IPdu, Identifiable, Multilanguage		
	Referrable, Packa	geableE	Element,	Pdu, Referrable		
Attribute	Туре	Mul.	Kind	Note		
iPduTiming Specificati on	IPduTiming	01	aggr	Timing specification for Com IPdus (Transmission Modes). This information is mandatory for the sender in a System Extract. This information may be omitted on receivers in a System Extract. atpVariation: The timing of a Pdu can vary. Stereotypes: atpVariation Tags: vh.latestBindingTime=postBuild		
iSignalToP duMapping	ISignalToIPduM apping	*	aggr	Definition of SignalToIPduMappings included in the SignalIPdu. atpVariation: The content of a PDU can be variable. Stereotypes: atpVariation Tags: vh.latestBindingTime=postBuild		
pduCounte r	SignallPduCoun ter	01	aggr	An included Pdu counter is used to ensure that a sequence of Pdus is maintained. Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime		
pduReplica tion	SignallPduRepli cation	01	aggr	Pdu Replication is a form of redundancy where the data content of one ISignallPdu (source) is transmitted inside a set of replica ISignallPdus. These ISignallPdus (copies) have different Pdu IDs, identical PduCounters, identical data content and are transmitted with the same frequency. Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime		
unusedBit Pattern	Integer	1	attr	AUTOSAR COM and AUTOSAR IPDUM are filling not used areas of an IPDU with this bit-pattern. This attribute is mandatory to avoid undefined behavior. This byte-pattern will be repeated throughout the IPdu.		

Table A.5: ISignallPdu





Class	ISignalTolPduMapping					
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::FibexCore::CoreCommunication					
Note	An ISignalToIPduMapping describes the mapping of ISignals to ISignalIPdus and defines the position of the ISignal within an ISignalIPdu.					
Base	ARObject, Identifi	able, Mu	ultilangu	ageReferrable, Referrable		
Attribute	Туре	Mul.	Kind	Note		
iSignal	ISignal	01	ref	Reference to a ISignal that is mapped into the ISignallPdu.		
				Each ISignal contained in the ISignalGroup shall be mapped into an IPdu by an own ISignalToIPduMapping. The references to the ISignal and to the ISignalGroup in an ISignalToIPduMapping are mutually exclusive.		
iSignalGro up	ISignalGroup	01	ref	Reference to an ISignalGroup that is mapped into the SignalIPdu. If an ISignalToIPduMapping for an ISignalGroup is defined, only the UpdateIndicationBitPosition and the transferProperty is relevant. The startPosition and the packingByteOrder shall be ignored. Each ISignal contained in the ISignalGroup shall be mapped into an IPdu by an own ISignalToIPduMapping. The references to the ISignal and to the ISignalGroup in an ISignalToIPduMapping are mutually exclusive.		
packingByt eOrder	ByteOrderEnum	01	attr	This parameter defines the order of the bytes of the signal and the packing into the SignallPdu. The byte ordering "Little Endian" (MostSignificantByteLast), "Big Endian" (MostSignificantByteFirst) and "Opaque" can be selected. For opaque data endianness conversion shall be configured to Opaque. The value of this attribute impacts the absolute position of the signal into the SignallPdu (see the startPosition attribute description).		
				For an ISignalGroup the packingByteOrder is irrelevant and shall be ignored.		



Attribute	Туре	Mul.	Kind	Note
startPositio n	Integer	01	attr	This parameter is necessary to describe the bitposition of a signal within an SignalIPdu. It denotes the least significant bit for "Little Endian" and the most significant bit for "Big Endian" packed signals within the IPdu (see the description of the packingByteOrder attribute). In AUTOSAR the bit counting is always set to "sawtooth" and the bit order is set to "Decreasing". The bit counting in byte 0 starts with bit 0 (least significant bit). The most significant bit in byte 0 is bit 7. Please note that the way the bytes will be actually sent on the bus does not impact this representation: they will always be seen by the software as a byte array. If a mapping for the ISignalGroup is defined, this
				attribute is irrelevant and shall be ignored.
transferPro perty	TransferPropert	01	attr	The triggered or triggeredOnChange, triggeredWithoutRepetition and triggeredOnChangeWithoutRepetition transferProperty causes immediate transmission of the IPdu, except if transmission mode Periodic or transmission mode NONE is defined for the IPdu. The Pending transfer property does not cause transmission of an I-PDU. The immediate transmission of the IPdu is caused even if only one Signal of an IPdu has the transferProperty triggered or triggeredWithoutRepetition or triggeredOnChange or triggeredOnChangeWithoutRepetition and all other Signals have the transferProperty pending. Also for ISignals of an ISignalGroup (GroupSignals) this attribute is relevant and shall be evaluated: • If none of the ISignals belonging to the ISignalGroup have a transferProperty defined the transferProperty of the ISignalGroup is considered. • If at least one of the ISignals belonging to the ISignalGroup has a transferProperty defined all other ISignals belonging to the same ISignalGroup shall have a transferProperty defined as well. All of the transferProperties of the GroupSignals are considered.



position of the update bit within the SignallPdu. For Signals of a ISignalGroup this attribute is irrelevant and shall be ignored. Note that the exact bit position of the updateIndicationBitPosition is linked to the value of the attribute packingByteOrder because the method of finding the bit position is different for the values mostSignificantByteFirst and mostSignificantByteLast. This means that if the value of packingByteOrder is changed while the value of updateIndicationBitPosition remains unchanged the exact bit position of updateIndicationBitPosition within the enclosing ISignallPdu still undergoes a change. This attribute denotes the least significant bit for "Little Endian" and the most significant bit for "Big Endian" packed signals within the IPdu (see the description of the packingByteOrder attribute). In	Attribute	Туре	Mul.	Kind	Note
	updateIndi cationBitP		_	_	The UpdateIndicationBit indicates to the receivers that the signal (or the signal group) was updated by the sender. Length is always one bit. The UpdateIndicationBitPosition attribute describes the position of the update bit within the SignalIPdu. For Signals of a ISignalGroup this attribute is irrelevant and shall be ignored. Note that the exact bit position of the updateIndicationBitPosition is linked to the value of the attribute packingByteOrder because the method of finding the bit position is different for the values mostSignificantByteLast. This means that if the value of packingByteOrder is changed while the value of updateIndicationBitPosition remains unchanged the exact bit position of updateIndicationBitPosition within the enclosing ISignalIPdu still undergoes a change. This attribute denotes the least significant bit for "Little Endian" and the most significant bit for "Big Endian" packed signals within the IPdu (see the description of the packingByteOrder attribute). In AUTOSAR the bit counting is always set to "sawtooth" and the bit order is set to "Decreasing". The bit counting in byte 0 starts with bit 0 (least

Table A.6: ISignalTolPduMapping

Class	Implementation (abstract)					
Package	M2::AUTOSARTe	mplates	::Comm	onStructure::Implementation		
Note	Description of an	impleme	entation	a single software component or module.		
Base	I	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable				
Attribute	Type Mul. Kind Note					
buildAction Manifest	BuildActionMani fest	01	ref	A manifest specifying the intended build actions for the software delivered with this implementation. Stereotypes: atpVariation Tags: vh.latestBindingTime=codeGenerationTime		
codeDescri ptor	Code	1*	aggr	Specifies the provided implementation code.		
compiler	Compiler	*	aggr	Specifies the compiler for which this implementation has been released		



Attribute	Туре	Mul.	Kind	Note
generated Artifact	DependencyOn Artifact	*	aggr	Relates to an artifact that will be generated during the integration of this Implementation by an associated generator tool. Note that this is an optional information since it might not always be in the scope of a single module or component to provide this information. Stereotypes: atpVariation
				Tags: vh.latestBindingTime=preCompileTime
hwElement	HwElement	*	ref	The hardware elements (e.g. the processor) required for this implementation.
linker	Linker	*	aggr	Specifies the linker for which this implementation has been released.
mcSupport	McSupportData	01	aggr	The measurement & calibration support data belonging to this implementation. The aggregtion is «atpSplitable» because in case of an already exisiting BSW Implementation model, this description will be added later in the process, namely at code generation time. Stereotypes: atpSplitable Tags: atpSplitkey=mcSupport
programmi ngLanguag e	Programmingla nguageEnum	1	attr	Programming language the implementation was created in.
requiredArt ifact	DependencyOn Artifact	*	aggr	Specifies that this Implementation depends on the existance of another artifact (e.g. a library). This aggregation of DependencyOnArtifact is subject to variability with the purpose to support variability in the implementations. Different algorithms in the implementation might cause different dependencies, e.g. the number of used libraries. Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime
requiredGe neratorToo I	DependencyOn Artifact	*	aggr	Relates this Implementation to a generator tool in order to generate additional artifacts during integration. Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime
resourceC onsumptio n	ResourceConsu mption	1	aggr	All static and dynamic resources for each implementation are described within the ResourceConsumption class. Stereotypes: atpSplitable Tags: atp.Splitkey=shortName
swVersion	RevisionLabelSt ring	1	attr	Software version of this implementation. The numbering contains three levels (like major, minor, patch), its values are vendor specific.



Attribute	Туре	Mul.	Kind	Note
swcBswMa pping	SwcBswMappin g	01	ref	This allows a mapping between an SWC and a BSW behavior to be attached to an implementation description (for AUTOSAR Service, ECU Abstraction and Complex Driver Components). It is up to the methodology to define whether this reference has to be set for the Swc- or BswImplementtion or for both.
usedCode Generator	String	01	attr	Optional: code generator used.
vendorld	PositiveInteger	1	attr	Vendor ID of this Implementation according to the AUTOSAR vendor list

Table A.7: Implementation

Class	Implementation D	ataTyp	е				
Package	M2::AUTOSARTemplates::CommonStructure::ImplementationDataTypes						
Note	Describes a reusable data type on the implementation level. This will typically correspond to a typedef in C-code. Tags: atp.recommendedPackage=ImplementationDataTypes						
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, AutosarDataType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable						
Attribute	Туре	Mul.	Kind	Note			
dynamicAr raySizePro file	String	01	attr	Specifies the profile which the array will follow in case this data type is a variable size array.			
subElemen t (ordered)	Implementation DataTypeEleme nt	*	aggr Specifies an element of an array, struct, or union data type. The aggregation of ImplementionDataTypeElement is subject to variability with the purpose to support the conditional existence of elements inside a ImplementationDataType representing a structure Stereotypes: atpVariation Tags: vh.latestBindingTime=preCompileTime				
symbolPro ps	SymbolProps	01	aggr	This represents the SymbolProps for the ImplementationDataType. Stereotypes: atpSplitable Tags: atp.Splitkey=shortName			
typeEmitte r	NameToken	01	attr	This attribute is used to control which part of the AUTOSAR toolchain is supposed to trigger data type definitions.			

Table A.8: ImplementationDataType



Class	PortPrototype (abstract)							
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components							
Note	Base class for the ports of an AUTOSAR software component. The aggregation of PortPrototypes is subject to variability with the purpose to support the conditional existence of ports.							
Base		eprintab	•	eature, AtpPrototype, Identifiable, Multilanguage				
Attribute	Туре	Mul.	Kind	Note				
clientServe rAnnotatio n	ClientServerAnn otation	*	aggr	Annotation of this PortPrototype with respect to client/server communication.				
delegated PortAnnota tion	DelegatedPortA nnotation	01	aggr	Annotations on this delegated port.				
ioHwAbstr actionServ erAnnotati on	IoHwAbstraction ServerAnnotatio n	*	aggr	Annotations on this IO Hardware Abstraction port.				
modePortA nnotation	ModePortAnnot ation	*	aggr	Annotations on this mode port.				
nvDataPort Annotation	NvDataPortAnn otation	*	aggr	Annotations on this non voilatile data port.				
parameter PortAnnota tion	ParameterPortA nnotation	*	aggr	Annotations on this parameter port.				
senderRec eiverAnnot ation	SenderReceiver Annotation	*	aggr	Collection of annotations of this ports sender/receiver communication.				
triggerPort Annotation	TriggerPortAnn otation	*	aggr	Annotations on this trigger port.				

Table A.9: PortPrototype

Class	SenderReceiverInterface					
Package	M2::AUTOSARTemplates::SWComponentTemplate::PortInterface					
Note	A sender/receiver interface declares a number of data elements to be sent and received.					
	Tags: atp.recommendedPackage=PortInterfaces					
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, DataInterface, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface, Referrable					
Attribute	Type Mul. Kind Note					
dataEleme nt	VariableDataPr 1* aggr The data elements of this ototype SenderReceiverInterface.					
invalidation Policy	InvalidationPolic y	*	aggr	InvalidationPolicy for a particular dataElement		

Table A.10: SenderReceiverInterface



Class	SenderReceiverToSignalGroupMapping						
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::DataMapping			
Note	Mapping of a send to a signal group.	Mapping of a sender receiver communication data element with a composite datatype to a signal group.					
Base	ARObject, DataMa	apping					
Attribute	Туре	Mul.	Kind	Note			
dataEleme nt	VariableDataPr ototype	1	iref	Reference to a data element with a composite datatype which is mapped to a signal group.			
signalGrou p	SystemSignalGr oup	1 ref Reference to the signal group, which contain all primitive datatypes of the composite type					
typeMappi ng	SenderRecCom positeTypeMap ping	1	aggr	The CompositeTypeMapping maps the the ApplicationArrayElements and ApplicationRecordElements to Signals of the SignalGroup.			

Table A.11: SenderReceiverToSignalGroupMapping

Class	SystemSignalGroup						
Package	M2::AUTOSARTe	mplates	::Systen	nTemplate::Fibex::FibexCore::CoreCommunication			
Note	A signal group refers to a set of signals that must always be kept together. A signal group is used to guarantee the atomic transfer of AUTOSAR composite data types.						
	The SystemSignalGroup defines a signal grouping on VFB level. On cluster level the Signal grouping is described by the ISignalGroup element. Tags: atp.recommendedPackage=SystemSignalGroups						
Base	ARElement, ARObject, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable						
Attribute	Type Mul. Kind Note						
systemSig nal	SystemSignal	* ref Reference to a set of SystemSignals that must always be kept together.					
transformin gSystemSi gnal	SystemSignal	01	ref	Optional reference to the SystemSignal which shall contain the transformed (linear) data.			

Table A.12: SystemSignalGroup



B Used ECU Configurtion

To ease the readability the relevant parts of the Com module configuration [4] are duplicated here (for information only).




Figure B.1: AR_EcucDef_ComSignalGroupArrayAccess

SWS Item	[ECUC_Com_00345]				
Container Name	ComSignalGroup				
Description	Contains the configuration parameters of the AUTOSAR COM module's signal groups.				
Post-Build Variant Multiplicity	true				
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE				
	Link time X VARIANT-LINK-TIME				
	Post-build time X VARIANT-POST-BUILD				
Configuration Parameter	S	•			

Name	ComDataInvalidAction [ECl	ComDataInvalidAction [ECUC_Com_00314]				
Description	This parameter defines the action performed upon reception of an invalid signal. Relating to signal groups the action in case if one of the included signals is an invalid signal. If Replace is used the ComSignalInitValue will be used for the replacement.					
Multiplicity	01	01				
Туре	EcucEnumerationParamDe	EcucEnumerationParamDef				
Range	NOTIFY					
	REPLACE Literal for DataInvalidAction					
Post-Build Variant Multiplicity	false					



Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME,
			VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

Name	ComErrorNotification [ECI	ComErrorNotification [ECUC_Com_00499]					
Description	Only valid on sender side: Name of Com_CbkTxErr callback function to be called. If this parameter is omitted no error notification shall take place.						
Multiplicity	01						
Туре	EcucFunctionNameDef						
Default Value							
Regular Expression							
Post-Build Variant Multiplicity	false						
Post-Build Variant Value	false						
Multiplicity Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE				
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD						
	Post-build time	_					
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE				
	Link time X VARIANT-LINK-TIME, VARIANT-POST-BUILD						
	Post-build time	_					
Scope / Dependency	scope: local						

Name	ComFirstTimeout [ECUC_Com_00183]					
Description	Defines the length of the first deadline monitoring timeout period in seconds. This timeout is used immediately after start (or restart) of the deadline monitoring service. The timeout period of the successive periods is configured by ECUC_Com_00263.					
Multiplicity	01					
Туре	EcucFloatParamDef					
Range	[0 3600]					
Default Value	·					
Post-Build Variant Multiplicity	true					



Post-Build Variant Value	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

Name	ComHandleId [ECUC_Com_00165]			
Description	The numerical value used as the ID.			
			nal groups in the COM APIs using	
	Com_SignalIdType or Com_SignalGroupIdType parameter			
	<u> </u>	respectively.		
Multiplicity	01			
Туре	EcucIntegerParamDef (Sym	bolic	Name generated for this parameter)	
Range	0 65535			
Default Value				
Post-Build Variant	false			
Multiplicity				
Post-Build Variant	false			
Value				
Multiplicity	Pre-compile time	X	All Variants	
Configuration Class				
	Link time	_		
	Post-build time	_		
Value Configuration	Pre-compile time	Х	All Variants	
Class				
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: ECU			

Name	ComInitialValueOnly [ECUC_Com_00811]
Description	This parameter defines that the respective signal's initial value shall be put into the respective PDU but there will not be any update of the value through the RTE. Thus the Com implementation does not need to expect any API calls for this signal (group).
Multiplicity	01
Туре	EcucBooleanParamDef
Default Value	false
Post-Build Variant Multiplicity	false
Post-Build Variant Value	false



Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT DOCT BUILD
			VARIANT-POST-BUILD
	Post-build time	-	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME,
			VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local	•	

Name	ComInvalidNotification [ECUC_Com_00315]				
Description	Only valid on receiver side: Name of Com_CbkInv callback function to be called. Name of the function which notifies the RTE about the reception of an invalidated signal/ signal group. Only applicable if ComDataInvalidAction is configured to NOTIFY.				
Multiplicity	01	01			
Туре	EcucFunctionNameDef				
Default Value					
Regular Expression					
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE		
	Link time X VARIANT-LINK-TIME,				
			VARIANT-POST-BUILD		
	Post-build time	_			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD		
	Post-build time	_			
Scope / Dependency	scope: local				

Name	ComNotification [ECUC_Com_00498]			
Description	On sender side: Name of Com_CbkTxAck callback function to be called. On receiver side: Name of Com_CbkRxAck callback function to be called. If this parameter is omitted no notification shall take place.			
	if this parameter is offitted no notification shall take place.			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default Value				
Regular Expression				
Post-Build Variant Multiplicity	false			



Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME,
			VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local	·	

Name	ComRxDataTimeoutAction [ECUC_Com_00412]				
Description	This parameter defines the action performed upon expiration of the				
	reception deadline monitoring timer.				
Multiplicity	01				
Туре	EcucEnumerationParamDe	ef			
Range	NONE	no	no replacement shall take place		
	REPLACE		nals shall be replaced by their mSignalInitValue		
	SUBSTITUTE				
Post-Build Variant Multiplicity	false				
Post-Build Variant Value	false				
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD		
	Post-build time	_			
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD		
	Post-build time	_			
Scope / Dependency	scope: local				

Name	ComSignalGroupArrayAccess [ECUC_Com_10003]
Description	Defines whether the uint8-array based access shall be used for this ComSignalGroup.
Multiplicity	01
Туре	EcucBooleanParamDef
Default Value	
Post-Build Variant Multiplicity	false
Post-Build Variant Value	false



Multiplicity Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency			

Name	ComTimeout [ECUC_Com_00263]			
Description	Defines the length of the deadline monitoring timeout period in seconds. The period for the first timeout period can be configured separately by ECUC_Com_00183.			
Multiplicity	01			
Туре	EcucFloatParamDef			
Range	[0 3600]	[0 3600]		
Default Value				
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

Name	ComTimeoutNotification [ECUC_Com_00552]			
Description	On sender side: Name of Com_CbkTxTOut callback function to be called. On receiver side: Name of Com_CbkRxTOut callback function to be called.			
Multiplicity	01	01		
Туре	EcucFunctionNameDef			
Default Value				
Regular Expression				
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD	
	Post-build time	_		



Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

Name	ComTransferProperty [ECUC_Com_00232]				
Description	Defines if a write access to this signal can trigger the transmission of the corresponding I-PDU. If the I-PDU is triggered, depends also on the transmission mode of the corresponding I-PDU.				
Multiplicity	01				
Туре	EcucEnumerationParamDef				
Range	PENDING	trig cor	rrite access to this signal never gers the transmission of the responding I-PDU.		
	TRIGGERED	a w the I-P	pending on the transmission mode, write access to this signal can trigger transmission of the corresponding DU.		
	TRIGGERED_ON_CHAN GE	a w the I-P	pending on the transmission mode, write access to this signal can trigger transmission of the corresponding DU, but only in case the written ue is different to the locally stored at sent or initial value) in length or ue.		
	TRIGGERED_ON_CHAN GE_WITHOUT_REPETITI ON				
	TRIGGERED_WITHOUT_ REPETITION	-			
Post-Build Variant Multiplicity	true				
Post-Build Variant Value	true				
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME		
	Post-build time	X	VARIANT-POST-BUILD		
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME		
	Post-build time	X	VARIANT-POST-BUILD		
Scope / Dependency	scope: local				
1 1 7	1				



Name	ComUpdateBitPosition [ECU	ComUpdateBitPosition [ECUC_Com_00257]		
Description	Bit position of update-bit inside I-PDU. If this attribute is omitted then there is no update-bit. This setting must be consistently on sender and on receiver side. Range: 063 for CAN and LIN, 0511 for CAN FD, 02031 for FlexRay, 04294967295 for TP.			
Multiplicity	01			
Туре	EcucIntegerParamDef			
Range	0 4294967295			
Default Value	'			
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true	true		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time X VARIANT-LINK-TIME			
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

Name	ComSystemTemplateSignalGroupRef [ECUC_Com_00001]				
Description	Reference to the ISignalToIPduMapping that contains a reference to the ISignalGroup (SystemTemplate) which this ComSignalGroup represents.				
Multiplicity	01				
Туре	Foreign reference to I-SIGN	AL-T	O-I-PDU-MAPPING		
Post-Build Variant Multiplicity	true				
Post-Build Variant Value	true				
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE				
	Link time	X	VARIANT-LINK-TIME		
	Post-build time	X	VARIANT-POST-BUILD		
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE				
	Link time X VARIANT-LINK-TIME				
	Post-build time X VARIANT-POST-BUILD				
Scope / Dependency	scope: ECU				

Included Containers		
Container Name	Multiplicity	Scope / Dependency
ComGroupSignal	0*	This container contains the configuration parameters of group signals. I.e. signals that are included within a signal group.



SWS Item	[ECUC_Com_00520]			
Container Name	ComGroupSignal	ComGroupSignal		
Description	This container contains the configuration parameters of group signals. I.e. signals that are included within a signal group.			
Post-Build Variant Multiplicity	true			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time X VARIANT-POST-BUILD			
Configuration Paramete	rs			

Name	ComBitPosition [ECUC_Co	ComBitPosition [ECUC_Com_00259]		
Description	Starting position within the I-PDU. This parameter refers to the position in the I-PDU and not in the shadow buffer. If the endianness conversion is configured to Opaque the parameter ComBitPosition shall define the bit0 of the first byte like in little endian byte order			
Multiplicity	1	1		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 4294967295			
Default Value		•		
Post-Build Variant Value	true	true		
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

Name	ComBitSize [ECUC_Com_0	ComBitSize [ECUC_Com_00158]		
Description	Size in bits, for integer signal types. For ComSignalType UINT8_N and UINT8_DYN the size shall be configured by ComSignalLength. For ComSignalTypes FLOAT32 and FLOAT64 the size is already defined by the signal type and therefore may be omitted.			
Multiplicity	01			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 64	064		
Default Value				
Post-Build Variant Multiplicity	true	true		
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	



Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT-LINK-TIME
	Post-build time	Х	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

Name	ComHandleld [ECLIC Co	ComHandleId [ECUC_Com_00165]			
110	• •				
Description	The numerical value use	The numerical value used as the ID.			
	This ID identifies signals	and sign	nal groups in the COM APIs using		
	Com_SignalIdType or Co	m_Sign	alGroupIdType parameter		
	respectively.				
Multiplicity	01				
Туре	EcucIntegerParamDef (S	Symbolic	Name generated for this parameter)		
Range	0 65535	0 65535			
Default Value					
Post-Build Variant	false	false			
Multiplicity					
Post-Build Variant	false	false			
Value					
Multiplicity	Pre-compile time	X	All Variants		
Configuration Class					
	Link time	_			
	Post-build time	_			
Value Configuration	Pre-compile time	Pre-compile time X All Variants			
Class					
	Link time –				
	Post-build time				
Scope / Dependency	scope: ECU				

Name	ComSignalDataInvalidValue [ECUC_Com_00391]	
Description	Defines the data invalid value of the signal.	
Multiplicity	01	
Туре	EcucStringParamDef	
Default Value		



Regular Expression			
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	-	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	-	
Scope / Dependency	scope: local dependency: In case of UINT8_N the length of ComSignalDataInvalidValue has to be the same as ComSignalLength.		

Name	ComSignalEndianness [ECUC_Com_00157]			
Description	Defines the endianness of the signal's network representation.			
Multiplicity	1			
Туре	EcucEnumerationParamDef	EcucEnumerationParamDef		
Range	BIG_ENDIAN			
	LITTLE_ENDIAN			
	OPAQUE	OPAQUE		
Post-Build Variant	true			
Value				
Value Configuration	Pre-compile time	X	VARIANT-PRE-COMPILE	
Class				
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			



Name	ComSignalInitValue [ECUC	Com	00170]	
Description	Initial value for this signal. In case of UINT8_N the default value is a string of length ComSignalLength with all bytes set to 0x00. In case of UINT8_DYN the initial size shall be 0.			
	In case the ComSignalType is UINT8, UINT16, UINT32, UINT64, SINT8, SINT16, SINT32, SINT64 the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification. In case the ComSignalType is FLOAT32, FLOAT64 the string shall be interpreted as defined in the chapter Float Type in the AUTOSAR EcuC specification. In case the ComSignalType is BOOLEAN the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification. In case the ComSignal is a UINT8_N, UINT8_DYN the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8_DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal.			
Multiplicity	01			
Туре	EcucStringParamDef			
Default Value	0			
Regular Expression				
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME			
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local dependency: In case of UINT8_N the length of ComSignalInitValue has to be the same as ComSignalLength.			

Name	ComSignalLength [ECUC_Com_00437]		
Description	Description: For ComSignalType UINT8_N this parameter specifies the length n in bytes. For ComSignalType UINT8_DYN it specifies the maximum length in bytes. For all other types this parameter shall be ignored. Range: 08 for normal CAN/ LIN I-PDUs, 064 for CAN FD I-PDUs, 0254 for normal FlexRay I-PDUs (all of ComIPduType NORMAL), 04294967295 for I-PDUs with ComIPduType TP.		
Multiplicity	01		
Туре	EcucIntegerParamDef		
Range	0 4294967295		
Default Value	·		



Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	_	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME,
			VARIANT-POST-BUILD
	Post-build time	_	
Scope / Dependency	scope: local		

Name	ComSignalType [ECUC_Cor	n_00	127]	
Description	The AUTOSAR type of the signal. Whether or not the signal is signed or unsigned can be found by examining the value of this attribute. This type could also be used to reserved appropriate storage in AUTOSAR COM.			
Multiplicity	1			
Туре	EcucEnumerationParamDef			
Range	BOOLEAN			
	FLOAT32			
	FLOAT64			
	SINT16			
	SINT32			
	SINT64			
	SINT8			
	UINT16			
	UINT32			
	UINT64			
	UINT8			
	UINT8_DYN			
	UINT8_N			
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME, VARIANT-POST-BUILD	
	Post-build time	_		
Scope / Dependency	scope: local			



Name	ComTimeoutSubstitutionValue [ECUC_Com_10006]				
Description	The signal substitution value will be used in case of a timeout and ComRxDataTimeoutAction is set to SUBSTITUTE. In case of UINT8_N the default value is a string of length ComSignalLength with all bytes set to 0x00.				
	In case ofUINT8_DYN the initial size shall be 0.				
	In case the ComSignalType is UINT8, UINT16, UINT32, UINT64, SINT8, SINT16, SINT32, SINT64 the string shall be interpreted as defined in the chapter Integer Type in the AUTOSAR EcuC specification.				
			OAT32, FLOAT64 the string shall be oter Float Type in the AUTOSAR EcuC		
	In case the ComSignalType is BOOLEAN the string shall be interpreted as defined in the chapter Boolean Type in the AUTOSAR EcuC specification.				
	In case the ComSignal is a UINT8_N, UINT8_DYN the string shall be interpreted as a decimal representation of the characters separated by blanks, e.g. "97 98 100" means a string "abd", where the char "a" is in byte 0(lowest address), "b" is in byte 1, and "d" is in byte 2 and (highest address). For the ComSignalType UINT8_DYN the dynamic length shall be set to the number of configured characters. An empty string "" shall be interpreted as 0-sized dynamic signal.				
Multiplicity	01				
Туре	EcucStringParamDef				
Default Value					
Regular Expression					
Post-Build Variant Multiplicity	true				
Post-Build Variant Value	true				
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	Х	VARIANT-LINK-TIME		
	Post-build time	Х	VARIANT-POST-BUILD		
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE		
	Link time	Х	VARIANT-LINK-TIME		
	Post-build time	Х	VARIANT-POST-BUILD		
Scope / Dependency	scope: local				



Name	ComTransferProperty [ECUC_Com_00560]			
Description	Optionally defines whether this group signal shall contribute to the TRIGGERED_ON_CHANGE transfer property of the signal group. If at least one group signal of a signal group has the "ComTransferProperty" configured all other group signals of that signal group shall have the attribute configured as well.			
Multiplicity	01			
Туре	EcucEnumerationParamDef			
Range	PENDING A change of the value of this group signal shall not be considered in the evaluation of the signal groups ComTransferProperty.			
	TRIGGERED_ON_CHAN GE			
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

Name	ComSystemTemplateSystemSignalRef [ECUC_Com_00002]			
Description	Reference to the ISignalToIPduMapping that contains a reference to the ISignal (System Template) which this ComSignal (or ComGroupSignal) represents.			
Multiplicity	01			
Туре	Foreign reference to I-SIGN	AL-T	O-I-PDU-MAPPING	
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE	
	Link time X VARIANT-LINK-TIME			
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: ECU			



Included Containers		
Container Name	Multiplicity	Scope / Dependency
ComFilter	01	This container contains the configuration parameters of the AUTOSAR COM module's Filters.
		Note: On sender side the container is used to specify the transmission mode conditions.

SWS Item	[ECUC_Com_00340]				
Container Name	ComlPdu	ComIPdu			
Description	Contains the configuration parameters of the AUTOSAR COM module's I-PDUs.				
Post-Build Variant Multiplicity	true				
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE		
	Link time	X	VARIANT-LINK-TIME		
	Post-build time X VARIANT-POST-BUILD				
Configuration Parameters					

Name	ComIPduCallout [ECUC_Com_00387]			
Description	This parameter defines the existence and the name of a callout function for the corresponding I-PDU. If this parameter is omitted no I-PDU callout shall take place for the corresponding I-PDU.			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default Value				
Regular Expression				
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false	false		
Multiplicity Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local		·	



Name	ComIPduCancellationSupport [ECUC_Com_00709]			
Description	Defines for I-PDUs with ComIPduType NORMAL: If the underlying IF-modul supports cancellation of transmit requests. Defines for I-PDUs with ComIPduType TP: If the underlying TP-module supports RX and TX cancellation of ongoing requests.			
Multiplicity	01			
Туре	EcucBooleanParamDef			
Default Value	false			
Post-Build Variant Multiplicity	true			
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	_		
	Post-build time	X	VARIANT-POST-BUILD	
Value Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time –			
	Post-build time	X	VARIANT-POST-BUILD	
Scope / Dependency	scope: ECU dependency: This parameter shall not be set to true if ComCancellationSupport is set to false			

Name	ComIPduDirection [ECUC_Com_00493]			
Description	The direction defines if this I-PDU, and therefore the contributing signals and signal groups, shall be sent or received.			
Multiplicity	1	1		
Туре	EcucEnumerationParamDef	EcucEnumerationParamDef		
Range	RECEIVE			
	SEND	SEND		
Post-Build Variant Value	false			
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD	
	Post-build time	_		
Scope / Dependency	scope: local dependency: If configured to Sent also a ComTxlpdu container shall be included, see ECUC_Com_00496			



Name	ComlPduHandleId [ECUC_Com_00175]		
Description	The numerical value used as the ID of this I-PDU. The ComIPduHandleId is required by the API calls Com_RxIndication, Com_TpRxIndication, Com_StartOfReception and Com_CopyRxData to receive I-PDUs from the PduR (ComIP-duDirection: Receive), as well as the PduId passed to an Rx-I-PDU-callout. For Tx-I-PDUs (ComIPduDirection: Send), this handle Id is used for the APIs calls Com_TxConfirmation, Com_TriggerTransmit, Com_TriggerIPDUSend or Com_TriggerIPDUSendWithMetaData, Com_CopyTxData and Com_TpTxConfirmation to transmit respectively confirm transmissions of I-PDUs, as well as the PduId passed to the Tx-I-PDU-callout configured with ComIPduCallout and/or ComIPduTriggerTransmitCallout.		
Multiplicity	01		
Туре	EcucIntegerParamDef (Sym	bolic	Name generated for this parameter)
Range Default Value Post-Build Variant Multiplicity	0 65535 false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time Link time Post-build time	X	All Variants
Value Configuration Class	Pre-compile time Link time Post-build time	X 	All Variants
Scope / Dependency	scope: ECU		

Name	ComIPduSignalProcessing [ECUC_Com_00119]				
Description	For the definition of the two modes Immediate and Deferred.				
Multiplicity	1	1			
Туре	EcucEnumerationParamDe	ef			
Range	DEFERRED	signal indication / confirmations are deferred for example to a cyclic task			
	IMMEDIATE	the signal indications / confirmations are performed in Com_RxIndication/Com_TxConfirmation			
Post-Build Variant Value	true				
Value Configuration Class	Pre-compile time	X VARIANT-PRE-COMPILE			
	Link time	X VARIANT-LINK-TIME			
	Post-build time	X VARIANT-POST-BUILD			
Scope / Dependency	scope: local				



Name	ComIPduTriggerTransmitCallout [ECUC_Com_00765]			
Description	If there is a trigger transmit callout defined for this I-PDU this parameter contains the name of the callout function.			
Multiplicity	01			
Туре	EcucFunctionNameDef			
Default Value				
Regular Expression				
Post-Build Variant Multiplicity	false			
Post-Build Variant Value	false			
Multiplicity Configuration Class	Pre-compile time	Х	All Variants	
_	Link time	_		
	Post-build time	_		
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

Name	ComIPduType [ECUC_Com_00761]			
Description	Defines if this I-PDU is a normal I-PDU that can be sent unfragmented or if this is a large I-PDU that shall be sent via the Transport Protocol of the underlying bus.			
Multiplicity	1			
Туре	EcucEnumerationParamDef			
Range	NORMAL	sent or received via normal L-PDU		
	TP	ser	nt or received via TP	
Post-Build Variant Value	true			
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			

Name	ComIPduGroupRef [ECUC_Com_00206]			
Description	Reference to the I-PDU grou	Reference to the I-PDU groups this I-PDU belongs to.		
Multiplicity	0*			
Туре	Reference to ComlPduGrou	р		
Post-Build Variant	true	true		
Multiplicity				
Post-Build Variant	true	true		
Value				
Multiplicity	Pre-compile time	Х	VARIANT-PRE-COMPILE	
Configuration Class				
	Link time	Х	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	



Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	Х	VARIANT-LINK-TIME
	Post-build time	Х	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

Name	ComlPduSignalGroupRef [ECUC Com 00519]		
Description	References to all signal grou	ups c	ontained in this I-Pdu
Multiplicity	0*		
Туре	Reference to ComSignalGro	up	
Post-Build Variant	true		
Multiplicity			
Post-Build Variant	true		
Value			
Multiplicity	Pre-compile time	X	VARIANT-PRE-COMPILE
Configuration Class			
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Value Configuration	Pre-compile time	Х	VARIANT-PRE-COMPILE
Class			
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: local		

Name	ComIPduSignalRef [ECUC_Com_00518]			
Description	References to all signals contained in this I-PDU.			
Multiplicity	0*			
Туре	Reference to ComSignal			
Post-Build Variant Multiplicity	true	true		
Post-Build Variant Value	true			
Multiplicity Configuration Class	Pre-compile time X VARIANT-PRE-COMPILE			
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	Post-build time X VARIANT-POST-BUILD		
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME	
	Post-build time	Х	VARIANT-POST-BUILD	
Scope / Dependency	scope: local			





Name	ComPduIdRef [ECUC_Com_00711]			
Description	Reference to the "global" Pdu structure to allow harmonization of handle IDs in the COM-Stack.			
Multiplicity	1			
Туре	Reference to Pdu	Reference to Pdu		
	false			
Post-Build Variant Value				
Value Configuration Class	Pre-compile time	Х	VARIANT-PRE-COMPILE	
	Link time	X	VARIANT-LINK-TIME,	
	VARIANT-POST-BUILD			
	Post-build time	_		
Scope / Dependency				

Included Containers				
Container Name	Multiplicity	Scope / Dependency		
ComIPduCounter	01	This optional container contains the configuration parameters of PDU Counter.		
ComIPduReplication	01	This optional container contains the information needed for each I-PDU replicated.		
ComTxlPdu	01	This container contains additional transmission related configuration parameters of the AUTOSAR COM module's I-PDUs.		



C History of Constraints and Specification Items

C.1 Constraint History of this Document according to AUTOSAR R4.2.1

Initial document release.

- C.2 Constraint History of this Document according to AUTOSAR R4.2.2
- C.2.1 Added Traceables in 4.2.2

[SWS ComXf 00032]

C.2.2 Changed Traceables in 4.2.2

[SWS_ComXf_00028]

C.2.3 Deleted Traceables in 4.2.2

none

- C.3 Constraint History of this Document according to AUTOSAR R4.3.0
- C.3.1 Added Traceables in 4.3.0

[SWS_ComXf_00033] [SWS_ComXf_00034] [SWS_ComXf_00035]

C.3.2 Changed Traceables in 4.3.0

[SWS_ComXf_00001] [SWS_ComXf_00004] [SWS_ComXf_00006] [SWS_ComXf_00007] [SWS_ComXf_00008] [SWS_ComXf_00010] [SWS_ComXf_00011]





C.3.3 Deleted Traceables in 4.3.0

none