

ACME Widget Installation Guide

This guide describes the installation and initial configuration of the ACME Widget v3.2. Follow all steps in order. Read Section 4 before applying power. Contact support@acme.example if you encounter issues not covered here.

1. Prerequisites

Before beginning, ensure all of the following conditions are met:

- Power supply: 24 V DC, minimum 2 A.
- Mounting surface rated for 5 kg static load.
- Ambient temperature between 0 degC and 50 degC.
- Firmware package ACME-FW-3.2.tar.gz available on local filesystem.
- Network switch port with 100 Mbit/s or higher.

2. Installation Procedure

2.1 Mechanical Mounting

Attach the mounting bracket to the DIN rail using the four M4 bolts supplied. Torque each bolt to 2.5 Nm. Slide the Widget chassis onto the bracket until the locking tab engages. Apply grease (NLGI Grade 2) to all exposed bearing surfaces before securing the cover plate. See Section 4.2 for torque specifications.

2.2 Electrical Connections

Connect the 24 V DC supply to terminal block TB1. Polarity is marked on the chassis silkscreen. Do NOT reverse polarity; doing so will void the warranty and may damage internal protection circuitry. The earth bonding point (green/yellow lug) MUST be connected to the enclosure protective earth.

3. Component Specifications

Table 1 lists the key component specifications for the ACME Widget v3.2.

Component	Part No.	Tolerance	Unit	Rating
Bearing A	PN-2041	+/-0.05	mm	5 kN
Bearing B	PN-2042	+/-0.05	mm	8 kN
Shaft Seal	PN-3011	+/-0.02	mm	IP65
Drive Gear	PN-4017	+/-0.10	mm	50 Nm
Motor Ctrl	PN-5001	N/A	N/A	24 V DC

4. Revision History

Rev	Date	Change
v3.2	2025-08-01	Added Section 2.2 electrical notes.
v3.1	2025-03-15	Corrected torque value in 2.1.
v3.0	2024-11-01	Initial release of v3 platform.