# out of the BS A

### How to Tri-state CPLD Pins



## **Table of Contents**

Table of Contents	2
Procedure	
Step 1: Open or Create a Quartus Project	
Step 2: Locate the Device Assignment Menu	3
Step 3: Select Device and Pin Options	4
Step 4: Set Pins as Input Tri-stated	4



### **Procedure**


By default, Altera CPLDs set unused i/o pins to outputting GND. This is not ideal for many reasons. Therefore, it is desirable to set all unused pins as input tri-stated.

### Step 1: Open or Create a Quartus Project

Unused pin assignments can only take effect inside of a project.

# Step 2: Locate the Device Assignment Menu

How to locate the menu is shown below.





### Step 3: Select Device and Pin Options

From the device menu, and specifically the device tab, select the button "Device and Pin Options"

### Step 4: Set Pins as Input Tri-stated

Select the category "Unused Pins". Use the dropdown menu as shown below to select "As input tri-stated".



After completing the selection press "OK" in the "Device and Pin Options", followed by "OK" in the "Device" menu.

