

Philips TUV PL-L 55W/4P HF — lockout and replacement steps

1

All Off + Disarm

ALL OFF

DISARM

Verify both relay groups
and all 4 lamps OFF

2

Disconnect and lock out

LOCK

Isolate UVC electrical supply
Prove de-energized

3

Cool and wear PPE

UV-rated eye protection
+ clean gloves

4

Open guarded fixture

Support cover; note orientation

5

Remove by the base

Pull straight; never twist tubes

6

Inspect and match lamp

TUV PL-L 55W/4P HF
2G11 · 4 pins · clear
No cracks · pins straight

EXACT MATCH

7

Seat base and close

Align 4 pins; press base evenly
Refit guard and seals

8

Test group safely

Group pair operates
No flicker · guard closed
Log hours and location