AquaPure W300 Under-Sink Water Purifier - User Manual

Thank you for choosing the AquaPure W300, manufactured by Clearwater Appliances Ltd. This manual covers installation, daily use, filter maintenance, troubleshooting and warranty.

1. Technical Specifications

Model number: W300-EU (230 V) and W300-US (120 V).
Purification stages: 4 (sediment pre-filter, activated carbon block, reverse osmosis (RO) membrane, mineral post-filter).
Maximum flow rate: 2.5 litres per minute.
Storage tank capacity: 8 litres.
Rated power consumption: 45 W during filtration; under 1 W in standby.
Operating water pressure: 1.0 to 4.0 bar. Install a pressure-reducing valve if mains pressure exceeds 4.0 bar.
Operating water temperature: 5 to 38 degrees Celsius.
Dimensions: 42 cm x 18 cm x 38 cm. Weight: 9.6 kg (empty).
Waste water ratio: 1 litre of concentrate for every 2 litres of purified water.

2. Installation

The AquaPure W300 is designed to be installed under a kitchen sink by an adult with basic plumbing experience. Installation normally takes about 45 minutes.

Before you start, close the cold-water supply valve and disconnect the purifier from power. Connect the feed adapter to the cold-water line only; never connect the unit to a hot-water supply, because water above 38 degrees Celsius permanently damages the RO membrane.

Mount the faucet on the sink top using the supplied 12 mm drill guide. Connect the blue tube to the faucet, the white tube to the cold-water feed and the red tube to the drain saddle. Leave at least 10 cm of free space above the unit for filter changes.

After installation, flush the system for 15 minutes and discard the first full tank (8 litres) of water. This removes carbon fines and preservative from the new membrane.

3. Filter Replacement Schedule

Replace the filters on the following schedule, or sooner if the filter indicator light turns red:

Stage 1 - Sediment pre-filter (part AP-S1): every 6 months.
Stage 2 - Activated carbon block (part AP-C2): every 12 months.
Stage 3 - Reverse osmosis membrane (part AP-RO3): every 24 months.
Stage 4 - Mineral post-filter (part AP-M4): every 12 months.

To replace a filter, turn off the water supply, press the pressure-release button for 5 seconds, then twist the filter housing a quarter-turn anticlockwise. After fitting a new filter, hold the RESET button for 3 seconds until the indicator turns green.

Using non-genuine filters may reduce purification performance and voids the warranty on the RO membrane.

4. Troubleshooting and Error Codes

E1 - Low inlet pressure. Check that the supply valve is fully open. If pressure is below 1.0 bar, a booster pump (accessory AP-BP1) is required.
E2 - Leak detected. The unit stops automatically. Disconnect power, dry the leak sensor tray and check all tube connections before restarting.
E3 - Filter life expired. Replace the filter whose indicator is red, then reset.
E4 - Tank over-temperature. The water in the tank is above 38 degrees Celsius. Move the unit away from heat sources such as dishwashers.

If the purified water tastes salty, the RO membrane may be damaged and should be replaced. For any other problem, contact Clearwater support at the number on the product label.

5. Warranty

Clearwater Appliances Ltd warrants the AquaPure W300 against defects in materials and workmanship for 2 years from the date of purchase. The stainless-steel storage tank is covered for 5 years. Replacement filters are consumables and are not covered by the warranty.

The warranty does not cover damage caused by connecting the unit to hot water, by freezing, by installation that does not follow this manual, or by using non-genuine filters. To make a claim, keep your proof of purchase and register the product within 30 days of purchase at the Clearwater website.

Registered owners can buy an extended warranty plan that adds 3 more years of cover for the electronic control board. The extended plan must be purchased within the first 12 months of ownership.