

GCC Lab المختبر الفليبي	Gulf Laboratory Technical Services
	Operational Procedure of DPF Megger OTD LG2 – P3

Equipment Number: EQ-26

Serial Number: 102279484



1. PURPOSE

This standard operating procedure is intended to provide users with the guide on the operation and maintenance of Megger OTD LG2 – P3.

2. RESPONSIBILITIES

- Use, care and maintenance of the Megger OTG LG2-P3 is directly assigned to the end user who is usually the laboratory chemist. This responsibility may be shared to other qualified user(s) upon the consent of the laboratory chemist.

3. TEST AN OIL SAMPLE

3.1 Install the Test Cell

1. The Test Cell must be filled with the oil to be tested. Either fill the Test Cell while it is on its stand or when it has been put in the Test Chamber.
 - Pour the oil to be tested into the glass funnel.
 - When the oil shows in the sight glass the Test Cell has the required amount of oil for test
2. Put the Test Cell in the Test Chamber.
3. Take care not to knock the Test Cell against the Test Chamber.
4. Install the probe. Push down until it clicks in place.

Note: The glass funnel and sight glass are fragile. Take care not to damage them when the Test Cell is put in or removed from the Test Chamber.

Doc.: EOP [6]-04-A	Version No.00	Issue Date: 1/11/2023	Revision No: 00	Date:1/11/2023
Prepared by: Quality Manager	Reviewed by: Technical Manager	Approved by: General Manager	Page 1 of 3	

GCC Lab المختبر الفليبي	Gulf Laboratory Technical Services
	Operational Procedure of DPF Megger OTD LG2 – P3

3.2 Oil Test

Caution: The instrument must not be moved once a Test Cell has been put into the Test Chamber. Any movement could damage the Test Cell glass components.

1. Before an oil test is started make sure that:
 - The Instrument has been set-up as required.
 - The instrument has completely warmed up To Test an Oil
2. Set the instrument to On.
3. Check that the oil drain valve is closed (LED off).
4. Make sure a Test Cell, with the oil to be tested, is correctly installed in the Test Chamber.
5. Go to the Home Screen
6. Select a Test Standard (if required, modify a Standard)
7. Enter a Test ID
8. Select a Test Cell
9. Make sure that the instrument has completely warmed up.
10. Press TEST.
11. Follow the instructions on the display.

3.3 Oil Drain

- Auto drain on: The Oil Drain Valve automatically opens after a test and closes automatically after 120 seconds (if required, press the Oil Drain button to close sooner)
- Auto drain Off: Use the Oil Drain button to open (green LED on) and close the Oil Drain Valve (prompted on the display)

4. MAINTENANCE

4.1 General

- The Instrument is not User serviceable.
- Before use make sure that the Instrument lid is not cracked or distorted.
- The only internal part of the Instrument that is accessible to the User is the printer paper housing, which gives access to install new printer paper and ribbon when required.
- It is strictly forbidden to open the Instrument. If opened it constitutes a breach of warranty.

4.2 Calibration

- The Instrument is calibrated in the factory before delivery and there is no need to calibrate the instrument on first set-up.

Doc.: EOP [6]-04-A	Version No.00	Issue Date: 1/11/2023	Revision No: 00	Date:1/11/2023
Prepared by: Quality Manager	Reviewed by: Technical Manager	Approved by: General Manager	Page 2 of 3	

GCC Lab المفتبر الفليبي	Gulf Laboratory Technical Services
	Operational Procedure of DPF Megger OTD LG2 – P3

- An Instrument Calibration Checker (OTD CC) is available, which can be used to check the Instrument calibration as and when required. Periodic checks with the OTD CC are recommended.
- A Test Cell must be calibrated after it has been cleaned.

REFERENCES

User Guide (OTD Oil Tan Delta)

Doc.: EOP [6]-04-A	Version No.00	Issue Date: 1/11/2023	Revision No: 00	Date:1/11/2023
Prepared by: Quality Manager	Reviewed by: Technical Manager	Approved by: General Manager	Page 3 of 3	