DisplayLink Drivers on Ubuntu

Installation

1. Start the ***installer*** with ***administrative privileges***:
   sudo ./displaylink-driver-x.x.x.xx.run

   Note: **X** = *driver file version.*

2. If ***apt update*** has already been called, a prompt to update the ***package list*** is

```
dl_test_user@dladmin-Dell-Precision-M3800:~$ sudo ./displaylink-driver-5.3.0.27.
run
Verifying archive integrity...  100%   All good.
Uncompressing DisplayLink Linux Driver 5.3.0.27  100%
DisplayLink Linux Software 5.3.0.27 install script called:
Distribution discovered: Ubuntu 20.04 LTS
[ Installing dependencies ]
Need to update package list.
apt update? [Y/n]
```

7.

--or--

Proceed to ***package installation*** by pressing **ENTER**.

```
dl_test_user@dladmin-Dell-Precision-M3800:~$ sudo ./displaylink-driver-5.3.0.27.
run
Verifying archive integrity...  100%   All good.
Uncompressing DisplayLink Linux Driver 5.3.0.27  100%
DisplayLink Linux Software 5.3.0.27 install script called:
Distribution discovered: Ubuntu 20.04 LTS
[ Installing dependencies ]

WARNING: apt does not have a stable CLI interface. Use with caution in scripts.

Reading package lists...
Building dependency tree...
Reading state information...
Suggested packages:
  menu
The following NEW packages will be installed:
  dkms libdrm-dev
0 upgraded, 2 newly installed, 0 to remove and 15 not upgraded.
Do you want to continue? [Y/n]
```

Packages required for the ***DisplayLink Driver:***

- ***dkms***
  - Enable loading of ***EVDI module***
- ***libdrm-dev***
  - Required due to ***libevdi*** being shipped as ***source code*** and ***build*** during the installation

Warnings

- The ***file permission*** may need to be changed before the ***driver installation***. To change the ***file permission***, enter the following:

chmod +x displaylink-driver-x.x.x.xx.run

Note: **X** = *driver file version.*

- The installation process will stop if permissions to install ***dkms*** and ***libdrm-dev*** are not granted. Should this occur, ***restart the installation process*** and wait for ***dkms*** and ***libdrm-dev*** to install before proceeding to the next step.

--or--

Install ***dkms*** and ***libdrm-dev*** manually by entering the following:

sudo apt update

sudo apt install dkms

sudo apt install libdrm-dev

- If ***Xorg session*** is currently active, disconnect the **Docking Station** before proceeding with the installation. Failure to do so will result in an incomplete installation accompanied by the following messages:

```
dl_test_user@dladmin-Dell-Precision-M3800:~$ sudo ./displaylink-driver-5.3.0.27.
run
Verifying archive integrity...  100%   All good.
Uncompressing DisplayLink Linux Driver 5.3.0.27  100%
DisplayLink Linux Software 5.3.0.27 install script called:
Distribution discovered: Ubuntu 20.04 LTS
Detected running Xorg session and connected docking station
Please disconnect the dock before continuing
Installation terminated.
dl_test_user@dladmin-Dell-Precision-M3800:~$
```

- If ***Xorg session*** is currently active, a ***restart*** is required to complete the installation. ***Restart*** when prompted by the following message:

```
Installation complete!

Please reboot your computer if intending to use Xorg.
Xorg is running. Do you want to reboot now? (Y/n)
```

Notes: *Press* **ENTER** *after entering* **Y**.

Do not connect the ***Docking Station*** *until the reboot has completed. Failure to do so may cause a failure/freeze of* ***Xserver****.*