

SAFETY

Read this manual before operating the machine.

OPERATION

HYDRAULIC OIL FILTER CLOGGING CAUTION LAMP

The caution lamp warns that the hydraulic oil filter is clogged.

MAINTENANCE

METHOD FOR REPLACING HYDRAULIC OIL FILTER ELEMENT

Stop the engine and replace the element.

Track tension adjustment

Check track tension every 250 hours.