Supply voltage



5V external from 5V Nucleo (USB)

Temperature and humid sensor



Display 4x10 characters



Gest detector



Accelerometer



Nucleo-L476RG
ST morpho connector



Communication

BT-module



FTDI serie PC



Jumpers to connect HC-06 to MCU or external PC FTDI

RTC calibrate out



Analog input from potentiometer



Title Sensorkort HT19 STM32L476 Nucleo-64 Inbyggda system		
Size	Number	Rev 1.0
Date 2019-04-26		Drawn by BM
Sensor_HT19.dch		