# 综合性课程设计 1: MIPS 汇编器设计

### 要求:

用算法语言(C或C++)设计 MIPS 汇编与反汇编器工具,支持 MIPS 指令子集(附件)。支持不小于 10K 指令的汇编容量。最终提交必须把所有动态链接编译进去(静态连接),可独立执行程序和源代码及工程。

### 基本功能:

#### 汇编:

- **1.** 支持附录 A.10(第 3 版)或附录子集所有整数指令和伪指令。生成 2 进制目标文件.bin 和.coe 格式文件:
  - 2. 汇编指令以";"为结束符,"//"和"#"为注释符;
  - 3. 寄存器符号支持 RO~R31(大小写均可)和 MIPS 使用约定(第 3 版图 2-18)

**反汇编:** 支持附录 A.10(第 3 版)所有整数指令或附录子集。支持.bin 和.coe 文件加载。

### 文件操作功能: 能加载保存 ASM、bin 和. coe 文件

File: 新建(N) Ctrl+N

打开(O) Ctrl+O→ (3 个子项: ASM、bin 和 coe)

保存(S) Ctrl+S

保存为(A) Ctrl+Shift+S→ (3 个子项: ASM、bin 和 coe)

打印(P) Ctrl+P(洗做)

Exit(X)

#### 以上为必做内容

### 扩展功能(选做): 编辑: 可以编辑文本和 2、16 进制

模拟器功能

**调试(Debug):** 支持单步执行、单步(跳过,不进入函数)、运行到。 内存 1MB, 支持运行结果显示格式如下:

寄存器: IP=12345678;

 R0(\$zero) = 00000000;
 R1(\$at) = 12345678;
 ......
 R7 (\$a3) = 12345678

 R8 (\$t0) = 00000000;
 R9 (\$t1) = 12345678;
 R15 (\$t7) = 12345678


 R16(\$s0) = 00000000;
 R17(\$s0)=12345678;
 R23 (\$7) = 12345678

 R24(\$t8) = 000000000;
 R25(\$t9)=12345678;
 R31(\$ra)=12345678

 内存

00000000: 12345678 12

窗口参考格式:



### 菜单

File: 新建(N) Ctrl+N

打开(O) Ctrl+O 保存(S) Ctrl+S

保存为(A) Ctrl+Shift+S

打印(P) Ctrl+P

Exit(X)

Edit: 撒消(U) Ctrl+Z

剪切(T) Ctrl+X

复制(C) Ctrl+C

粘贴(P) Ctrl+V

删除(L) Del

查找(F) Ctrl+F

替换(R)... Ctrl+H

转到(G) Ctrl+G

全选(A) Ctrl+A

Bulid: 汇编(Asm)

Coe

反汇编

Debug: 单步(Step)

单步(跳过 Jal)

运行到…

停止

### 汇编器的一些补充说明(参考后面的例子):

汇编器语法参考附录 A.10.2,并增加下列伪指令:

1. 指定代码起始地址: BaseAddre

BaseAddre: 00008c00;

//用","分隔,";"结束。可以多个定义,但后继地址 //必须大于前面定义的地址。中间不确定区域填"0"

.....;

2. 指定数据起始地址: DataAddre

DataAddre: 00008d00; //用","分隔,";"结束。可以多个定义,但后继

地址

DB: 0x12, 0x34, ……; //必须大于前面定义的地址。中间不确定区域填"0"

DW: 0x1234, 0x4567, .....;

二个地址申明之间的空余处填"0000000",后继申明地址必须大于"前次申明地址+已使用空间",否则结出错误指示。代码空间超出范围也结出错误指示

3. 初始化数据伪指令

关键字后定义指定,每个数据由逗号分隔:

DB: 定义字节数据 例: DB 0x12, 0x34, ······;

DW: 定义 16 位字数据 例: DW 0x1234, 0x4567, ······;

DD: 定义 32 位字数据 DD 0x12345678, 0x87654321, ······;

参数定义:

EQU: 定义常量 例: X EQU 12; //定义 X 为常数 12

4. 所有标号包括数据区基地址都支持伪指令: la rdest, label\_address

以上为必须

声明未初始化的数据(定义数据空间):

RESB: 定义字节空间

L1: RESB 16; //定义 16 个字节空间, L1 是标号

RESW: 定义 16 位字空间

L2: RESW 16; //定义 16 个 16 位字空间, L2 是标号

RESD: 定义 32 位字节空间

L3: RESD 16 //定义 16 个 32 位字空间,L3 是标号

数据定义例子, 逗号隔离(默认为 16 进制):

db 0x55; //ust the byte 0x55

db 0x55,0x56,0x57; // three bytes in succession db 'a',0x55; //character constants are OK

db 'hello',13,10,'\$'; // so are string constants

dw 0x1234; // 0x34 0x12

 dw 'a';
 // 0x41 0x00 (it's just a number)

 dw 'ab';
 //0x41 0x42 (character constant)

 dw 'abc';
 //0x41 0x42 0x43 0x00 (string)

dd 0x12345678; //0x78 0x56 0x34 0x12

定义空间的例子:

buffer: resb 64; // reserve 64 bytes, buffer 是标号 wordvar: resw 1; // reserve a word, wordvar 是标号

## 例,代码和数据,以字地址计算:

```
#baseAddr 0000
        start;
                                 //0
                                 //4
    add $zero, $zero, $zero;
    add $zero, $zero, $zero;
                                 //8
    add $zero, $zero, $zero;
                                 //C
    add $zero, $zero, $zero;
                                 //10
    add $zero, $zero, $zero;
                                 //14
    add $zero, $zero, $zero;
                                 //18
    add $zero, $zero, $zero;
                                 //1C
                                 //标号,可以不换行,后面直接跟代码
start:
                                 //r1=FFFFFFF
    nor $at, $zero, $zero;
    add $v1, $at, $at;
                                 //r3=FFFFFFE
    add $v1, $v1, $v1;
                                 //r3=FFFFFFC
    add $v1, $v1, $v1;
                                 //r3=FFFFFF8
    add $v1, $v1, $v1;
                                 //r3=FFFFFF0
    add $v1, $v1, $v1;
                                 //r3=FFFFFE0
    add $v1, $v1, $v1;
                                 //r3=FFFFFC0
    nor $s4, $v1, $zero;
                                 //r20=0000003F
    add $v1, $v1, $v1;
                                 //r3=FFFFF80
    add $v1, $v1, $v1;
                                 //r3=FFFFF00
    add $v1, $v1, $v1;
                                 //r3=FFFFE00
    add $v1, $v1, $v1;
                                 //r3=FFFFC00
    add $v1, $v1, $v1;
                                 //r3=FFFF800
    add $v1, $v1, $v1;
                                 //r3=FFFF000
    add $v1, $v1, $v1;
                                 //r3=FFFE000
    add $v1, $v1, $v1;
                                 //r3=FFFC000
    add $v1, $v1, $v1;
                                 //r3=FFFF8000
    add $v1, $v1, $v1;
                                 //r3=FFFF0000
    add $v1, $v1, $v1;
                                 //r3=FFFE0000
    add $v1, $v1, $v1;
                                 //r3=FFFC0000
    add $v1, $v1, $v1;
                                 //r3=FFF80000
    add $v1, $v1, $v1;
                                 //r3=FFF00000
    add $v1, $v1, $v1;
                                 //r3=FFE00000
    add $v1, $v1, $v1;
                                 //r3=FFC00000
```

```
add $v1, $v1, $v1;
                              //r3=FF800000
   add $v1, $v1, $v1;
                              //r3=FF000000
   add $v1, $v1, $v1;
                              //r3=FE000000
   add $v1, $v1, $v1;
                              //r3=FC000000
   add $a2, $v1, $v1;
                              //r6=F8000000
   add $v1, $a2, $a2;
                              //r3=F0000000
   add $a0, $v1, $v1;
                              //r4=E0000000
   add $t5, $a0, $a0;
                              //r13=C0000000
   add $t0, $t5, $t5;
                              //r8=80000000
                              //标号,可以不换行,后面直接跟代码
loop:
                              //r2=00000001
   slt $v0, $zero,$at;
   add $t6, $v0, $v0;
   add $t6, $t6, $t6;
                              //r14=4
   nor $t2, $zero, $zero;
                              //r10=FFFFFFF
   add $t2, $t2, $t2;
                              //r10=FFFFFFE
loop1:
                              //计数器端口:F0000004, 送计数常数 r6=F8000000
   sw $a2, 4($v1);
   lw $a1, 0($v1);
   add $a1, $a1, $a1;
                              //左移
   add $a1, $a1, $a1;
   sw $a1, 0($v1);
   add $t1, $t1, $v0;
                              //r9=r9+1
   sw $t1, 0($a0);
                              //r9 送 r4=E0000000 七段码端口
   lw $t5, 14($zero);
                              //取存储器 20 单元预存数据至 r13,程序计数延时常数
                              //标号,可以不换行,后面直接跟代码
loop2:
   lw $a1, 0($v1);
                              //读 GPIO 端口 F0000000 状态
   add $a1, $a1, $a1;
   add $a1, $a1, $a1;
                              // 左移 2 位将 SW 与 LED 对齐,同时 D1D0 置 00,选择计数器
通道0
                              //r5 输出到 GPIO 端口 F0000000, 计数器通道
   sw $a1, 0($v1);
counter_set=00
   lw $a1, 0($v1);
                              //再读 GPIO 端口 F0000000 状态
   and $t3,$a1,$t0;
                              //取最高位=out0,屏蔽其余位送 r11
//
   beq
           $t3,$t0,C_init;
                              //out0=0,Counter 通道 0 溢出,转计数器初始化,修改 7 段码显
示:C_init
                              //程序计数延时
   add $t5, $t5, $v0;
```

```
//程序计数 r13=0,转计数器初始化,修改 7 段码显
   beq $t5, $zero,C_init;
示:C_init
I next:
                             // 判断 7 段码显示模式: SW[4:3]控制
   lw $a1, 0($v1);
                             //再读 GPIO 端口 F0000000 开关 SW 状态
   add $s2, $t6, $t6;
                             //r14=4,r18=00000008
   add $s6, $s2, $s2;
                             //r22=00000010
   add $s2, $s2, $s6;
                             //r18=00000018(00011000)
   and $t3, $a1, $s2;
                             //取 SW[4:3]
                             //SW[4:3]=00,7 段显示"点"循环移位: L20, SW0=0
   beq $t3, $zero, L20;
                             //SW[4:3]=11,显示七段图形,L21,SW0=0
   beq $t3, $s2, L21;
   add $s2, $t6, $t6;
                             //r18=8
   beq $t3, $s2, L22;
                             //SW[4:3]=01,七段显示预置数字,L22,SW0=1
                             //SW[4:3]=10,显示 r9,SW0=1
   sw $t1, 0($a0);
       loop2;
   j
L20:
   beq $t2, $at, L4;
                             //r10=fffffff,转移 L4
       L3;
L4:
   nor $t2, $zero, $zero;
                             //r10=ffffffff
   add $t2, $t2, $t2;
                             //r10=ffffffe
L3:
                             //SW[4:3]=00,7 段显示点移位后显示
   sw $t2, 0($a0);
   j
       loop2;
L21:
                             //SW[4:3]=11, 从内存取预存七段图形
   lw $t1, 60($s1);
   sw $t1, 0($a0);
                             //SW[4:3]=11,显示七段图形
       loop2;
   İ
L22:
   lw $t1, 20($s1);
                             //SW[4:3]=01,从内存取预存数字
   sw $t1, 0($a0);
                             //SW[4:3]=01,七段显示预置数字
       loop2;
   İ
C init:
   lw $t5, 14($zero);
                             //取程序计数延时初始化常数
   add $t2, $t2, $t2;
                             //r10=ffffffc, 7 段图形点左移
                             //r10 末位置 1,对应右上角不显示
   or $t2, $t2, $v0;
   add $s1, $s1, $t6;
                             //r17=00000004, LED 图形访存地址+4
   and $s1, $s1, $s4;
                             //r17=000000XX, 屏蔽地址高位, 只取 6 位
```

```
add $t1, $t1, $v0;
                             //r9+1
   beq $t1, $at, L6;
                             //若 r9=fffffff,重置 r9=5
   j L7;
L6:
   add $t1, $zero, $t6;
                             //r9=4
                             //重置 r9=5
   add $t1, $t1, $v0;
L7:
                             //读 GPIO 端口 F0000000 状态
   lw $a1, 0($v1);
   add $t3, $a1, $a1;
   add $t3, $t3, $t3;
                             // 左移 2 位将 SW 与 LED 对齐,同时 D1D0 置 00,选择计数器
通道0
   sw $t3, 0($v1);
                             //r5 输出到 GPIO 端口 F0000000, 计数器通道
counter_set=00
                             //计数器端口:F0000004, 送计数常数 r6=F8000000
   sw $a2,4($v1);
   j l_next;
```

### ···· //从此处-0000FFFC 填 "00000000"。

#DataAddre: 00001000; //数据地址,此处 00001000H 开始定义数据

Data1: //数据区 1,标号

dd FFFFF00, 000002AB, 80000000, 0000003F, 00000001, FFFF0000, 0000FFFF, 80000000, 00000000, 11111111, 22222222, 33333333, 44444444, 55555555, 66666666, 77777777, 88888888, 99999999, AAAAAAAA, BBBBBBBB, CCCCCCCC, DDDDDDDD, EEEEEEEE, FFFFFFFFF;

db 0x55,0x56,0x57,0x58; //db伪指令,定义数据0x55…在00001060 dw 'ab',0x1234; //dw伪指令,定义数据0x41,0x42,0x1234在

000010604

dd 0x12345678; //dd伪指令,定义数据0x12345678在00001068 data2:RESB16; //data2是标号,从0000106C开始定义16个字节空间

#### ····· //此处 00001070-00001FFC 填 "00000000"。

#DataAddre: 00002000; //数据地址,此处 00002000H 开始定义数据

Data2: //数据区 2,标号

557EF7E0, D7BDFBD9, D7DBFDB9, DFCFFCFB, DFCFBFFF, F7F3DFFF, FFFFDF3D, FFFF9DB9,

FFFFBCFB, DFCFFCFB, DFCFBFFF, D7DB9FFF, D7DBFDB9, D7BDFBD9, FFFF07E0, 007E0FFF,

03bdf020, 03def820, 08002300;

······ //此处从0000204C-0000BFFC填"00000000"。

#DataAddre: 0000C000; buffer:RESD32; 位字空间 //数据地址,此处0000C000H开始定义数据//数据区3,buffer标号=0000C000,定义32个32

//到 0000C080 结束

# MIPS 指令子集

本表根据 MIPS32 指令集和教材 Computer Organization and Design-The Hardware/Software Interface(第 3 版)附录 A10,选择了常用整数指令构成了 MIPS 指令子集。指令子集包括 CPO、异常处理等指令,可以支持简单的操作系统的运行。指令二进制编码以附录 A10 为标准。

# 1. Instruction format

# > Typical format of R type instruction

	•••					
Field	opcode	rs	rt	rd	shamt	func
Length	6	5	5	5	5	6

# > Typical format of I type instruction

Field	opcode	rs	rt	imme
Length	6	5	5	16

# Table 1 Typical format of J type instruction

Field	opcode	target
Length	6	26

# 2. Instruction Table:

No	类型	功能	汇编符	OPCODE/FUNCT	描述(Displ.=Displacement*)	
1		取字	lw	23H	GPR [rt] <= Mem[GPR[rs]+sign_ext(Displacement)]	
2		取字节	lb	20H	GPR [rt] <= {24{Mem[GPR[rs]+sign_ext(Displ.)][7]}, Mem[GPR[rs]+sign_ext(Displ.)][7:0]}	
3	访存/取	取字节	lbu	24H	GPR [rt] <={24'b0, Mem[GPR[rs]+ sign_ext(Displ.)][7:0]}	
4		取半字	lh	21H	R[rt] <= {16{Mem[GPR[rs]+sign_ext(Displ.)][15]}, Mem[GPR[rs]+sign_ext(Displ.)][15:0]}	
5		取半字	lhu	25H	R[rt] <= {16'b0, Mem[GPR[rs] + sign_ext(Displ.)][15:0]]	
6		存字	sw	2BH	Mem[GPR[rs]+sign_ext(Displacement)] <= R[rt]	
7	访存/存	存字节	sb	28H	Mem[GPR[rs]+sign_ext(Displ.)][7:0] <= R[rt][7:0]	
8		存半字	sh	29H	Mem[GPR[rs]+sign_ext(Displ.)][15:0] <= R[rt][15:0]	
9		加	add	0/20H	GPR[rd] <= GPR[rs] + GPR[rt]	
10		无符号加	addu	0/21H	GPR[rd] <= GPR[rs] + GPR[rt]	
11		减	sub	0/22H	GPR[rd] <= GPR[rs] - GPR[rt]	
12		无符号减	subu	0/23H	GPR[rd] <= GPR[rs] - GPR[rt]	
13		小于置 1	slt	0/2AH	GPR[rd] <= (GPR[rs] < GPR[rt]) ? 1:0	
14	ALU-R	小于置 1	sltu	0/2BH	GPR[rd] <= (GPR[rs] < GPR[rt]) ? 1:0	
15	ALU-K	坷	and	0/24H	GPR[rd] <= GPR[rs] & GPR[rt	
16		或	or	0/25H	GPR[rd] <= GPR[rs]   GPR[rt]	
17	异或       xor         或非       nor         逻辑左移       sll         逻辑右移       srl		xor	0/26H	GPR[rd] <= GPR[rs] ^ GPR[rt]	
18			nor	0/27	GPR[rd] <= ~(GPR[rs]   GPR[rt])	
19			sll	0/0H	GPR[rd] <= GPR[rt] << sa,符号不变	
20			0/2H	GPR[rd]<= GPR[rt] >> sa,符号不变		

21		算术右移	sra	0/3H	GPR[rd]<= GPR[rt] << sa	
22		乘	mult	0/3H	$\{HI, LO\} \leftarrow GPR[rs] \times GPR[rt]$	
23				0/19H	$\{HI, LO\} \leftarrow GPR[rs] \times GPR[rt]$	
24	乘除-R*	除	multu div	0/1A	{HI, LO} <= GPR[rs] / GPR[rt]	
25	无符号隊		divu	0/1BH	{HI, LO} <= GPR[rs] / GPR[rt]	
26		加立即数	addi	8H	GPR[rt] <= GPR[rs] + SignExt(Imm)	
27		无符加立	addiu	9Н	GPR[rt] <= GPR[rs] + SignExt(Imm)	
28		与立即数	andi	СН	GPR[rt] <= GPR[rs] & ZeroExt(Imm)	
29		或立即数	ori	DH	GPR[rt] <= GPR[rs]   ZeroExt(Imm)	
30	ALU-I	异或常数	xori	EH	GPR[rt] <= GPR[rs] ^ ZeroExt(Imm)	
31		高位取常	lui	FH	GPR[rt] <= {imm, 16'b0}	
32		小于置 1	slti	AH	GPR[rt] <= (GPR[rs] < SignExt(Imm)) ? 1 : 0	
33		小于置 1 无符号	sltiu	ВН	GPR[rt] <= (GPR[rs] < SignExt(Imm)) ? 1:0	
34		相等转移	beq	4H	if (GPR[rs] == GPR[rt]) PC <= PC + 4 + Branch offset	
35		不等转移	bne	5H	if (GPR[rs] != GPR[rt]) PC <= PC + 4 + Branch offset	
36	分支	<=0 转移	blez	6H	if (GPR[rs] <= 0) PC <= PC + 4 + Branch offset	
37	刀又	>0 转移	bgtz	7H	if (GPR[rs] > 0) PC <= PC + 4 + Branch offset	
38		<0 转移	bltz	01/*	if (GPR[rs] <0) PC <= PC + 4 + Branch offset	
39		>=0 转移	bgez	01/*	if (GPR[rs] >= 0) PC <= PC + 4 + Branch offset	
40		无条件		2H	PC <= JumpAddr	
41	<b>转移</b> 直接调用		jal	3Н	PC <= JumpAddr; GPR[ra] <= PC + 4	
42	73/12	间址调用	jalr	0/9H	PC <= GPR[rs]; GPR[rd] <= PC + 4	
43		间址转移	jr	0/8H	PC <= GPR[rs]	
44		读HI	mfhi	0/10H	GPR[rd] <= HI	
45	传输*	读 LO	mflo	0/12H	GPR[rd] <= LO	
46	1 < 1110 .	写HI	mthi	0/11H	HI <= GPR[rs]	
47		写 LO	mtlo	0/13H	LO <= GPR[rs	
48	d+ l→	异常返回	eret	10/18H	PC <= EPC; (IR25==1, CP0 的 Cause 和 Status 寄存器有变化)	
49	特权	读 CP0	mfco	10H/*	GPR[rt] <= CP0[rd]	
50	写 CP0		mtco	10H/*		
51	陷阱	断点异常	break 0/DH		EPC <= PC+4; PC <= 异常处理地址; (CP0 的 Cause 和 Status 寄存器有变化)	
52	P'의 P'JT	系统调用		0/CH	EPC = PC+4; PC <= 异常处理地址; (CPO 的 Cause 和 Status 寄存器有变化)	
53		取地址	la rdest, address move rdest,rsrc		将地址值(而不是地址中的内容)保存到寄存器 rdest, rdest 是通用寄存器。(Rdest — & Table, Table 是标号)	
54	伪指令	传输指令			Rdest 和 rsrc 是通用寄存器	
55	N44H /	取立即数 li rdest,imm		, imm	Rdest 是通用寄存器	
		清寄存器				

注:\*Displacement 和 Offset 均为 16 立即数 Immediate(Imm),应根据需要按符号位扩展或逻辑扩展。用于数据存储器偏移量(相对指针)时用 Displacement(Displ)表示,用于指令偏移(相对转移)时用 Offset 表示,需要除 4 转换为字地址。

①BLTZ: IR31..26/IR20..16=01/00H

②BGEZ: IR31..26/IR20..16=01/01H ③MFCO: IR31..26/IR25..21=10/00H ④MTCO: IR31..26/IR25..21=10/04H

# 3. Instruction description(历史版本)

# **R-Type**

# add

Format: add rd, rs, rt

**Description:**  $GPR[rd] \leftarrow GPR[rs] + GPR[rt]$ 

**Exceptions:** 

**Integer Overflow** 

### addu

Format: addu rd, rs, rt

**Description:**  $GPR[rd] \leftarrow GPR[rs] + GPR[rt]$ 

**Exceptions:** 

None

### sub

Format: sub rd, rs, rt

**Description:**  $GPR[rd] \leftarrow GPR[rs] - GPR[rt]$ 

**Exceptions:** 

Integer Overflow

#### subu

Format: subu rd, rs, rt

**Description:**  $GPR[rd] \leftarrow GPR[rs] - GPR[rt]$ 

**Exceptions:** 

None

### and

Format: and rd, rs, rt

**Description:** GPR[rd] ← GPR[rs] AND GPR[rt]

or

Format: or rd, rs, rt

**Description:**  $GPR[rd] \leftarrow GPR[rs] OR GPR[rt]$ 

xor

Format: xor rd, rs, rt

**Description:** GPR[rd] ← GPR[rs] XOR GPR[rt]

nor

Format: nor rd, rs, rt

**Description:** GPR[rd] ← GPR[rs] NOR GPR[rt]

sII

Format: sll rd, rt, sa

**Description:**  $GPR[rd] \leftarrow GPR[rt] << sa$  (logical)

Shift word Left Logical

srl

Format: srl rd, rt, sa

**Description:**  $GPR[rd] \leftarrow GPR[rt] >> sa$  (logical)

Shift word Right Logical

sra

Format: sra rd, rt, sa

**Description:**  $GPR[rd] \leftarrow GPR[rt] >> sa$  (arithmetic)

Shift word Right Arithmetic

sllv

Format: sllv rd, rt, rs

**Description:**  $GPR[rd] \leftarrow GPR[rt] << GPR[rs]$ 

Shift word Left Logical Variable

srlv

Format: srlv rd, rt, rs

**Description:**  $GPR[rd] \leftarrow GPR[rt] >> GPR[rs]$  (logical)

Shift word Right Logical Variable

srav

Format: srav rd, rt, rs

**Description:**  $GPR[rd] \leftarrow GPR[rt] >> GPR[rs]$  (arithmetic)

Shift word Right Arithmetic Variable

slt

Format: slt rd, rs, rt

**Description:**  $GPR[rd] \leftarrow (GPR[rs] < GPR[rt]) ? 1 : 0$ 

Set on Less Than.

GPR rs and GPR rt are treated as signed integers.

sltu

Format: sltu rd, rs, rt

**Description:**  $GPR[rd] \leftarrow (GPR[rs] < GPR[rt]) ? 1 : 0$ 

Set on Less Than Unsigned.

GPR rs and GPR rt are treated as unsigned integers.

jr

Format: jr rs

**Description:**  $PC \leftarrow GPR[rs]$ 

Jump Register.

Jump to the effective target address stored in GPR rs.

### jalr

Format: jalr rs (rd = 31 implied)

**Description:**  $GPR[rd] \leftarrow return\_addr$ ,  $PC \leftarrow GPR[rs]$ 

Jump and Link Register.

### syscall

Format: syscall

**Description:** To cause a system call exception

System Call.

A system call exception occurs, immediately and unconditionally transferring control to the exception handler.

# > Type

### addi

Format: addi rt, rs, imme

**Description:**  $GPR[rt] \leftarrow GPR[rs] + imme$ 

The 16-bit immediate is signed.

# **Exceptions:**

**Integer Overflow** 

#### addiu

Format: addiu rt, rs, imme

**Description:**  $GPR[rt] \leftarrow GPR[rs] + imme$ 

The 16-bit immediate is signed.

# **Exceptions:**

None

#### ori

Format: ori rt, rs, imme

**Description:**  $GPR[rt] \leftarrow GPR[rs] OR imme$ 

The 16-bit immediate is zero-extended.

#### andi

Format: andi rt, rs, imme

**Description:**  $GPR[rt] \leftarrow GPR[rs]$  AND imme

The 16-bit immediate is zero-extended.

#### xori

Format: xori rt, rs, imme

**Description:**  $GPR[rt] \leftarrow GPR[rs] XOR imme$ 

The 16-bit immediate is zero-extended.

#### lui

Format: lui rt, imme

**Description:** GPR[rt]  $\leftarrow$  imme | |  $0^{16}$ 

Load Upper Immediate.

The 16-bit immediate is shifted left 16 bits and concatenated with 16 bits of low-order zeros.

### slti

Format: slti rt, rs, imme

**Description:**  $GPR[rt] \leftarrow (GPR[rs] < imme) ? 1 : 0$ 

Set on Less Than Immediate.

The 16-bit immediate is signed.

#### sltiu

Format: sltiu rt, rs, imme

**Description:**  $GPR[rt] \leftarrow (GPR[rs] < imme) ? 1 : 0$ 

Set on Less Than Immediate. Unsigned

The sign-extended 16-bit immediate is treated as an unsigned integer.

#### lw

**Format:** lw rt, imme(rs)

**Description:** GPR[rt] ← memory[GPR[rs] + imme]

Load Word.

The 16-bit imme is signed.

lb

**Format:** lb rt, imme(rs)

**Description:** GPR[rt] ← memory[GPR[rs] + imme]

Load Byte.

The contents of the 8-bit byte at the memory location specified by the effective address are fetched, sign-extended, and placed in GPR rt. The 16-bit signed offset is added to the contents of GPR rs to form the effective address.

lbu

Format: Ibu rt, imme(rs)

**Description:** GPR[rt] ← memory[GPR[rs] + imme]

Load Byte Unsigned.

The contents of the 8-bit byte at the memory location specified by the effective address are fetched, zero-extended, and placed in GPR rt. The 16-bit signed offset is added to the contents of GPR rs to form the effective address.

lh

Format: Ih rt, imme(rs)

**Description:**  $GPR[rt] \leftarrow memory[GPR[rs] + imme]$ 

Load Halfword.

The contents of the 16-bit halfword at the memory location specified by the aligned effective address are fetched, sign-extended, and placed in GPR rt. The 16-bit signed offset is added to the contents of GPR rs to form the effective address.

lhu

Format: Ihu rt, imme(rs)

**Description:** GPR[rt] ← memory[GPR[rs] + imme]

Load Halfword.

The contents of the 16-bit halfword at the memory location specified by the aligned effective address are fetched, zero-extended, and placed in GPR rt. The 16-bit signed offset

is added to the contents of GPR rs to form the effective address.

sw

**Format:** sw rt, imme(rs)

**Description:** memory[GPR[rs] + imme]  $\leftarrow$  GPR[rt]

Store Word.

The least-significant 32-bit word of GPR rt is stored in memory at the location specified by the aligned effective address. The 16-bit signed offset is added to the contents of GPR rs to

form the effective address.

sh

Format: sh rt, imme(rs)

**Description:** memory[GPR[rs] + imme]  $\leftarrow$  GPR[rt]

Store Halfword.

The least-significant 16-bit halfword of GPR rt is stored in memory at the location specified by the aligned effective address. The 16-bit signed offset is added to the contents of GPR rs

to form the effective address.

sb

**Format:** sb rt, imme(rs)

**Description:** memory[GPR[rs] + imme]  $\leftarrow$  GPR[rt]

Store Byte.

The least-significant 8-bit byte of GPR rt is stored in memory at the location specified by the effective address. The 16-bit signed offset is added to the contents of GPR rs to form the

effective address.

beq

Format: beq rs, rt, imme

**Description:** if GPR[rs] == GPR[rt] then branch

Branch on Equal.

#### bne

Format: bne rs, rt, imme

**Description:** if GPR[rs] != GPR[rt] then branch

Branch on Not Equal.

### bgez

Format: bgez rs, imme

**Description:** if GPR[rs] >= 0 then branch

Branch on Great than or Equal to Zero.

### bgezal

Format: bgezal rs, imme

**Description:** if GPR[rs] >= 0 then procedure\_call

Branch on Great than or Equal to Zero And Link.

### bgtz

Format: bgtz rs, imme

**Description:** if GPR[rs] > 0 then branch

Branch on Great Than Zero

# blez

Format: blez rs, imme

**Description:** if GPR[rs] <= 0 then branch

Branch on Less than or Equal to Zero

# bltz

Format: bltz rs, imme

**Description:** if GPR[rs] < 0 then branch

Branch on Less Than Zero

#### bltzal

Format: bltzal rs, imme

**Description:** if GPR[rs] < 0 then procedure\_call

Branch on Less Than Zero And Link.

# > J-Type

j

Format: j target

### **Description:**

Jump.

This is a PC-region branch (not PC-relative); the effective target address is in the "current" 256 MB-aligned region.

The low 28 bits of the target address is the 26-bit target field shifted left 2 bits. The remaining upper 4 bits are the corresponding bits of the address of the instruction in the delay slot (not the branch itself).

Jump to the effective target address. Execute the instruction that follows the jump, in the branch delay slot, before executing the jump itself.

### jal

Format: jal target

### **Description:**

Jump And Link.

The same to j instruction except that the return address is placed in GPR 31.

# **Coprocessor 0 instructions**

#### mfc0

Format: mfc0 rt, rd, sel

**Description:**  $GPR[rt] \leftarrow CPR[0, rd, sel]$ 

Move From Coprocessor 0.

#### mtc0

Format: mtc0 rt, rd, sel

**Description:**  $CPR[0, rd, sel] \leftarrow GPR[rt]$ 

Move To Coprocessor 0.

# **Exception Scheme in QS-I CPU**

QS-I CPU has implemented some registers used in the handling of exception defined in MIPS architecture, though with some slight changes. Users can use instructions MFCO and MTCO to read or write these registers. Such as,

MFC0 \$t0, Cause

MTC0 \$t1, Cause

# **Coprocessor 0 registers**

Status (#12):

31 30 29 28 27 9 8 0

IE	Interrupt Mask	Reserved

Cause (#13):

31 30 29 28 27 9 8 7 6 2 1 0

BR	Interrupt Pending		EXC	

**IE**: Interrupt Enable. If this bit is clear, then all interrupts will be disabled.

**Interrupt Mask**: this part is 20 bits wide, respectively indicates whether the up to 20 external interrupts should be masked or not. This part will be "and" with the interrupt pending part of the Cause register, and the priority of the 20 external interrupts is handled by software.

**BR**: Branch. If the instruction executing in the pipeline is a branch, then the BR will be asserted when any exception happens.

**Interrupt Pending**: this field indicates the pending state of the up to 20 external interrupts. Note that whenever an interrupt is serviced by software, the pending bit of the interrupt pending filed should be cleared.

**EXC**: Exception Code. When any exception happens, the exception code will be written into the Cause(#13) system register. And software can use the information provided by Cause register to determine which ISR to invoke.

EPC(#14):

#### **Exception PC**

When any exception happens, the PC of the victim instruction will be written into the EPC register. And when leaving from the ISR, software needs to read from EPC and then goes back to the interrupted instruction.

# **Programming guide**

What exactly should software do whenever an exception occurs? The steps should be taken are listed below:

- 1. Note that when an exception starts, PC will jump to 0x4000000, which is the exception entrance. And software takes over the handling task from this point. First, the context of the CPU should be saved. Usually software should save all the registers and the stack.
- After properly saving the context, software needs to know what the cause is of the
  occurring exception. The EXC (exception code) part of the Cause register offers the
  information.
- 3. If the cause of the occurring exception is an external interrupt, then check the interrupt pending bits of Cause register, and probably there will be more than one external interrupt pending. If that is true, software takes hold the priority management of the pending external interrupts. Attention should be paid that after servicing an external interrupt, the pending bit of Cause register must be cleared. If the occurring exception is not an external interrupt, then it's internal. Like a clock tick timer interrupt, a system call, a range issue and so forth.
- 4. After finding out the cause of the occurring exception, the according ISR (Interrupt Service Routine) is called and the exception is handled.

5. Before leaving from an exception, software needs to know the original interrupted PC, which is offered by EPC register. And what is very important, the context needs to be restored properly before leaving.