


Apache License, version 2.0


https://github.com/atoomnetmarc/AVR-demo-board

Sheet: /Power/ File: Power.kicad_sch

Title: AT90S8535 demo board


Size: A4 Date: 2023-04-01 Rev: V1.0 KiCad E.D.A. 8.0.5 ld: 3/6








Open JP1 to disable auto reset.



Voltage monitor.

Only needed for devices without BOD like AT90S4434 or AT90S8535



Apache License, version 2.0


https://github.com/atoomnetmarc/AVR-demo-board

Sheet: /Programming & debug/ File: Programming debug.kicad_sch

Title: AT90S8535 demo board

 Size: A4
 Date: 2023-04-01
 Rev: V1.0

 KiCad E.D.A. 8.0.5
 Id: 4/6



Apache License, version 2.0 https://github.com/atoomnetmarc/AVR-demo-board Sheet: /10/ File: IO.kicad_sch Title: AT90S8535 demo board Size: A4 Date: 2023-04-01 Rev: V1.0 KiCad E.D.A. 8.0.5 ld: 5/6

