

Audio Products - Care and Troubleshooting Guide

Policy version 2026-01

1.1 Audio products - charging problems. If headphones or earbuds do not charge, clean the charging contacts, try another cable and charger, and leave them on charge for 30 minutes. If they still do not charge it is a charging fault.

1.2 Audio products - no sound in one side. If sound is missing on one side, reset the device and pair it again. If the fault remains it is a hardware fault.

2.1 Audio products - care. Keep audio products dry. Sweat and rain resistance does not mean the product can be put in water.