Opening or Vent Between Inside and Outside Compartments

Z = Layer Interface Height
H = Height of Sill or Soffit of Opening or Vent

 $h_{o,i}$  = Limits of Integration Associated with the Height of Individual Flow Areas (i.e.  $h_o$  x w) of Opening or Vent (Layer numbers refer to nomenclature used in text)