



GND

Two-pin headers go to panel toggle switches.
4-pin headers go to circuilar M8-4 panel connectors.