
## Block Diagram of ABlocks functional properties



ESP32



	B00+.89
2	71.79
3	fz. Py
Ч	Settings.ty



Boot Py

Se Hongs . Py

Wifi_status	0
Firmware_toggle	0
New_firmware	0
Other	0

New\_firmware:-

New\_firmware\_default value will 0 therefore After updates come it become 1 and (f1,f2) Accordingly filled with check Firmware\_toggle Then filled according to that buffer.

