Microlab® 600 RS-232 Communication Manual



Table of Contents

CHAPTER 1: General Overview	4
1.1 Microlab 600 Communication Ports	5
1.1.1 Ethernet Port	5
1.1.2 Serial RS-232 Port	5
1.1.3 CAN IN/OUT	6
1.1.4 Digital TTL IN/OUT Port	6
1.2 Daisy Chain Compatibility	6
1.2.1 Microlab 600 Units Only	6
1.2.2 Microlab 600 Units With Other RNO Protocol Devices	7
1.2.3 Required Cables For Daisy Chaining	7
CHAPTER 2: Communication via RS-232	8
2.1 Hamilton Protocol 1/RNO+ Overview	9
2.2 Data Transfer Format	10
2.3 Establishing Communication (Auto-addressing and Initializing)	10
2.4 Data String Components	12
CHAPTER 3: Protocol Command Summary	14
3.1 General Commands	15
3.1.1 Syringe Pump Selection Commands	15
3.1.2 Initialization Commands	15
3.1.3 Syringe Positioning Commands	17
3.1.4 Valve Positioning Commands	19
3.1.5 Timer Commands	21
3.1.6 Digital I/O Commands	22
3.1.7 Execution Commands	24
3.1.8 Instrument Control Commands	25
3.2 Parameter Change Commands	26
3.2.1 Syringe Parameter Change	26
3.2.2 Valve Parameter Change	28
3.2.3 Save and Erase Current Parameters	29

3.3 Status Request Commands	30
3.3.1 Instrument Information Requests	30
3.3.2 Instrument Status Request	32
3.3.3 Syringe Parameter Request	35
3.3.4 Valve Parameter Request	36
3.3.5 Timer Requests	37
3.3.6 Digital I/O Requests	37
3.3.7 Firmware Version Request	39
APPENDICES	40
Appendix A — Simple Program Examples	40
Appendix B — ASCII Chart	43

CHAPTER 1: GENERAL OVERVIEW

CHAPTER 1:

General Overview


The Microlab® 600 receives commands via three different communication methods. These methods are Ethernet, Serial RS-232 and Digital TTL. This manual provides detailed information on connecting and controlling a Microlab 600 or a daisy chain of Microlab 600 instruments using Hamilton's Protocol 1/RNO+. Protocol 1 is a serial communication language that sends ASCII commands to the Microlab 600 via the electrical standard RS-232C.

This chapter discusses the following topics:

- 1.1 Microlab 600 Communication Ports
- 1.2 Daisy Chain Compatibility

1.1 Microlab 600 Communication Ports

The diagram below shows the communication ports on the back of the Microlab 600 syringe pump. The pump receives inputs via RS-232C, Ethernet, CAN, and Digital TTL. With the exception of the Digital TTL port, once the instrument is connected to a communication port it ignores commands sent over the other ports. The instrument must be power cycled or reset to connect via a new port. Below is a description as to when each input port could be used.



* Before connecting the Ethernet (RJ-45) port to any device the Power over Ethernet (PoE) must be turned off to avoid damage to the connected device. This is achieved by starting with the instrument off. Press and hold the power button to turn the instrument on. After 3 seconds the Ready light will illuminate solid indicating the PoE is turned off.

1.1.1 Ethernet Port

The Ethernet protocol provides maximum control of the Microlab 600 functions. The command set exposes greater functionality than the serial protocol and allows for remote connection of the instrument. Commands sent over the internet from a PC anywhere in the world can be received and executed by the Microlab 600. However, there is an important caveat to using the Ethernet control. Ethernet control commands must be sent from a programming language that is Microsoft® .NET 2.0 compatible. This means the commands must be sent from a PC running a Windows® operating system. Compatible programming languages include Visual C#®, Visual Basic®, and LabVIEW™. An electronic programmer's guide, example files and the .Net 2.0 Application Programming Interface (API) are shipped on a CD with each Advanced or standalone Microlab 600.

1.1.2 Serial RS-232 Port

The serial protocol controls the most commonly used commands. For the majority of applications there is no need for enhanced Ethernet commands. The main benefit of RS-232 communication is platform independence. Commands can be sent from any device with a serial port. This means PC, Linux, Mac and embedded controllers can all send commands to RS-232 port.

CHAPTER 1: GENERAL OVERVIEW

1.1.3 CAN IN/OUT

The CAN IN port is only used when daisy chaining multiple pumps. The CAN IN port must be connected to the CAN OUT port of a Microlab 600 earlier in the chain. The first instrument in the chain must be connected to the control device using either Ethernet or RS-232. There is no way to control the instrument directly using the CAN port.

1.1.4 Digital TTL IN/OUT Port


The Digital TTL port can be used to send and receive simple triggers from other devices. Using the Microlab 600 controller, it is possible to create a custom method that is programmed to wait for triggers sent via the TTL input pins and send signals out through the output pins when a specific task is completed. This method can then be downloaded to the pump and run independently from any control device.

This port can also be utilized by both the Ethernet and the RS-232 protocols to send and receive signals from other instruments that are not connected to the control device.

1.2 Daisy Chain Compatibility

1.2.1 Microlab 600 Units Only

The Microlab 600 supports the daisy chaining and control of up to 16 instruments via RS-232. The control device communicates with the first instrument in the daisy chain. Then, the first device communicates with the other 15 instruments via a proprietary CAN interface.




1.2.2 Microlab 600 Units With Other RNO Protocol Devices

The Microlab 600 is compatible with other devices that communicate via Hamilton's Protocol 1/RNO+. These devices include the older Microlab 500 series and the Modular Valve Positioner. Only the first Microlab 600 in a daisy chain communicates with RS-232. This means that all other RNO protocol devices must come before the Microlab 600 in a daisy chain.


1.2.3 Required Cables For Daisy Chaining

A variety of cables are required to connect the Microlab 600 with a control device or other Protocol 1 devices. The major cables required for this purpose are outlined in the table below. If other connections are required, please contact Hamilton Company for a cable or pin diagram.




Part Number	Description	Upstream Cable Connector	Downstream Cable Connector	Pinout
3553-01	PC to Microlab 600	DB-9 Female	DB-9 Male	Upstream pins 1-9 are directly connected to downstream pins 1-9
66650-01	Microlab 600 to Microlab 600	RJ-12	RJ-12	Upstream pins 2-7 are directly connected to downstream pins 2-7
66626-01	Modular Valve Positioner to Microlab 600	DB-9 Male	DB-9 Male	Upstream pins 1, 2 & 3 are connected to downstream pins 2, 3 & 5 respectively
66627-01	Microlab 500 to Microlab 600	RJ-12	DB-9 Male	Upstream pins 2, 3 & 4 are connected to downstream pins 3, 2 & 5 respectively





9 6

00000



Male DB-9 Female DB-9

CHAPTER 2: COMMUNICATION VIA RS-232 CHAPTER 2: COMMUNICATION VIA RS-232

CHAPTER 2:

Communication via RS-232

Hamilton Company provides a protocol for communication with this instrument: Protocol 1/RNO+. This protocol uses the industry standard RS-232C interface (using RXD, TXD and GND) and allows up to 16 instruments to be linked in a daisy chain configuration. The instruments may be individually accessed via their own address, while a broadcast addressing scheme allows all instruments to be accessed simultaneously using broadcast addressing.

Note: All information transferred between the controlling device and the instrument is case sensitive and must be sent exactly as shown.

This chapter discusses the following topics:

- 2.1 Hamilton Protocol 1/RNO+ Overview
- 2.2 Data Transfer Format
- 2.3 Establishing Communication (Auto-Addressing and Initializing)
- 2.4 Data String Components

2.1 Hamilton Protocol 1/RNO+ Overview

The Hamilton Protocol 1/RNO+ syntax is used to communicate with instruments (Microlab diluters/dispensers, PSD pumps and modular valve positioners) which are designed and manufactured by Hamilton Company.

To successfully communicate using this protocol the serial port must be configured as follows:

Data Format

Baud Rate: Variable
Parity: Odd
Data bits: 7
Stop bits: 1

All commands sent to the instrument must be terminated using a carriage return. When a command is received by an instrument it is processed, and the instrument responds back to the control device with an acknowledgement. There are two types of acknowledgements. The first is a positive acknowledgement that communicates the command is understood and can be executed. The second is a negative acknowledgement that communicates the command is not understood or cannot be executed. The communication is performed using three basic control characters (Table 2-1).


Notation	Name	ASCII Code (decimal)	Description
<cr></cr>	Carriage return	13	A control character that terminates a data string
<ack></ack>	Acknowledge	06	A control character transmitted by the instrument indicating an affirmative response to the controlling device
<nak></nak>	Negative acknowledge	21	A control character transmitted by the instrument indicating a non-affirmative response to the controlling device

Table 2-1 Protocol 1/RNO+ Control Characters

CHAPTER 2: COMMUNICATION VIA RS-232

2.2 Data Transfer Format

Commands sent from a controlling device to an instrument must begin with the instrument's address and end with a carriage return. Instruments configured in a daisy chain will only respond to commands that start with their address. If it is desirable to send a single command to all instruments, a ":" can be used for the instrument address. This is the broadcast address which will be acted upon by all instruments in the chain. The control device will not receive a response from broadcasted commands.



*A minimum 1 millisecond delay must occur between the controlling device receiving the <CR> of the response and the transmission of any data on a daisy chain.

2.3 Establishing Communication (Auto-addressing and Initializing)

When an instrument is first turned on (prior to auto-addressing) it does not know if it is a single instrument or one instrument in a daisy chain of other instruments. Without knowing its position in the chain, it will not know which commands to respond to and which to ignore. For this reason, the auto-address command should be the first sequence of characters transmitted to the instrument(s). Until the auto-address command is sent and addresses are assigned to the instrument(s), the instrument(s) will ignore all commands and requests.

Protocol 1/RNO+ instruments are auto-addressed using the following sequence:

1a<CR>

The first instrument in the daisy chain will be assigned the address "a" and will transmit the sequence 1b<CR> to the next instrument. The process of assigning the address received and transmitting the next address continues for all instruments in the daisy chain. The last instrument in the daisy chain responds to the controlling device with

1<last address + 1><CR>

Example: Four instruments are in a daisy chain, and the controlling device transmits 1a<CR>. The controlling device will receive 1e<CR>, indicating that the instruments have been assigned addresses a, b, c and d.

If the daisy chain has already been auto-addressed sending the auto-address command again will not readdress the instruments. Instead the expected response will be 1a.

Broadcast Addressing

In addition to addressing a single unit in a daisy chain, the Protocol 1/RNO+ allows all units in a daisy chain to be addressed at once using the broadcast address. Instead of the instrument-specific lettered address, the broadcast instrument address is ":". Note, however, that the instrument(s) will NOT transmit protocol or status information when addressed with the broadcast address (i.e., to ensure no corruption of data on the serial line when multiple instruments attempt to transmit data at the same time).

Instrument Initialization

Commands can be sent to the instruments after auto-addressing. Before sending commands that move the valves and syringes, it is necessary to initialize the drives. Commands sent to the syringe drive are ignored until initialization is complete. Commands sent to the valve drives result in the automatic initialization of the valve drive prior to rotation to the desired position. Depending on the user case, there are several initialize commands that can be found in Table 3.1.2.

Recovering from Resets and Power Failures

When controlling a single Microlab 600 an instrument reset or a power failure will result in the need to auto-address the instrument using the 1a<CR> command

When controlling a daisy chain of Microlab 600s and other Protocol 1/RNO+ devices the recovery will require a few steps. The first step is to broadcast a reset command:!<CR> to all the pumps. Then issue the 1a<CR> command to auto-address the instruments. Next issue the reset command again followed by an additional auto address. Repeat the reset and auto-address commands until the same auto-address response is received twice. These extra steps are required because the reset command will only be seen by instruments that have been auto-addressed. If multiple instruments have power failures throughout the chain multiple resets may be required.

Note: Instruments are assigned their addresses by auto-addressing.

with this protocol.

Hardware addressing is not supported

CHAPTER 2: COMMUNICATION VIA RS-232

CHAPTER 2: COMMUNICATION VIA RS-232


2.4 Data String Components

A data string may contain one status request and/or one or more commands. Multiple status requests in a single data string should be avoided as they are not explicitly supported. The instrument buffers the commands received until the execute command is received. Once the execute command is received, the commands are executed in the order received. The instrument command buffer can contain up to two valves, one syringe, one timer delay and one digital output command per syringe pump. If the command buffer is already full, new commands replace existing commands.

While the instrument is executing commands, it will ignore any new commands received for that given side of the instrument with the exception of execution commands such as Halt.

Command Example 1: Auto-addressing the instrument

The following example assumes there is only one instrument connected to the control device.



Command Example 2: Initializing the instrument

The following example assumes the instrument has already been auto-addressed as per the previous example.




Command Example 3: A complex command

The following example assumes the instrument has already been auto-addressed and initialized as per the previous examples.



Command Example 4: A status or parameter request

The following example assumes the instrument has already been auto-addressed as per the previous example. The response shown will vary depending upon the instrument model used.



CHAPTER 3: PROTOCOL COMMAND SUMMARY

CHAPTER 3:

Protocol Command Summary

This section provides detailed information on the Protocol 1/RNO+ supported by Hamilton Company:

- 3.1 General Commands
- 3.2 Parameter Change Commands
- 3.3 Status Request Commands

3.1 General Commands

These are the individual command strings that can be used together to create a synchronized dispense or fill action. The commands are used to move the valves and syringes, and set the state of the Digital I/O port. Some commands have optional parameters listed in the tables that control things like speed and return steps. If these parameters are not specified, the instrument will use the default settings. These general commands will be stored in the command buffer until the Execute command "R" is sent by the control device.

3.1.1 Syringe Pump Selection Commands The Dual Syringe Microlab 600 has two complete syringe drives one left and one

Command Description

B Select left syringe drive

C Select right syringe drive

The Dual Syringe Microlab 600 has two complete syringe drives one left and one right. For this instrument is it critical to indicate which syringe drive should execute the command. If a channel selection command is not sent before a given command, the left (default) side is assumed as the target for commands and parameter change requests. For status requests, the response will be for the whole instrument. Exceptions to this rule are noted after the given commands.

For instruments without two syringe drives, all devices are considered to be on the left (default) side. Commands attempted on the right side will result in an error.

Example of Syringe Select commands:

This example assumes the syringes have just been initialized. Sending this command will fill the left syringe full and the right syringe to half stroke.

Instrument address

Select the left syringe drive

Move the left syringe down 48,000 steps

Select the right syringe drive

Move the right syringe down 24,000 steps

Execute command

3.1.2 Initialization Commands

Before commands can be sent to move an object like a valve or a syringe, the object must first be initialized. During initialization the valve and syringe find their home position which acts as the starting position for all subsequent movements. If the left or right syringe pump is not explicitly specified via one of the syringe selection commands, the initialization commands are performed on all available sides of the instrument.

The instrument will not execute any initialization commands until an Execute command is received.

Optional parameters can be used to temporarily set the syringe speed during initialization. If the optional parameter is not used the syringe will initialize at the default speed stored in the memory. When sending a speed parameter it is not necessary to include leading zeros. For example speed 2 can be sent as S2 or S0002.

Command	Optional Parameters	Description
		Command Name:
X		Initialize Instrument
		Command Description:
	Syringe speed Sxxxx	 1) Valve(s) to initialize and rotate to the output position 2) Syringe(s) drive up until overload (bottomed out) 3) Valve(s) to rotate to input position 4) Syringe(s) to back off the default back-off steps
		Parameter Values:
		xxxx = This is an optional parameter that sets the syringe speed used during initialization. If not specified, the syringes initialize at the speed currently stored in memory. Valid values are 2-3692 seconds per stroke.
		Command Name:
		Initialize Syringe(s) Only
		Command Description:
X1	Syringe speed Sxxxx	 Syringe(s) drive up until overloaded (bottomed out) Syringe(s) to back off the default back-off steps
		Parameter Values:
		xxxx = This is an optional parameter that sets the syringe speed used during initialization. If not specified, the syringes initialize at the speed currently store in memory. Valid values are 2-3692 seconds per stroke.
		Command Name:
		Initialize Syringe(s) Only with Error Bit
		Command Description:
X2	Syringe speed Sxxxx	This initialization command can only be performed after a previous successful syringe initialization. After this command is completed, the pump compares the new initialization position to the original and sets the "syringe move" error bit if the syringe overloads before it reaches the top of the stroke.
		Parameter Values:
		xxxx = This is an optional parameter that sets the syringe speed used during initialization. If not specified, the syringes initialize at the speed currently store in memory. Valid values are 2-3692 seconds per stroke.
		Command Name:
		Initialize Valve(s) Only
_X		Command Description:
		1) Rotate the valve(s) at least 395°2) Stop valve(s) at the input position

Example of Initialization commands:

Sending the command below initializes the left and right valve drives. Then it initializes the right syringe at speed 10 and the left syringe at speed 5.



3.1.3 Syringe Positioning Commands

Syringe positioning commands are used to move the syringe drive up, down, or to an absolute position. One syringe positioning command per syringe drive can be held in the command buffer at a time. New syringe commands will overwrite commands in the command buffer that have not been executed.

To determine the volume dispensed per step the total syringe volume is divided by 48,000 steps. All Hamilton instrument syringes are designed with a 60 mm stroke length and the Microlab 600 is designed to move 60 mm in 48,000 steps. For example to dispense 9 mL from a 10 mL syringe you would determine the number of steps by multiplying 48000 steps (9 mL/10 mL) to get 43,200 steps.

Optional parameters can be used to temporarily set the syringe speed and return steps during a move. If the optional parameter is not used the syringe will move at the default speed and return steps stored in the memory. When sending a speed and return step parameters it is not necessary to include leading zeros. For example speed 2 can be sent as \$2 or \$0002.

Command	Optional Parameters	Description
		Command Name:
		Syringe Pickup
		Command Description:
	Syringe speed	This command moves the syringe a set number of steps down from the currer syringe position.
DVVVVV	Snnnn	Parameter Values:
PXXXXX	Return steps Nrrrr	xxxxx = This is the number of steps to move the syringe. Valid values are 1–52,800 steps.
		nnnn = This sets the syringe speed used during the positioning command. Valid values are 2-3692 seconds per stroke.
		rrrr = This is the number of return steps to apply to the end of a downward syringe movement. This removes the mechanical slack from the system. Valid values are 0-1000 steps.
		Command Name:
		Syringe Dispense
		Command Description:
DXXXXX	Syringe speed Snnnn	This command will move syringe a set number of steps up from the current syringe position
<i>D</i> ////////		Parameter Values:
		xxxxx = This is the number of steps to move the syringe. Valid values are 1–52,800 steps.
		nnnn = This sets the syringe speed used during the positioning command. Valid values are 2-3692 seconds per stroke.
		Command Name:
		Syringe Absolute Move
		Command Description:
	Syringe speed Snnnn Return steps Nrrrr	This command moves the syringe from its current position to any step position along the stroke. It automatically calculates how far it needs to move in either the up or down direction.
MXXXXX		Parameter Values:
WIXXXX		xxxxx = This is the step position where syringe should move. Valid values are 1–52,800 steps.
		nnnn = This sets the syringe speed used during the positioning command. Valid values are 2-3692 seconds per stroke.
		rrrr = If the syringe move is in the downward direction, this is the number of return steps to apply to the end of the movement. This removes the mechanic slack from the system. Valid values are 0–1000 steps.

Example of syringe positioning commands:

This example assumes that both syringe drives have been initialized and the left syringe is empty. Sending this command fills the left syringe full and moves the right syringe to half stroke.



3.1.4 Valve Positioning Commands

Valve positioning commands are used to move the valve drives to a desired position name or a defined angle. Up to two valve positioning commands per syringe drive can be held in the command buffer at a time. Once the command buffer is full new valve commands will overwrite the last valve command in the buffer. The reason for accepting two valve commands per syringe drive is to allow for positioning the valve, moving the syringe, and then positioning the valve to a new location all in one command string.

When sending valve position names and valve angles leading zeros will be ignored. For example to rotate the valve to 15 degrees LA115 and LA1015 will perform the same action.

Command	Description
	Command Name:
	Valve to Input Position (Position 9)
	Command Description:
	This command rotates the valve to the default input positon for the valve type that is currently stored in the pump.
	Command Name:
	Valve to Output Position (Position 10)
O	Command Description:
	This command rotates the valve to the default output positon for the valve type that is currently stored in the pump.
	Command Name:
V	Valve to Output Position (Position 11)
VV	Command Description:
	This command rotates the valve to the default wash position for the valve type that is currently stored in the pump.
	Command Name:
	Valve Positioning by Name
	Command Description:
_Pdpp	This command rotates the valve to the valid valve position names for the valve type that is currently stored in the pump. Position 9 is always the default input position. Position 10 is always the default output position. Position 11 is always the wash position, but not all valves have a wash position.
_гарр	Parameter Values:
	d = This parameter determines the direction the valve turns when moving to the desired valve positio Valid values are 0 = clockwise (CW), 1 = counter-clockwise (CCW).
	pp = These are the named valve ports. The port names are mapped to different ports depending on the current instrument valve configuration. Valid values are positions 1–11 but not all valves have 11 valid positions.
	Command Name:
	Valve Positioning by Degree
	Command Description:
LAdaaa	This command rotates the valve to a defined position in degrees. The valve drive's home position is specified as zero degrees. All movements are absolute so the pump automatically calculates how far needs to move the valve to reach the desired angle.
	Parameter Values:
	d = This parameter determines the direction the valve turns when moving to the desired valve position Valid values are $0 = CW$, $1 = CCW$.
	aaa = This is the desired valve position specified by the angles in degrees. Valid values are from 0° to 359° in whole degree increments.

Example of Valve Positioning commands:

This example assumes that both syringe drives have been initialized and the left syringe is empty. Sending this command rotates the left valve to the output and the right valve to 195°. When the left valve finishes its move, the left syringe drive fills completely. Once the left syringe drive finishes its move, the left valve rotates to Position 1.



3.1.5 Timer Commands

Command	Description
	Command Name:
	Timer Delay
	Command Description:
>Txxxxxxxx	This command adds a delay before a command is executed or between the execution of two commands. The order of the commands determines when the delay will occur. Leading zeros will be ignored so sending >T100 is the same as >T00000100.
	Parameter Values:
	xxxxxxxx = This is the duration of the delay in milliseconds. Valid values are between 0–9999999 milliseconds.

CHAPTER 3: PROTOCOL COMMAND SUMMARY

Example of the Timer command:

This example assumes both syringe drives have been initialized and the left syringe is empty. Sending this command fills the left and right syringe. The left syringe starts 1 second after the right syringe. After the right syringe completes its move, there will be a 1 second delay before the right valve rotates to 195 degrees.



3.1.6 Digital I/O Commands

Command	Description
	Command Name:
	TTL Data Output Command Description:
	This command turns on and off the four output pins of the TTL IN/OUT port. This can be used to send a 5V signal to trigger an action in another device. There is only one Digitial I/O port so it works independent of the syringe pump selection. Leading zeros will be ignored so sending >D1 is the same as <d01.< td=""></d01.<>
>Dxx	Parameter Values:
	xx = This is the decimal value corresponding to the pins that will be turned on and off. Valid values are 0–15. The decimal value maps to a binary value which can be seen in the table below. Since there are only four output pins, only the last four binary digits are used. For example, a decimal value of 0 is equal to the binary value 0000 and results in all pins being turned off. A decimal value of 15 is equal to the binary value 1111 and results in all pins being turned on.

Decimal values mapped to output pins

Pin	Function
1	Output 1 (O°)
2	Output 2 (O1)
3	Output 3 (O²)
4	Output 4 (O³)
5	Input 1 (O°)
6	Input 2 (O1)
7	Input 3 (O²)
8	Input 4 (O³)
9	Ground




Table 2-4 TTL Pin Configuration

Decimal	Output 0	Output 1	Output 2	Output 3
)	0	0	0	0
1	1	0	0	0
2	0	1	0	0
3	1	1	0	0
4	0	0	1	0
5	1	0	1	0
6	0	1	1	0
7	1	1	1	0
3	0	0	0	1
9	1	0	0	1
10	0	1	0	1
11	1	1	0	1
12	0	0	1	1
13	1	0	1	1
14	0	1	1	1
15	1	1	1	1

A value of 0 indicates the pin will be turned off. A value of 1 indicates the pin will be turned on.

Example of the Digital I/O command:



Instrument address

Turns on Output Pins 0, 2, and 3 while
Output Pin 1 is turned off

Execute command

3.1.7 Execution Commands

Command	Description
	Command Name:
	Execute command
R	Command Description:
	This command executes commands stored in the instrument's command buffer. The command can be included at the end of a command string to execute the string or can be sent as separate command to execute the commands in the instruments command buffer.
	Command Name:
K	Halt execution of commands
	Command Description:
	This command immediately stops a command the instrument is already executing.
	Command Name:
ψ	Resume execution of commands
Φ	Command Description:
	This command restarts a command that has been stopped by the Halt command.
	Command Name:
./	Clear all buffered commands
V	Command Description:
	This command clears the command buffer of all commands that have not been executed.

3.1.8 Instrument Control Commands

Command	Description
	Command Name:
	Total system reset
	Command Description:
!	This command powers the instruments off and back on. It can take more than 2 seconds for a single Microlab 600 to power cycle and be ready to receive commands. For a daisy chain of Microlab 600s, it can take as much as 12 seconds to power cycle all instruments and be ready for the auto-address command.

3.2 Parameter Change Commands

The parameter change commands changes the default syringe settings and valve configuration.

3.2.1 Syringe Parameter Change

Command	Description
	Command Name:
	Set syringe default speed
	Command Description:
YSSxxxx	This command changes the speed of the syringe drive. All changes are temporary unless they are saved to non-volatile memory using the parameter save commands. Suggested speeds are defined per syringe the table below. Leading zeros will be ignored so sending YSS2 is the same as YSS0002.
	Parameter Values:
	xxxx = This is the syringe speed parameter that is temporarily saved in memory as the default syring speed. Valid values are 2-3692 seconds per stroke.
	Command Name:
	Set default return steps
	Command Description:
/SNxxxx	This command is used to change the default return steps. Syringe return steps are used to compensa for the mechanical drive system backlash, which improves accuracy and precision. Return steps are added to all downward movements, which ultimately causes them to go past the desired position. The return steps are then subtracted by an upward stroke so the syringe ends at the exact desired location All changes will be temporary unless they are saved to non-volatile memory using the parameter save commands. Return steps are independent of syringe size and the default for the Microlab 600 is 24 steps. Leading zeros will be ignored so sending YSN25 is the same as YSN0025.
	Parameter Values:
	xxxx = This is the return step parameter that is temporarily saved in memory as the new default. Val values are 0–1000 steps.
	Command Name:
	Set default back-off steps
	Command Description:
YSBxxxx	This command changes the default back-off steps. Syringe back-off steps are used during initialization. The syringe is driven to the top of stroke until the drive overloads. Then the syringe is adjusted a small distance away from the overload point, and this final position is used as the zero point for future syringe movements. The small distance moved from the overload point is defined by the back-off steps. Larger syringes generally require more back-off steps because the plunger tips are larger and tend to compress, requiring more back-off distance before being in the right position to draw liquid. All changes are temporary unless they are saved to non-volatile memory using the parameter save commands. Suggested back-off steps are defined per syringe in the table below. Leading zeros will be ignored so sending YSB25 is the same as YSB0025.
	Parameter Values:
	xxxx = This is the back-off step parameter that is temporarily saved in memory as the new default. Valid values are 0-1000 steps.

Microlab 600 Syringe Recommended Settings

Syringe Size	Default Speed (sec/stroke)	Default Back-off Steps
10 μL	2	80
25 μL	2	80
50 μL	2	80
100 μL	2	80
250 μL	2	80
500 μL	2	80
1 mL	2	80
2.5 mL	4	96
5 mL	4	96
10 mL	4	96
25 mL	8	96
50 mL	16	96

3.2.2 Valve Parameter Change

Command Description

Command Name:

Set Valve Configuration

Command Description:

This command sets the type of valve attached to the instrument. Values 11–17 are used to control PSD/4 valves. Values 18-19 are the standard valve configurations for the Microlab 600. When used with a dual syringe system, values 19–20 automatically configure the left and right valves.

Parameter Values:

xx = This parameter corresponds to the valve types found in the table below. Valid values are 11-20.

LSTxx

LST Parameter	Valve Name
11	8-5
12	6-5
13	4-5
14	3-2
15	3-5
16	3-3
17	Υ
18	Single/Dual Dispense
19	Continuous Dispense
20	Dual Diluter

Command Name:

Set Valve Speed

Command Description:

LSFxxx

This command adjusts the default valve rotation speed. The default speed is 240 degrees per second. Faster speeds less torque and could result in more frequent valve drive stalls. This is application-dependent and affected by valve type, duty cycle, solvent, etc. Leading zeros will be ignored so sending LSF15 is the same as LSF015.

Parameter Values:

xxxx = This parameter sets the valve drive speed. Valid values are 15–720 degrees per second.

Microlab 600 Valid Valve Positions by Name and Degree

LST Parameter	Valve Name	Valid Position	n Names	Positions in Deg	grees		
11	8-5 (8-Port Distribution)	1-11		0, 45, 90, 135, 1 0, 270, 90	80, 225, 270, 3 ⁻		
12	6-5 (6-Port Distribution)	1-6 & 9-11	1-6 & 9-11 45, 90, 135, 180, 225, 270, 135		, 225, 270, 45,		
13	4-5 (4-Port Distribution)	1-4 & 9-11		0, 90, 180, 270,	0, 270, 90		
14	3-2 (2-Port Distribution)	1-4 & 9-11		0, 90, 180, 270,	0, 270, 90		
15	3-5 (3-Port Distribution)	1-3 & 9-11		0, 90, 180, 0, 18	0, 90, 180, 0, 180, 90		
16	3-3 (2-Port T valve)	1-4 & 9-11		0, 90, 180, 270,	0, 180, 270		
17	Y (2-Port Y valve)	1-3 & 9-11		0, 120, 240, 0, 2	40, 120		
		Left Valve	Right Valve	Left Valve	Right Valve		
18	Single/Dual Dispense	1, 3, 9 & 10	1, 2, 9 & 10	0, 135, 0, 135	0, 90, 90, 0		
19	Continuous Dispense	1, 2, 9 & 10	1, 2, 9 & 10	0, 270, 0, 270	0, 90, 90, 0		
20	Dual Diluter	1, 2, 9 & 10	1, 2, 9 & 10	0, 270, 0, 270	0, 90, 0, 0		

3.2.3 Save and Erase Current Parameters

Command	Description				
	Command Name:				
	Save current instrument parameters				
#SP1	Command Description:				
	This command stores the current left and right side parameters for syringe speed, return steps, back-off steps, valve configuration (type) and valve speed to non-volatile memory.				
	Command Name:				
	Erase stored parameters				
#SP2	Command Description:				
	This command erases stored values for the left and right side for syringe speed, return steps, back-osteps, valve configuration (type) and valve speed from non-volatile memory and resets the values to the instrument default values.				

3.3 Status Request Commands

3.3.1 Instrument Information Requests

Request	Response	Descriptions
		Request Name:
		Instrument Done Request
		Request Description:
		This request checks to see if there are commands in the command buffer.
F	X	Response Values (x = Instrument status):
		Y = Instrument is idle and command buffer is empty
		N = Instrument is idle and command buffer is not empty
		* = Instrument is busy
		Request Name:
		Syringe Error Request
		Request Description:
		This request checks to see if there was a syringe error.
7	X	Response Values (x = Syringe status):
		Y = Syringe overload or initialization error
		N = No syringe error
		* = Instrument is busy
		Request Name:
		Valve Error Request
		Request Description:
		This request checks to see if there was a valve error.
G	X	Response Values (x = Valve status):
		Y = Valve overload or initialization error
		N = No valve error
		* = Instrument is busy

Request	Response	Descriptions
		Request Name:
		Instrument Configuration
		Request Description:
		This request checks to see if the instrument has one or two syringe drives.
-	X	Response Values (x = Instrument configuration):
		Y = Single syringe instrument
		N = Dual syringe instrument
		* = Instrument is busy
		Request Name:
		Hand Probe/Foot Switch Status
		Request Description:
\circ	V	This request checks for a switch press on the left or right trigger port.
Q	Χ	Response Values (x = Switch status):
		Y = Switch is pressed
		N = Switch is not pressed

CHAPTER 3: PROTOCOL COMMAND SUMMARY

3.3.2 Instrument Status Request

Request	Response	Description								
		Request Name:								
		Instrument Status Re	equest							
		Request Description:								
		This request checks errors or syntax erro		he instr	ument is	s busy o	r if there	have b	een any	instrumen
		Response Values (x = Ir	strument	status	byte):					
		The response is an A where a bit value of See Appendix B for	1 means t	he cond	dition is	true and				
		Example:								
			Byte)						
		Bits#	7	6	5	4	3	2	1	0
E1	Χ	ASCII value = @	0	1	0	0	0	0	0	0
		x = An ASCII value v	where the	bits are	defined	as:				
		0: Instru	ument idle	, comm	and buf	fer is no	t empty			
		1: Syrin	ge drive(s) busy						
		2: Valve	drive(s) b	usy						
		3: Synta	ax error							
		4: Instru	ument erro	or (valve	or syrin	ge error	.)			
		5: Alwa	ys 0							
		6: Alwa	ys 1							
		7: Alway	ys 0							
		The instrument error bit is reset after the			an Instru	ıment E	rror Req	uest an	d the sy	ntax error

Request	Response	Description
		Request Name:
		Instrument Error Request
		Request Description:
		This request checks for errors with the valve or syringe drives.
		Response Values (see E1 for an example):
		a and c = These ASCII values show errors for the left (a) and right (c) syringes. The bits are defined as:
		0: Not initialized
		1: Overload error
		2: Stroke too large
		3: Initialization error
		4: This syringe does not exist
		5: Always 0
E2	abcd	6: Always 1
		7: Always 0
		b and d = These ASCII values show errors for the left (b) and right (d) valves. The bits are defined as:
		0: Not initialized
		1: Initialization error
		2: Overload error
		3: Always 0
		4: This valve does not exist
		5: Always 0
		6: Always 1
		7: Always 0
		Request Name:
		Timer Status
		Request Description:
		This request checks to see if the instrument is currently waiting for a timer to complete.
		Response Values (see E1 for an example):
		x = An ASCII value where the bits are defined as:
E3	X	0: Timer(s) busy
		1: Always 0
		2: Always 0
		3: Always 0
		4: Always 0
		5: Always 0
		6: Always 1
		7: Always 0



Command	Response	Description
		Request Name:
		Instrument Busy Status
		Request Description:
		This request checks to see if the valve and syringe drives on the instrument are busy.
		Response Values (see E1 for an example):
		x = An ASCII value where the bits are defined as:
		0: Left valve busy
T1	Χ	1: Left syringe busy
		2: Right valve busy
		3: Right syringe busy
		4: Prime/Step active
		5: Handprobe/Foot switch active
		6: Always 1
		7: Always 0
	<u>.</u>	
		Request Name:
		Instrument Error Status
		Request Description:
		This request checks to see if the instrument is currently waiting for a timer to complete.
		Response Values (see E1 for an example):
		x = An ASCII value where the bits are defined as:
T2	X	0: Left valve error
12	^	1: Left syringe error
		2: Right valve error
		3: Right syringe error
		4: Always 1
		5: Always 1
		6: Always 1
		7: Always 0

3.3.3 Syringe Parameter Request

Request	Response	Description
		Request Name:
		Syringe default speed
		Request Description:
YQS	XXXX	This requests the current syringe speed setting.
		Response Value:
		xxxx = This is the syringe speed parameter. Valid response values are 2-3692 seconds per stroke.
		Request Name:
		Syringe default return steps
YQN	xxxx	Request Description:
TQN		This requests the current return steps setting.
		Response Value:
		xxxx = Valid values are 0-1000 steps.
		Request Name:
		Current syringe position
YQP		Request Description:
TQF	XXXXX	This request returns the current location of the syringe drive in steps.
		Response Value:
		xxxxx = Valid values are 0-52,800 steps.
		Request Name:
		Syringe default back-off steps
YQB	XXXX	Request Description:
ועט		This requests the current back-off steps setting.
		Response Value:
		xxxx = Valid values are 0-1000 steps.

3.3.4 Valve Parameter Request

Request	Response	Description
		Request Name:
		Valve position
		Request Description:
LQP	XX	This requests the current valve position. The request will return a position name between 1 and 8. Value positioning 7–11 can be mapped to a position between 1–8 which is shown by the table in Section 3.2.2.
		Response Value:
		xx = Valid values are 1-8 steps.
		Request Name:
		Valve angle
_QA	xxx	Request Description:
		This requests the current valve angle.
		Response Value:
		xxx = Valid values are 0-359 degrees.
		Request Name:
		Valve configuration
		Request Description:
LQT	XX	This requests the current valve configuration.
		Response Value:
		xx = Valid values are 11–20. See Section 3.2.2 for a configuration cross reference.
		Request Name:
1.05		Valve speed
	XXX	Request Description:
_QF		This requests the current valve speed.
		Response Value:
		xxx = Valid values are 15-720 degrees per second.

3.3.5 Timer Requests

Request		Description
		Request Name:
		Timer delay value
		Request Description:
<⊺	xxxxxxx	This requests the current timer delay value. If a timer delay is in the command buffer, it returns with the value of the timer. If the command has already been executed, the request returns with the number of milliseconds remaining. If no timer is queued or active, the request returns with 0.
		Response Value:
		xxxxxxxx = Valid values are 0-99999999 milliseconds.

3.3.6 Digital I/O Requests

Request	Response	Description
		Request Name:
		TTL data input
		Request Description:
<d< td=""><td>xx</td><td>This request returns a decimal value that corresponds to the state of four input TTL pir on the back of the instrument. The decimal value maps to a binary value. The last four digits of the binary value indicate the status of each input pin. If nothing is connected, this command will return 15 indicating that all at their default state of on. If the Input 0 pin is shorted to ground, then the command would return 14 indicating a signal is bein received on Input 0.</td></d<>	xx	This request returns a decimal value that corresponds to the state of four input TTL pir on the back of the instrument. The decimal value maps to a binary value. The last four digits of the binary value indicate the status of each input pin. If nothing is connected, this command will return 15 indicating that all at their default state of on. If the Input 0 pin is shorted to ground, then the command would return 14 indicating a signal is bein received on Input 0.
		Response Value:
		xx = Valid values are 0-15.

CHAPTER 3: PROTOCOL COMMAND SUMMARY

Decimal values mapped to input pins

Pin	Function
1	Output 1 (O°)
2	Output 2 (O1)
3	Output 3 (O²)
4	Output 4 (O³)
5	Input 1 (O°)
6	Input 2 (O¹)
7	Input 3 (O²)
8	Input 4 (O³)
9	Ground




Table 2-4 TTL Pin Configuration

Decimal	Input 0	Input 1	Input 2	Input 3
)	0	0	0	0
1	1	0	0	0
2	0	1	0	0
3	1	1	0	0
4	0	0	1	0
5	1	0	1	0
6	0	1	1	0
7	1	1	1	0
8	0	0	0	1
9	1	0	0	1
10	0	1	0	1
11	1	1	0	1
12	0	0	1	1
13	1	0	1	1
14	0	1	1	1
15	1	1	1	1

3.3.7 Firmware Version Request

Request	Response	Description
		Request Name:
		Firmware Version Request
		Request Description:
		This requests the current valve configuration.
		Response Value:
		xx = Product identifier
U	xxii.jj.k	ii = Major version (01–99)
		jj = Minor version (01–99)
		k = Revision (A-Z)
		Product Identifiers/Version
		OM01 = PSD/2
		MV = MVP
		NV01 = ML600

APPENDICES

Appendices

Appendix A — Simple Program Examples

Example program 1:

This series of commands can be used with the Dual Syringe Dispenser setup to fill both syringes and then wait for a trigger to aliquot 25% of the syringe volume in four dispenses from the left and right syringe. When the dispense are complete the Digital TTL signal is sent.

Note: If the instrument was

configured with two 10 mL syringes step

4 would fill both syringes with 10 mL (48,000*(10 mL/10 mL) = 48,000) and

steps 6, 8, 10, and 12 would dispense 2.5 mL (48000*(2.5 mL/10 mL) = 12,000).

Commands	Description
1. 1a	1. Auto-address (expect response 1b)
2. aXR	2. Initialize the left and right syringe drives
3. aQ	3. Repetitively send this command until the pump is no longer busy from the initialize command. Then the next command can be sent. This is called polling.
4. aBI48000S10OCIP48000S25OR	4. Fill the left syringe full from the input position at speed 10. At the same time fil the right syringe full from the input position at speed 25. After completing the syringe movements rotate the valves to the output position.
5. aQ	5. Poll until the pump is no longer busy and the hand probe is pressed.
6. aBD12000CD12000R	6. Dispense ¼ of the left and right syringe volume at the default speed.
7. aQ	7. Poll until the pump is no longer busy and the hand probe is pressed.
8. aBD12000CD12000R	8. Dispense another ¼ of the left and right syringe volume at the default speed.
9. aQ	9. Poll until the pump is no longer busy and the hand probe is pressed.
10. aBD12000CD12000R	10. Dispense another ¼ of the left and right syringe volume at the default speed.
11. aQ	11. Poll until the pump is no longer busy and the hand probe is pressed.
12. aBD12000CD12000R	12. Dispense the final ¼ of the left and right syringe volume at the default speed.
13. aQ	13. Poll until the pump is no longer busy.
14. a>D15R	14. Turns on the Digital TTL signal.

Example program 2:

This series of commands can be used with a daisy chain of three Dual Syringe Dispensers. The commands will fill all six syringes and then it will wait for a TTL trigger before using the broadcast command to simultaneously dispense various volumes from syringes across all three pumps.

Commands	1. Auto-address (Expect response 1d)		
1. 1a			
2. :XR	2. Initialize the left and right syringe drives		
3. aQ 4. bQ 5. cQ	3-5. Repetitively send these commands waiting between each command for the response. When all three pumps are no longer busy from the initialize command the next command can be sent. This is called polling.		
6. aBI480000CIP48000OR 7. bBI480000CIP48000OR 8. cBI480000CIP48000OR	6-8. Fill the left and right syringe from the input position for each of the three pumps on the daisy chain. Then after completing the syringe movements rotate all valves to the output position.		
9. aQ 10. bQ 11. cQ	9-11. Poll all three units one at a time until all pumps are no longer busy		
12. aBD12000C24000	12. Buffers command to dispense ¼ of left syringe and ½ of right syringe		
13. bBD48000C4800	13. Buffers command to dispense all of left syringe and 1/10 of right syringe		
14. cBD42000CD42000	14. Buffers command to dispense 7/8 of left syringe and 7/8 of right syringe		
15. a <d< td=""><td>15. Poll the Digital TTL Input until the trigger signal is received.</td></d<>	15. Poll the Digital TTL Input until the trigger signal is received.		
16. :R	16. Broadcasts the Execute command to all pumps to trigger the commands stored in the command buffer.		

APPENDICES APPENDICES

Example program 3:

This series of commands can be used to determine what the current syringe speeds and valve configuration is for a Single Syringe Dispenser or for the left side of a Dual Syringe Dispenser. Then adjust the syringe speed and valve configuration and finally store the change into non-volatile memory.

Commands	Description 1. Auto-address (expect response 1b)		
1. 1a			
2. aLQT	2. Requests the configuration for the left valve (expect a numeric response between 11–20)		
3. aYQS	3. Requests the current syringe speed (expect a numeric response between 2-3692)		
4. aLST19	4. Sets the current valve configuration to 19 which is Continuous Dispenser		
5. aYSS25	5. Sets the current syringe speed to 25 seconds per stroke		
6. a#SP1	6. Stores the current instrument settings to non-volatile memory so they will remain set after the power is cycled.		

Appendix B — ASCII Chart

The following chart shows the relationship between binary numbers, decimal numbers, hexadecimal numbers and their ASCII equivalents for the numbers between 0 and 127.

Binary	Decimal	Hex	ASCII
00000000	0	00	<nul></nul>
00000001	1	01	<soh></soh>
00000010	2	02	<stx></stx>
00000011	3	03	<etx></etx>
00000100	4	04	<eot></eot>
00000101	5	05	<enq></enq>
00000110	6	06	<ack></ack>
00000111	7	07	<bel></bel>
00001000	8	08	<bs></bs>
00001001	9	09	<ht></ht>
00001010	10	0A	<lf></lf>
00001011	11	0B	<vt></vt>
00001100	12	0C	<ff></ff>
00001101	13	0D	<cr></cr>
00001110	14	0E	<s0></s0>
00001111	15	0F	<si></si>
00010000	16	10	<dle></dle>
00010001	17	11	<dc1></dc1>
00010010	18	12	<dc2></dc2>
00010011	19	13	<dc3></dc3>
00010100	20	14	<dc4></dc4>
00010101	21	15	<nak></nak>
00010110	22	16	<syn></syn>
00010111	23	17	<etb></etb>
00011000	24	18	<can></can>
00011001	25	19	
00011010	26	1A	
00011011	27	1B	<esc></esc>
00011100	28	1C	<fs></fs>
00011101	29	1D	<gs></gs>
00011110	30	1E	<rs></rs>
00011111	31	1F	<us></us>

Binary	Decimal	Hex	ASCII
00100000	32	20	
00100001	33	21	!
00100010	34	22	"
00100011	35	23	#
00100100	36	24	\$
00100101	37	25	%
00100110	38	26	&
00100111	39	27	£
00101000	40	28	(
00101001	41	29)
00101010	42	2A	*
00101011	43	2B	+
00101100	44	2C	3
00101101	45	2D	-
00101110	46	2E	
00101111	47	2F	/
00110000	48	30	0
00110001	49	31	1
00110010	50	32	2
00110011	51	33	3
00110100	52	34	4
00110101	53	35	5
00110110	54	36	6
00110111	55	37	7
00111000	56	38	8
00111001	57	39	9
00111010	58	3A	:
00111011	59	3B	;
00111100	60	3C	<
00111101	61	3D	=
00111110	62	3E	>
00111111	63	3F	?

01000000 64 40 @ 01000001 65 41 A 01000010 66 42 B 01000010 68 44 D 01000101 69 45 E 01000110 70 46 F 01001000 72 48 H 01001001 73 49 I 01001010 74 4A J 01001100 76 4C L 01001101 77 4D M 01001101 77 4D M 01001010 78 4E N 01010100 78 4E N 01010100 78 4E N 010101001 78 4E N 010101001 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010111 87 <td< th=""><th>Binary</th><th>Decimal</th><th>Hex</th><th>ASCII</th></td<>	Binary	Decimal	Hex	ASCII
01000010 66 42 B 01000011 67 43 C 01000100 68 44 D 01000110 70 46 F 01000111 71 47 G 01001000 72 48 H 01001010 74 4A J 01001010 74 4A J 01001101 75 4B K 01001101 78 4E N 01001101 78 4E N 01001010 78 4E N 01001111 79 4F O 01010000 80 50 P 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010101 85 55 U 01010101 86 56 V 01010111 87 5	01000000	64	40	@
01000011 67 43 C 01000100 68 44 D 01000110 69 45 E 01000110 70 46 F 01000100 72 48 H 01001001 73 49 I 01001010 74 4A J 01001101 75 4B K 01001100 76 4C L 01001101 77 4D M 01001101 78 4E N 010101000 80 50 P 010100001 81 51 Q 01010000 82 52 R 01010010 84 54 T 01010101 85 55 U 01010101 86 56 V 01010111 87 57 W 01011010 88 58 X 01011010 90 <td< td=""><td>01000001</td><td>65</td><td>41</td><td>Α</td></td<>	01000001	65	41	Α
01000100 68 44 D 01000110 69 45 E 01000110 70 46 F 01000100 72 48 H 01001010 74 4A J 01001010 74 4A J 01001101 75 4B K 01001101 77 4D M 01001101 78 4E N 01001010 78 4E N 01010000 80 50 P 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 84 54 T 01010101 85 55 U 01010101 86 56 V 01010110 86 56 V 01011010 89 59 Y 01011000 88 5	01000010	66	42	В
01000101 69 45 E 01000110 70 46 F 01000111 71 47 G 01001000 72 48 H 01001010 74 4A J 01001011 75 4B K 01001100 76 4C L 01001101 77 4D M 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 82 52 R 01010010 84 54 T 01010101 85 55 U 01010110 86 56 V 01010111 87 57 W 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5	01000011	67	43	С
01000110 70 46 F 010001000 72 48 H 01001001 73 49 I 01001010 74 4A J 01001011 75 4B K 01001101 77 4D M 01001110 78 4E N 01001011 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 84 54 T 01010101 85 55 U 01010101 86 56 V 01010101 89 59 Y 01011001 89 59 Y 01011001 89 59 Y 01011101 91 5B [01011101 93 5D] 010111101 94 <td< td=""><td>01000100</td><td>68</td><td>44</td><td>D</td></td<>	01000100	68	44	D
01000111 71 47 G 01001000 72 48 H 01001001 73 49 I 01001010 74 4A J 01001100 76 4B K 01001101 77 4D M 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 82 54 T 01010101 85 55 U 01010101 86 56 V 01010101 89 59 Y 01011000 88 58 X 01011010 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5	01000101	69	45	E
01001000 72 48 H 01001001 73 49 I 01001010 74 4A J 01001101 75 4B K 01001100 76 4C L 01001101 77 4D M 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 84 54 T 01010101 85 55 U 01010101 86 56 V 01011001 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011101 93 5D J 010111101 93 5D J 010111110 94 <td< td=""><td>01000110</td><td>70</td><td>46</td><td>F</td></td<>	01000110	70	46	F
01001001 73 49 I 01001010 74 4A J 01001011 75 4B K 01001100 76 4C L 01001101 77 4D M 01001110 78 4E N 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010101 83 53 S 01010100 84 54 T 01010101 85 55 U 01010101 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5	01000111	71	47	G
01001010 74 4A J 01001011 75 4B K 01001100 76 4C L 01001101 77 4D M 01001110 78 4E N 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010001 82 52 R 01010010 82 52 R 01010101 83 53 S 01010101 85 55 U 01010101 85 55 U 01010101 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011001 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5	01001000	72	48	Н
01001011 75 4B K 01001100 76 4C L 01001101 77 4D M 01001111 78 4E N 01001011 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010101 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011001 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 6	01001001	73	49	1
01001100 76 4C L 01001101 77 4D M 01001110 78 4E N 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010101 83 53 S 01010101 85 55 U 01010101 85 55 U 01010101 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011001 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011110 94 5E ^ 01100000 96 60 ^ 01100001 98 6	01001010	74	4A	J
01001101 77 4D M 01001110 78 4E N 01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010101 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ^ 01100001 98 62 b 01100010 98 6	01001011	75	4B	K
010011110 78 4E N 010011111 79 4F O 010100000 80 50 P 010100010 81 51 Q 01010010 82 52 R 01010010 83 53 S 01010101 85 55 U 01010101 86 56 V 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ^ 01100001 97 61 A 01100010 98 62 b 01100100 100	01001100	76	4C	L
01001111 79 4F O 01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011100 92 5C \ 01011110 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100100 100	01001101	77	4D	М
01010000 80 50 P 01010001 81 51 Q 01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010110 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011101 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 0100000 96 60 ^ 01100001 97 61 A 01100011 99 63 c 01100010 100 64 d	01001110	78	4E	N
01010001 81 51 Q 01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010110 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 0100000 96 60 ` 01100001 97 61 A 01100011 99 63 c 01100100 100 64 d	01001111	79	4F	0
01010010 82 52 R 01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011100 92 5C \ 010111101 93 5D] 010111101 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100010 100 64 d	01010000	80	50	Р
01010011 83 53 S 01010100 84 54 T 01010101 85 55 U 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011100 92 5C \ 01011110 93 5D] 01011111 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01010001	81	51	Q
01010100 84 54 T 01010101 85 55 U 01010111 86 56 V 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100010 100 64 d	01010010	82	52	R
01010101 85 55 U 01010110 86 56 V 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011101 91 5B [01011100 92 5C \ 010111101 93 5D J 010111101 93 5D J 010111110 94 5E ^ 010111111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100010 99 63 c 01100100 100 64 d	01010011	83	53	S
01010110 86 56 V 01010111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 010111101 93 5D] 010111110 94 5E ^ 010111111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100011 99 63 c 01100100 100 64 d	01010100	84	54	Т
010101111 87 57 W 01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 01011110 93 5D] 01011111 95 5F _ 010100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01010101	85	55	U
01011000 88 58 X 01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01010110	86	56	V
01011001 89 59 Y 01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01010111	87	57	W
01011010 90 5A Z 01011011 91 5B [01011100 92 5C \ 01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011000	88	58	Χ
01011011 91 5B [01011100 92 5C \ 01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 \ 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011001	89	59	Υ
01011100 92 5C \ 01011101 93 5D J 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011010	90	5A	Z
01011101 93 5D] 01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011011	91	5B	[
01011110 94 5E ^ 01011111 95 5F _ 01100000 96 60 ^ 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011100	92	5C	\
01011111 95 5F _ 01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011101	93	5D]
01100000 96 60 ` 01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011110	94	5E	٨
01100001 97 61 A 01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01011111	95	5F	_
01100010 98 62 b 01100011 99 63 c 01100100 100 64 d	01100000	96	60	`
01100011 99 63 c 01100100 100 64 d	01100001	97	61	А
01100100 100 64 d	01100010	98	62	b
	01100011	99	63	С
01100101 101 65 0	01100100	100	64	d
01100101 101 00 6	01100101	101	65	е

Binary	Decimal	Hex	ASCII
01100110	102	66	f
01100111	103	67	g
01101000	104	68	h
01101001	105	69	i
01101010	106	6A	j
01101011	107	6B	k
01101100	108	6C	I
01101101	109	6D	m
01101110	110	6E	n
01101111	111	6F	0
01110000	112	70	þ
01110001	113	71	q
01110010	114	72	r
01110011	115	73	S
01110100	116	74	t
01110101	117	75	u
01110110	118	76	V
01110111	119	77	W
01111000	120	78	X
01111001	121	79	У
01111010	122	7A	Z
01111011	123	7B	{
01111100	124	7C	
01111101	125	7D	}
01111110	126	7E	~
01111111	127	7F	



Web: www.hamiltoncompany.com USA: 800-648-5950 Europe: +41-81-660-60-60

Via Crusch 8 CH-7402 Bonaduz, GR, Switzerland Tel: +41-81-660-60-60 Fax: +41-81-660-60-70 contact@hamilton.ch

To find a representative in your area, please visit hamiltoncompany.com/contacts.