

Flash programming for Neon:

GUI Tool:

Windows OS: Neon_DownloadTool_Windows.exe

Linux OS: Neon_DownloadTool_Linux

Script:

Main script: ./scripts/boot.py

For help run command: python3 boot.py or python3 boot.py -h

Example:

Clear flash:

python3 boot.py --clear_flash

Program Flash: python3 boot.py --app_elf

../apps/hello_world/bin/hello_world.elf --npu_img ../apps/npu/npu.bin --boot_arg
"hio.baudrate=921600 hio.maxsize=1600"

Note:

1. --serial, --app_addr, --npu_addr, and --bootarg_addr can
be provided to override the default flash addresses.

2. All arguments are optional; provide only those that are
required.

Write filesystem image to flash:

python3 boot.py --fs_img ../apps/data.img --fs_addr

0x00580000

Read filesystem image from flash:

python3 boot.py --out_img ./data.img --read_addr 0x00580000

--read_size 0x00280000