Arduino GIGA R1 WiFi + RC522 - Working Wiring Reference

RC522 Pin	Connects To	Details
SDA (SS)	D10	Digital pin on GIGA side header
RST	D9	Digital pin on GIGA side header
3.3V (VCC)	3.3V	3.3V pin on GIGA power rail
GND	GND	Any GND pin on GIGA or SPI header
SCK	SPI Header SCK	Middle LEFT pin on 2x3 SPI header
MOSI	SPI Header MOSI	Middle RIGHT pin on 2x3 SPI header
MISO	SPI Header MISO	Top LEFT pin on 2x3 SPI header

SPI Header Orientation (USB to RIGHT):

[MISO] [5V]

[SCK] [MOSI]

[RESET] [GND]

Do not use the SPI header 5V pin. Always use the 3.3V rail.

SDA (SS) and RST are normal GPIO pins.

SPI.begin() uses these pins automatically.

This is your proven working reference.