Requirements on External interrupt Driver

Team X

Contents

Scope of document:	2
Requirement specifications:	2
Functional Requirements:	2
Configuration and initialization:	2
Normal operation:	3

Scope of document:

This document specifies requirements on the module External interrupt Driver.

Functional overview:

The external interrupt driver initializes External interrupt0, initializes External interrupt1, and initializes External interrupt2

Requirement specifications:

Functional Requirements:

Configuration and initialization:

1- [SRS_External interrupt _1001] The External interrupt driver shall provide a service that initializes the External interrupt 0.

Туре:	Valid
Description:	The External interrupt driver shall provide a service that initializes External interrupt 0
Rationale:	Basic functionality
Use cases	Initialize the External interrupt 0.
Dependencies	
Supporting material	

2- [SRS_External interrupt _1002] The External interrupt driver shall provide a service that initializes the External interrupt 1.

Туре:	Valid
Description:	The External interrupt driver shall provide a service that initializes External interrupt 1
Rationale:	Basic functionality
Use cases	Initialize the External interrupt 1.
Dependencies	**
Supporting material	

3- [SRS_External interrupt _1003] The External interrupt driver shall provide a service that initializes the External interrupt 2.

Туре:	Valid
Description:	The External interrupt driver shall provide a service that initializes External interrupt 2
Rationale:	Basic functionality
Use cases	Initialize the External interrupt 2.
Dependencies	
Supporting material	

Normal operation:

1- [SRS_External interrupt_1004] The External interrupt driver shall provide a service that set call back function

Type:	Valid
Description:	The External interrupt driver shall provide a service that set call ISR function.
Rationale:	Basic functionality
Use cases	Take the address of a function
Dependencies	
Supporting material	