1. **List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.**

No.	Common Issue	Possible Solution
1	Keyboard or mouse is not working.	Unplug the USB cable and reconnect it to another USB port.
2	Some keyboard keys are not responding.	Clean the keyboard and check for dust or dirt under the keys.
3	Mouse cursor is moving slowly or freezing.	Clean the mouse sensor and try using it on a proper mouse pad.
4	USB device is connecting and disconnecting repeatedly.	Check the USB cable and try another USB port.
5	Laptop does not detect the keyboard or mouse.	Restart the laptop and update or reinstall the USB drivers.

2. **Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.**

Step	Action to Perform	What to Check
1. Check battery	Make sure the headphones are charged.	Check the battery indicator or charging light.
2. Turn on Bluetooth	Open phone Settings → Bluetooth and switch Bluetooth ON.	Make sure Bluetooth is enabled.
3. Enable pairing mode	Turn on the headphones and press and hold the Bluetooth/power button until the indicator light flashes.	A flashing blue or red-blue light usually indicates pairing mode.

4. Search for devices	Open Bluetooth settings and tap Pair new device or Scan.	Check whether the headphone name appears in the available devices list.
5. Connect headphones	Tap the headphone name displayed on the phone.	Check whether the status changes to Connected.
6. Disconnect other devices	Turn off Bluetooth on other nearby devices previously connected to the headphones.	Make sure the headphones are not connected to another phone or laptop.
7. Forget and reconnect	If they still don't connect, tap the headphone name, select Forget/Unpair, and pair them again.	Check whether the device appears again in the available devices list.
8. Restart devices	Restart both the phone and headphones, then repeat the pairing process.	Check whether Bluetooth works after restarting.
9. Reset headphones	Follow the manufacturer's instructions to reset the headphones.	Check whether the headphones enter pairing mode again.
10. Test with another phone	Try connecting the headphones to another phone.	This helps identify whether the problem is with the headphones or the original phone.

3. **A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.**

No.	Checklist / Action	What to Check
1.	Check USB connection	Unplug the webcam and reconnect it to another USB port. Make sure the cable is properly connected.

2.	Check Device Manager	Open Device Manager → Cameras or Imaging Devices. Check whether the webcam is listed or shows a warning sign.
3.	Check Camera Privacy Settings	Go to Settings → Privacy → Camera and turn ON camera access for the device.
4.	Check Zoom Permissions	Open Zoom → Settings → Video and make sure Zoom has permission to use the webcam.
5.	Select the Correct Camera	In Zoom → Settings → Video, select the external webcam from the camera dropdown menu.
6.	Update Drivers and Restart	Update the webcam driver through Device Manager, restart the laptop, and try joining the Zoom call again.

4. **You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.**

Step	Action to Perform	What to Check
1.	Open Settings by pressing Windows + I.	Make sure the Windows Settings window opens.
2.	Open Troubleshoot settings by going to Update & Security → Troubleshoot → Additional troubleshooters.	Find the Printer option.
3.	Run the Printer Troubleshooter and select the printer showing offline.	Windows will start checking for printer-related problems.
4.	Follow the instructions displayed on the screen.	Windows may detect connection problems, driver issues, or printing errors.

5.	Apply the recommended fixes suggested by Windows.	Check whether Windows fixes the problem automatically or asks you to perform an action.
6.	Test the printer by printing a test page.	Check whether the printer status changes from Offline to Online.