

West Ring Road Area
Drainage Run within this section:

FW17 - FW29; FW29 - FW37; FW37 - FW PS02; FW37 - FW36; FW36
- FW20; FW20 - FW44; FW44 - FW42; FW42 - FW43; FW43 -
Separator 1; Separator 1 - FW30; FW30 - FW31; FW31 - FWIC6.

SW161 - SW87; SW87 - SW48; SW48 - SW49; SW49 - SW50; SW50
- SW51; SW51 - SW52; SW52 - SW53; SW53 - SW54.

MH120 - MH127; MH127 - MH128; MH128 - MH129; MH129 - MH130;
MH130 - MH119; MH120 - Tank 1.

