GENESIS COUPE(BK) >2010 > G 2.0 DOHC > Body (Interior and Exterior) > General Information > Specifications

Specifications

Hood	Туре	Rear hinged, gas lifter type
Door	Construction	Front hinged, Frameless door construction
	Regulator system	Wire drum type
	Locking system	Pin-fork system
Trunk Lid	Туре	Gas rifter type
Seat Belts	Front	3 point type with Emergency Locking Retractor (E.L.R)
	Rear	3 point type with Emergency Locking Retractor (E.L.R)

Tightening Torques

Items		N.m	Kgf.m	Lb-ft
Trunk	Trunk lid latch	16.7~21.6	1.7~2.2	12.3~15.9
Front doors	Door hinge to body	34.3~41.2	3.5~4.2	25.3~30.4
	Door hinge to door	7.8~19.6	1.0~2.0	7.2~14.5
	Door striker	16.7~21.6	1.7~2.2	12.3~15.9
	Checker to body	16.7~21.6	1.7~2.2	12.3~15.9
	Checker to door	6.9~10.8	0.7~1.1	5.1~8.0
Seat	Front seat mounting bolts	34.3~53.9	3.5~5.5	25.3~39.8
	Rear seat mounting bolts	39.2~53.9	3.5~5.5	25.3~39.8
Seat belt	Front seat belt buckle mounting bolt	39.2~53.9	4.0~5.5	28.9~39.8
	Front seat belt retractor mounting bolt	39.2~53.9	4.0~5.5	28.9~39.8
	Front seat belt lower anchor	39.2~53.9	4.0~5.5	28.9~39.8
	Front seat belt upper anchor	39.2~53.9	4.0~5.5	28.9~39.8
	Rear seat belt anchor attaching bolt	39.2~53.9	4.0~5.5	28.9~39.8
	Rear seat belt retractor mounting bolt	39.2~53.9	4.0~5.5	28.9~39.8

GENESIS COUPE(BK) >2010 > G 2.0 DOHC > Body (Interior and Exterior) > General Information > Special Service Tools

Special Service Tools

Tool (Number and name)	Illustration	Use
09793-21000 Door hinge adjusting wrench		Adjustment, removal and installation of the door hinge
09800-21000 Ornament remover		Trim removal
09853-31000 Headliner clip remover		Headliner clip removal
09861-31100 Sealant cut-out tool		Cutting windshield sealant (use with 09861-31200)
09861-31200 Sealant cutting blade	0	Cutting windshield sealant (use with 09861-31100)
09861-31000 Windshield molding remover		Windshield moding removal
09880-4F000 Hog ring clip installer		Hog ring clip installation



GENESIS COUPE(BK) >2010 > G 2.0 DOHC > Body (Interior and Exterior) > General Information > Troubleshooting

Troubleshooting

Symptom	Suspect Area	Remedy	
Water leaks from sunroof	Dirt accumulation in drain tube	Remove dirt from drain	
	Clogged drain tube	Blow air into drain to remove dirt	
	Broken or dislocated drain tube, defective or cracked clip	Check tube installation and flange contact	
	Deteriorated roof lid weatherstrip	Replace	
	Excessive roof lid-to-body clearance and improperly fitted weatherstrip	Adjust	
Wind noise around sunroof	Loose or deformed deflector, gaps in body work	Retighten adjust or replace	
Noise heard when opening. closing sunroof	Foreign particles lodged in guide rail	Check drive cable and guide rails for foreign particles	
	Loose guide rails and lid	Retighten	
Motor runs but sunroof does not	Foreign particles lodged in guide rail	Adjust or replace	
move or moves only partially	Incorrect engagement of motor pinion with drive cable		
	Decrease in motor's clutch slipping force		
	Increased sunroof sliding resistanceor interference of sunroof with drive cables, weatherstrip, etc. due tomal adjustment of sunroof		
Noise in motor (clutch slipping noise from motor when sunroofls	Incorrect engagement of motor pinion with drive cable	Check pinion installation and retighten motor	
fully opened or closed is not an	Worn out or damaged motor pinion bearing	Replace motor assembly	
unusual noise	Worn out or deformed drive cable	Replace	
Door glass fails to operate up	Incorrect window glass installation	Adjust position	
and down	Damaged or faulty regulator arm or regulator	Correct or replace	
Door does not open or close	Incorrect door installation	Adjust position	
completely	Defective door check assembly	Correct or replace	
	Door hinge requires grease	Apply grease	
Hood does not open or close	Striker and latch not properly aligned	Adjust	
completely	Incorrectly installed hood	Adjust	
	Incorrect hood bumper height	Adjust	
Water leak through windshield	Defective seal	Fill with sealant	
end rear window	Defective flange	Correct	
		1 2 3.1000	