

Document Type	FAQ	
Product ID:	BLNFN100001 (20173009)	
Product Name	BalenaFin	
Product Version	1.0.0	
Document Version	1.0.0	
Author	Carlo Maria Curinga	
State (Draft/Proposed/Approved)	Proposed	

Revision history

Date (dd/mm/yyyy)	Version	Author	Description
10/01/2019	0.0.1	Carlo Maria Curinga	First release

Is Balena Fin compatible with the Raspberry Pi Compute Module with integrated eMMC (CM1, CM3)?

No. Balena Fin is only compatible with the eMMC-less Raspberry Pi compute modules (aka lite)

Is Balena Fin compatible with standard rasbian or its derivates?

It will boot, but some peripherials won't work without some minor modification:

- WiFi+BT: while the balena-fin device tree overlay is merged upstream, you still need to set in in your config.txt (dtoverlay=balena-fin). You also need to compile and install the drivers, a process we are working on simplifying. In the meantime, we can provide you guidance on how to do it yourself
- RTC (Real Time Clock): while the balena-fin device tree overlay is merged upstream, you still need to set in in your config.txt (dtoverlay=balena-fin).
- RGB LED: while the balena-fin device tree overlay is merged upstream, you still need to set in in your config.txt (dtoverlay=balena-fin).
- miniPCle airplane mode switch GPIO: while the balena-fin device tree overlay is merged upstream, you still need to set in in your config.txt (dtoverlay=balena-fin).
- DSI and CSI connectors (camera and display) + automatic HAT identification over I2C: As per the standard Raspberry Pi Foundation design (dt-blob.bin section of https://www.raspberrypi.org/documentation/hardware/computemodule/cm-peri-sw-guide.md) you need to add the Balena Fin dt-blob.bin (https://github.com/resin-io/balena-fin/raw/master/software/dt-blob/dt-blob.bin) in the root of the boot partition

Is Balena Fin HAT compliant?

Yes it is, including power over HAT (5V @2.5A)

Can I deploy Balena Fin in my Raspberry Pi 3 resin.io application?

Yes, we support mixed fleet https://resin.io/blog/evolve-your-fleet-manage-multiple-device-types-in-one-application/

Does the RTC always run on its battery?

No - the RTC only runs on its battery when the device is powered off. This means that the real battery lifetime is way longer than the nominal one.

How can I power Balena Fin?

You can power the board from the DC 5.5/2.1mm barrel jack connector or the 2 position phoenix connector with any input voltage between 6 and 24V with at least 12.5W (that is 12V @1A for example). You can also power Balena Fin from its 5V HAT pins with 5V @2.5A

I cannot see any wireless interface listed, wifi does not work

Please make sure you have the balena-fin device tree overlay set in in your config.txt (dtoverlay=balena-fin).

My HAT does not work on the Balena Fin unless I manually set up things that are automatic on a Raspberry Pi 3

Please make sure you have the Balena Fin dt-blob.bin (https://github.com/resin-io/balena-fin/raw/master/software/dt-blob/dt-blob.bin) in the root of the boot partition

Raspberry Pi camera or display don't work on my Balena Fin

Please make sure you have the Balena Fin dt-blob.bin (https://github.com/resin-io/balena-fin/raw/master/software/dt-blob/dt-blob.bin) in the root of the boot partition

WiFi signal is very weak

Please make sure you have the antenna switch on the right position based on your setup (OFF for internal antenna, ON for external antenna)

My Balena Fin is heating a lot while running my application

The thermal performance of the Raspberry Pi Compute Module 3 Lite (aka CM3L) on Balena Fin has been benchmarked against the reference IO carrier board reference design from the Raspberry Pi Foundation and the Raspberry Pi 3 model B. IF your application does GPU intensive logic we suggest adding an heatsink to the SoC of the CM3L (the ones for the Raspberry Pi 3 model B are compatible)