

Removal (For FJ series)

1. Remove the bolts retaining the engine hood onto the hood hinge, then remove the engine hood.
2. Drain the cooling system.
3. Remove the radiator grille, and the hood lock support rod.
4. Disconnect the hood lock from the radiator support, and remove the radiator support.
5. Disconnect the heater hose from the radiator pipe.
6. Disconnect the radiator upper hose from the water outlet housing, also disconnect the radiator lower hose from the water pump.
7. Remove six retaining bolts, and remove the radiator assembly.
8. Remove the two heater hoses.
9. Disconnect the battery to starter cable and the battery to ground cable from the battery terminals.
10. Disconnect wires from the starter magnetic switch terminal.
11. Disconnect the fuel hoses, and remove the fuel filter assembly.
12. Disconnect the primary wire from the ignition coil terminal.
13. Disconnect the rod end of high and low shift rod from the high and low shift link lever.
14. Remove the air cleaner assembly.
15. Disconnect the wires from the alternator.
16. Disconnect the throttle rod, choke rod and the accelerator rod from the carburetor.
17. Remove the vacuum hose connecting on intake manifold and the check valve of the transfer front drive controller.
18. Disconnect the wires from the water temperature sender gauge unit and the oil pressure sender gauge unit.
19. Remove the nuts, and disconnect the exhaust pipe from the exhaust manifold.
20. Disconnect the parking brake cable from the intermediate lever.
21. Disconnect the front propeller shaft from the transfer output front shaft flange.
22. Remove the engine under covers RH and LH.
23. Remove the transmission under cover.
24. Remove the hole pin, and disconnect the high and low shift rod from the transfer high and low shift inner lever.
25. Remove the high and low shift link lever No.3, and the high and low shift rod.
26. Unhook the clutch release fork spring, and remove the clutch release cylinder assembly from the engine mounting rear bracket.
27. Loosen the clamp screws, and disconnect the vacuum hoses from the transfer diaphragm cylinder.
28. Remove the front drive indicator switch.
29. Disconnect the speedometer drive cable from the transmission.
30. Disconnect the rear propeller shaft from the transmission.