

Age Group	Percentage
18-24	15%
25-34	25%
35-44	35%
45-54	45%
55-64	55%
65-74	65%
75-84	75%
85+	85%

SEVEN SHORT BLASTS FOLLOWED BY ONE PROLONGED BLAST ON THE SHIP'S ALARMS & WHISTLE.
IT'S USED TO CALL PASSENGERS TO THEIR ASSEMBLY STATION DECK 5 LOBBY OR MAIN LOUNGE. WHEN ALL PASSENGERS ARE MUSTERED AT THEIR ASSEMBLY STATION : A CREW ALERT BY PA ANNOUNCEMENT WILL CALL SHIP EVACUATION TEAMS TO JOIN CREW MUSTER STATIONS

LIFERAFTS PREPARATION TEAM 1 609 - 611		BRIDGE TEAM 101 - 102 - 209	
LIFERAFTS PREPARATION TEAM 2 610 - 612			
LIFEBOATS No. 1 PREPARATION TEAM 113 - 121 - 213		EVACUATION LEADER 301	
LIFEBOATS No. 2 PREPARATION TEAM 114 - 120 - 214			
RESCUE BOATS PREPARATION TEAM 123 - 215			ADA TEAM 132 - 306 - 307 629 - 630 - 920 921 - 922
LSA TEAM SUPERVISOR 107		ADMIN TEAM 303 - 310	
POLAR KITS PREPARATION TEAM 111 - 117 - 119 - 124			
CROWD CONTROL TEAM 801 - 304 - 305 - 901 - 902 & Expedition guides			A: LOBBY DECK 5
			B: MAIN LOUNGE DECK 5
ASSEMBLY STATION A LEADER 601 - 608			C: SECONDARY MUSTER STATION RESTAURANT DECK 5
ASSEMBLY STATION A TEAM 309 - 313 - 405 - 503 - 505 - 507 - 509			
ASSEMBLY STATION B LEADER 501 - 311			
ASSEMBLY STATION B TEAM 308 - 312 - 502 - 504 - 506 - 508 - 510			

CREW ASSEMBLY STATION CONTROLLER A
403 - 605 - 433
CREW ASSEMBLY STATION CONTROLLER B
402 - 606 - 432

- IF NECESSARY, YOU CAN FIND EXTRA SURVIVAL SUITS IN THE BOXES LOCATED AT LIFEBOATS DECK PORTSIDE & STARBOARD-SIDE.

© 2007 The Authors

IN BOTH MUSTER STATIONS , PASSENGERS AND CREW MEMBERS WILL BE DIRECTED TOWARD LIFEBOATS. EACH LIFEBOATS HAVE AN EQUAL DISTRIBUTION OF ITS 115 SEATS CAPACITY BETWEEN PASSENGERS & CREW MEMBERS. DISTRIBUTION PLAN MUST BE DONE AS FOLLOW.

ASSEMBLY STATION A						ASSEMBLY STATION B					
125 PASSENGERS & 107 CREW MEMBERS**						125 PASSENGERS & 103 CREW MEMBERS **					
LIFEBOAT STATION 1 - STARBOARD SIDE DECK 5						LIFEBOAT STATION 2 - PORTSIDE DECK 5					
LIFEBOAT 1 - 115 PERS			LIFEBOAT 3 - 115 PERS			LIFEBOAT 2 - 115 PERS			LIFEBOAT 4 - 115 PERS		
64 PAX + 51 CREW MEMBERS + 3 ADDITIONALS			61 PAX + 54 CREW MEMBERS + 2 ADDITIONALS			65 PAX + 50 CREW MEMBERS + 3 ADDITIONALS			60 PAX + 51 CREW MEMBERS + 2 ADDITIONALS		
PASSENGER CABINS:			PASSENGER CABINS:			PASSENGER CABINS:			PASSENGER CABINS:		
DECK 7 MVZ 3 STB DECK 8 MVZ 4 DECK 8 MVZ 3 STB			DECK 6 MVZ 4 DECK 6 MVZ 3 STB DECK 7 MVZ 4			DECK 6 MVZ 3 PS DECK 7 MVZ 3 PS DECK 6 MVZ 2			DECK 8 MVZ 2 DECK 8 MVZ 3 PS DECK 7 MVZ 2		
CREW MEMBERS :			CREW MEMBERS :			CREW MEMBERS :			CREW MEMBERS :		
105	431	713	101	305	611	106	424	712	104	306	618
109	503	715	107	307	617	114	430	714	108	308	626
121	505	721	111	309	619	120	502	720	112	312	628
123	507	723	113	313	627	122	504	722	116	316	706
127	509	725	115	401	629	132	506	724	118	318	708
133	603	801	117	403	707	214	508	802	124	402	716
135	605	803	119	405	709	220	602	804	126	406	718
211	608	805	125	407	717	222	604	810	128	408	726
213	613	811	129	409	719	304	606	812	130	416	806
221	615	901	131	415	727	311	614	904	134	418	808
303	621	903	201	417	807	314	620	910	202	426	902
310	623	905	203	419	809	319	622	912	206	428	906
315	625	911	205	425	907	404	624	914	208	432	908
317	631	913	207	427	909	410	630	920	210	501	916
411	701	915	209	429	917	412	632	922*	212	510	918
413	703	921*	215	433	919	414	702	924*	216	610	926*
421	705	923*	217	601	927*	420	704	930*	218	612	928*
423	711	925*	219	607	929*	422	710		302	616	
			301	609					Including Liferaft Commanders & 2nd in Command		
			Including Liferaft Commanders & 2nd in Command								
			203	207	209						
			119	125	117				216	124	118

** Total number of crew members in assembly stations take in account 4 crew abandoning in Rescue boats

1	LIFEBOAT No. 1 PASSENGERS CREW MEMBERS + ADDITIONALS	VHF SART EPIRB
	NAVIGATION OFFICER: COMMANDER	
	105	
	LIFEBOAT TECHNICAL CREW	
	121 - 123 - 213	
	ASSEMBLY STATION CREW	
	608 - 503 - 505 - 507 - 509	
	CROWD CONTROL TEAM	
	801	
	MEDICAL TEAM ONLY IF DIRECTED	



LIFEBOAT No. 2 PASSENGERS CREW MEMBERS + ADDITIONALS	VHF SART EPIRB
OSSE OFFICER : COMMANDER	
106	
LIFEBOAT TECHNICAL CREW	
120 - 122 - 214	
ASSEMBLY STATION CREW	
311 - 502 - 504 - 506 - 508	
CROWD CONTROL TEAM	
304	
MEDICAL TEAM	
132	

3	LIFEBOAT No.3 PASSENGERS CREW MEMBERS + ADDITIONALS	VHF SART EPIRB
	EXPEDITION OFFICER: COMMANDER	
	107	
	LIFEBOAT TECHNICAL CREW	
	205 - 113 - 115 - 215	
	ASSEMBLY STATION CREW	
	601 - 309 - 313 - 315	
	CROWD CONTROL TEAM	
	305	
	MEDICAL TEAM	
	131	



LIFEBOAT No. 4 PASSENGERS CREW MEMBERS + ADDITIONALS	VHF SART EPIRB
JUNIOR OFFICER 1: COMMANDER	
108	
LIFEBOAT TECHNICAL CREW	
104 - 112 - 116 - 212	
ASSEMBLY STATION CREW	
501 - 510 - 308 - 312	
CROWD CONTROL TEAM	
902	
MEDICAL TEAM	
130	

IN CASE OF LIFEBOAT LAUNCHING SYSTEM FAILURE OR ANY SITUATIONAL ISSUE OF ONE LIFEBOAT, PASSENGERS & CREW MEMBERS ARE DIRECTED TO LIFERAFT STATIONS.

LIFERAFT STATION 1				
	COMMANDER	2ND IN COMMAND	CAPACITY	
			NON POLAR AREA	POLAR AREA
1	203	119	25 PERS	20 PERS
3	207	125	25 PERS	20 PERS
5	209	117	25 PERS	20 PERS



LIFERAFT STATION 2				
CAPACITY		COMMANDER	2ND IN COMMAND	
NON POLAR AREA	POLAR AREA			
25 PERS	20 PERS	210	216	2
25 PERS	20 PERS	206	124	4
25 PERS	20 PERS	202	118	6



GMDSS VHF EPIRB & SART	RESCUE BOAT STATION 1	
1	FIRST OFFICER: COMMANDER	103
	BOSUN : 2ND IN COMMAND	110

RESCUE BOAT STATION 2		GMDSS VHF EPIRB & SART
STAFF CAPTAIN : COMMANDER	102	2
HOTEL ENGINEER : 2ND IN COMMAND	204	