

Camera View

The camera view display may differ depending on the shooting mode. This display is for reference only.



1. Home

⌂ : tap to return to the home screen.

2. Wi-Fi

WiFi : displays Wi-Fi connection.

3. Battery Level

99% : displays the current battery level of Osmo Action 4.

4. microSD Card Information

SD 59:59 : displays either the remaining number of photos that can be taken or the video duration that can be recorded according to the current shooting mode.

5. Custom Mode

👤 : tap ⚙️ and tap 📸 to save the current configuration as a custom mode. Save the shooting parameters in the custom mode, which can then be used directly to shoot similar scenes. Users can save up to five custom modes.

6. Shutter/Record Button

📸 : tap to take a photo or to start or stop recording a video.