MFTD/FBS 3 · A320

TRAINEE A

APU inoperative · alternate engine starts

MEL 49-10-01A · Power Plant (APU)

FCOM · Engine Start With An Air Start Unit → Crossbleed Engine Start

AIR START UNIT · ENGINE 2

Before connecting the air start unit:

PACK 1	OFF
PACK 2	OFF
APU BLEED	OFF
ENG 1 BLEED	OFF
ENG 2 BLEED	OFF
X BLEED	OPEN
AIR START UNIT CONNECTION	REQUEST

↓

When cleared to start:

Captain	"CLEAR TO START ?"
GND	"CLEAR TO START"
Captain	"STARTING ENG(S)__"

↓

ENG 2 ..... START

Starter air ≥25 PSI recommended with start valve open.

↓

After engine 2 is started:

EXT PWR ..... CHECK AVAIL

EXT PWR DISCONNECTION ..... REQUEST

Request disconnection only with EXT PWR pb-sw at AVAIL.

↓

CROSSBLEED · CHANGE AIR SUPPLY

If crossbleed start is used for engine 1:

AIR START UNIT DISCONNECTION	REQUEST
PACK 1	ON
PACK 2	ON
ENG 2 BLEED	ON

↓

No crossbleed start during pushback; no simultaneous engine bleed and external pneumatic supply.

↓

CROSSBLEED · ENGINE 1 START

Before second engine start:

APU BLEED	OFF
ENG 2 BLEED	ON
ENG 1 BLEED	OFF
X BLEED	OPEN

↓

When cleared to start:

Captain	"CLEAR TO START ?"
GND	"CLEAR TO START"

↓

AREA CLEAR OF OBSTACLES ..... CONFIRM

THR LEVER (ENG 2) ..... ADJUST

ENG 2 bleed 30 PSI before start; ≥25 PSI during. Confirm jet blast poses no hazard.

↓

Captain "STARTING ENG(S)__"

↓

RECEIVING ENGINE (ENG 1) ..... START

Apply normal engine start procedure.

↓

After start:

THR LEVER (ENG 2)	IDLE
X BLEED	AUTO
ENG 1 BLEED	ON
PACK 1	ON
PACK 2	ON

↓

SOP — AFTER START · RESUME

MANUAL REFERENCES

MEL · item 49-10-01A · MI-49-10 p. 1/2 · PDF p. 1014

FCOM · Air start unit · PRO-NOR-SUP-ENG p. 10/18 · PDF p. 4395

FCOM · Air start to crossbleed · PRO-NOR-SUP-ENG p. 11/18 · PDF p. 4396

FCOM · After Start SOP · PRO-NOR-SOP-09 p. 1/12 · PDF p. 4142

MEL · APU operational procedure · MO-49-10 pp. 1–2/2 · PDF pp. 1554–1555

FCOM · Engine-start ground callouts · PRO-NOR-SCO p. 6/10 · PDF p. 4315

FCOM · Crossbleed engine start · PRO-NOR-SUP-ENG pp. 12–13/18 · PDF pp. 4397–4398

MFTD/FBS 3 · A320

TRAINEE B · IF SIMULATED

Loss of braking

[MEM] LOSS OF BRAKING

If no braking:

Crew — **“LOSS OF BRAKING”**

↓

REV ..... **MAX**

(PF) **BRAKE PEDALS** ..... **RELEASE**

↓

PF — **“A/SKID OFF”**

↓

(PM) **A/SKID & N/W STRG** ..... **OFF**

BRAKE PEDALS ..... **PRESS**

MAX BRK PR ..... **1 000 PSI**

↓

If still no braking:

PARK BRAKE ..... **USE**

Short successive applications until stopped.

↓

When stopped and runway vacated, resume After Landing SOP.

MANUAL REFERENCES

FCOM · Loss of braking · PRO-ABN-BRAKES p. 1/22 · PDF p. 3024
FCOM · Memory-item callout · PRO-ABN-ABN-00 p. 10/12 · PDF p. 2833
FCOM · After Landing SOP · PRO-NOR-SOP-21 p. 1/8 · PDF p. 4288