MFTD/FBS 4 · A320

TRAINEE A

Wing tank pump failures · gravity feed

FCOM · FUEL L (R) TK PUMP 1(2) LO PR → FUEL L (R) TK PUMP 1 + 2 LO PR
QRH · GRAVITY FUEL FEEDING

ONE AFFECTED WING TANK PUMP

FUEL L (R) TK PUMP 1(2) LO PR:

PF “ECAM ACTION”

↓

TK PUMP (AFFECTED) ..... OFF

↓

PM “CLEAR FUEL ?”
PF “CLEAR FUEL”

↓

Review STATUS: INOP SYS TK PUMP (affected).

↓

PF “REMOVE STATUS”
PM “ECAM ACTIONS COMPLETE”

↓

BOTH PUMPS ON THE SAME WING TANK

FUEL L (R) TK PUMP 1 + 2 LO PR:

PF “ECAM ACTION”

↓

HS-TXA–O, center tank not empty:

FUEL MODE SEL (IF CTR TK NOT FEEDING) ..... MAN
TK PUMP 1 (AFFECTED) ..... OFF
TK PUMP 2 (AFFECTED) ..... OFF

HS-TXA–O · center tank not empty

↓

HS-TXA–O with center tank empty, or HS-TXP–U: if no fuel leak:

FUEL X FEED (IF ABOVE FL150) ..... ON
ENG MODE selector ..... IGN
TK PUMP 1 (AFFECTED) ..... OFF
TK PUMP 2 (AFFECTED) ..... OFF

HS-TXA–O empty · HS-TXP–U

↓

When affected tank fuel is required:

TK (AFFECTED) FEED ..... GRVTY ONLY

Continued on next page →

MFTD/FBS 4 · A320

TRAINEE A · CONTINUED

Wing tank pump failures · gravity feed

FCOM · FUEL L (R) TK PUMP 1(2) LO PR → FUEL L (R) TK PUMP 1 + 2 LO PR
QRH · GRAVITY FUEL FEEDING

QRH · GRAVITY FUEL FEEDING

On gravity feed:

- **ENG MODE SEL** ..... **IGN**
- **NEGATIVE G FACTOR** ..... **AVOID**

↓

HS-TXA–T gravity-feed ceiling:

- **>30 min above FL300** ..... **CURRENT FL**
- **<30 min above FL300** **FL300**
- **FL300 never exceeded** .... **HIGHER: FL150 or T/O airport +7 000 ft**
- **JET B fuel** **FL100**

HS-TXA–T

↓

HS-TXU gravity-feed ceiling:

- **>30 min above FL300** **FL360**
- **<30 min above FL300** **FL260**
- **FL300 never exceeded** .... **HIGHER: FL150 or T/O airport +7 000 ft**

HS-TXU

↓

When reaching gravity-feed ceiling:

- **FUEL X FEED** ..... **OFF**

↓

HS-TXA–O empty, or HS-TXP–U: if below FL150:

- **FUEL X FEED** ..... **OFF**

HS-TXA–O empty · HS-TXP–U

↓

- **PM** **“CLEAR FUEL ?”**
- **PF** **“CLEAR FUEL”**

↓

Review STATUS: affected pumps inoperative; gravity feed only. Center tank feed MAN only where applicable.

↓

- **PF** **“REMOVE STATUS”**
- **PM** **“ECAM ACTIONS COMPLETE”**

↓

Resume the applicable Cruise or Initial Approach SOP · monitor fuel and flight path.

MANUAL REFERENCES

FCOM · FUEL L (R) TK PUMP 1(2) LO PR · PRO-ABN-FUEL p. 53/76 · PDF p. 3658

FCOM · FUEL L (R) TK PUMP 1 + 2 LO PR · PRO-ABN-FUEL pp. 54–55/76 · PDF pp. 3659–3660

FCOM · FUEL L (R) TK PUMP 1 + 2 LO PR · center tank not empty · PRO-ABN-FUEL pp. 58–59/76 · PDF pp. 3663–3664

FCOM · Cruise SOP · PRO-NOR-SOP-15 p. 1/4 · PDF p. 4198

FCOM · ECAM abnormal callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831

FCOM · FUEL L (R) TK PUMP 1 + 2 LO PR · center tank empty · PRO-ABN-FUEL pp. 56–57/76 · PDF pp. 3661–3662

QRH · Gravity Fuel Feeding · ABN-21 pp. 21.10A–B · PDF pp. 206–207

FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224

MFTD/FBS 4 · A320

TRAINEE A

Engine failure · successful in-flight relight

FCOM · ENG 1(2) FAIL
QRH · ENG RELIGHT IN FLIGHT

ENG 1(2) FAIL in flight, with no damage:

PF “ECAM ACTION”

↓

ENG MODE SEL ..... IGN
THR LEVER (AFFECTED ENGINE) ..... IDLE

↓

If no engine relight after 30 s from alert:

ENG MASTER (AFFECTED ENGINE) ..... OFF

↓

If no damage and no relight:

Apply QRH ENG RELIGHT IN FLIGHT; check the QRH engine-relight envelope for current altitude and airspeed.

↓

ENG MASTER (AFFECTED ENGINE) ..... OFF
THR LEVER (AFFECTED ENGINE) ..... IDLE
ENG MODE selector ..... IGN
X BLEED ..... OPEN

↓

For starter-assisted relight:

WING ANTI-ICE ..... OFF

↓

ENG MASTER (AFFECTED ENGINE) ..... ON
ENG PARAMETERS (N2, EGT) ..... MONITOR

Light-up should occur within 30 s after fuel flow increases. Automatic start abort is unavailable.

↓

When idle is reached (ENG AVAIL):

ENG MODE selector ..... NORM
TCAS MODE selector ..... TA/RA
X BLEED ..... AUTO
Affected SYS ..... RESTORE

↓

PM “ECAM ACTIONS COMPLETE”

↓

Resume the applicable Cruise or Initial Approach SOP · review engine and flight path.

MANUAL REFERENCES

FCOM · ENG 1(2) FAIL · PRO-ABN-ENG pp. 84–86/226 · PDF pp. 3331–3333
QRH · ENG RELIGHT IN FLIGHT · ABN-19 pp. 19.06B–C · PDF pp. 175–176
FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224
FCOM · ECAM abnormal callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831
FCOM · Cruise SOP · PRO-NOR-SOP-15 p. 1/4 · PDF p. 4198

MFTD/FBS 4 · A320

TRAINEE A

IDG oil low pressure or overheat

FCOM · ELEC IDG 1(2) OIL LO PR/OVHT

ELEC IDG 1(2) OIL LO PR/OVHT:

PF “ECAM ACTION”

↓

IDG (AFFECTED) ..... **OFF**

Engine at or above idle. Hold IDG pb until GEN FAULT; do not exceed 3 s.

↓

PM “CLEAR ELEC ?”

PF “CLEAR ELEC”

↓

Review STATUS: GEN 1(2) inoperative; CAT 3 SINGLE ONLY. APU GEN may be used if available.

↓

PF “REMOVE STATUS”

PM “ECAM ACTIONS COMPLETE”

↓

Resume Initial Approach SOP · monitor flight path and approach phase.

MANUAL REFERENCES

FCOM · ELEC IDG 1(2) OIL LO PR/OVHT · PRO-ABN-ELEC pp. 117–118/122 · PDF pp. 3242–3243
FCOM · ECAM abnormal callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831
FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224

MFTD/FBS 4 · A320

TRAINEE B

Manual engine start

FCOM · MANUAL ENGINE START - PROCEDURE

For a manual engine start:

- THR LEVERS ..... IDLE
- ENG MODE sel ..... NORM THEN IGN/START

↓

Engine start occurs regardless of thrust-lever position; a non-idle setting can cause hazardous thrust.

↓

When ready and cleared to start:

- Captain — “CLEAR TO START ?”
- GND — “CLEAR TO START”
- Captain — “STARTING ENG(S)__”

↓

When all engine parameters except N1/N2 are available, with no amber crosses:

- ENG MAN START pb-sw ..... ON
- START VALVE ..... CHECK IN-LINE
- N2 INCREASE ..... CHECK
- OIL PRESS INCREASE ..... CHECK

↓

At maximum motoring speed (N2 ≥16 %) and 30 s after MAN START ON:

- ENG MASTER ..... ON
- (PM) CHRONO ..... START
- IGNITERS A AND B ..... CHECK ON
- FUEL FLOW INCREASE ..... CHECK

↓

Within 20 s after fuel flow increases:

- EGT INCREASE ..... CHECK
- N1 INCREASE (BEFORE 34 % N2) ..... CHECK

↓

At N2 43 % / slightly above:

- IGNITERS A AND B (AT 43 % N2) ..... CHECK OFF
- START VALVE (SLIGHTLY ABOVE 43 % N2) ..... CHECK CROSS LINE
- MAIN ENG PARAMETERS ..... CHECK NORMAL
- SECONDARY ENG PARAMETERS ..... CHECK NORMAL
- ENG MAN START pb-sw ..... OFF
- ENG MODE sel ..... NORM

↓

When no other engine requires manual start:

- SHEDDED SYSTEMS ..... RESTORE

↓

SOP – ENGINE START · RESUME

MANUAL REFERENCES

FCOM · Manual Engine Start - Procedure · PRO-NOR-SUP-ENG pp. 6–8/18 · PDF pp. 4391–4393

FCOM · Engine-start ground callouts · PRO-NOR-SCO p. 6/10 · PDF p. 4315

MFTD/FBS 4 · A320

TRAINEE B

Cabin pressure controller fault

FCOM · CAB PR SYS 1(2) FAULT

CAB PR SYS 1(2) FAULT:

PF “ECAM ACTION”

↓

Crew awareness: cabin pressure controller 1(2) failed.

↓

PM “CLEAR CAB PR ?”

PF “CLEAR CAB PR”

↓

Review STATUS: INOP SYS CAB PR 1(2).

↓

PF “REMOVE STATUS”

PM “ECAM ACTIONS COMPLETE”

↓

Resume Initial Approach SOP · monitor flight path and approach phase.

MANUAL REFERENCES

FCOM · CAB PR SYS 1(2) FAULT · PRO-ABN-CAB_PR p. 11/14 · PDF p. 3058
FCOM · ECAM abnormal callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831
FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224