MFTD/FBS 5 · A320

TRAINEE A

Hot start · automatic start fault

FCOM · ENG 1(2) START FAULT
FCOM · AUTOMATIC ENGINE START → MANUAL ENGINE START

On ground during automatic start: ENG 1(2) START FAULT — EGT OVERLIMIT:

PF **“ECAM ACTION”**

↓

Monitor the FADEC automatic start abort and dry crank; ECAM displays AUTO CRANK IN PROGRESS.

↓

When dry crank is completed:

ENG MASTER (AFFECTED) ..... **OFF**

Confirms automatic start abort.

↓

After starter cooling, use Manual Engine Start for any new attempt, or report the no-start condition to maintenance.

↓

PM **“ECAM ACTIONS COMPLETE”**

↓

If a subsequent start succeeds, resume After Start SOP.

MANUAL REFERENCES

FCOM · ENG 1(2) START FAULT · PRO-ABN-ENG pp. 186–188/226 · PDF pp. 3433–3435
FCOM · Automatic Engine Start · PRO-NOR-SOP-08 pp. 1–2/6 · PDF pp. 4136–4137
FCOM · Abnormal and emergency callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831
FCOM · Manual Engine Start · PRO-NOR-SUP-ENG pp. 6–8/18 · PDF pp. 4391–4393
FCOM · After Start SOP · PRO-NOR-SOP-09 p. 1/12 · PDF p. 4142

MFTD/FBS 5 · A320

TRAINEE Both

Slats fault or locked · slats below 1

FCOM · F/CTL SLATS FAULT/LOCKED
FCOM · F/CTL FLAPS/SLATS FAULT/LOCKED
QRH · LANDING WITH SLATS OR FLAPS JAMMED

F/CTL SLATS FAULT or SLATS LOCKED before extension; check actual slat position:

PF — "ECAM ACTION"

↓

If slats locked:

MAX SPEED ..... REFER

Use the HS-TX FCOM speed table for actual slat/flap position; limited to VFE for next slat position.

↓

If slats not locked, when speed is below VFE:

FLAPS LEVER ..... RECYCLE

Return to previous selection, then back to desired position.

↓

HS-TXA-O, if slats are not at zero:

FUEL MODE SEL ..... MAN
CTR TK PUMPS ..... AS RQRD

Set center pumps OFF when the center tank is empty or during approach.

HS-TXA–O · slats not at zero

↓

If slats extended:

Fuel consumption increases and FMS fuel predictions are unreliable.

↓

If recovery is unsuccessful:

Apply QRH LANDING WITH SLATS OR FLAPS JAMMED; determine the landing flap lever position and landing distance.

↓

LDG DIST PROC ..... APPLY
SPD SEL ..... VFE NEXT − 5 kt

At VFE NEXT, select FLAPS lever one step down; repeat until landing configuration.

↓

In landing configuration and final approach:

SPEED ..... CALCULATED VAPP
AP BELOW 500 ft AGL ..... DO NOT USE

↓

PM — "CLEAR FLIGHT CONTROLS ?"
PF — "CLEAR FLIGHT CONTROLS"

↓

S/F JAMMED PROC ..... APPLY
FOR LDG ..... FLAP LVR 3
CTR TK PUMPS ..... OFF
GPWS LDG FLAP 3 (IN CONF 3) ..... ON
APPR SPD ..... REFER
LDG DIST PROC ..... APPLY

Use the actual slat/flap position for the FCOM approach-speed table.

HS-TXA–O · STATUS

↓

S/F JAMMED PROC ..... APPLY
FOR LDG ..... FLAP LVR 3
GPWS LDG FLAP 3 (IN CONF 3) ..... ON
APPR SPD ..... REFER
LDG DIST PROC ..... APPLY

Use the actual slat/flap position for the FCOM approach-speed table.

HS-TXP–U · STATUS

↓

PF — "REMOVE STATUS"
PM — "ECAM ACTIONS COMPLETE"

↓

Resume the applicable Initial Approach SOP with the jammed-slats landing configuration.

MANUAL REFERENCES

FCOM · F/CTL SLATS FAULT/LOCKED · HS-TXA–O · PRO-ABN-F_CTL pp. 99–101/132 · PDF pp. 3572–3574

FCOM · Abnormal and emergency callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831

QRH · Landing with Slats or Flaps Jammed · ABN-20 pp. 20.02B–D · PDF pp. 188–190

FCOM · F/CTL SLATS FAULT/LOCKED · HS-TXP–U · PRO-ABN-F_CTL pp. 102–104/132 · PDF pp. 3575–3577

FCOM · F/CTL FLAPS/SLATS FAULT/LOCKED · speed tables · PRO-ABN-F_CTL p. 59/132 · PDF p. 3532

FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224

MFTD/FBS 5 · A320

TRAINEE A

Aft cargo smoke

FCOM · SMOKE AFT CARGO SMOKE

SMOKE AFT CARGO SMOKE in flight:

PF “ECAM ACTION”

↓

LAND ASAP ..... APPLY

↓

If the aft isolation valve has not closed automatically:

AFT ISOL VALVE ..... OFF

↓

CAB FANS ..... OFF

AGENT 1 ..... DISCH

↓

After 60 min:

AGENT 2 ..... DISCH

↓

The smoke warning may remain after agent discharge even if the source is extinguished.

↓

PM “CLEAR SMOKE ?”

PF “CLEAR SMOKE”

↓

Review STATUS: before opening cargo doors on ground, passengers disembark.

↓

PF “REMOVE STATUS”

PM “ECAM ACTIONS COMPLETE”

↓

On ground, before opening the affected cargo door:

PAX ..... DISEMBARK

Keep the affected cargo door closed until passengers disembark and fire services are present.

↓

When the aircraft is secured, resume the applicable After Landing SOP and fire-service coordination.

MANUAL REFERENCES

FCOM · SMOKE AFT CARGO SMOKE · PRO-ABN-SMOKE pp. 31–33/50 · PDF pp. 3988–3990

FCOM · After Landing SOP · PRO-NOR-SOP-21 p. 1/8 · PDF p. 4288

FCOM · Abnormal and emergency callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831

MFTD/FBS 5 · A320

TRAINEE A

Emergency evacuation · decision and action

FCOM / QRH · EMER EVAC
FCTM · EMER EVAC task sharing

After landing, when considering an emergency evacuation:

Captain **"I HAVE CONTROL"**

↓

F/O **AIRCRAFT / PARKING BRK** ..... **STOP / ON**
F/O **ATC (VHF1)** ..... **NOTIFY**

State the emergency and intentions.

↓

Captain **CABIN CREW (PA)** ..... **ALERT**

Warn that evacuation may be required.

↓

Only if MAN CAB PR was used:

F/O **ΔP** ..... **CHECK ZERO**

↓

If ΔP is not zero:

F/O **CAB PR MODE SEL** ..... **MAN**
F/O **V/S CTL** ..... **FULL UP**

↓

F/O **ALL ENG MASTERS** ..... **OFF**
F/O **ALL FIRE pb (ENGs & APU)** ..... **PUSH**
F/O **ALL AGENTS (ENGs & APU)** ..... **AS RQRD**

Use agents when ENG FIRE or APU FIRE is displayed; Engine Agent 2 is unavailable.

↓

Captain decides evacuation is required:

Captain **EVACUATION** ..... **INITIATE**

Order evacuation over PA, press EVAC COMMAND, and advise ATC if required.

↓

If evacuation is not required:

Captain **CABIN CREW AND PASSENGERS (PA)** ..... **NOTIFY**

↓

If evacuation was not initiated, resume the applicable Parking SOP; otherwise continue evacuation response.

MANUAL REFERENCES

FCOM · [QRH] EMER EVAC · PRO-ABN-MISC p. 16/30 · PDF p. 3811
FCTM · EMER EVAC · PR-AEP-MISC pp. 6–7/32 · PDF pp. 451–452
QRH · EMER EVAC · C2 · PDF pp. 294–295
FCOM · Parking SOP · PRO-NOR-SOP-22 p. 1/8 · PDF p. 4298

MFTD/FBS 5 · A320

TRAINEE B

Engine failure · successful in-flight relight

FCOM · ENG 1(2) FAIL
QRH · ENG RELIGHT IN FLIGHT

ENG 1(2) FAIL in flight, with no damage:

PF — **"ECAM ACTION"**

↓

- **LAND ASAP** ..... **APPLY**
- **ENG MODE SEL** ..... **IGN**
- **THR LEVER (AFFECTED ENGINE)** ..... **IDLE**

↓

If no engine relight after 30 s from alert:

- **ENG MASTER (AFFECTED ENGINE)** ..... **OFF**

↓

If no damage and no relight:

Check the QRH engine-relight envelope for current altitude and airspeed.

↓

- **ENG MASTER (AFFECTED ENGINE)** ..... **OFF**
- **THR LEVER (AFFECTED ENGINE)** ..... **IDLE**
- **ENG MODE selector** ..... **IGN**
- **X BLEED** ..... **OPEN**

↓

For starter-assisted relight:

- **WING ANTI-ICE** ..... **OFF**

↓

- **ENG MASTER (AFFECTED ENGINE)** ..... **ON**
- **ENG PARAMETERS (N2, EGT)** ..... **MONITOR**

Light-up should occur within 30 s after fuel flow increases; automatic start abort is unavailable.

↓

When idle is reached (ENG AVAIL):

- **ENG MODE selector** ..... **NORM**
- **TCAS MODE selector** ..... **TA/RA**
- **X BLEED** ..... **AUTO**
- **Affected SYS** ..... **RESTORE**

↓

PM — **"ECAM ACTIONS COMPLETE"**

↓

Resume the applicable Cruise or Initial Approach SOP; monitor the engine and flight path.

MANUAL REFERENCES

FCOM · ENG 1(2) FAIL · PRO-ABN-ENG pp. 84–86/226 · PDF pp. 3331–3333

QRH · ENG RELIGHT IN FLIGHT · ABN-19 pp. 19.06B–C · PDF pp. 175–176

FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224

FCOM · Abnormal and emergency callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831

FCOM · Cruise SOP · PRO-NOR-SOP-15 p. 1/4 · PDF p. 4198

MFTD/FBS 5 · A320

TRAINEE B

Yellow hydraulic reservoir low level

FCOM · HYD Y RSVR LO LVL

HYD Y RSVR LO LVL:

PF — **“ECAM ACTION”**

↓

PTU ..... **OFF**
YELLOW ENG 2 PUMP ..... **OFF**
YELLOW ELEC PUMP ..... **OFF**
BRK Y ACCU PR ..... **MONITOR**

↓

If yellow brake accumulator pressure is lost:

Only green-pressure normal braking remains; do not use the unavailable parking brake. Chocks must be in place before engine 1 shutdown.

↓

PM — **“CLEAR HYDRAULIC ?”**
PF — **“CLEAR HYDRAULIC”**

↓

Review STATUS: apply landing distance procedure; note YELLOW HYD, spoilers 2 + 4, nosewheel steering, and reverser 2 inoperative.

↓

PF — **“REMOVE STATUS”**
PM — **“ECAM ACTIONS COMPLETE”**

↓

Resume Initial Approach SOP with the applicable landing distance and braking plan.

MANUAL REFERENCES

FCOM · HYD Y RSVR LO LVL · PRO-ABN-HYD pp. 33–35/76 · PDF pp. 3722–3724
FCOM · Abnormal and emergency callouts · PRO-ABN-ABN-00 p. 8/12 · PDF p. 2831
FCOM · Parking SOP · PRO-NOR-SOP-22 p. 1/8 · PDF p. 4298
FCOM · Initial Approach SOP · PRO-NOR-SOP-18-B p. 1/12 · PDF p. 4224

MFTD/FBS 5 · A320

TRAINEE B

Loss of braking

FCOM · [MEM] LOSS OF BRAKING

If no braking:

Crew — **“LOSS OF BRAKING”**

↓

REV ..... **MAX**

(PF) **BRAKE PEDALS** ..... **RELEASE**

↓

PF — **“A/SKID OFF”**

↓

(PM) **A/SKID & N/W STRG** ..... **OFF**

BRAKE PEDALS ..... **PRESS**

MAX BRK PR ..... **1 000 PSI**

↓

If still no braking:

PARK BRAKE ..... **USE**

Use short successive applications until stopped.

↓

When stopped and runway vacated, resume After Landing SOP.

MANUAL REFERENCES

FCOM · [MEM] LOSS OF BRAKING · PRO-ABN-BRAKES p. 1/22 · PDF p. 3024
FCOM · Memory-item callout · PRO-ABN-ABN-00 p. 10/12 · PDF p. 2833
FCOM · After Landing SOP · PRO-NOR-SOP-21 p. 1/8 · PDF p. 4288