









CM4_Reset	CM4_Enable
(float = normal work)	(float = normal work)
GND_CM4	GND_CM4
Wifi_Off	OTG to Host
(float = normal work)	(float = normal slave)
GND_CM4	GND_CM4
GND_CM4	Boot_Mode_CM4 (float = normal work) (GND = Bootloader)
UART0_DEBUG_TX	GND_CM4
UART0_DEBUG_RX	Bluetooth_Off (float = normal work
GND_CM4	GND_CM4
3V3 STM32	3V3 STM32
GND STM32	GND STM32
JTDI	SWDIO
JTMS	SWCLK
JTCK	Reset STM32
JTDO	GND STM32
GND STM32	Boot 0 STM32
Reset STM32	



